

Kenmore®

For Sears Home Services in-home repair
of all Kenmore major appliances.

For the replacement parts, accessories and
Use & Care Guides that you need to do-it-yourself.
For professional installation of major home appliances
and items like air conditioners and water heaters.

1-844-553-6667

www.kenmore.com

In Canada 1-800-469-4663

www.sears.ca

Call anytime for the location of your nearest
Sears Parts & Repair Service Center

1-800-488-1222 (U.S.A.)

1-800-469-4663 (Canada)

To purchase a protection agreement on a serviceable product:

1-800-827-6655 (U.S.A.)

1-800-361-6665 (Canada)

Para pedir servicio de reparación a domicilio, y ordenar piezas:

Au Canada pour service en français:

1-888-SU-HOGAR®

(1-888-784-6427)

www.kenmore.com

1-800-LE-FOYER^{MC}

(1-800-533-6937)

www.sears.ca



Use & Care Guide
Manual de Uso y Cuidado
English / Español



Models, Modelos : 251.55530510, 251.55550510, 251.55570510

Kenmore® Dehumidifier Deshumidificador

P/N J8300026600

Sears Brands Management
Corporation, Hoffman Estates,
IL 60179 USA

www.sears.com
www.kenmore.com



© Registered Trademark / TM Trademark of KCD IP, LLC in the United States, or Sears Brands, LLC in other countries
© Marca Registrada / TM Marca de Fábrica de KCD IP, LLC en Estados Unidos, o Sears Brands, LLC in otros países
^{MC} Marque de commerce / ^{MD} Marque déposée de Sears Brands, LLC

TABLE OF CONTENTS

Package Contents	2	Control Panel	8, 9
Warranty	3	Water Disposing Options	10
Master Protection Agreements	4	Care and Maintenance	11
Safety Instructions	5	Troubleshooting	12
Electrical Requirements	6	Product Specification	13
Installation	6	Spanish/Español	14
Key Features	7	Sears Service	Back Cover

PACKAGE CONTENTS

- Kenmore Dehumidifier
- Use & Care Guide

WARRANTY

KENMORE LIMITED WARRANTY

FOR ONE YEAR from the date of sale this appliance is warranted against defects in material or workmanship when it is correctly installed, operated and maintained according to all supplied instructions.

WITH PROOF OF SALE, a defective appliance will receive free repair or replacement at option of seller.

For warranty coverage details to obtain free repair or replacement, visit the web page:

www.kenmore.com/warranty

This warranty applies for only 90 DAYS from the sale date in the United States, and is void in Canada, if this appliance is ever used for other than private household purposes.

This warranty covers ONLY defects in material and workmanship, and will NOT pay for:

1. Expendable items that can wear out from normal use, including but not limited to filters, belts, bags or screw-in base light bulbs.
2. A service technician to clean or maintain this appliance, or to instruct the user in correct appliance installation, operation and maintenance.
3. Service calls to correct appliance installation not performed by Sears authorized service agents, or to repair problems with house fuses, circuit breakers, house wiring, and plumbing or gas supply systems resulting from such installation.
4. Damage to or failure of this appliance resulting from installation not performed by Sears authorized service agents, including installation that was not in accord with electrical, gas or plumbing codes.
5. Damage to or failure of this appliance, including discoloration or surface rust, if it is not correctly operated and maintained according to all supplied instructions.
6. Damage to or failure of this appliance, including discoloration or surface rust, resulting from accident, alteration, abuse, misuse or use for other than its intended purpose.
7. Damage to or failure of this appliance, including discoloration or surface rust, caused by the use of detergents, cleaners, chemicals or utensils other than those recommended in all instructions supplied with the product.
8. Damage to or failure of parts or systems resulting from unauthorized modifications made to this appliance.
9. Service to an appliance if the model and serial plate is missing, altered, or cannot easily be determined to have the appropriate certification logo.

Disclaimer of implied warranties; limitation of remedies

Customer's sole and exclusive remedy under this limited warranty shall be product repair or replacement as provided herein. Implied warranties, including warranties of merchantability or fitness for a particular purpose, are limited to one year or the shortest period allowed by law. Seller shall not be liable for incidental or consequential damages. Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages, or limitation on the duration of implied warranties of merchantability or fitness, so these exclusions or limitations may not apply to you.

This warranty applies only while this appliance is used in the United States or Canada*.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

* In-home repair service is not available in all Canadian geographical areas, nor will this warranty cover user or servicer travel and transportation expenses if this product is located in a remote area (as defined by Sears Canada Inc.) where an authorized servicer is not available.

**Sears Brands Management Corporation, Hoffman Estates, IL 60179
Sears Canada Inc., Toronto, Ontario, Canada M5B 2C3**

Master Protection Agreements

Congratulations on making a smart purchase. Your new Kenmore® product is designed and manufactured for years of dependable operation. But like all products, it may require preventive maintenance or repair from time to time. That's when having a Master Protection Agreement can save you money and aggravation.

The Master Protection Agreement also helps extend the life of your new product. Here's what the Agreement* includes:

- ☑ **Parts and labor** not just for repairing defects, but to help keep products operating properly **under normal use**. Our coverage goes **well beyond the product warranty**. No deductibles, no functional failure excluded from coverage— **real protection**.
- ☑ **Expert service** by a force of more than **10,000 authorized Sears service technicians**, which means someone you can trust will be working on your product.
- ☑ **Unlimited service calls and nationwide service**, as often as you want us, whenever you want us.
- ☑ **"No-lemon" guarantee** – replacement of your covered product if four or more product failures occur within twelve months.
- ☑ **Product replacement** if your covered product can't be fixed.
- ☑ **Annual Preventive Maintenance Check** at your request – no extra charge.
- ☑ **Fast help by phone** – we call it **Rapid Resolution** – phone support from a Sears representative on all products. Think of us as a "talking owner's manual."
- ☑ **Power surge protection** against electrical damage due to power fluctuations.
- ☑ **\$250 Food Loss Protection** annually for any food spoilage that is the result of mechanical failure of any covered refrigerator or freezer.
- ☑ **Rental reimbursement** if repair of your covered product takes longer than promised.
- ☑ **25% discount** off the regular price of any non-covered repair service and related installed parts.

Once you purchase the Agreement, a simple phone call is all that it takes for you to schedule service. You can call anytime day or night, or schedule a service appointment online.

The Master Protection Agreement is a risk free purchase. If you cancel for any reason during the product warranty period, we will provide a full refund. Or, a prorated refund anytime after the product warranty period expires. Purchase your Master Protection Agreement today!

■ **Some limitations and exclusions apply. For prices and additional information in the U.S.A. call 1-800-827-6655.**

■ *** Coverage in Canada varies on some items. For full details call Sears Canada at 1-800-361-6665.**

■ **Sears Installation Service**

For Sears professional installation of home appliances, garage door openers, water heaters, and other major home items, in the U.S.A. or Canada call **1-800-4-MY-HOME®**.

INSTRUCTIONS

IMPORTANT CAUTIONS FOR USING YOUR DEHUMIDIFIER.



To reduce the risk of fire, electrical shock, injury, or damage to the dehumidifier, these safety precautions must be followed:

Safety

- Do not place the power cord near a heater.
- Do not use an electrical outlet near flammable or combustible materials such as gasoline, propane, paint thinners, etc.
- Do not disassemble or modify dehumidifier parts or components. It may cause electric shock and failure.
- Plug in the power cord properly.
- Do not turn the unit on and off by inserting or pulling out the power plug.
- Do not damage the power cord or use an unspecified power cord.
- Do not modify power cord length.
- Do not share the outlet with another appliance.
- Always plug into a grounded outlet. Not grounding unit may cause electrical shock.
- Unplug the unit if it emits strange sounds, odors, or smoke.
- Do not use an electrical outlet if it is loose or damaged.
- Do not operate or plug in unit with wet hands or in a wet environment.
- Ventilate area before operating dehumidifier. Check for the presence of natural gas or the buildup of other combustible vapors.
- Do not clean the dehumidifier with water. Water may enter the unit and degrade the insulation resulting in an electrical shock.
- If water enters the product, turn off the dehumidifier's power switch, then unplug the unit. Do not plug in unit until it has been inspected by an authorized repair service.
- Because the fan rotates at high speed during operation, always unplug dehumidifier before attempting any recommended maintenance or cleaning.
- Do not block the inlet or outlet. It may cause unit to fail or to operate inefficiently.
- Do not remove plug from outlet by pulling on the cord.
- When not in use, turning the unit off will save energy. Unplug the dehumidifier when not using for long periods of time.
- When removing the filter, be aware that some metal parts may have sharp edges and may cause injury.
- Do not use the water collected in the bucket for drinking purposes. It is not sanitary and could cause illness.
- Do not allow children to play with this product.

Tips

- Auto is the suggested setting for typical everyday use.
- Make sure the dehumidifier is the correct size for the area you want to dehumidify. It is not designed to dehumidify the entire house.
- For proper operation, the dehumidifier should only be placed on a level floor.
- Close all doors, windows and other openings to the room. The dehumidifier must operate in an enclosed area to be effective.
- To clean, use a soft cloth; do not use wax, thinners, or strong detergents as they may change the color of the unit or cause surface damage.
- Be sure to replace the bucket properly after emptying to prevent water from collecting on the floor causing damage to some types of flooring.
- Do not put a pet or house plant where it will be exposed to direct air flow. This could injure the pet or plant.
- Operation without filter will cause unit failure. Insert the filter securely. Clean it every two weeks. (See Care and Maintenance section in this manual.)

ELECTRICAL REQUIREMENTS


OBSERVE ALL LOCAL CODES AND ORDINANCES.

DO NOT, UNDER ANY CIRCUMSTANCES, REMOVE THE POWER SUPPLY CORD GROUND PRONG.

ELECTRICAL GROUND IS REQUIRED ON THIS APPLIANCE.

A 115-VOLT 60Hz, AC ONLY, 15A FUSED AND PROPERLY GROUNDED ELECTRICAL SUPPLY IS REQUIRED.

A time delay fuse or time delay circuit breaker is recommended. Use a dedicated circuit serving only this appliance.



NOTE: If an extension cord must be used, the cord must be a minimum of 14AWG, and rated not less than 1875 watts, or 20A.

RECOMMENDED GROUNDING METHOD

For your personal safety, this appliance must be grounded. This appliance has a power supply cord with a 3-prong grounded plug. To minimize possible shock hazard, the cord must be plugged into a matching grounded electrical outlet that complies with the latest edition of the National Electrical Code and all local codes and ordinances.

If a grounded 3-prong electrical outlet is not available, it is the personal responsibility and obligation of the customer to have one installed by a qualified electrician.



ELECTRICAL SHOCK HAZARD

Plug into a grounded 3-prong outlet.

- Do not remove ground prong.
- Do not use a two-prong adapter.

Failure to follow these instructions can result in death, fire or electrical shock.

INSTALLING YOUR DEHUMIDIFIER

- Install the dehumidifier on a level floor strong enough to support the unit with a full bucket of water.
- For best performance, allow at least 12-18 inches of air space on all sides of the unit for good air circulation.
- Keep all outside doors, windows and other openings closed when operating the dehumidifier. Humid outdoor air will add to the unit's workload.
- For maximum efficiency, install your dehumidifier in an area where the temperature will not fall below 65°F.

- Leave the dehumidifier in an upright position for 30 minutes before turning on.

DEFROST OPERATION

The dehumidifier has a built-in defrost control that senses frost buildup on the evaporator coils.

During defrosting, the compressor will automatically turn off; the fan will continue running to defrost the coils.


CHOOSING THE PROPER LOCATION

Use the dehumidifier:


- in the basement to help prevent moisture damage.
- in the kitchen, laundry room, bathroom, and spa/exercise areas that have excessive moisture.
- to prevent moisture damage anywhere books or valuables are stored.
- during construction or remodeling to reduce drying time for drywall and paint; however, check and clean filter often.

AUTOMATIC SHUT OFF

- When the bucket is full, or when the bucket is not in the proper position, the Bucket Full light goes on and the unit automatically shuts off.
- The bucket must be placed in the proper position for the dehumidifier to work. The light will stay on and the dehumidifier will not run if the bucket is not in the proper position.
- The dehumidifier will shut off once the desired humidity setting is reached, plus or minus 5% Relative Humidity (RH).




KEY FEATURES OF YOUR DEHUMIDIFIER



cleancel antimicrobial technology inhibits odor-causing bacterial growth on bucket surface.

Model : 55550/55570

CONTROL PANEL 55530



POWER ON/OFF (1)

Pressing Power button once turns the dehumidifier “ON” and pressing it again turns the dehumidifier “OFF.”

Settings (2)

Press this key to cycle through the control panel settings from Humidity to Cycle Timer to Delay Start. The indicator lights will show which setting you are in.

Humidity (9)

When the unit is turned on the control panel will default to the Humidity setting. You may also use the Settings key to enter the Humidity setting. In this setting you can manually select the desired humidity level by pressing the Up or Down arrow keys (4/5). Humidity values are changed in 5% increments ranging from 35% to 70%. The humidity setting is shown in the display **window (8)**. Pressing the Down arrow key when the displayed value is 35% will cause the unit to operate continuously. In continuous operation, **Lo** will be displayed in the **window (8)**. To leave continuous operation, press the Up arrow or press the Settings key to change the control panel setting.

Cycle Timer (10)

In this setting, the unit will run for either 3, 6, or 12 hours, then shut off for 3, 6, or 12 hours. Cycle time can be adjusted by pressing the Up or Down arrow keys (4/5) repeatedly to set operating time for 3, 6, or 12 hours. The cycle timer function will continue until you change the setting or turn the unit off.

Delay Start (11)

Unit can be programmed to turn on at a desired delay time by pressing the Up or Down arrow keys (4.5). Time can be adjusted in 1 hour increments ranging from 1 to 12 hours. Delay time will be shown in **window (8)** and will count down to start time in 1 hour increments.

FAN SPEED (3)

Press Fan Speed to toggle between Low and High fan speeds. Speed will be shown in **FAN SPEED INDICATOR (6)**.


BUCKET FULL INDICATOR (7).

When the collection bucket is full, BUCKET FULL indicator (7) will come on. The dehumidifier will not run until the bucket is empty.

IMPORTANT:

When the unit is turned off and re-started, it will resume operation in the same mode it was in. If there is a power failure, when the power returns the unit will be set to 50% humidity and Fan Speed Low.

CONTROL PANEL 55550/55570



POWER ON/OFF (1)

Pressing Power button once turns the dehumidifier “ON” and pressing it again turns the dehumidifier “OFF.”

Settings (2)

Press this key to cycle through the control panel settings from Auto to Humidity to Cycle Timer to Delay Start. The indicator lights will show which setting you are in.

Auto (9)

The first time the unit is turned on, the control panel will default to the Auto setting. The next time it is turned on, the control panel will default to the last mode the unit was in before turning off. You may also use the Settings key to enter the Auto setting. **AUTO (9)** and “50%” humidity value will be displayed in **window (8)**. In this setting, the Relative Humidity (RH) is automatically set to 50%. Because lower temperatures usually correlate with lower humidity levels, the unit will not run frequently. At higher temperatures higher humidity is normal so the unit will run more often.

Humidity (9)

In this setting you can manually select the desired humidity level by pressing the Up or Down arrow keys (4/5). Humidity values are changed in 5% increments ranging from 35% to 70%. The humidity setting is shown in the **display window (8)**. Pressing the Down arrow key when the displayed value is 35% will cause the unit to operate continuously. In continuous operation, **Lo** will be displayed in the **window (8)**. To leave continuous operation, press the Up arrow or press the Settings key to change the control panel setting.

Cycle Timer (10)

In this setting, the unit will run for either 3, 6, or 12 hours, then shut off for 3, 6, or 12 hours. Cycle time can be adjusted by pushing the timer arrow up or down (4/5) repeatedly to set operating time for 3, 6, or 12 hours. The cycle timer function will continue until you change the setting or turn the unit off.

Delay Start (11)

Unit can be programmed to turn on at a desired delay time by pressing the Up or Down arrow keys (4.5). Time can be adjusted in 1 hour increments ranging from 1 to 12 hours. Delay time will be shown in **window (8)** and will count down to start time in 1 hour increments.

FAN SPEED (3)

Press Fan Speed to toggle between Auto, Low, and High fan speeds. Speed will be shown in **FAN SPEED INDICATOR (6)**. When **AUTO** is selected, the unit will adjust the fan speed accordingly depending on the humidity level.

BUCKET FULL INDICATOR (7)

When the collection bucket is full, BUCKET FULL indicator (7) will come on. The dehumidifier will not run until the bucket is empty.

IMPORTANT:



When the unit is turned off and re-started, it will resume operation in the same mode it was in. If there is a power failure, when the power returns the unit will be set to AUTO mode.

WATER DISPOSING OPTIONS

OPTION 1. EMPTYING MANUALLY

1. Pull out the bucket, grasping side handles.
2. Carry the bucket by grasping the inside handle of the bucket.
3. After emptying the bucket, replace the bucket in the dehumidifier.

NOTE: Dehumidifier will not work when the BUCKET FULL light is on or without the bucket properly placed in the unit.



OPTION 2, GRAVITY DRAIN HOSE (Hose Not Provided)

1. Take off GRAVITY DRAIN cap. (Fig.1)
2. Assemble the DRAIN CONNECTOR to the dehumidifier by turning clockwise. (Fig.2)
3. Next, screw a standard drain hose to drain connector by turning clockwise. (Fig.3)




Fig.1




Fig.2




Fig.3

CARE AND MAINTENANCE



WARNING

- Disconnect power supply cord from receptacle before performing any maintenance.




Fig.1




Fig.2




Fig.3




Fig.4




Fig.5


CLEANING FRONT GRILL AND AIR FILTER

1. Remove the bucket from unit. Air filter is located behind front grill. (Fig.1)
2. Pull the filter down and away from unit until it is all the way out. (Fig.2)
3. Wash filter with mild detergent. Rinse thoroughly. Air dry away from direct sunlight. (Fig.3)
4. Front grill can be cleaned using a vacuum cleaner or a soft brush to remove dust. (Fig.4)
5. After cleaning, assemble the air filter to front grill. (Fig.5)

NOTE : Check your filter periodically to ensure proper operation.

CLEANING THE EXTERIOR

Clean the exterior using a soft brush or dry towel. But do not spray water directly on the exterior.



CLEANING THE BUCKET

Remove the bucket from the unit. Lift off bucket cover. (Fig.1) Clean the inside of bucket as needed. (Fig.2)

After cleaning, replace the bucket cover and slide the bucket into the unit. (Fig.3) Check the float switch to make sure it is not obstructed. Proper position of the bucket and the float switch is required for the dehumidifier to turn on.




Fig.1




Fig.2

Float Switch




Fig.3

TROUBLESHOOTING

Before calling for service, try the suggestions below to see whether you can solve your problem without outside help.

PROBLEMS	CHECK POINT	SOLUTIONS
Dehumidifier does not work when pressing the POWER ON button.	Is the power cord plugged into a grounded 3-prong outlet? Is BUCKET FULL light on? Does BUCKET FULL light appear after emptying the water bucket?	Plug the power cord securely into a grounded 3-prong outlet. Empty the water bucket and re-install. Check the float switch to make sure it is free and not obstructed.
Dehumidifier is operating, but the unit is not drawing any water	Is the compressor running as well as the fan?	The unit may be in the defrost mode. The fan is running but not the compressor. The unit will return to dehumidification automatically. If both compressor and fan are running, but the air discharged from the dehumidifier is not at least 13 degrees above the room temperature, then there may be a sealed system failure. Service is then required.
Loud noise and/or vibration during operation.	Is the unit on a level surface?	Move the unit to a level surface.
Sounds.	Sounds like flowing water during and after operation. It makes a pinging sound.	This is the normal sound of the refrigerant flowing through the coils. Normal sound of expansion and contraction caused by temperature changes.
Dehumidifier is not running efficiently	Are the filter and grill dirty? Is indoor temperature under 65°F?	Clean the FRONT GRILL and AIR FILTER. Although the unit will dehumidify at temperatures below 65 degrees, there is a potential for frost to develop which may inhibit the unit's efficiency
Unit is discharging warm air.		Normal: Compressor and electric motor discharge a small amount of heat.
Water does not drain through hose.	Check the DRAIN CONNECTOR. Is it installed correctly? Check the drain hose for kinks or obstructions.	Re-install drain hose according to this manual. Flatten the hose or remove blockage.

PRODUCT SPECIFICATIONS

Classification	Specification			Remark
Model	55530	55550	55570	
Power Supply	AC 115V/60Hz	AC 115V/60Hz	AC 115V/60Hz	
Power Requirements	4.4 A, 506 W	5.2 A, 598 W	6.5 A, 747.5 W	
Moisture Removal	30 Pint (14.2liters)	50 Pint (23.6liters)	70 Pint (33.1liters)	24-Hour Period
Control Type	Electronic	Electronic	Electronic	
Refrigerant	R-410a 8.46 OZ(240g)	R-410a 10.23 OZ(290g)	R-410a 11.99 OZ(340g)	
Humidity Setting	LO, 35-70%	LO, 35-70%	LO, 35-70%	5% Increments
Cycle Timer	3, 6, 12 Hours	3, 6, 12 Hours	3, 6, 12 Hours	
Delay Time	1-12 Hours	1-12 Hours	1-12 Hours	1Hour Increments
Fan Motor Modes	High, Low	Auto, High, Low	Auto, High, Low	
Operating Temp.	36°F-99°F	36°F-99°F	36°F-99°F	
Dimensions	13.0X20.8X9.5 in	14.6X23.03X12.5 in	14.6X23.03X12.5 in	
	330X528X241 mm	370X585X318 mm	370X585X318 mm	
Net Weight	30.53 lbs (13.85Kg)	40.30 lbs (18.28Kg)	43.63 lbs (19.79Kg)	
Bucket Capacity	10.5 Pint (5.0liters)	19.2 Pint (9.1liters)	19.2 Pint (9.1liters)	