


# SERVICING PRECAUTIONS

## AIR RECHARGING IN COMPRESSOR


Test the refrigeration system connecting it electrically before refilling operation. It is necessary to ascertain the function of the motor-compressor and identify the defects immediately. If defects have been found, empty the old system of possible R-134a residue by breaking off the end of the extension piece at its narrow point. (Figure 1)

Replace the filter and any damaged components. Unsolder and pull off the piece remaining inside the service tube and then attach a complete extension with male Hansen and at last, solder it to the same tube again. (Figure 2)



It is necessary to execute the soldering operation with valve open so that the fumes caused by oil residue can come out freely without blowholes between two tubes during the heating of the point to be soldered.

The extension fitted with the male Hansen is connected to the female fitting of the vacuum pump tube. (Figure 3)




Air evacuating from the system begins as soon as the pump starts. The refrigeration system must be kept under vacuum until the reading on the low-pressure gauge indicates vacuum (0 absolute, -1 atm., -760 mm hg) in any case it is advisable to keep the pump running for about 30 minutes. (Figure 3)


In case that a considerable leakage occurs it will be necessary to stop the vacuum pump and to add a small quantity of Freon to the system, if vacuum should not be obtained (pressure gauge can't fall to 1 atmosphere), start the refrigeration unit and find the leakage with the special leak-finder. When the defective soldering point is visible, re-do it after opening the extension tube valve and reestablishing the normal outside pressure inside the group.

Because the melted alloy is sucked into the tubes and block them, the pressure must be rebalanced when vacuum is in the system in soldering. As soon as the

vacuum operation is over, add the quantity in grams of R-134a to the refrigeration system. Remember that every system has an exact quantity of R-134a with a tolerance of  $\pm 5$  grams that can be added. (Figure 4)



Before performing this operation (if the vacuum pump and refilling cylinder are connected), make sure that the valve placed between the vacuum pump and the refilling tube are closed in order to keep the Freon for addition to the system. (Figure 5)



In addition, check the graduated scale on the cylinder for the quantity of R-134a to be added, for example, if we have 750 grams of Freon in the cylinder and must add 140 grams to the group, this amount will be reached when R-134a has dropped to 610 grams, remembering that the indicator shows a lower limit of meniscus. Do this after choosing the scale corresponding to the gas pressure different scales reported as the same gas pressure indicated by the pressure gauge on the top of the column.

To make R-134a flow into the system, open the valve placed at the base of the cylinder and connected to the filling tube. The amount of Freon cannot be added to the system all at once because it may cause a blocking of motor-compressor. Therefore, proceed by adding the original quantity of about 20-30 grams and close the valve immediately.

The pressure rises and the motor compressor must start sucking the gas and lowering the pressure again. Regulate the valve again, maintaining the same manner until reaching to the quantity of R-134a established for the system being charged. When the system is running, the suction pressure must be stabilized between 0.30 to 0.6 (0.10 to 0.4) atmosphere.

# 1. SPECIFICATIONS

## 1-1. Ref. No.: GR-T622DE


ITEMS	SPECIFICATIONS	ITEMS	SPECIFICATIONS	
DOOR DESIGN	Side Rounded	VEGETABLE TRAY	Transparent Drawer Type	
DIMENSIONS (mm)	750x723x1732(WxDxH)	COMPRESSOR	PTC Starting Type	
NET WEIGHT (kg)	90	EVAPORATOR	Fin Tube Type	
COOLING SYSTEM	Fan Cooling	CONDENSER	Wire Condenser	
TEMPERATURE CONTROL	Knob Dial	REFRIGERANT	R-134a (140 g)	
DEFROSTING SYSTEM	Full Automatic	LUBRICATING OIL	Freol @ 15G (320 cc)	
	Heater Defrost With a Timer	DEFROSTING DEVICE	SHEATH HEATER	
DOOR FINISH	Embossed Metal	LAMP	FREEZER	15 W*
HANDLE TYPE	Bar		REFRIGERATOR	40 W
INNER CASE	ABS Resin	* Freezer lamp is optional part.		
INSULATION	Polyurethane Foam			

## 1-2. Ref. No.: GR-T722DE

ITEMS	SPECIFICATIONS	ITEMS	SPECIFICATIONS	
DOOR DESIGN	Side Round	VEGETABLE TRAY	Transparent Drawer Type	
DIMENSIONS (mm)	750x776x1732(WxDxH)	COMPRESSOR	PTC Starting Type	
NET WEIGHT (kg)	93	EVAPORATOR	Fin Tube Type	
COOLING SYSTEM	Fan Cooling	CONDENSER	Wire Condenser	
TEMPERATURE CONTROL	Knob Dial	REFRIGERANT	R-134a (140 g)	
DEFROSTING SYSTEM	Full Automatic	LUBRICATING OIL	Freol @ 15G (320 cc)	
	Heater Defrost With a Timer	DEFROSTING DEVICE	SHEATH HEATER	
DOOR FINISH	Pre Coated Metal	LAMP	FREEZER	15 W*
INNER CASE	ABS Resin		REFRIGERATOR	40 W
INSULATION	Polyurethane Foam	* Freezer lamp is optional part.		

# 2. PARTS IDENTIFICATION

## FREEZER COMPARTMENT




# 3. DISASSEMBLY


## 3-1 DOOR

### ● Freezer Door

1. Remove the hinge cover by pulling it upwards.
2. Loosen hexagonal bolts fixing the upper hinge to the body and lift the freezer door.




3. Pull out the door gasket to remove from the door foam Ass'y.



### ● Refrigerator Door


1. Loosen hexagonal bolts fixing the lower hinge to the body to remove the refrigerator door only.



2. Pull out the door gasket to remove from the door foam Ass'y.


## 3-2 DOOR SWITCH

1. To remove the door switch, pull out it with a '-' type driver as shown in (figure 9).
2. Disconnect the lead wire from the switch.




## 3-3 THERMOSTAT

1. Remove Control Box-R by loosening 2 screw fixed to ceiling of Refrigerator compartment (Figure 10)
2. Separate the thermostat and dial knob F.
3. Remove the thermostat by disconnecting the lead wire.



### 3.4 FAN AND FAN MOTOR

1. Remove the freezer shelf. (If your refrigerator have an Ice Maker, disassemble the Ice maker first)
2. Remove the Grille by pulling it out and by loosening a screw.
3. Remove the Fan Motor Assy by loosening 4 screws and disassemble the shroud.
4. Pull out the fan and, separate the Fan Motor, Bracket.





### 3-5 DEF' CONTROL ASSY

Def control Assy consists of Defrost Thermostat and FUSE-M. Defrost Thermostat functions to defrost automatically and it is attached to metal side of the Evaporator and senses Temp.


Fuse-M is a kind of safety device for preventing over-heating of the Heater when defrosting.

At the temperature of 77°C, it stops the emission of heat from the Heater.

1. Pull out the Grille Ass'y.
2. Separate the connector connected with the Def Control Assy and replace the Def Control Assy after cutting the Tie Wrap. (Figure 14)




### 3-6 LAMP



#### 3-6-1 Freezer room lamp

1. Unplug the power cord from the outlet.
2. Remove the room lamp lid by taking down while pulling it forward with your hand after inserting finger into the inside hole as shown in (figure 15).
3. Remove the lamp by turning it counterclockwise.
4. Assemble in reverse order of disassembly. Replacement bulb must be the same specification as original.




#### 3-6-2 Refrigerator room lamp

1. Unplug the power cord from the outlet.
2. Remove refrigerator shelves.
3. Upper Refrigerator Lamp. Release the hooks on both ends of the lamp shield and pull the shield downward to remove it.
4. Turn the lamp counterclockwise.
5. Assemble in reverse order of disassembly. Replacement bulb must be the same specification as original. (Max 40 W)

### 3-7 CONTROL BOX-R

1. First, remove all shelves in the refrigerator and Control Box-R by loosening 2 screw.



2. Remove the Control Box-R by pulling it downward.
3. Disconnect the L/wire on the right position and separate timer, thermostat, Lamp socket, etc.

# 4. ADJUSTMENT

## 4-1 COMPRESSOR

### 4-1-1 Role

The compressor intakes low temperature and low pressure gas evaporated from Evaporator of the Refrigerator, and condenses this gas to high temperature and high pressure gas, and then plays delivering role to Condenser.

### 4-1-2 Composition

The Compressor is Composed of Compressor Apparatus compressing gas, Compressor Motor moving Compressor Apparatus and Case protecting Compressor Apparatus and Motor. There are PTC-Starter, and Over Load Protector (OLP) in the Compressor outside. On the other hand, because the Compressor consists of 1/1000mm processing precision components and is sealed after production in absence of dust or humidity, deal and repair with care.

### 4-1-3 Note for Usage

- (1) Be careful not to allow over-voltage and over-current.
- (2) No Strike  
If applying forcible power or strike (dropping or careless dealing), poor operation and noise may occur.
- (3) Use proper electric components appropriate to the Compressor.
- (4) Note to Keep Compressor.  
If Compressor gets wet in the rain and rust in the pin of Hermetic Terminal, the result may be poor operation and poor contact may cause.
- (5) Be careful that dust, humidity, and flux welding don't inflow in the Compressor inside in replacing the Compressor. Dust, humidity, and flux due to welding which inflows to Cylinder may cause lockage and noise.

## 4-2 PTC-STARTER

### 4-2-1 Composition of PTC-Starter


- (1) PTC (Positive Temperature Coefficient) is a no-contact semiconductor starting device which uses ceramic material and this material consists of BaTiO<sub>3</sub>.
- (2) The higher the temperature is, the higher becomes the resistance value. These features are used as starting device for the Motor.

### 4-2-2 Role of PTC-Starter

- (1) PTC is attached to Hermetic Compressor used for Refrigerator, Show Case and starts Motor.
- (2) Compressor for household refrigerator applies to single-phase induction Motor.  
For normal operation of the single-phase induction motor, in the starting operation flows in both main coil and sub-coil. After the starting is over, the current in subcoil is cut off. The proper features of PTC play all the above roles. So, PTC is used as a motor starting device.

## 4-2-3 PTC-Applied Circuit Diagram

● According to Starting Method for the Motor



## 4-2-4 Motor Restarting and PTC Cooling

- (1) For restarting after power off during normal Compressor Motor operation, plug the power cord after 5 min. for pressure balance of Refrigerating Cycle and PTC cooling.
- (2) During normal operation of the Compressor Motor, PTC elements generate heat continuously. Therefore, if PTC isn't cooled for a while after the power has been shut off, Motor can't operate again.

## 4-2-5 Relation of PTC-Starter and OLP

- (1) If the power is off during operation of Compressor and the power is on before the PTC is cooled, (instant shut-off within 2 min. or reconnect a power plug due to misconnecting), the PTC isn't cooled and a resistance value grows. As a result, current can't flow to the sub-coil and the Motor can't operate and the OLP operates by flowing over current in only in the main-coil.
- (2) While the OLP repeats on and off operation about 3-5 times, PTC is cooled and Compressor Motor performs normal operation.  
If OLP doesn't operate when PTC is not cooled, Compressor Motor is worn away and causes circuit-short and fire. Therefore, use a properly fixed OLP without fail.

## 4-2-6 Note to Use PTC-Starter

- (1) Be careful not to allow over-voltage and over-current.
- (2) No Strike  
Don't apply a forcible power or strike.
- (3) Keep apart from any liquid.  
If liquid such as oil or water away enter the PTC, PTC materials it may break due to insulation breakdown of the material itself.
- (4) Don't change PTC at your convenience.  
Don't disassemble PTC and mold. If the exterior to the PTC-starter is damaged, resistance value is altered and it may cause poor starting of the compressor motor may cause.
- (5) Use a properly fixed PTC.

### 4-3 OLP (OVERLOAD PROTECTOR)

#### 4-3-1 Definition of OLP

- (1) OLP (OVERLOAD PROTECTOR) is attached to the Compressor and protects the Motor by cutting the current to the Motor if the temperature rises and activates the bimetal spring in the OLP.
- (2) When over-voltage flows to Compressor motor, the Bimetal works by heating the heater inside the OLP, and the OLP protects Motor by cutting off current which flows to the Compressor Motor.

#### 4-3-2 Role of the OLP

- (1) The OLP is attached to the Hermetic Compressor used for the Refrigerator and Show Case and prevents the Motor Coil from being started in the Compressor.
- (2) Do not turn the Adjust Screw of the OLP in any way for normal operation of the OLP.  
(Composition and connection Diagram of OLP)





Figure 21


## 5. CIRCUIT DIAGRAM



NOTE : 1. This is a basic diagram and specifications vary in different localities.

# 6. TROUBLESHOOTING

## 6-1 COMPRESSOR AND ELECTRIC COMPONENTS





### 6-2 PTC AND OLP





Figure 21




Figure 22

### 6-3 DEFROST TIMER








Figure 23

## 6-4 ANOTHER ELECTRIC COMPONENTS

### ▼ Cooling is impossible




### ▼ Cooling ability is poor



## 6-4 SERVICE DIAGNOSIS CHART

COMPLAINT	POINTS TO BE CHECKED	REMEDY
Cooling is impossible.	<ul style="list-style-type: none"> <li>Is the power cord unplugged from the outlet?</li> <li>Check if the power S/W is set to OFF.</li> <li>Check if the fuse of power S/W is shorted.</li> <li>Measure the voltage of power outlet.</li> </ul>	<ul style="list-style-type: none"> <li>Plug to the outlet.</li> <li>Set the switch to ON.</li> <li>Replace a regular fuse.</li> <li>If voltage is low, wire newly.</li> </ul>
Cooling ability is poor.	<ul style="list-style-type: none"> <li>Check if the set is placed close to wall.</li> <li>Check if the set is placed close to stove, gas cooker and direct rays.</li> <li>Is the ambient temperature high or the room door closed?</li> <li>Check if put in is hot.</li> <li>Did you open the door of the set too often or check if the door is closed up?</li> <li>Check if the Control is set to WARM.</li> </ul>	<ul style="list-style-type: none"> <li>Place the set with the space of about 10cm.</li> <li>Place the set apart from these heat appliances.</li> <li>Make the ambient temperature below.</li> <li>Put in foods after cooled down.</li> <li>Don't open the door too often and close it firmly.</li> <li>Set the control to mid-position.</li> </ul>
Foods in the Refrigerator are frozen.	<ul style="list-style-type: none"> <li>Is foods placed in cooling air outlet?</li> <li>Check if the Dial is set to COLD.</li> <li>Is the ambient temperature below 5°C?</li> </ul>	<ul style="list-style-type: none"> <li>Place foods in high temperature section. (Front Part)</li> <li>Set the dial to MID.</li> <li>Set the dial to WARM.</li> </ul>
Dew or ice forms in the chamber of the set.	<ul style="list-style-type: none"> <li>Is liquid food stored?</li> <li>Check if put in is hot.</li> <li>Did you open the door of the set too often or check if the door is closed up.</li> </ul>	<ul style="list-style-type: none"> <li>Seal up liquid foods with wrap.</li> <li>Put in foods after cooled down.</li> <li>Don't open the door too often and close it firmly.</li> </ul>
Dew forms in the Exterior Case.	<ul style="list-style-type: none"> <li>Check if ambient temperature and humidity of surrounding air are high.</li> <li>Is there gap in the door packed?</li> </ul>	<ul style="list-style-type: none"> <li>Wipe dew with a dry cloth. This occurrence is solved naturally in low temperature and humidity.</li> <li>Fill up the gap.</li> </ul>
Abnormal noise generates.	<ul style="list-style-type: none"> <li>Are the set positioned in a firm and even place?</li> <li>Are any unnecessary objects set in the back side of the set?</li> <li>Check if the Drip Tray is not firmly fixed.</li> <li>Check if the cover of mechanical room in below and front side is taken out.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the Adjust Screw, and position in the firm place.</li> <li>Remove the objects.</li> <li>Fix it firmly on the original position.</li> <li>Place the cover at the original position.</li> </ul>
To close the door is not handy.	<ul style="list-style-type: none"> <li>Check if the door packing is dirty with filth such as juice.</li> <li>Is the set positioned in a firm and even place?</li> <li>Is too much food putted in the set?</li> </ul>	<ul style="list-style-type: none"> <li>Clean the door packing.</li> <li>Position in the firm place and adjust the Adjust Screw.</li> <li>Keep foods not to reach the door.</li> </ul>
Ice and foods smell unpleasant.	<ul style="list-style-type: none"> <li>Check if the inside of the set is dirty.</li> <li>Did you keep smelly foods without wrapping?</li> <li>It smells of plastic.</li> </ul>	<ul style="list-style-type: none"> <li>Clean the inside of the set.</li> <li>Wrap smelly foods.</li> <li>The new products smells of plastic, but it is eliminated after 1-2 weeks.</li> </ul>

● In addition to the items described left, refer to the followings to solve the complaint.




## 6-5 REFRIGERATING CYCLE

### ▼ Troubleshooting Chart

CAUSE		STATE OF THE SET	STATE OF THE EVAPORATOR	TEMPERATURE OF THE COMPRESSOR	REMARKS
LEAKAGE	PARTIAL LEAKAGE	Freezer room and Refrigerator don't cool normally.	Low flowing sound of Refrigerant is heard and frost forms in inlet only	A little high more than ambient temperature.	<ul style="list-style-type: none"> <li>Refrigerant level is low due to a leak.</li> <li>Normal cooling is possible when injecting of Refrigerant the regular amount.</li> </ul>
	WHOLE LEAKAGE	Freezer room and Refrigerator don't cool normally.	Flowing sound of Refrigerant is not heard and frost isn't formed.	Equal to ambient temperature.	<ul style="list-style-type: none"> <li>No discharging of Refrigerant.</li> <li>Normal cooling is possible when injecting of Refrigerant the regular amount.</li> </ul>
CLOGGED BY DUST	PARTIAL CLOG	Freeze room and Refrigerator don't cool normally.	Flowing sound of Refrigerant is heard and frost forms in inlet only.	A little high more than ambient temperature.	<ul style="list-style-type: none"> <li>Normal discharging of refrigerant.</li> <li>The capillary tube is faulty.</li> </ul>
	WHOLE CLOG	Freezer room and Refrigerator don't cool.	Flowing sound of Refrigerant is not heard and frost isn't formed.	Equal to ambient temperature.	<ul style="list-style-type: none"> <li>Normal discharging of Refrigerant.</li> </ul>
MOISTURE CLOG		Cooling operation stops periodically.	Flowing sound of Refrigerant is not heard and frost melts.	Low than ambient temperature	<ul style="list-style-type: none"> <li>Cooling operation restarts when heating the inlet of capillary tube.</li> </ul>
DEFECTIVE COMPRESSION	COMP-RESSION	Freezer and Refrigerator don't cool.	Low flowing sound of Refrigerant is heard and frost forms in inlet only.	A little high than ambient temperature.	<ul style="list-style-type: none"> <li>Low pressure at high side of compressor due to low refrigerant level.</li> </ul>
	NO COMP-RESSION	No compressing operation.	Flowing sound of Refrigerant is not heard and no frost.	Equal to ambient temperature.	<ul style="list-style-type: none"> <li>No pressure of high pressure part in the compressor.</li> </ul>

### ▼ Leakage Detection

- Observe discharging point of refrigerant which may be in the oil discharging part in the compressor and hole of evaporator.



▼ General Control of Refrigerating Cycle

NO.	ITEMS	UNIT	STANDARDS	PURPOSES	REMARKS	
1	Pipe and piping system opening time	Min.	Pipe: within 1 hour. Comp: within 10 minutes. Drier: within 20 minutes.	To protect moisture penetration.	The opening time should be reduced to a half of the standards during rain and rainy seasons (the penetration of water into the pipe is dangerous).	
2	Welding	Nitrogen pressure	Weld under Nitrogen atmosphere. (N <sub>2</sub> pressure: 0.1~0.2 kg/cm <sup>2</sup> )	To protect oxide scale formation.	- Refer to repair note in each part. - R-134a refrigerant is more susceptible to leaks than R-12 and requires more care during welding. - Do not apply force to pipes before and after welding to protect pipe from cracking.	
3	N <sub>2</sub> sealed parts	Confirm N <sub>2</sub> leak	Confirm air leaking sounds when removing rubber cap. Sound: usable No sound: not usable	To protect moisture penetration.	- In case of evaporator parts, if it doesn't make sound when removing rubber cap, blow dry air or N <sub>2</sub> gas for more than 1 min and use the parts.	
4	Refrigeration Cycle	Evacuation time	Min.	More than 40 minutes	To remove moisture.	
		Vacuum degree	Torr	Below 0.03 (ref)		Note: Only applicable to the model equipped with reverse flow protect plate.
		Vacuum	EA	High and low pressure sides are evacuated at the same time for models above 200 l.		Vacuum efficiency can be improved by operating compressor during evacuation.
		Vacuum piping	EA	Use R-134a exclusive manifold.	To protect mixing of mineral and ester oils.	The rubber pipes for R-12 refrigerant shall be melted when they are used for R-134a refrigerant (causes of leak).
		Pipe coupler	EA	Use R-134a exclusive.	To protect R-12 refrigerant mixing.	
		Outlet (Socket)		R-134a exclusive.	"	
		Plug		R-134a exclusive.	"	
5	Refrigerant weighing	EA	Use R-134a exclusively. Weighing allowance: ±5g Note: Winter: -5g Summer: +5g	Do not mix with R-12 refrigerant.	- Do not weigh the refrigerant at too hot or too cold an area. (77°F[25°C] is adequate.) - Make Copper bombe Socket: 2SV Plug: 2PV R-134a Note: Do not burn O-ring (rubber) during welding.	
6	Drier replacement		- Use R-134a exclusively for R-134a refrigerator. - Use R-12 exclusively for R-12 refrigerator. - Replace drier whenever repairing refrigerator cycle piping.	To remove the moisture from pipe inside.		
7	Leak check		- Do not use soapy water for check. It may be sucked into the pipe by vacuum.	Defect refrigerant leak area.	- Check oil leak at refrigerant leak area. Use electronic leak detector if oil leak is not found. - The electronic leak detector is very sensitive to halogen gas in the air. It also can detect R-141b in urethane. Please practice, therefore, many times before use.	

# 7. ICE MAKER


## 7-1. HOW TO INSTALL WATER PIPE

### ■ Before Installation

1. The icemaker requires the water pressure of 1.5 - 8.5kgf/cm<sup>2</sup>. (It is acceptable if city water fills a cup of 180cc with water for 3 seconds)
2. Install booster pump where the city water pressure is below 1.5kgf/cm<sup>2</sup> for normal operation of Ice Maker.
3. The total length of water pipe shall be less than 10m. Do not bend the pipe at right angle. If the length is more than 10m, there will be troubles on water supply due to water pressure drop.
4. Please install water pipe where there is no heat around.

### 7-1-1. When connecting directly to the water tap.

#### ■ Please confirm the following installation parts.




Class.	Shape and Spec.	Nomenclature	P/No	Remarks
Convertible Water Valve		Valve Feed	5221JA3001A	Common Use
Water Connector		Connector, (MECH) Pipe Conversion Connector(3/4") Balance Conector(3/4") Packing(ø24x3t)	4932JA3003A 6631JA3004A 6631JA3004B 3920JA3001B	No Holes
		Connector, (MECH) Pipe Conversion Connector(W25) Balance Conector(W25) Packing(ø23x3t)	4932JA3003B 6631JA3004C 6631JA3004D 3920JA3001A	No Holes
		Connector, (MECH) Pipe Conversion Connector(W28) Balance Conector(W28) Packing(ø26x3t)	4932JA3003C 6631JA3004E 6631JA3004F 3920JA3001C	No Holes
		Connector, (MECH) Pipe Conversion Connector(1/2") Balance Conector(1/2") Packing(ø19x3t)	4932JA3003D 6631JA3004G 6631JA3004H 3920JA3001D	No Holes

### 7-1-2. Connection of Pipe Connector A and B.


- 1) Turn off main valve of water pipe.
- 2) Disconnect water tap from piping by loosening nuts.
- 3) Connect pipe connector A and B to piping after sealing the pipe connector with sealing tapes.
- 4) Connect feed valve to pipe connector A.
- 5) If there is only one tap water pipe, connect pipe connector A only and install feed pipe.

- Caution :**
- Feed pipe should be connected to cold water line. If it is connected to hot water line, trouble may occur.
  - Please check rubber packing when connecting feed pipe.



### 7-1-3. Water Supply

- 1) Check leakage at connecting part, then arrange water tube and locate the refrigerator at its regular place if there is no leaking.




#### 7-1-4. When customer uses bottled water.

\*If customer wants to use bottled water, extra pump should be installed as shown below.

1. The pump system should not be on the floor (it may cause noise and vibration). Securely fasten the inlet and outlet nuts of pump.
2. If there is any leakage after installation, cut the water tube at right angle and reassemble.
3. When put the water tube end into the bottle, leave a clearance between bottle bottom and water tube end.
- 4 Check water coming out and any leakage.


**Caution :** • If feed tube is more than 4m, less water will come out due to pressure drops.  
• Use standard feed tube to prevent leaking.



#### ■ Outernal Filter (optional)


##### 1. Filter Fixation

- 1) Connect feed tube to the filter outlet and water valve connecting tube.
- 2) Fix the filter at proper place around the sink where it is easy to replace the filter and to receive the cleaning water. Please consider the length of tube shall be less than 12m when locating filter.
- 3) When fixing the filter, use fixing plate and cable depending on the surrounding conditions.




##### 2. Filter Cleaning

- 1) Connect feed tube to the inlet of feed valve and filter.
- 2) Clean the main valve and feed valve with water for at least one minute until clean water comes out.







## 7-2. STARTING THE ICE MAKER



- Make sure the switch on the ice maker assy is turned "on".





- To check on the amount of water being supplied, press the Test button. (Hold for 0.5 seconds)



- If only a small amount of water is put in the ice tray as the diagram above, the water supply must be adjusted.

Adequate water level.


Water supply control switch



- Adjust the water supply control switch to adjust the amount of water being supplied.


- Refer to the water supply time control option table on the right to extend the supply time.

WATER SUPPLY TIME CONTROL OPTION




SWITCH NO			TIME
SW1	SW2	SW3	
OFF	OFF	OFF	10.5 sec
ON	OFF	OFF	9 sec
OFF	ON	OFF	10 sec
ON	ON	OFF	11 sec
OFF	OFF	ON	12 sec
ON	OFF	ON	13 sec
OFF	ON	ON	14 sec
ON	ON	ON	15 sec


Line indicating the adequate amount of water supply.



- Make sure it is adjusted to meet the line indicating the adequate amount of water supply.



- Place the cover on the ice maker.



- Clean the ice storage box and place it under the ice maker. (see the figure above)  
The ice storage will eventually be located on the freezer shelf.


### CAUTION.

It takes the ice maker 24 hours to start making ice. If ice is made, the ice will be 'off taste'. If this happens, throw away the ice 2-3 times before using.

This will get rid of the "off taste". If any problems appear, refer to 'Troubleshooting' (see page 25).

This will complete the ice maker installation process.

Also, check on the location of the ice maker. If it is bent or needs to be adjusted, unscrew the screws to adjust the location. Then, install the screws again. (as shown in the diagram below)



---

## 7-3. TROUBLESHOOTING

### Operational Notes

1. The ice maker water valve contains a flow washer that acts like a pressure regulator to control the water flow. For the ice maker to work properly, the water pressure in your home must be between 20 and 120 pounds-per-square-inch(psi). If you encounter problems with your ice maker's ability to produce ice, call your water utility company and have the water pressure checked.
2. The ice maker's water valve is equipped with two strainers; a plastic basket type and a wire-mesh screen. Both of these can be cleaned by turning off the water and disassembling the water valve (your service center should be able to provide this service). If local water conditions require periodic cleaning, or if you use a well as a water source, you should consider installing a second water strainer in the water line. You can obtain a water strainer from your local appliance dealer.


### TROUBLESHOOTING CHART

The following chart lists several common problems that could occur with your ice maker.

PROBLEM	CAUSE
One or more of the following sounds is heard: 1. Buzzing 2. Trickling water 3. Thud (clatter of ice)	The water valve is operating. Water is entering the ice maker fill cup. Ice is being dumped into the ice bin.
Ice tastes stale.	The ice is old. Make a new batch. Water in ice maker overflows.
Refrigerator or ice maker is not level.	If the ice maker still overflows after leveling, turn off the ice maker's water supply at the shut-off valve. Raise the ice maker's bail arm to the "off" position. Contact your local service center.
Not enough ice.	Freezer door is being opened too often. Adjust the Air Control or Freezer Control for a colder setting.
Ice making has stopped.	Be sure that the bail arm is lowered into the ice bucket. Make sure that the water shut-off valve is on. The water shut-off valve or the water valve screen is clogged (contact your local service center).

7-5 Main PWB Assembly and Parts List


7-5-1 MAIN PWB




7-5-2 Replacement Part List

NO.	DWG. NO.	DESCRIPTION	SPEC	MAKER	REMARK
1	6670.B2039	PWB,MAIN	FR-1(05-1107A)	DOO SAN	1=1.8
2	6170.B2002	TRANS PCB	I:117V.O:15V	TAE SUNG	TRANS
3	6630.B8001B	WAFER	420-11-43P-2A	JAE EUN	CON1
4	6630.B8004G		SMW250-0B		
5	6630.B8004D		SMW250-04	YEON HO	CON2
6	6630.B8004D				CON3
7	0177.B2004A	MICOM CHIP	TMP87C409N	TOSHIBA	IC1(=027.B2004B)
8	01RH78050B 01RE78050A	REGULATOR	(1)BA17B05T (2)KIA7805SP	ROHM REC	IC3
9	01RH178120A 01NE781200B	REGULATOR	(1)BA17812T uPC7812AHF	ROHM NEC	IC2
10	01KE704200A 01KD010100A	RESET IC	K1A7042P BMR-0101D	K.E.C RODENSEH	IC4
11	8920.B2003A	RELAY	G5N-1	OMRON	RY1
12	1570-00012A 1570-00012B	RESONATOR	CST4.00MGW CST4.00MGW-1F01	MURATA	OSC1 (=8212A28002B)
13	1572-00001C (=6102A0075A)	VARISTOR	(1)INR14D471	EL JIN	VA1
14	6102.B8001B		(2)SVC471D-14A	SAMHWA	
15	6102.B8001A		(1)INR14D621	EL JIN	
16	1572-00001D 6102.B8003A		(2)SVC621D-14A (1)SVC271D-14A (2)INR14D271	SAMHWA EL JIN	
17	00D414806B	SWITCHING DIODE	1N4148	(1)P C (2)ROHM	D5
18	00D400409CC	DIODE,RECTIFIER	1N4004	(1)P C (2)ROHM	D1~D4
19	6600.B8003A	DIP S/W	3P,DIP	OTAX	SW1
20	01RH622200A	DRIVE IC	BA8222	ROHM	IC5
21	0CE2286J618	ELE CAPACTOR	2200uF/35V		CE1
22	0CE1081H618		1000uF/25V		CE2
23	0CE1071H638		100uF/25V	(1)SAM HWA	CE4
24	0CE4771H618		470uF/25V	ROHM	CE5
25	0CE2271F638		220uF/16V		CE3
26	0CE4781H638		47uF/25V		
27	0CC2231H409	WVL CAPACTOR	223/100V	SEL	CM1~CM3
28	0CK1020H908		102/25V		
29	0CK2230H908	COF CAPACTOR	223/25V	TAE YANG	
30	0CK1040H908		104/50V		CC1~12
31					
32	0RD0682H609		68J 1/2W		R6
33	0RD2001G608	R,CARBON FILM	2KJ 1/4W	(1)TAE YANG (2)K-ONN	R7,R9~11
34	0RD4701G609		4.7K 1/4W	(3)DONG HO (4)SUNG TO	R3~5,8 R14~16
35	0RD1004G608		1MJ 1/4W		
36	0RN1812G408	R,METAL FILM	18.2KF 1/4W		RF1
37					
38					
39	0TR06009AC	TRANSISTOR	KR106M(KRA226)	K.E.C	Q1
40	0TR102009AB	TRANSISTOR	KRC102M(KRC120)	K.E.C	Q2
41	43607015	JUMP WIRE	0.6*5mm 0.6*8mm 0.6*10mm 0.6*12.5mm 0.6*15mm		J01,J04~J06 J09~J11,CC13 J02,J03,J07 J08,J12~J14
42	4920.B3003A	HEAT SINK(12V)	(=572-00004A)		(IC2)
43	4920.B3001A	HEAT SINK(5V)	(=572-00002A)		
44	1S8F030241B	SCREW	ASSEMBLE WITH H/SINK		
45	49111001	SOLDER	ALMT KR-196MA	HEE SUNG SOLDER	
46	49111004	SOLDER LEAD BOND	H63A		
47	58333105	FLUX AUTO	JS71	KOKI	
48					

7-6 PWB DIAGRAM



TOSHIBA TMP87C409N(IC1)






# 8. EXPLODED VIEW & REPLACEMENT PARTS LIST

▼ The parts of refrigerator and the shape of each part are subject to change in different localities.


▼ Capacitors and fuse are optional parts.

**GR-T622, GR-T722**

\*: Option



\* : Option



# ICE MAKER PART

\* : Option

