


Panasonic®




Wide Plasma Display Operating Instructions

Model No. **TH-37PWD4**



Before connecting, operating or adjusting this product, please read these instructions completely. Please keep this manual for future reference.

English



The lightning flash with arrow-head within a triangle is intended to tell the user that parts inside the product are a risk of electric shock to persons.



The exclamation point within a triangle is intended to tell the user that important operating and servicing instructions are in the papers with the appliance.

WARNING To prevent damage which may result in fire or shock hazard, do not expose this appliance to rain or moisture. Do not place containers with water (flower vase, cups, cosmetics, etc.) above the set (including on shelves above, etc.)

WARNING 1) To prevent electric shock, do not remove cover. No user serviceable parts inside. Refer servicing to qualified service personnel.
2) Do not remove the grounding pin on the power plug. This apparatus is equipped with a three pin grounding-type power plug. This plug will only fit a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact an electrician. Do not defeat the purpose of the grounding plug.

Important Safety Instructions

- 1) Read these instructions
All the safety and operating instructions should be read before the appliance is operated
- 2) Keep these instructions
The safety and operating instructions should be retained for future reference
- 3) Heed all warnings
All warnings on the appliance and in the operating instructions should be adhered to
- 4) Follow all instructions
All operating and use instructions should be followed
- 5) Do not use this apparatus near water
For example, near a bathtub, wash bowl, kitchen sink, or laundry tube, in a wet basement, or near a swimming pool, and the like
- 6) Clean only with dry cloth
Do not use liquid cleaners or aerosol cleaners Use a dry cloth for cleaning
- 7) Do not block any ventilation openings Install in accordance with the manufacture's instructions
Slots and Openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface
- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat
This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to
- 9) Do not defeat the safety purpose of the polarized or grounding-type plug A polarized plug has two blades with one wider than the other A grounding type plug has two blades and a third grounding prong The wide blade or the third prong are provided for your safety If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet
- 10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus
- 11) Only use attachments / accessories specified by the Manufacturer
- 12) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus When a cart is used, use caution when moving the cart / apparatus combination to avoid injury from tip-over
Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn
- 13) Unplug this apparatus during lightning storms or when unused for long periods of time
This will prevent damage to the product due to lightning and power-line surges
- 14) Refer all servicing to qualified service personnel Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped
- 15) To prevent electric shock, ensure the grounding pin on the AC cord power plug is securely connected



Dear Panasonic Customer

Welcome to the Panasonic family of customers. We hope that you will have many years of enjoyment from your new Plasma Display.

To obtain maximum benefit from your set, please read these Instructions before making any adjustments, and retain them for future reference.

Retain your purchase receipt also, and note down the model number and serial number of your set in the space provided on the rear cover of these instructions.

Note:

Do not allow a still picture to be displayed for an extended period, as this can cause a permanent after-image to remain on the Plasma Display.

Examples of still pictures include logos, video games, computer images, teletext and images displayed in 4:3 mode.

Trademark Credits

- VGA is a trademark of International Business Machines Corporation
- S-VGA is a registered trademark of the Video Electronics Standard Association

Even if no special notation has been made of company or product trademarks, these trademarks have been fully respected.

Table of Contents

Important Safety Instructions	3	SOUND Adjustment	26
FCC STATEMENT	6	MUTE	26
Safety Precautions	7	SURROUND Controls	27
Accessories	9	PICTURE Adjustments	28
Accessories Supplied	9	Advanced settings	29
Optional Accessories	9	SET UP for MULTI DISPLAY	30
Remote Control Batteries	10	How to setup MULTI DISPLAY	30
Basic Controls	11	How to set the Display location number for each Plasma Display	31
Connections	12	SET UP TIMER	32
Speakers connection	13	PRESENT TIME OF DAY Set	32
AV Input Terminals connection	13	TIMER Set	33
AV Input connection	14	SCREENSAVER (For preventing after-images)	34
COMPONENT/RGB Input connection	14	Setup of SCREENSAVER Time	35
PC Input connection	16	SIDE BAR ADJUST	36
SERIAL Terminals connection	17	SET UP for Input Signals	37
Power ON/OFF and Input Signal Selection	18	COMPONENT/RGB/ IN SELECT	37
AC cord connection	18	3D Y/C FILTER – For NTSC Video images	37
Power ON/OFF	18	COLOR SYSTEM / Panasonic AUTO	38
Select the Input Signal	19	[SYNC]	39
Selecting the ON-Screen Menu Language	19	[PULL IN RANGE]	39
On-Screen Menu Display from Remote Control	20	[CLAMP POSITION]	39
ASPECT Controls	22	[H-FREQ (kHz)/V-FREQ (Hz)]	39
Adjusting PICTURE POS./SIZE	24	Troubleshooting	40
		Specifications	42

FCC STATEMENT

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC CAUTION

Pursuant to 47CFR, Part 15.21 of the FCC rules, any changes or modifications to this monitor not expressly approved by Matsushita Electric Corporation of America could cause harmful interference and would void the user's authority to operate this device.

CANADIAN NOTICE

This Class A digital apparatus complies with Canadian ICES-003.

FCC CAUTION:

To assure continued compliance and possible undesirable interference, the provided ferrite cores must be used when connecting this plasma display to video equipment, and maintain at least 40cm spacing to other peripheral devices. Refer to instructions on pages 16, and 17.

Safety Precautions

WARNING

Set up

Do not place the Plasma Display on sloped or unstable surfaces

- The Plasma Display may fall off or tip over

Do not place any objects on top of the Plasma Display.

- If water spills onto the Plasma Display or foreign objects get inside it, a short-circuit may occur which could result in fire or electric shock. If any foreign objects get inside the Plasma Display, please consult an Authorized Service Center

Do not cover the ventilation holes

- Doing so may cause the Plasma Display to overheat, which can cause fire or damage to the Plasma Display

If using the pedestal (optional accessory), leave a space of 3 15/16" (10 cm) or more at the top, left and right, 2 3/8" (6 cm) or more at the bottom, and 2 3/4" (7 cm) or more at the rear. If using some other setting-up method, leave a space of 3 15/16" (10 cm) or more at the top, bottom, left and right, and 3/4" (1.9 cm) or more at the rear

Avoid installing this product near electronic equipment that generates electromagnetic waves

- It will cause interference in image, sound, etc. In particular, keep video equipment away from this product

AC Power Supply Cord

The Plasma Display is designed to operate on 120 V AC, 50/60 Hz

Securely insert the power cord plug as far as it will go

- If the plug is not fully inserted, heat may be generated which could cause fire. If the plug is damaged or the wall socket plate is loose, they should not be used

Do not handle the power cord plug with wet hands.

- Doing so may cause electric shocks

Do not do anything that might damage the power cable. When disconnecting the power cable, hold the plug, not the cable

- Do not make any modifications, place heavy objects on, place near hot objects, heat, bend, twist or forcefully pull the power cable. Doing so may cause damages to the power cable which can cause fire or electric shock. If damage to the cable is suspected, have it repaired at an Authorized Service Center

If the Plasma Display is not in use for a long period of time, unplug the power cord from the wall outlet

If problems occur during use

If a problem occurs (such as no picture or no sound), or if smoke or an abnormal odor is detected from the Plasma Display, unplug the power cord immediately

- Continuous use of the Display under these conditions might cause fire or permanent damage to the unit. Have the Display evaluated at an Authorized Service Center. Services to the Display by any unauthorized personnel are strongly discouraged due to its high voltage dangerous nature

If water or foreign objects get inside the Plasma Display, if the Plasma Display is dropped, or if the cabinet becomes damaged, disconnect the power cord plug immediately

- A short may occur, which could cause fire. Contact an Authorized Service Center for any repairs that need to be made

Safety Precautions

CAUTION

This Plasma Display is for use only with the following optional accessories. Use with any other type of optional accessories may cause instability which could result in the possibility of injury

(All of the following accessories are manufactured by Matsushita Electric Industrial Co., Ltd.)

- | | |
|-----------------------------------|--------------|
| ▪ Speakers | TY-SP37P4W-K |
| ▪ Pedestal | TY-ST42PT3-K |
| ▪ Wall stand | TY-ST42PW1 |
| ▪ Wall-hanging bracket (vertical) | TY-WK37PV3 |
| ▪ Ceiling unit | TY-CE42PS1 |
| ▪ Terminal cover | TY-UPS200 |

Always be sure to ask a qualified technician to carry out set-up

When using the Plasma Display

Do not bring your hands, face or objects close to the ventilation holes of the Plasma Display.

- Top of the Plasma Display is usually very hot due to the high temperature of exhaust air being released through the ventilation holes. Burns or personal injuries can happen if any body parts are brought too close. Placing any object near the top of the display could also result in heat damages to the object as well as to the Display if its ventilation holes are blocked.

Be sure to disconnect all cables before moving the Plasma Display

- Moving the Display with its cables attached might damage the cables which, in turn, can cause fire or electric shock.

Disconnect the power plug from the wall outlet as a safety precaution before carrying out any cleaning

- Electric shocks can result if this is not done.

Clean the power cable regularly to prevent it from becoming dusty

- Built-up dust on the power cord plug can increase humidity which might damage the insulation and cause fire. Unplug the cord from the wall outlet and clean it with a dry cloth.

Cleaning and maintenance

The front of the display panel has been specially treated. Wipe the panel surface gently using only a cleaning cloth or a soft, lint-free cloth.

- If the surface is particularly dirty, soak a soft, lint-free cloth in a weak detergent solution and then wring the cloth to remove excess liquid. Use this cloth to wipe the surface of the display panel, then wipe it evenly with a dry cloth, of the same type, until the surface is dry.
- Do not scratch or hit the surface of the panel with fingernails or other hard objects. Furthermore, avoid contact with volatile substances such as insect sprays, solvents and thinner, otherwise the quality of the surface may be adversely affected.

If the cabinet becomes dirty, wipe it with a soft, dry cloth

- If the cabinet is particularly dirty, soak the cloth in a weak detergent solution and then wring the cloth dry. Use this cloth to wipe the cabinet, and then wipe it dry with a dry cloth.
- Do not allow any detergent to come into direct contact with the surface of the Plasma Display. If water droplets get inside the unit, operating problems may result.
- Avoid contact with volatile substances such as insect sprays, solvents and thinner, otherwise the quality of the cabinet surface may be adversely affected or the coating may peel off. Furthermore, do not leave it for long periods in contact with articles made from rubber or PVC.

Note

Do not allow a still picture to be displayed for an extended period, as this can cause a permanent after-image to remain on the Plasma Display.


Examples of still pictures include logos, video games, computer images, teletext and images displayed in 4:3 mode.

Accessories


Accessories Supplied

Check that you have the Accessories and items shown


Operating Instruction book




Remote Control Transmitter
EUR646525




Batteries for the Remote
Control Transmitter
(AA(R6) Battery x 2)




Warranty




Ferrite core
J0KF0000001B x 2



Fixing bands
TMME1B7 x 2




AC cord



Optional Accessories


■ Speakers
TY-SP37P4W-K




■ Pedestal
TY-ST42PT3-K




■ Wall stand
TY-ST42PW1



■ Wall-hanging bracket
(vertical)
TY-WK37PV3



■ Ceiling unit
TY-CE42PS1



■ Terminal cover
TY-UPS200




For assembling

Full instructions are supplied with each optional accessories for use with this Plasma Display


Remote Control Batteries

Requires two AA batteries


1 Turn the transmitter face down
Press and slide off the battery cover



2 Install the batteries as shown in the battery compartment
(Polarity + or - must match the markings in the compartment)



3 Replace the cover and slide in reverse until the lock snaps



Helpful Hint:

For frequent remote control users, replace old batteries with Alkaline batteries for longer life


⚠ Precaution on battery use

Incorrect installation can cause battery leakage and corrosion that will damage the remote control transmitter

Observe the following precautions.

- 1 Batteries should always be replaced as a pair. Always use new batteries when replacing the old set
- 2 Do not combine a used battery with a new one
- 3 Do not mix battery types (example "Zinc Carbon" with "Alkaline")
- 4 Do not attempt to charge, short-circuit, disassemble, heat or burn used batteries
- 5 Battery replacement is necessary when the remote control acts sporadically or stops operating the Plasma Display

Basic Controls



Main Power On/Off Switch

Power Indicator

The Power Indicator will light

- Power-OFF Indicator not illuminated (The unit will still consume some power as long as the power cord is still inserted into the wall outlet)
- Stand-by ⏻ Red
- Power-ON Green


Input button (VIDEO (S VIDEO)/COMPONENT, RGB/PC Mode Selection)
Push the "INPUT" button to select VIDEO(S VIDEO)/COMPONENT or RGB/PC input signal modes sequentially

Volume Adjustment
Push the Volume Up "+" or Down "-" button to increase or decrease the sound volume level

Stand-by (ON/OFF) button

The Plasma Display must first be plugged into the wall outlet and turned on at the power switch (see page 18) Push this button to turn the Plasma Display ON, from STANDBY mode Push it again to turn the Plasma Display OFF to STANDBY mode

Status button
Push the "Status" button to display the current system status



- ① VIDEO(S VIDEO)/COMPONENT, RGB/PC mode
- ② Aspect mode (see page 22)
- ③ Off timer

The off timer indicator is displayed only when the off timer has been set

N button
(see page 25, 26, 28, 29)

PICTURE button
(see page 28)

PICTURE POS./SIZE button
(see page 24)

PC button
Push the "PC" mode selection button to select the PC mode This button is used to switch directly to PC mode

SURROUND button
(see page 27)

Input button (VIDEO(S VIDEO)/COMPONENT, RGB/PC Mode Selection)
Press to select VIDEO(S VIDEO)/COMPONENT or RGB/PC input signal modes sequentially (see page 19)

Sound mute On/Off (see page 26)

Volume Adjustment
Press the Volume Up "+" or Down "-" button to increase or decrease the sound volume level

R button (see page 21)

ACTION button
Press to make selections


POSITION buttons
SET UP button (see page 20)
SOUND button (see page 26)

ASPECT button
Press to adjust the aspect (see page 22)


OFF TIMER button

The Plasma Display may be preset to switch to stand-by after a fixed period The setting changes to 30 minutes, 60 minutes, 90 minutes and 0 minutes (off timer cancelled) each time the button is pressed

When three minutes remain, "Off timer 3" will flash The off timer is cancelled if a power interruption occurs



Connections




- Cable fixing bands

Secure any excess cables with bands, as required


Pass the attached cable fixing band through the clip as shown in the figure

1




To secure cables connected to Terminals, wrap the cable fixing band around them then pass the pointed end through the locking block, as shown in the figure



2



To tighten



To loosen



AV IN Terminals
(see page 13, 14)

COMPONENT/RGB IN and Audio
IN Terminals (see page 15)


From EXIT monitor Terminal
on Computer (see page 16)

From SERIAL Terminal on
Computer (see page 17)

Speakers connection

When connecting the speakers, be sure to use only the optional accessory speakers


Refer to the speaker's Installation Manual for details on speaker installation



AV Input Terminals connection

Connect the signal source equipment (see page 14 to 17)

(Example) When connecting an S VIDEO VCR




Note:

Additional equipment and cables shown are not supplied with this set

AV Input connection


VIDEO signal connection



Note:
Additional equipment and cables shown are not supplied with this set


COMPONENT/RGB Input connection

Component signals (Y, P_B, P_R) connection



Notes.
(1) Change the "COMPONENT/RGB-IN" setting in the "SET UP" menu to "COMPONENT" (see page 37, 39)
(2) Additional equipment, cables and adaptor plugs shown are not supplied with this set


RGB signal (R, G, B, HD, VD) connection




Notes

- (1) Change the "COMPONENT/RGB-IN" setting in the "SET UP" menu to "RGB" (see page 37, 39)
- (2) Additional equipment, cables and adaptor plugs shown are not supplied with this set

PC Input connection




Installing the ferrite core



Notes

- (1) Computer signals which can be input are those with a horizontal scanning frequency of 15.5 to 110 kHz and vertical scanning frequency of 48 to 120 Hz (However, signals cannot be displayed if signals exceeding 1200 lines will not be displayed properly)
- (2) The display resolution is a maximum of 640 × 480 dots when the aspect mode is set to "NORMAL", and 852 × 480 dots when the aspect mode is set to "FULL". If the display resolution exceeds these maximums, it may not be possible to show fine detail with sufficient clarity.
- (3) The PC input terminals are DDC1/2B-compatible. If the computer being connected is not DDC1/2B-compatible, you will need to make setting changes to the computer at the time of connection.
- (4) Some PC models cannot be connected to the set.
- (5) There is no need to use an adapter for computers with DOS/V compatible D-sub 15P terminal.
- (6) The computer shown in the illustration is for example purposes only.
- (7) Additional equipment and cables shown are not supplied with this set.
- (8) Do not set the horizontal and vertical scanning frequencies for PC signals which are above or below the specified frequency range.

Signal Names for D-sub 15P Connector




Pin layout for PC input terminal

Pin No	Signal Name	Pin No	Signal Name	Pin No	Signal Name
①	R	⑥	GND (Ground)	⑪	GND (Ground)
②	G	⑦	GND (Ground)	⑫	SDA
③	B	⑧	GND (Ground)	⑬	HD/SYNC
④	GND (Ground)	⑨	NC (not connected)	⑭	VD
⑤	GND (Ground)	⑩	GND (Ground)	⑮	SCL

SERIAL Terminals connection

The SERIAL terminal is used when the Plasma Display is controlled by a computer



Notes

- (1) Use the RS-232C cable to connect the computer to the Plasma Display
- (2) The computers shown is for example purposes only
- (3) Additional equipment and cables shown are not supplied with this set

The SERIAL terminal conforms to the RS-232C interface specification, so that the Plasma Display can be controlled by a computer which is connected to this terminal

The computer will require software which allows the sending and receiving of control data which satisfies the conditions given below Use a computer application such as a programming language to software Refer to the documentation for the computer application for details


Communication parameters

Signal level	RS-232C compliant
Synchronization method	Asynchronous
Baud rate	9600 bps
Parity	None
Character length	8 bits
Stop bit	1 bit
Flow control	-

RS-232C Conversion cable	
D-sub 9-pin female	Details
②	R X D
③	T X D
⑤	GND
④ - ⑥	Non use
⑦	Shorted
⑧	
① - ⑨	NC

Basic format for control data

The transmission of control data from the computer starts with a STX signal, followed by the command, the parameters, and lastly an ETX signal in that order If there are no parameters, then the parameter signal does not need to be sent



Note

- (1) If multiple commands are transmitted, be sure to wait for the response for the first command to come from this unit before sending the next command
- (2) If an incorrect command is sent by mistake, this unit will send an "ER401" command back to the computer

Command


Command	Parameter	Control details
PON	None	Power ON
POF	None	Power OFF
AVL	**	Volume 00 - 63
AMT	0	Audio MUTE OFF
	1	Audio MUTE ON
IIS	None	Input select (toggle)
	VID	AV Mode
	YP1	Component / RGB mode (processed as a Y/Pb/Pr or RGB signals as sel by this unit)
DAM	RG1	PC mode
	None	Screen mode select (toggle)
	NORM	NORMAL (4 3)
	ZOOM	ZOOM
	FULL	FULL
JUST	JUST	
SELF	SELF	Panasonic AUTO

With the power off, this display responds to PON command only


Power ON/OFF and Input Signal Selection

AC cord connection

Connecting the AC cord plug to the Plasma Display



Power ON/OFF



Connecting the plug to the Wall Outlet

Push the POWER switch on the Plasma Display to turn the set on POWER-ON


Power Indicator Green

Example The screen below is displayed for a while after the Plasma Display is turned on (setting condition is an example)



When the POWER is turned on for the first time, the LANGUAGE selection screen is displayed


From the second time on, language selection can be done from the setup menu (see page 19)

Select the desired language using the ▲ and ▼ keys and press the ACTION button




From the second time on, the screen shown below is displayed for a while (setting condition is an example)




Press the  button on the remote control to turn the Plasma Display off




Power Indicator Red (standby)

Press the  button on the remote control to turn the Plasma Display on

Power Indicator Green

To turn the power for the Plasma Display off, press the  switch on the Plasma Display, when the Plasma Display is on or in standby mode

Select the Input Signal




Press the INPUT button to select the input video signal desired from equipment such as a VCR which has been connected to the Plasma Display

Input signals will change as follows

For COMPONENT INPUT (see page 37)





For RGB INPUT (see page 37)



Selecting the On-Screen Menu Language



press to display the SET UP menu




press to select OSD LANGUAGE

press to select your preferred language

selectable languages


- English(UK)
- Deutsch
- Français
- Italiano
- Español
- ENGLISH(US)
- 中文

(Chinese)




On-Screen Menu Display from Remote Control


To PICTURE adjust menu
(see page 26)




To ADVANCED SETTINGS
(see page 28, 29)




To SOUND adjust menu
(see page 26)









To PICTURE POS /SIZE adjust menu (see page 24)
During "VIDEO" and "COMPONENT" input signal modes




During "RGB" and "PC" input signal modes




Press to select each item



On-Screen Menu Display from Remote Control




Press to access each adjust screen




Press the R button to return to "SET UP" menu

To SIGNAL screen for VIDEO (see page 38)




To SIGNAL screen for RGB (see page 39)



To SIGNAL screen for COMPONENT (see page 39)





To SIGNAL screen for PC (see page 39)



Note


"SIGNAL" setup menu displays different setting condition for each input signals (see page 19)

To setup SCREENSAVER (See page 34)







Press to select each TIME adjust screen


Press to display each adjust screen




Press the R button to return to "SCREENSAVER" menu




To setup MULTIDISPLAY screen(see page 30)




To SET UP TIMER selection screen (see page 32)






Press to select each TIMER adjustment items



When select TIMER adjustment item, press this button to SET UP TIMER screen



Press the R button to return to "SET UP" menu




ASPECT Controls

The Plasma Display will allow you to enjoy viewing the picture at its maximum size, including wide screen cinema format picture




ASPECT button







The aspect mode changes each time the ASPECT button is pressed



Notes

- (1) During RGB and PC input signal modes, the mode switches between "NORMAL", "ZOOM" and "FULL" only
- (2) For a 525p (480p) signal input during "COMPONENT" input signal mode, the mode switches between "ZOOM" and "FULL" only
- (3) For a 1125i (1080i), 750p (720p) signal input during "COMPONENT" input signal mode, the mode is set to "FULL" mode, and switching is not possible
For a 525i (480i), 625i (576i) signal input during "Component" input signal mode, "Panasonic Auto" can not be selected
- (4) The aspect mode is memorized separately for each input terminal (VIDEO, COMPONENT, RGB and PC)





Mode	Picture	Explanation
NORMAL		NORMAL will display a 4 3 picture at its standard 4 3 size
ZOOM		ZOOM mode magnifies the central section of the picture
FULL		FULL will display the picture at its maximum size but with slight elongation
JUST		JUST mode will display a 4 3 picture at its maximum size but with aspect correction applied to the center of the screen so that elongation is only apparent at the left and right edges of the screen. The size of the picture will depend on the original signal.
Panasonic AUTO	 <p>For an elongated image Image is expanded</p>  <p>For a 4 3 image Changes in accordance with the Panasonic AUTO mode setting (see page 38)</p>	<p>The display will automatically become enlarged (depending on the picture source), allowing you to view the picture at its maximum size</p> <p>Note Panasonic AUTO mode is designed to automatically adjust the aspect ratio to handle a mix of 16 9 and 4 3 program material. Certain 4 3 program material, such as stock market data screens, may occasionally cause the image size to change unexpectedly. When viewing such programs, it is recommended that the ASPECT be set to NORMAL.</p>



Notes


- (1) Do not allow 4 3 mode to be displayed for an extended period, as this can cause a permanent after-image to remain on the Plasma Display Panel
- (2) The S VIDEO terminal on this set can detect specially encoded signals that are compatible with a wide screen monitor. When a full image from the S VIDEO terminal of specially encoded video is detected by the set, the screen size is automatically set to FULL mode.

Adjusting PICTURE POS./SIZE


Adjusting screen

1  **ASPECT**
 Press to select the screen mode to adjust


2  **PICTURE POS / SIZE**
 Press to display the PICTURE POS / SIZE menu

 Press to select H-POS/H-SIZE/V-POS/V-SIZE/CLOCK PHASE



During "VIDEO" and "COMPONENT" input signal modes




During "RGB" and "PC" input signal modes



3  Press to adjust screen/position









 **R**
 Press to exit from adjust mode



Notes


- (1) Adjustment details are memorized separately for different input signal formats (Adjustments for component signals are memorized for 525i (480i), 625i (576i), 525p (480p), 1125i (1080i) and 625p (576p), 750p (720p) each, and RGB/PC signals are memorized for each frequency)
- (2) If a "Cue" or "Rew" signal from a VCR or DVD player is received, the picture position will shift up or down. This picture position movement cannot be controlled by the PICTURE POS./SIZE function

Adjusting PICTURE POS./SIZE

<p>H-POS</p>	<p>When the Position Left "◀" button is pressed</p> 	<p>When the Position Right "▶" button is pressed</p> 
<p>H-SIZE</p>	<p>When the Position Left "◀" button is pressed</p> 	<p>When the Position Right "▶" button is pressed</p> 
<p>V-POS</p>	<p>When the Position Left "◀" button is pressed</p> 	<p>When the Position Right "▶" button is pressed</p> 
<p>V-SIZE</p>	<p>When the Position Left "◀" button is pressed</p> 	<p>When the Position Right "▶" button is pressed</p> 
<p>CLOCK PHASE (RGB/PC in Mode)</p>	<p>Flickering and distortion can be eliminated by using the Position Left "◀" or Right "▶" button to carry out adjustment</p>	




Helpful Hint (/ Normalization)


While the PICTURE POS /SIZE display is active, if either the N button on the remote control is pressed at any time or the  (ACTION button) is pressed during "NORMALIZE", then all adjustment values are returned to the factory settings

SOUND Adjustment

1  Press to display the Sound menu

2 Select to adjust each item

 Press to select the desired adjustment menu
Select the desired level by listening to the sound



BASS
Adjusts low sounds


TREBLE
Adjusts high sounds

BALANCE
Adjusts left and right volumes

SURROUND (see next page)
Select ON or OFF

■ To end adjustments

 Press the R button



STANDARD Emits the original sound




AUTO Automatically controls proper volume level

Note


Press the SURROUND button to directly turn the surround effect ON and OFF (see next page)

Helpful Hint (/ Normalization)

While the "SOUND" menu is displayed, if either the N button on the remote control is pressed at any time or the  (ACTION button) is pressed during "NORMALIZE", then all adjustment values are returned to the factory settings

Mute

Useful when answering the phone or receiving unexpected visitors

 Press this button to mute the sound
Press again to reactivate sound. Sound is also reactivated when power is turned off or volume level is changed

SURROUND Controls





SURROUND Button

The benefits of surround sound are enormous. You can be completely enveloped in sound, just as if you were at a concert hall or cinema.

The surround setting switches on and off each time the SURROUND button is pressed.

ON \longleftrightarrow OFF




Note


The surround settings are memorized separately for each SOUND mode (AUTO, STANDARD).


PICTURE Adjustments

1  Press the PICTURE button on the Remote Control to display the PICTURE menu




2 Select to adjust each item

 Press to select the menu to adjust
Select the desired level by looking at the picture behind the menu



Press the left ◀ or right ▶ button to switch between modes



STANDARD

For viewing in standard (evening lighting) environments

This menu selects the normal levels of BRIGHTNESS and PICTURE

DYNAMIC

For viewing in brighter environments


This menu selects higher than normal levels of BRIGHTNESS and PICTURE

CINEMA

Ideal for movies

- Can be selected for VIDEO/COMPONENT

Press the left ◀ or right ▶ button to select "ON" Press the down ▼ button to enter ADVANCED SETTINGS mode
ADVANCED SETTINGS ON
Enables fine picture adjustment at a professional level (see next page)




ADVANCED SETTINGS OFF
Displays images with settings of the PICTURE menu


Note-

If you would like to change the picture and color of the selected PICTURE menu to something else, adjust using the items in the PICTURE menu (see page 29)

Press the left ◀ or right ▶ button to switch between modes



Helpful Hint (/ Normalization)

While the "PICTURE" menu is displayed, if either the N button on the remote control is pressed at any time or the  (ACTION button) is pressed during "NORMALIZE", then all adjustment values are returned to the factory settings

Item	Effect	Adjustments
PICTURE	Less More	Selects the proper brightness and density for the room
BRIGHTNESS	Darker Brighter	Adjusts for easier viewing of dark pictures such as night scenes and black hair
COLOR	Less More	Adjusts slightly to a lighter color
TINT (NTSC only)	Reddish Greenish	Adjust for nice skin color
SHARPNESS	Less More	Displays a sharp image

Notes

- (1) "COLOR", "TINT" and "SHARPNESS" settings cannot be adjusted for "RGB" and "PC" input signal modes
- (2) You can change the level of each function (PICTURE, BRIGHTNESS, COLOR, TINT, SHARPNESS) for each PICTURE menu
- (3) The setting details for normal, dynamic and cinema respectively are memorized separately for each input mode (VIDEO, COMPONENT, RGB)
- (4) The "TINT" setting can be adjusted for NTSC signal only

Note

There is little change when PICTURE is increased with a bright picture or reduced with a dark picture

ADVANCED SETTINGS

Item	Effect	Details
BLACK EXTENSION	Less More	Adjusts the dark shades of the image in gradation
W/B HIGH R	Less More	Adjusts the white balance for light red areas
W/B HIGH B	Less More	Adjusts the white balance for light blue areas
W/B LOW R	Less More	Adjusts the white balance for dark red areas
W/B LOW B	Less More	Adjusts the white balance for dark blue areas
GAMMA	Down Up	2.0 ↔ 2.2 ↔ 2.5

Notes

- (1) Carry out "W/B" adjustment as follows
 - (A) Adjust the white balance of the bright sections using the "W/B HIGH R" and "W/B HIGH B" settings
 - (B) Adjust the white balance of the dark sections using the "W/B LOW R" and "W/B LOW B" settings
 - (C) Repeat steps (A) and (B) to adjust

Steps (A) and (B) affect each other's settings, so repeat each step in turn to make the adjustment
- (2) The adjustment values are memorized separately for each input mode (VIDEO, COMPONENT, RGB and PC)
- (3) The adjustment range values should be used as an adjustment reference


Helpful Hint (/ Normalization)

On the remote control unit, while the "Advanced settings" menu is displayed, if either the N button is pressed at any time or the (Access button) is pressed during "Normalise", then all adjustment values are returned to the factory settings


Setup for MULTI DISPLAY

- ① By lining up Plasma Displays in groups of 4 or 9 as illustrated below, an enlarged picture may be displayed across all screens
- ② For this mode of operation, each plasma display has to be set up with a DISPLAY number to determine its location

group of 4 (2x2)



group of 9 (3x3)




How to setup MULTI DISPLAY


1



Press to display the SETUP menu screen




2




Press to select the MULTI DISPLAY SETUP

Press to the "MULTI DISPLAY SETUP" menu




3



Press to select the MULTI DISPLAY SETUP


Press to "ON" or "OFF"

Press to store the above setup




How to set the Display location number for each Plasma Display

4



MULTI DISPLAY SETUP		
MULTI DISPLAY SETUP	◀	ON ▶
ARRANGEMENT	◀	2x2 ▶
LOCATION	◀	A1 ▶

5



MULTI DISPLAY SETUP		
MULTI DISPLAY SETUP	◀	ON ▶
ARRANGEMENT	◀	2x2 ▶
LOCATION	◀	B1 ▶

DISPLAY NUMBER locations for each arrangement

(2x2)		(3x3)		
A1	A2	A1	A2	A3
B1	B2	B1	B2	B3
		C1	C2	C3

6



Notes


- For PC or RGB input signals, normal multi-display magnification is only available at the VGA resolution
- The multi-display capability is not functional for component signals

SET UP TIMER

The timer can switch the Plasma Display ON or OFF

Before attempting Timer Set, confirm the PRESENT TIME OF DAY and adjust if necessary Then set POWER ON TIME/POWER OFF TIME

Display the SET UP TIMER screen




1





Press to display the SETUP menu screen

2



Press to select SET UP TIMER


Press to display the SET UP TIMER screen



PRESENT TIME OF DAY Set


To set up PRESENT TIME, follow the procedure described below

1




Press to select PRESENT TIME OF DAY

Press to display the PRESENT TIME OF DAY SETTING screen




2



Press to select HOURS ADJUSTMENT/ MINUTES ADJUSTMENT


Press to set up Hours or Minutes
 ▶ button Forward
 ◀ button Back

Press to complete PRESENT TIME OF DAY setup



TIMER Set

1




Press to select
POWER ON TIME/
POWER OFF TIME

Press to display the POWER ON SET
UP / POWER OFF SET UP screen

SET UP TIMER	
PRESENT TIME OF DAY	0:52
POWER ON FUNCTION	OFF
POWER ON TIME	0:00
POWER OFF FUNCTION	OFF
POWER OFF TIME	0:00

2



Press to select HOURS ADJUSTMENT/
MINUTES ADJUSTMENT


Press to adjust each time

Press to complete POWER ON TIME/
POWER OFF TIME, and return to the
SET UP TIMER screen

POWER ON SETUP	
POWER ON FUNCTION	0:52
HOURS ADJUSTMENT	00
MINUTES ADJUSTMENT	52

POWER OFF SETUP	
POWER OFF TIME	0:00
HOURS ADJUSTMENT	00
MINUTES ADJUSTMENT	00

3



Press to select POWER ON FUNCTION/
POWER OFF FUNCTION

Press to select ON

Press to store setting

SET UP TIMER	
PRESENT TIME OF DAY	0:52
POWER ON FUNCTION	ON
POWER ON TIME	0:00
POWER OFF FUNCTION	ON
POWER OFF TIME	0:00

4





Press twice to exit from SETUP


Note
Timer function will not work unless "PRESENT TIME OF DAY ADJUSTMENT" is set

SCREENSAVER (For preventing after-images)


Do not display a still picture, especially in 4:3 mode, for any length of time
If the display must remain on, a SCREENSAVER should be used


1  Press to display the SETUP menu screen

2  Press to select the SCREENSAVER
Press to select the SCREENSAVER screen





NEGATIVE / SCROLL selection


3  Press to select the FUNCTION
Press to select the desired function
NEGATIVE ↔ WHITE BAR SCROLL
NEGATIVE Negative image will be displayed on the screen
WHITE BAR SCROLL The white bar will scroll from left to right




MODE selection

4  Press to select the MODE
Press to select each mode items



- OFF
- ↕
- INTERVAL Operates when SHOW DURATION and SAVER DURATION are set up and those times arrive
- ↕
- TIME OF DAY Operates when START TIME and FINISH TIME are set up and those times arrive
- ↕
- ON Operates when the  (ACTION) is pressed

To stop the SCREENSAVER under ON, press the  button.




If the MODE is at ON, the menu screen will disappear and the SCREENSAVER will be activated

After selecting TIME OF DAY or INTERVAL, the relevant SET UP TIME will become available for selection and the OPERATING TIME may be set






Setup of SCREENSAVER Time

5



Press to select START TIME/ FINISH TIME (When TIME OF DAY is selected)
 Press to select SHOW DURATION/ SAVER DURATION (When INTERVAL is selected)
 Press to select each time adjustment screen



START TIME

START TIME 0:00

HOURS ADJUSTMENT ◀ 00 ▶

MINUTES ADJUSTMENT ◀ 00 ▶

FINISH TIME

FINISH TIME 0:00

HOURS ADJUSTMENT ◀ 00 ▶

MINUTES ADJUSTMENT ◀ 00 ▶

PERIODIC TIME

SHOW DURATION 0:00

HOURS ADJUSTMENT ◀ 00 ▶

MINUTES ADJUSTMENT ◀ 00 ▶


OPERATING TIME

SAVER DURATION 0:00

HOURS ADJUSTMENT ◀ 00 ▶

MINUTES ADJUSTMENT ◀ 00 ▶

6





Press to select HOURS ADJUSTMENT/ MINUTES ADJUSTMENT
 Press to set up HOURS or MINUTES
 ▶ button Forward
 ◀ button Back
 Press to store settings

Note

Timer function will not work unless "PRESENT TIME OF DAY ADJUSTMENT" is set

SIDE BAR ADJUST

Do not display a picture in 4 3 mode for an extended period, as this can cause an after-image to remain on the side bars either side of the display field
 To prevent the appearance of such an after-image, illuminate the side bars



1 To display the SCREENSAVER screen
 (Refer to page 34, operation guide steps 1 and 2)

2

Press to select the
SIDE BAR ADJUST

Press to select
DARK, MID, BRIGHT

OFF ↔ DARK ↔ MID ↔ BRIGHT ←

SCREENSAVER	
FUNCTION	◀ WHITE BAR SCROLL ▶
MODE	◀ ON ▶
START TIME	0:00
FINISH TIME	0:00
SIDE BAR ADJUST	◀ MID ▶

3

Press to exit from SCREENSAVER

Notes

- Setting the side bar to bright mode for an extended period may result in occurrence of after-images
- The side bar may flash (alternate black/white) depending on the picture being shown on the screen. In such an occurrence, use the Cinema mode


SET UP for Input Signals

COMPONENT/RGB IN SELECT

Select to match the signals from the source connected to the COMPONENT/RGB input terminals

Y, P_B, P_R signals ⇒ "COMPONENT"

R, G, B, HD, VD signals ⇒ "RGB"




1




Press to display the SET UP menu screen

2



Press to select the "COMPONENT/RGB IN SELECT"

Press to select the desired mode




COMPONENT ↔ RGB



Press to exit from adjust mode

3D Y/C FILTER – For NTSC Video images

Select "SIGNAL" from the "SET UP" menu during VIDEO input signal mode ("SIGNAL [VIDEO]" menu is displayed)





Press to select the "3D Y/C FILTER (NTSC)"


Press to set ON/OFF



Press to exit from adjust mode



↓ Press  (ACTION) button




Note.

When on, this setting only affects NTSC input signals


COLOR SYSTEM / Panasonic AUTO

Select SIGNAL from the "SET UP" menu during VIDEO (S VIDEO) input signal mode ("SIGNAL [VIDEO]" menu is displayed)



Press to select the "COLOR SYSTEM" or "Panasonic AUTO"


Press to select each functions



↓ Press (ACTION) button


If the picture image becomes unstable

With the system set on Auto, under conditions of low level or noisy input signals the image may in rare cases become unstable. Should this occur, set the system to match the format of the input signal.






Mode	Function
Color system	Set the color system to match the input signal. If set to "AUTO", the color system is determined automatically. <div style="text-align: center; border: 1px solid black; padding: 5px;"> → AUTO ↔ PAL ↔ SECAM ↔ M NTSC ↔ NTSC ← </div>
Panasonic AUTO (4 3)	Set to "NORMAL" to view 4 3 images in an unchanged format when Panasonic AUTO is selected. If you would like to view 4 3 images in "Just" format, set to "JUST".

Select SIGNAL from the "SET UP" menu during RGB or PC input signal mode



The following operation methods are the same for both the SIGNAL [RGB] and SIGNAL [PC]




SYNC

Setting RGB sync signal

Confirm that the input is set to RGB INPUT (this setting is valid only for RGB INPUT)

- H&V The H and V sync signals are input from the HD/VD connector
- ON G Uses a synchronized signal on the Video G signal, which is input from the G connector
- ON VIDEO Compatible with the scart plug (Europe)
The composite video signal input from the VIDEO input terminal is used by dividing the sync signals



Setting PC sync signal

Confirm that the input is set to PC INPUT (this setting is valid only for PC INPUT)

- H&V The H and V sync signals are input from the HD/VD connector
- ON G Uses a synchronized signal on the Video G signal, which is input from the G connector

PULL IN RANGE


Sets the width for different frequencies.

(This setting is the same for both SIGNAL [RGB] and SIGNAL [PC])

CLAMP POSITION

Adjusts the clamp position.

The following operation methods are the same for "SIGNAL" menu during COMPONENT, RGB and PC input signal mode
Normally, these adjustments are set to appropriate levels and, therefore, do not need to be altered




H-FREQ (kHz)/V-FREQ (Hz)

Displays the H (Horizontal)/V (Vertical) frequencies.

This display is valid only for RGB input and PC input











Display range

- Horizontal 15.5 - 110 kHz
- Vertical 48 - 120 Hz




Troubleshooting

Before you call for service, determine the symptoms and make a few simple checks as shown below


Symptoms		Checks
Picture	Sound	
 Interface	 Noisy Sound	Electrical Appliances Cars/Motorcycles Fluorescent light
 Normal Picture	 No Sound	Volume (Check whether the mute function has been activated on the remote control)
 No Picture	 No Sound	Not plugged into AC outlet Not switched on PICTURE and BRIGHTNESS/Volume setting (Check by pushing the power switch or stand-by button on the remote control)
 No Picture	 Normal Sound	If a signal with a non-applicable color system format, or frequency is input, only the input terminal indication is displayed
 No Color	 Normal Sound	Color controls set at minimum level Color system (see page 28, 29)

Plasma Display panel

Symptoms	Check
Some parts of the screen do not light up	The plasma display panel is manufactured using an extremely high level of precision technology, however, sometimes some parts of the screen may be missing picture elements or have luminous spots. This is not a malfunction.
 After-images appear	Do not allow a still picture to be displayed for an extended period, as this can cause a permanent after-image to remain on the Plasma Display. Examples of still pictures include logos, video games, computer images, teletext and images displayed in 4:3 mode. Note: The permanent after-image on the Plasma Display resulting from fixed image use is not an operating defect and as such is not covered by the Warranty. This product is not designed to display fixed images for extended periods of time.
Whirring sounds can be heard from the display unit	The display unit is fitted with a cooling fan to dissipate heat generated during normal use. The whirring sound is caused by rotation of the fan and is not a malfunction.

Specifications

		TH-37PWD4
Power Source	120 V AC, 50/60 Hz	
Power Consumption		
Maximum	325 W	
Stand-by condition	1.2 W	
Power off condition	0.9 W	
Plasma Display panel	Drive method AC type 37-inch, 16.9 aspect ratio	
Contrast Ratio	3000:1	
Brightness Capability	(Panel only) 650 cd / m ² (As a set) 330 cd / m ²	
Screen size	818 mm (W) × 461 mm (H) × 939 mm (diagonal) No. of pixels 408,960 (852 (W) × 480 (H)) [2,556 × 480 dots]	
Operating condition		
Temperature	34 °F - 104 °F (0 °C - 40 °C)	
Humidity	20 % - 80 %	
Applicable signals		
Color System	NTSC, PAL, PAL60, SECAM, Modified NTSC	
Scanning format	525i (480i), 625i (576i), 525p (480p), 625p (576p), 750p (720p), 1125/60i, 50i, 24p, 24SF (1080/60i, 50i, 24p, 24SF) SMPTE 274M	
PC signals	VGA display VGA SVGA, XGA, SXGA, UXGA (compressed) Horizontal scanning frequency 15.5 - 110 kHz Vertical scanning frequency 48 - 120 Hz	
Connection terminals		
AV	Video IN (RCA) S VIDEO IN (MINI DIN 4PIN) AUDIO IN (RCA PIN JACK × 2)	1.0 Vp-p (75-ohm) Y 1 Vp-p (75-ohm), C 0.286 Vp-p (75-ohm) 0.5 Vrms (high impedance)
COMPONENT/RGB	Y/G (RCA) P _B /B (RCA) P _R /R (RCA) HD (RCA) VD (RCA) AUDIO IN (RCA PIN JACK × 2)	1.0 Vp-p/composite (75-ohm) 0.7 Vp-p/non-composite (75-ohm) 0.7 Vp-p (75-ohm) 0.7 Vp-p (75-ohm) 1.0 - 5.0 Vp-p (high impedance) 1.0 - 5.0 Vp-p (high impedance) 0.5 Vrms (high impedance)
PC	(HIGH-DENSITY D-SUB 15PIN) AUDIO IN (M3.5 JACK)	R, G, B/0.7 Vp-p (75-ohm) HD, VD/1.0 - 5.0 Vp-p (high impedance) 0.5 Vrms (high impedance)
SERIAL	EXTERNAL CONTROL TERMINAL (D-SUB9PIN)	RS-232C COMPATIBLE
SPEAKERS (6 Ω)	16W [8 W + 8 W] (10 % THD) For TY-SP37P4W-K only	

TH-37PWD4	
Accessories Supplied	
Remote Control Transmitter	EUR646525
Batteries	2 x AA Size
Ferrite core	2 x J0KF0000001B
Fixing bands	2 x TMME187
Optional Supplied	
Speakers	TY-SP37P4W-K
Pedestal	TY-ST42PT3-K
Wall stand	TY-ST42PW1
Wall-hanging bracket(vertical)	TY-WK37PV3
Ceiling unit	TY-CE42PS1
Terminal Cover	TY-UPS200
Dimensions (W x H x D)	<p>36 2" (920 mm) x 21 7" (550 mm) x 3 5" (89 mm)</p>  <p>The drawing shows three views of the rectangular unit. The front view is a rectangle with a width dimension of 36 2" (920 mm) and a height dimension of 21 7" (550 mm). The side view shows the depth of the unit as 3 5" (89 mm).</p>
Mass (Weight)	<p>approx 55 1 lbs (main unit only)</p> <p>approx 64 4 lbs (with speakers)</p>

Note

Design and specifications are subject to change without notice. Weight and dimensions shown are approximate.

Customer' Record

The model number and serial number of this product can be found on its back cover. You should note this serial number in the space provided below and retain this book, plus your purchase receipt, as a permanent record of your purchase to aid in identification in the event of theft or loss, and for Warranty Service purposes.

Model Number TH-37PWD4

Serial Number _____

Panasonic Broadcast & Digital Systems Company

Division of Matsushita Electric Corporation of America

Executive Office

3330 Cahuenga Blvd W , Los Angeles, CA 90068 (323) 436-3500

EASTERN ZONE One Panasonic Way 4E-7 Secaucus, NJ 07094 (201) 348-7621

Mid-Atlantic/New England One Panasonic Way 4E-7 Secaucus, NJ 07094 (201) 348-7621

Southeast Region 1225 Northbrook Parkway, Ste 1-160 Swanee GA 30024 (770)338-6835

Central Region 1707 N Randall Road E1-C-1, Elgin, IL 60123 (847)468-5200

WESTERN ZONE 3330 Cahuenga Blvd W , Los Angeles, CA 90068 (323) 436-3500

Dallas Region 6226 Abington Way, Houston, TX 77008 (713) 802-2726

No CA/Northwest Region 5870 Stone Ridge, #3, Pleasanton, CA (925) 416-5108

Government Marketing Department 52 West Gude Drive, Rockville, MD 20850 (301) 738-3840