


OPERATOR'S MANUAL



Model 390 Shown

Front Tine Tillers Models 340 Thru 390

IMPORTANT: Read safety rules and instructions carefully before operating equipment.

Warning: This unit is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator. In the State of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on federal lands. A spark arrester for the muffler is available through your nearest engine authorized service dealer or contact the service department, P.O. Box 368022 Cleveland, Ohio 44136-9722.

MTD PRODUCTS INC. P.O. BOX 368022 CLEVELAND, OHIO 44136-9722

PRINTED IN U.S.A.

FORM NO. 770-10132A
(9/99)

TABLE OF CONTENTS

Content	Page
Important Safe Operation Practices.....	3, 4
Assembling Your Tiller.....	5
Know Your Tiller.....	7
Operating Your Tiller.....	8
Making Adjustments	12
Maintaining Your Tiller	13
Off-Season Storage	14
Troubleshooting	15
Parts List.....	16

FINDING MODEL NUMBER

This Operator's Manual is an important part of your new tiller. It will help you assemble, prepare and maintain the unit for best performance. Please read and understand what it says.



Before you start assembling your new equipment, please locate the model plate on the equipment and copy the information from it in the space provided below. The information on the model plate is very important if you need help from our Customer Support Department or an authorized dealer.

- You can locate the model number by standing in the operating position behind the unit and looking down at the frame on the right side. A sample model plate is explained below. For future reference, please copy the model number and the serial number of the equipment in the space below.

_____	_____
(Model Number)	(Serial Number)
MTD PRODUCTS INC	
P.O. BOX 368022	
CLEVELAND, OHIO 44136	

Copy the model number here: _____

Copy the serial number here: _____

CALLING CUSTOMER SUPPORT

If you have difficulty assembling this product or have any questions regarding the controls, operation or maintenance of this unit, please call the Customer Support Department.



Call **1- (330) 220-4MTD** (4683) or **1- (800)-800-7310** to reach a Customer Support representative. Please have your unit's model number and serial number ready when you call. See previous section to locate this information. You will be asked to enter the serial number in order to process your call .

SECTION 1: IMPORTANT SAFE OPERATION PRACTICES



This Symbol Points Out Important Safety Instructions Which, If Not Followed, Could Endanger The Personal Safety And/or Property Of Yourself And Others. Read And Follow All Instructions In This Manual Before Attempting To Operate Your Tiller. Failure To Comply With These Instructions May Result In Personal Injury. When You See This Symbol— Heed Its Warning.

DANGER: Your tiller was built to be operated according to the rules for safe operation in this manual. As with any type of power equipment, carelessness or error on the part of the operator can result in serious injury. This tiller is capable of amputating hands and feet. Failure to observe the following safety instructions could result in serious injury or death.

WARNING: The Engine Exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

GENERAL OPERATION

- Read this operator's manual carefully in its entirety before attempting to assemble this machine. Read, understand, and follow all instructions on the machine and in the manual(s) before operation. Be completely familiar with the controls and the proper use of the machine before operating it. Keep this manual in a safe place for future and regular reference and for ordering replacement parts.
- Your tiller is a powerful tool, not a plaything. Therefore, exercise extreme caution at all times. Your unit has been designed to perform one job: to till soil. Do not use it for any other purpose.
- Never allow children under age 14 to operate the unit. Children 14 years and older should only operate the unit under close parental supervision. Only responsible individuals who are familiar with these rules of safe operation should be allowed to use your unit.
- Do not operate tiller while under the influence of alcohol or drugs.
- Keep the area of operation clear of all persons, particularly small children and pets. Stop the engine when they are in the vicinity of your tiller.
- Wear sturdy, rough-soled work shoes and close fitting slacks and shirt. Shirt and slacks that cover the arms and legs and steel-toed shoes are recommended. Do not wear loose fitting clothes or jewelry and secure hair so it is above shoulder length. They can be caught in moving parts. Never operate a unit in bare feet, sandals or sneakers.
- Operate tiller only in daylight or good artificial light.
- Do not start tiller unless the shift lever (if provided) is in the neutral (N) position.
- Do not allow anyone to stand or walk in front of tiller when starting or running engine.
- Do not place feet or hands on or near the tines when starting the engine or while the engine is running.
- Never attempt to make depth bar, tine width, cable, handle, or wheel adjustments while the engine is running.
- Do not leave the tiller unattended with the engine running.
- Before attempting to remove rocks, bricks and other objects from tines, stop the engine and be sure the tines have stopped completely. Disconnect the spark plug wire and move it away from the spark plug.
- If your machine should start making an unusual noise or vibration, immediately stop the engine and allow the machine to come to a complete stop. Disconnect the spark plug wire and move it away from the spark plug. Take the following steps:
 - Inspect for damage.
 - Repair or replace any damaged parts.
 - Check for any loose parts and tighten to assure continued safe operation.
- Muffler and engine become hot and can cause a burn. Do not touch.
- Keep all shields, guards and safety devices in place and operating properly.
- Use caution when tilling near fences, buildings and underground utilities. Rotating tines can cause damage or injury.
- Do not operate engine if air cleaner or cover over carburetor air intake is removed, except for adjustment. Removal of such parts could create a fire hazard.
- Only use accessories approved for this machine by the manufacturer. Read, understand, and follow all instructions provided with the approved accessory.
- If situations occur which are not covered by this manual, use care and good judgment. Contact your dealer for assistance.

CHILDREN

- Tragic accidents can occur if the operator is not alert to the presence of small children. Children are often attracted to the tilling activity. Never assume that children will remain where you last saw them.
- Keep children out of the work area and under the watchful eye of a responsible adult other than the operator.
- Be alert and turn the unit off if a child enters the area.
- Never allow children under the age of 14 to operate the tiller.


SERVICE

- Use extreme care in handling gasoline and other fuels. They are extremely flammable and the vapors are explosive.
- Store fuel and oil in approved containers, away from heat and open flame, and out of the reach of children. Check and add fuel before starting the engine. Never remove gas cap or add fuel while the engine is running. Allow engine to cool at least two minutes before refueling.
- Replace gasoline cap securely and wipe off any spilled gasoline before starting the engine as it may cause a fire or explosion.
- Extinguish all cigarettes, cigars, pipes and other sources of ignition.
- Never refuel unit indoors because flammable vapors will accumulate in the area.

- Never store the machine or fuel container inside where there is an open flame or spark such as a gas hot water heater, space heater, clothes dryer or furnace.
- Never run your machine in an enclosed area as the exhaust from the engine contains carbon monoxide, which is a odorless, tasteless and deadly poisonous gas.
- To reduce fire hazard, keep engine and muffler free of leaves, grass, and other debris build-up. Clean up fuel and oil spillage. Allow unit to cool at least 5 minutes before storing.
- Before cleaning, repairing, or inspecting, make certain the tines and all moving parts have stopped. Disconnect the spark plug wire and keep wire away from spark plug to prevent accidental starting. Do not use flammable solutions to clean air filter.
- We do not recommend the use of pressure washers to clean your unit. They may cause damage to electric components, spindles, pulleys, bearings or the engine. The use of pressure washers will result in shortened life and reduce serviceability.
- Keep all nuts, bolts, and screws tight to be sure the equipment is in safe working condition.
- Never tamper with safety devices. Check their proper operation regularly.
- Do not alter or tamper with the engine's governor setting. The governor controls the maximum safe operating speed of the engine. Overspeeding the engine is dangerous and will cause damage to the engine and to other moving parts of the machine.



WARNING — YOUR RESPONSIBILITY: Restrict the use of this power machine to persons who read, understand and follow the warnings and instructions in this manual and on the machine.



SECTION 2: ASSEMBLING YOUR TILLER

NOTE: This operator's guide covers three different model tillers. Models 340 thru 345 have forward tine drive only. Model 390 has both forward and reverse tine drive. Follow only the instructions which pertain to your model tiller. See the model plate on your tiller for the correct model number.

IMPORTANT: This unit is shipped WITHOUT GASOLINE or OIL. After assembly, see separate engine manual for proper fuel and engine oil recommendations.

NOTE: Left and right is determined from the operator's position, standing behind the tiller.

Removing Unit From Carton

- Remove staples, break glue on top flaps, or cut tape at carton end and peel along top flap to open carton.
- Remove all loose parts included with unit (i.e., operator's manual, etc.)
- Cut corners and lay carton down flat.
- Remove packing material.
- Roll or slide unit out of carton. Check carton thoroughly for loose parts.
- Extend control cable(s) to the rear of the tiller and lay them on the floor. Be careful not to bend or kink control cable(s).

Setting Up Your Tiller

Attaching The Tailpiece And Depth Stake

Remove the two self-tapping screws on the frame. Slide the tailpiece into the frame, with the lower hole in the tailpiece toward the front. Secure with screws just removed. See Figure 1.




Figure 1

Attaching The Handle Assembly

NOTE: When attaching the handle assembly, steps three (3) and four (4) will vary depending on the engine you have. Follow instructions which pertain to your model tiller.

- Remove the hex bolt and cupped washer from the top right side of the frame halves. Hold the cable guide bracket on the left side of the frame as it will fall when the bolt is removed. See Figure 2.
- Insert the handle assembly between the two frame halves. Insert the hex bolt just removed through the frame halves, handle assembly, and into the cable guide bracket (notch in cable guide bracket goes over the flange on the frame). Tighten securely.
- Loosen the hand knob which secures the handle brace to the handle assembly. (**Standard Briggs & Stratton & Tecumseh Engines**).
- Remove handle crank from the handle brace. (**Briggs & Stratton Intek Only**).
- Remove the hex lock nut from on top of the engine, just to the left of the spark plug. Attach the curved end of the handle brace to the top of the engine, using hex lock nut just removed. Tighten securely. See Figure 3. (**Standard Briggs & Stratton & Tecumseh engines**).
- Insert handle crank through the welded bracket on the handle and into the threaded u-nut on the end of the handle brace. (**Briggs & Stratton Intek only**).
- Select one of the three handle height positions (three notches in welded bracket), and tighten the hand knob to secure the handle in desired position. Make certain carriage bolt is seated **securely** into one of the three positions provided.







Figure 2



Briggs and Stratton Intek Engine



Briggs and Stratton Standard Engine



Tecumseh Engine

Figure 3

Attaching Clutch Control Cable(s)


Forward Cable

Attach the end of the forward cable to the bracket underneath the handle assembly as follows. (On model 390, the forward clutch cable is the cable which is

attached closer to the rear of the tiller).

- Loosen the hex nut on the threaded rod near the end of the cable, and move it up the rod as far as it will go.
- Unthread the rod from the rest of the cable. Hook the "Z" end of the rod into the bracket underneath the handle assembly from the right hand side. See Figure 4.
- Thread the rod back into the cable until the cable is straight. Do not tighten it enough to put any tension on the spring.
- Thread the hex nut down against the end of cable. Use a pair of pliers and a wrench to lock the nut against the rod.

NOTE: Do not overtighten control cable. Too much tension may cause it to break when engaged.




Models 340 thru 345

Figure 4

Reverse Cable (Model 390 Only)

The reverse clutch cable is the cable which is attached closer to the front of the tiller. Attach the end of the reverse cable to the reverse tine drive clutch lever, above the handle assembly, in the same manner as you attached the forward cable. See Figure 5.



Model 390

Figure 5

Final Clutch Adjustment

To check the clutch cable adjustment, proceed as follows.

- Disconnect the spark plug wire and move it away from the spark plug to prevent accidental starting.
- Engage and release the tine engagement handle, then the reverse tine engagement lever (model 390 only). If an excessive noise is heard when releasing either the tine drive clutch handle or lever, the cable may be too loose. Adjust either the forward or reverse clutch cable by loosening the hex nut, threading the rod into the cable one or two turns, then retightening the nut.





Figure 6

- With tine engagement handle in neutral (released) as shown in Figure 6, pull the starter rope several times. **The tines should not turn.** If they turn forward, loosen the hex nut on the forward cable (underneath the handle assembly). If they turn toward the rear (model 390 only), loosen the hex nut on the reverse cable (above the handle assembly). Unthread the rod from the cable 2 or 3 turns. Retighten the hex nut, and check again for correct adjustment. See Figure 6.

SECTION 3: KNOW YOUR TILLER



Model 390 Shown

Figure 7

Read this operator's manual and safety rules before operating your tiller. Compare the illustrations in Figure 7 with your tiller to familiarize yourself with the location of various controls and adjustments. Save this manual for future reference.

Throttle Control

The throttle control lever is located on the engine. It controls the engine speed and stops the engine. See Figure 8.

Choke Lever (Model 340/390)

The choke lever is located above the throttle control. It is used to enrich the fuel mixture when starting a cold engine. See Figure 8.

Primer Button (Model 345)

The primer button is located behind the air cleaner. It is used to enrich the fuel mixture in the carburetor when starting a cold engine. See Figure 8

Forward Tine Engagement Handle

The forward tine engagement handle is located beneath the tiller handle. See Figure 7. Squeezing the handle up against the tiller handle engages the tines. Release the handle to stop the tines.

Reverse Tine Drive Clutch Lever

(Model 390 Only)

The reverse tine drive clutch lever is located on top of the handle panel. See Figure 7. Pull the lever to the rear to move the tines in reverse. Release the lever to stop the reverse tine drive.


NOTE: Never engage both the forward and reverse tine drives at the same time. Engaging both forward and reverse tine drives at the same time could damage the belt drives and cause the engine to stall.

Depth Stake


The depth stake controls the tilling depth. Refer to OPERATING YOUR TILLER in Section 4.

Tines And End Caps


The tilling tines and end caps (are used to cultivate, furrow, and prepare your garden for seeding. The end caps (Model 390 only) are used to avoid tilled soil from overflowing onto unwanted areas.



Briggs and Stratton Intek



Briggs and Stratton Standard



Tecumseh

Figure 8

SECTION 4: OPERATING YOUR TILLER

Gas and Oil Fill up

Service the engine with gasoline and oil as instructed in the separate engine manual packed with your tiller.

Read instructions carefully.

NOTE: Your tiller is shipped without oil; however, a small amount of oil may be present from the factory.

Starting Engine



WARNING: Be sure no one is standing in front of the tiller while the engine is running or being started.

Models 340, 342, & 390

- Attach spark plug wire to spark plug. Make certain the metal loop on the end of the spark plug wire (inside the boot) is fastened securely over the metal tip on the spark plug.
- Make certain all controls are in the neutral position (released). See Figure 6.
- Place the throttle control lever in FAST position. See Figure 8.
- Move choke lever to CHOKE position. (A warm engine requires little or no choke.)
- Grasp starter handle and pull rope out slowly until engine reaches start of compression cycle (rope will pull slightly harder at this point). Let the rope rewind slowly.

- Pull rope with a rapid, continuous, full arm stroke. Keep a firm grip on starter handle. Let rope rewind slowly. Do not let starter handle snap back against starter.
- Repeat preceding instructions 5 and 6 until engine starts. When engine starts, move choke lever on engine halfway between CHOKE and RUN.
- Move throttle control to IDLE position for a few minutes warm-up. Move choke lever to RUN position as engine warms up.

Models 343 & 345

- Attach spark plug wire to spark plug. Make certain the metal loop on the end of the spark plug wire (inside the boot) is fastened securely over the metal tip on the spark plug.
- Make certain all controls are in the neutral position (released). See Figure 6.
- Place the engine speed control in the START position.
- Push primer two (2) or three (3) times. See Figure 10. Wait about two (2) seconds between each push.

NOTE: Primer may be needed to restart a warm engine after a short shutdown.

- Stand at side of tiller. Grasp the starter handle and pull out slowly, until it pulls slightly harder. Let rope rewind slowly.
- Pull rope with a rapid full arm stroke. Do not allow handle to snap back. Allow it to rewind slowly while keeping a firm hold on the starter handle.

NOTE: If engine fails to start after three (3) pulls, push primer two (2) times and pull starter rope again.

- Repeat steps 4 and 5 until engine starts. Refer to engine manual for additional engine information.

NOTE: After starting engine and prior to using the tiller, be certain to check the clutch adjustment as described in "Checking the Clutch Adjustment" section of the Assembly Instructions.

To Stop Engine

- Move throttle control lever to STOP or OFF position.
- Disconnect spark plug wire from spark plug and ground against the engine to prevent accidental starting while equipment is unattended.

Using Your Tiller

Your tiller is a precision built machine designed for seed bed preparation, cultivating, furrowing and mulching. It is engineered to minimize the hardest work in the vegetable or flower garden, to till the soil for planting and cultivating, and to perform many other useful labor saving tasks in the garden.

With the proper amount of care and maintenance, this machine will provide the owner with many years of service.

Wheel Position

The tiller is shipped with the wheels adjusted such that the unit sits level. While tilling, as the tines enter the ground and the front of the tiller lowers, the wheels must be raised to level the unit, which is essential for proper engine operation. This adjustment is made by removing the clevis pin and hairpin clip from wheel yoke, raising the wheels to the desired height, and replacing the clevis pin and hairpin clip. See Figure 9.




Figure 9

Removing End Caps (Model 390 only)

The end cap, which are used to avoid tilled soil from overflowing onto unwanted areas, are removable from the outer axle. Remove the hairpin clip and clevis pin that is securing each end cap and slide end cap off the axle. See Figure 10.




Figure 10

Controlling Speed And Tilling Depth

- Wheel Yoke Adjustment:** Place wheel yoke so that the wheels are forward (nearest point between wheels and tines) for shallow tilling, cultivating and transport. The forward speed will increase. Turn yoke around (farthest point between wheels and tines) for deep tilling. Forward speed will decrease. See Figure 11.




Figure 11

Depth Stake Adjustment:

The depth stake acts as a brake for the tiller and controls the depth and speed at which the machine will operate. Remove the clevis pin and hairpin clip to raise or lower depth stake. See Figure 9.

By increasing the depth of the depth stake, the forward speed of the machine is reduced, and the working depth is increased. See Figure 12. When the depth stake is raised, the working depth of the machine is reduced and the forward speed is increased. The working depth of the machine may be predetermined by setting the depth stake and wheels so that the wheels are about four inches from the ground when the tines and depth stake are resting on the ground. This setting will permit a working depth of about four inches. When presetting the working depth, the handles should be adjusted so the hand grips are a little above waist height because the tiller will be lower when the tines and depth stake penetrate the ground.




Figure 12

When tilling, leave approximately 8 inches of untilled soil between the first and second tilling paths, then make the third path between the first and second as shown in Figure 13. In some soils, the desired depth is obtained the first time over the garden. In other soils, the desired depth is obtained by going over the garden two or three times. In the latter case, the depth stake should be lowered before each succeeding pass over the garden. Passes should be made across the length and width of the garden alternately. Rocks which are turned up should be removed from the garden area.




Figure 13

Handle Pressure: Further control of tilling depth and travel speed can be obtained by variation of pressure on the handles. A downward pressure on the handles will reduce the working depth and increase the forward speed. An upward pressure on the handles will increase the working depth and reduce the forward speed. The type of soil and working conditions will determine the actual setting of the depth stake and the handle pressure required.

Throttle Control: The throttle control lever adjusts the engine speed and stops the engine. With the throttle control lever pushed completely forward, the carburetor is in START position. Pulling the throttle control back slightly adjusts the engine speed to FAST. Pulling the throttle back further reduces the engine speed to SLOW. Pull the throttle completely back to stop the engine.

Use maximum engine speed for deep tilling. Move the throttle control to SLOW when transporting the tiller.

Transporting The Tiller

To transport the tiller to or from the garden, pivot the depth stake forward, out of the way. See Figure 12. With the throttle control in SLOW position, the unit will walk freely on top of the lawn. If the operator does not allow the tiller to move freely, the unit will start to till the surface.

Cultivating

For cultivating, a two to three inch depth is desirable. Setting the wheels and depth stake so that the wheels are about two inches above the ground while the tiller is resting on the tines and depth stake will allow the machine to work at cultivating depth. The throttle should be set to control forward movement to a slow walking speed. With the outer tines installed, the working width of the machine is 22 or 24 inches. For cultivation, this may be reduced to 13 inches by removing the outer tines. Refer to Tine Width Adjustment in Adjustment section. When laying out plant rows, be sure to allow enough width to permit cultivation between the rows. In growing corn or similar crops, check-row planting will permit cross cultivation and practically eliminate hand hoeing.




Figure 14

The tiller has many uses other than tilling and cultivating a garden. One of these is the preparation of lawn area for seeding. The tiller will prepare a deep seed bed which will be free of hard untilled spots, allowing a better stand of grass to grow. The tiller is very useful for loosening hard soil for excavation with a shovel. No tedious hand pickwork will be necessary. Your tiller may be used for mixing compost in the pile, or for mixing it with the soil in your garden. This should be done after the soil has been broken to the full working depth. The compost should be worked in to a depth of six to seven inches. This may be done by working the length of the garden, and then by making separate passes across its width. The addition of decayed organic matter will substantially increase the fertility of your garden. For proper decaying action, fertilizer should be applied and worked in with the mulch materials. Breaking up leaves and straw and mixing it with several inches of soil causes the soil to hold moisture longer and allows proper aeration of the plant root system. This also retards the growth of weeds.

The U.S. Department of Agriculture and various state and local agencies offer published booklets and expert advice on all phases of gardening. They should be consulted regarding soil information, planting dates, and the most satisfactory varieties of crop for your particular area.

SECTION 5: MAKING ADJUSTMENTS



WARNING: Disconnect the spark plug wire and ground against the engine before performing any adjustments, repairs, or maintenance.

Tine Width Adjustment

The tilling width of the unit is 22 inches. See Figure 15. Tilling width can be increased to 24 inches by removing the clevis pins and hairpin clips, sliding the outer tines out one inch, and securing in this position with the clevis pins and hairpin clips. See Figure 15. For cultivation, reduce the tine width to 13 inches by removing the outer tines completely.

Wheel Adjustments

To adjust the wheel yoke and wheel position, refer to OPERATING YOUR TILLER in Section 4.

Depth Stake Adjustment

To adjust the depth stake, refer to OPERATING YOUR TILLER in Section 4.

Clutch Control Adjustments

To adjust the clutch controls, refer to the Final Adjustment section of assembly instructions.

Carburetor Adjustment



WARNING: If any adjustments are made to the engine while the engine is running (e.g. carburetor), disengage all clutches and tines. Keep clear of all moving parts. Be careful of heated surfaces and muffler.

Minor carburetor adjustment may be required to compensate for differences in fuel, temperature, altitude or load. If adjustments are needed, refer to the engine manual packed with the tiller.

NOTE: A dirty air cleaner will cause engine to run rough. Be certain air cleaner is clean and attached to the carburetor before adjusting carburetor. Do not make unnecessary adjustments. Factory settings are satisfactory for most applications and conditions.




Figure 15

SECTION 6: MAINTAINING YOUR TILLER

Lubrication



WARNING: Always stop engine and disconnect spark plug wire before cleaning, lubricating or doing any kind of work on tiller.

Pivot Points-Remove the belt cover and lubricate all moving parts and pivot points at least once a season using SAE 30 engine oil.

Chain Drive-The chain case is pre-lubricated and sealed at the factory.



WARNING: Disconnect spark plug wire and ground it against the engine before performing any repairs or maintenance.

Trouble Shooting

Refer to the trouble shooting chart for more information.

Engine

Refer to the separate engine manual for all engine maintenance instructions.

Maintain **engine oil** as instructed in the separate engine manual packed with your unit. Read and follow instructions carefully.

Service **air cleaner** every 25 hours under normal conditions. Clean every few hours under extremely dusty conditions. Poor engine performance and flooding usually indicates that the air cleaner should be serviced. To service the air cleaner, refer to the separate engine manual packed with your unit.

IMPORTANT: Never run your engine without air cleaner completely assembled.

The **spark plug** should be cleaned and the gap reset once a season. Spark plug replacement is recommended at the start of each tilling season; check engine manual for correct plug type and gap specifications.

Clean the engine regularly with a cloth or brush.

Keep the cooling system (blower housing area) clean to permit proper air circulation which is essential to engine performance and life. Be certain to remove all dirt and combustible debris from muffler area.

Cleaning The Tine Area

Clean the underside of the tine shield after each use. The dirt washes off the tines easier if washed off immediately instead of after it dries.

We do not recommend the use of pressure washers to clean your unit. It may cause damage to electric

components, spindles, pulleys, bearings or the engine. The use of pressure washers will result in shortened life and reduce serviceability.

Belt Removal And Replacement

Your tiller has been engineered with belts made of special material (Kevlar Tensile). They should not be replaced with an off-the-shelf belt. If belt replacement is required, order belt or belts by part number from your nearest authorized service dealer.

Forward Drive Belt - Part No. 754-0428

Reverse Drive Belt (390 Only) - Part No. 754-0429

Reverse Drive Belt (Model 390 Only)

- Disconnect and ground the spark plug wire against the engine. Remove the belt cover from the left side of the tiller as follows.
- Remove two self-tapping screws and flat washers from the front of belt cover. See Figure 16.
- Remove the hex stop nut and flat washer from the side of the belt cover. Remove belt cover.





Figure 16

- Lift the belt off the transmission pulley.
- Remove the hex nut which secures the reverse idler pulley to the idler bracket. Slide idler pulley out and remove the belt. See Figure 17.



Model 390 Shown

Figure 17




Figure 18

- Reassemble the new belt, following instructions in reverse order. Make certain the reverse drive belt is assembled with the wide side of the belt against the transmission and engine pulleys.

Be certain to adjust the clutch control as instructed in the final clutch adjustment section of assembly instructions.

Forward Drive Belt See Figure 17

- **Models 340 thru 345:** Remove the belt cover by following steps 1 thru 3 of the previous section.
- **Model 390:** Remove the reverse drive belt as instructed in the previous section.
- Remove the belt keeper from the idler pulley by removing the idler pulley nut.
- Lift belt off the idler pulley and transmission pulley. See Figure 18.
- Using a 9/16" wrench, remove bolt from engine pulley.
- Push reverse idler pulley bracket forward, and remove engine pulley and belt. See Figure 18.
- Reassemble the new belt, following instructions in reverse order. Make certain the forward drive belt is assembled with the wide side of the belt away from the transmission and engine pulleys. Be certain to adjust the clutch control as instructed in the final clutch adjustment section of assembly instructions.

SECTION 7: OFF-SEASON STORAGE

If the tiller is to be inoperative for a period longer than 30 days, the following precautions are recommended.

- Working outdoors, drain all fuel from the fuel tank. Run the engine until it stops from lack of fuel.



WARNING: Do not drain fuel while smoking, or if near an open fire.

- Drain all the oil from the crankcase (this should be done after the engine has been operated and is still warm) and refill the crankcase with fresh oil.
- Protect the inside of the engine for storage as instructed in the separate engine manual packed with your tiller.
- Clean the engine and the entire tiller thoroughly.

- Wipe tines with oiled rag to prevent rust.
- We do not recommend the use of pressure washers to clean your unit. It may cause damage to electric components, spindles, pulleys, bearings or the engine. The use of pressure washers will result in shortened life and reduce serviceability.


NOTE: When storing any type of power equipment in an unventilated or metal storage shed, care should be taken to rustproof the equipment. Using a light oil or silicone, coat the equipment, especially any springs, bearings and cables.

- Store in a clean, dry area. Do not store next to corrosive materials, such as fertilizer.

SECTION 8: TROUBLE SHOOTING GUIDE

Trouble	Possible Cause(s)	Corrective Action
Engine fails to start	Fuel tank empty, or stale fuel. Throttle control lever not in correct starting position (if so equipped). Blocked fuel line. Dirty air cleaner. Choke not in ON position. Spark plug wire disconnected. Faulty spark plug. Engine flooded.	Fill tank with clean, fresh gasoline. Fuel will not last over thirty days unless a fuel stabilizer is used. Move throttle lever to start position. Clean fuel line. Refer to the engine manual packed with your unit. Move switch to ON position. Connect wire to spark plug. Clean, adjust gap or replace. Refer to the engine manual packed with your unit.
Engine runs erratic	Unit running on CHOKE. Spark plug wire loose. Blocked fuel line or stale fuel. Vent in gas cap plugged. Water or dirt in fuel system. Dirty air cleaner. Carburetor out of adjustment.	Move choke lever to OFF position. Connect and tighten spark plug wire. Clean fuel line; fill tank with clean, fresh gasoline. Fuel will not last over thirty days unless a fuel stabilizer is used. Clear vent. Drain fuel tank. Refill with fresh fuel. Refer to the engine manual packed with your unit. Refer to the engine manual packed with your unit.
Engine over-heats	Engine oil level low. Dirty air cleaner. Air flow restricted. Carburetor not adjusted properly.	Fill crankcase with proper oil. Refer to the engine manual packed with your unit. Refer to the engine manual packed with your unit. Adjust carburetor as instructed in separate engine manual.
Tines do not engage	Foreign object lodged in tines. Tine clevis pin(s) missing. Pulley and idler not in correct adjustment. Control cable not adjusted properly. Belt worn and/or stretched.	Dislodge foreign object. Replace tine clevis pin(s). Take unit to authorized service dealer. Adjust control cable (see assembly instructions). Replace belt.

Model 340 Thru 345




Model 340 Thru 345

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	712-0442	Acorn Lock Nut 1/4-20	27.	736-0119	L-Wash. 5/16" I.D.
2.	736-3020	Flat Washer .271" I.D. x .630" O.D.	28.	710-3008	Hex Bolt 5/16-18 Gr. 5
3.	731-1599	Handle Cover	29.	786-0129	Cable Guide Bracket
4.	712-0287	Hex Nut 1/4-20 Gr.2	30.	710-0604	Hex Wash Screw 5/16-18 x .62"
5.	720-0274	Grip-Handle	31.	710-0602	Hex Wash. Hd. TT-Tap Scr.
6.	686-0083	Clutch Handle Assembly	32.	738-0934	Shdl. Bolt 5/16-18
7.	720-0269	Grip-Clutch	33.	786-0138	Frame (R.H.)
8.	710-0641	Hex Bolt 1/4-20 x 2.25" Lg. Gr.5	34.	786-0139	Frame (L.H.)
9.	731-1645A	Clutch Handle Holder	35.	736-0171	Lock Washer 7/16
10.	736-0140	Flat Washer .385" I.D. x .62" O.D.	36.	712-0240	Jam Nut 7/16-20 Gr. 2
11.	649-0039	Handle Assembly Comp. †	37.	710-0176	Hex Bolt 5/16-18 x 2.75" Lg.
	649-0022A	Handle Assembly Comp. ††	38.	712-0429	Hex Nyloc Nut 5/16-18 Thd.
12.	647-0042	Adjustment Crank †	39.	711-0415	Clevis Pin
13.	726-0211	U Nut 5/16-18 †	40.	714-0149B	Cotter Pin
14.	749-1101	Handle Brace †	41.	686-0081A	Wheel Hanger Brkt. Assy
15.	736-0921	Lock Washer 1/2 †	42.	734-1566	Wheel Ass'y 8" x 1.75"
16.	710-3194	Hex Bolt 1/2-20 Gr. †	43.	738-0929	Shoulder Screw .496 x 1.445
17.	786-0005	Depth Bar	44.	750-0890	Spacer
18.	714-0149B	Cotter Pin	45.	712-3004A	Hex Flange L-Nut 5/16-18 Thd. (Gr. 5)††
19.	712-3004A	Hex Flange L-Nut 5/16-18	46.	720-0195	Hand Knob ††
20.	786-0003	Tail Piece Bracket (L.H.)	47.	749-0915A	Engine Tube Brace (Std. B&S)
21.	786-0004	Tail Piece Bracket (R.H.)		749-1082	Engine Tube Brace (Tec.)
22.	711-0415	Clevis Pin	48.	710-1236	Carr. Bolt 5/16-18 x 1 ††
23.	710-0805	Hex Bolt 5/16-18 x 1.5" Lg.	49.	736-0242	Bell. Wash. .34" I.D. ††
24.	710-0189	Hex Bolt 5/16-18 x 3" Lg.	50.	786-0159	Engine Brkt. (Std B&S)
25.	736-0242	Wash. Bell. .340" I.D. x .872" O.D.			
26.	711-1036	Spec. Hex Nut			

† Briggs & Stratton Intek Engine

†† Standard Briggs & Stratton and Tec. Engine


Model 340 Thru 345



Model 340 Thru 345

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	712-0392	Hex L-Stop nut 1/4-28	22.	746-0918	Forward Clutch Cable
2.	736-3020	Flat Wash. .266" I.D. x .625" O.D.	23.	786-0053	Tine Shield Bracket
3.	710-0599	Hex Washer Screw 1/4-20 x .5"	24.	736-0171	L-Wash. 7/16" I.D.
4.	711-0920	Belt Cover Bolt	25.	712-0240	Hex Nut 7/16-20 Thd.
5.	712-3004A	Hex Flange Top L-Nut 5/16-18	26.	710-0502A	Hex Washer Screw 3/8-16 x 1.25"
6.	710-0723	Hex Hd. Scr. 3/8-16 x 1.25" Lg.	27.	786-0145A	Engine Plate
7.	756-0313	FI-Idler 2.12" O.D.	28.	786-0039B	Bracket Cover
8.	786-0149	Idler Belt Keeper	29.	736-0119	Lock Washer 5/16
9.	786-0144	Idler Bracket	30.	710-0107	Hex Bolt 5/16-24 x .5"
10.	712-0266	Hex Cent. Jam Nut 3/8-16 Thd.	31.	756-0971	Inner Engine Pulley Half
11.	786-0056	Belt Cover	32.	756-0972	Outer Engine Pulley Half
12.	710-0599	Hex Washer Screw 1/4-20 x .5"	33.	736-0258	Flat Washer .385 ID x 1.0 OD
13.	786-0035A	Tiner Shield	34.	736-0169	Lock Washer 3/8
14.	710-3008	Hex Hd. Cap Scr. 5/16-18 x .75" Lg	35.	710-0191	Hex Bolt 3/8-24 x 1.25"
15.	712-3004A	Hex Flange Top L-Nut 5/16-18	36.	736-0112	Bell-Wash. .525" I.D. x 1.5" O.D.
16.	686-0091	Chain Case Assembly Complete	37.	712-3029	Hex Jam Nut 1/2-20 Thd. (Gr. 5)
18.	714-0149B	Internal Cotter Pin	38.	736-0312	Retainer Washer Bearing
19.	711-0415	Clevis Pin	39.	756-0585	FI-Pulley 6" Dia.
20.	642-0005	Outer Tine Assembly L.H.	40.	754-0428	V-Belt (Forward)
	642-0004	Outer Tine Assembly R.H.	41.	750-0892	Spacer .64" Dia. x 2.4" Lg.
21.	642-0003	Inner Tine Assembly L.H.	42.	748-0350	Pulley Mounting Adapter
	642-0002	Inner Tine Assembly R.H.			

Model 390




Model 390

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	712-0442	Acorn Lock Nut 1/4-20	30	736-0242	Wash. Bell. .340" I.D. x .872" O.D.
2	736-3020	Flat Washer .271" I.D. x .630" O.D.	31	711-1036	Spec. Hex Nut
3	720-0270A	Reverse Handle Grip	32	736-0119	L-Wash. 5/16" I.D.
4	731-1600	Handle Cover w/o throttle	33	710-3008	Hex Bolt 5/16-18 Gr. 5
5	710-0779A	Truss Mach. Scr. #10 x 1/2" Lg.	34	786-0129	Cable Guide Bracket
6	720-0274	Grip-Handle	35	710-0604	Hex Wash. Hd. TT-Tap Scr. 5/16-18 x .62" Lg.
7	712-0287	Hex Nut 1/4-20 Gr.2	36	710-0602	Hex Wash. Hd. TT-Tap Scr.
8	726-0135	Cap Speed Nut	37	738-0934	Shdl. Bolt 5/16-18
9	686-0083	Clutch Handle Assembly	38	786-0138	Frame (R.H.)
10	720-0269	Grip-Clutch	39	786-0139	Frame (L.H.)
11	710-0641	Hex Bolt 1/4-20 x 2.25" Lg. Gr.5	40	736-0171	Lock Washer 7/16
12	731-1645A	Clutch Handle Holder	41	712-0240	Jam Nut 7/16-20 Gr. 2
13	736-0140	Flat Washer .385" I.D. x .62" O.D.	42	710-0176	Hex Bolt 5/16-18 x 2.75" Lg.
14	686-0014A	Reverse Handle Ass'y	43	712-0429	Hex Nyloc Nut 5/16-18 Thd.
15	736-0264	Flat Washer .344" I.D. x .62" O.D.	44	711-0415	Clevis Pin
16	649-0039	Handle Assembly Comp. †	45	714-0149B	Cotter Pin
	649-0022A	Handle Assembly Comp. ††	46	686-0081A	Wheel Hanger Brkt. Assy
17	647-0042	Adjustment Crank †	47	734-1566	Wheel Ass'y 8" x 1.75"
18	726-0211	U Nut 5/16-18 †	48	738-0929	Shoulder Screw .496 I.D. x 1.445 O.D.
19	749-1101	Handle Brace †	49	750-0890	Spacer
20	736-0921	Lock Washer 1/2 †	50	710-1236	Carr. Bolt 5/16-18 x 1 ††
21	710-3194	Hex Bolt 1/2-20 Gr. 5 †	51	749-0915A	Engine Tube Brace (Std. B&S)
22	786-0005	Depth Bar		749-1082	Engine Tube Brace (Tec.)
23	714-0149B	Cotter Pin	52	712-3004A	Hex Flange L-Nut 5/16-18 Thd. Gr.5 (Gr. 5) ††
24	712-3004A	Hex Flange L-Nut 5/16-18 Thd. Gr.5	53	786-0159	Engine Brkt. (Std. B&S)
25	786-0003	Tail Piece Bracket (L.H.)	54	736-0242	Bell. Wash. .34" I.D. ††
26	786-0004	Tail Piece Bracket (R.H.)	55	720-0195	Hand Knob††
27	711-0415	Clevis Pin			
28	710-0805	Hex Bolt 5/16-18 x 1.5" Lg.			
29	710-0189	Hex Bolt 5/16-18 x 3" Lg.			

† Briggs & Stratton Intek Engine

†† Standard Briggs & Stratton and Tec. Engine

Model 390



Model 390

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	712-0392	Hex L-Stop nut 1/4-28	25	750-0892	Spacer .64" Dia. x 2.4" Lg.
2	736-3020	Flat Wash. .266" I.D. x .625" O.D.	26	748-0350	Pulley Mounting Adapter
3	710-0599	Hex Washer TT-Tap Scr. 1/4-20 x .5"	27	736-0112	Bell-Wash. .525" I.D. x 1.5" O.D.
4	711-0920	Belt Cover Bolt	28	712-3029	Hex Jam Nut 1/2-20 Thd. (Gr. 5)
5	712-3004A	Hex Flange Top L-Nut 5/16-18 (Gr.5)	29	732-0697	Return Spring
6	710-0723	Hex Hd. Scr. 3/8-16 x 1.25" Lg. (Gr.5)	30	786-0040B	Reverse Bracket
7	756-0313	FI-Idler 2.12" O.D.	31	736-0119	Lock Washer 5/16
8	786-0149	Idler Belt Keeper	32	710-0107	Hex Bolt 5/16-24 x .5"
9	786-0144	Idler Bracket	33	756-0971	Inner Engine Pulley Half
10	712-0266	Hex Cent. Jam Nut 3/8-16 Thd.	34	756-0600	Outer Engine Pulley Half
11	786-0057	Belt Cover	35	736-0452	Bell Washer .396" I.D. x 1/14" O.D.
12	710-0599	Hex Wash. TT-Tap Scr. 1/4-20 x .5" Lg.	36	710-0191	Hex Bolt 3/8-24 x 1.25"
13	786-0043A	Tiner Shield	38	686-0013	Reverse Arn Assembly
14	710-3008	Hex Hd. Cap Scr. 5/16-18 x .75" Lg	39	712-0266	Hex Cent. Jam Nut 3/8-16 Thd.
15	712-3004A	Hex Flange Top L-Nut 5/16-18 (Gr. 5)	40	710-0723	Hex Cap Bolt 3/8-16 x 1.25" Lg. (Gr. 5)
16	686-0091	Chain Case Assembly Complete	41	756-0313	FI-Idler 2.12" O.D.
17	686-0106	Tine Disc Ends	42	786-0041	Keeper Plate
18	714-0149B	Internal Cotter Pin	43	710-0502A	Hex L-Wash. TT-Tap 3/8-16 x 1.25"
19	711-0415	Clevis Pin	44	786-0145A	Engine Plate
20	642-0023	Outer Tine Assembly L.H.	45	786-0053	Tine Shield Bracket
	642-0024	Outer Tine Assembly R.H.	46	736-0171	L-Wash. 7/16" I.D.
21	642-0003	Inner Tine Assembly L.H.	47	712-0240	Hex Nut 7/16-20 Thd.
	642-0002	Inner Tine Assembly R.H.	48	754-0428	V-Belt (Forward)
22	746-0918	Forward Clutch Cable	49	754-0429	V-Belt (Reverse)
23	746-0953	Reverse Clutch Cable	50	738-0102	Shld. Bolt
24	756-0585	FI-Pulley 6" Dia.	51	738-0930	Shld. Bolt

MANUFACTURER'S LIMITED WARRANTY

The limited warranty set forth below is given by MTD PRODUCTS INC ("MTD") with respect to new merchandise purchased and used in the United States, its possessions and territories.

MTD warrants this product against defects in material and workmanship for a period of two (2) years commencing on the date of original purchase and will, at its option, repair or replace, free of charge, any part found to be defective in material or workmanship. This limited warranty shall only apply if this product has been operated and maintained in accordance with the Operator's Manual furnished with the product, and has not been subject to misuse, abuse, commercial use, neglect, accident, improper maintenance, alteration, vandalism, theft, fire, water or damage because of other peril or natural disaster. Damage resulting from the installation or use of any accessory or attachment not approved by MTD Products Inc. for use with the product(s) covered by this manual will void your warranty as to any resulting damages.

Normal wear parts or components thereof are subject to separate terms as follows: All normal wear part or component failures will be covered on the product for a period of 90 days regardless of cause. After 90 days, but within the two year period, normal wear part failures will be covered ONLY IF caused by defects in material or workmanship of OTHER component parts. Normal wear parts and components include, but are not limited to, belts, blades, blade adapters, grass bags, rider deck wheels, seats, snow thrower skid shoes, shave plates and tires. Batteries are covered by a 90-day limited replacement warranty.

HOW TO OBTAIN SERVICE: Warranty service is available, WITH PROOF OF PURCHASE THROUGH YOUR LOCAL AUTHORIZED SERVICE DEALER. To locate the dealer in your area, please check for a listing in the Yellow Pages or contact the Customer Service Department of MTD PRODUCTS INC by calling 1-800-800-7310 or writing to P.O. Box 368022, Cleveland, Ohio 44136-9722.

This limited warranty does not provide coverage in the following cases:

- a. The engine or component parts thereof. These items carry a separate manufacturer's warranty. Please refer to the applicable manufacturer's warranty on these items.
- b. Log splitter pumps, valves and cylinders have a separate one year warranty.

- c. Routine maintenance items such as lubricants, filters, blade sharpening and tune-ups, or adjustments such as brake adjustments, clutch adjustments or deck adjustments; and normal deterioration of the exterior finish due to use or exposure.
- d. MTD does not extend any warranty for products sold or exported outside of the United States of America, its possessions and territories, except those sold through MTD's authorized channels of export distribution.

No implied warranty, including any implied warranty of merchantability or fitness for a particular purpose, applies after the applicable period of express written warranty above as to the parts as identified. No other express warranty or guaranty, whether written or oral, except as mentioned above, given by any person or entity, including a dealer or retailer, with respect to any product shall bind MTD. During the period of the Warranty, the exclusive remedy is repair or replacement of the product as set forth above. (Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.)

The provisions as set forth in this Warranty provide the sole and exclusive remedy arising from the sales. MTD shall not be liable for incidental or consequential loss or damages including, without limitation, expenses incurred for substitute or replacement lawn care services, for transportation or for related expenses, or for rental expenses to temporarily replace a warranted product. (Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you.)

In no event shall recovery of any kind be greater than the amount of the purchase price of the product sold. Alteration of the safety features of the product shall void this Warranty. You assume the risk and liability for loss, damage, or injury to you and your property and/or to others and their property arising out of the use or misuse or inability to use the product.

This limited warranty shall not extend to anyone other than the original purchaser, original lessee or the person for whom it was purchased as a gift.

How State Law Relates to this Warranty: This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state.