

Memory Camcorder user manual

SC-MX10
SC-MX10P
SC-MX10A
SC-MX10AU



imagine the possibilities

Thank you for purchasing this Samsung product.
To receive more complete service, please
register your product at

www.samsung.com/global/register

SAMSUNG

key features of your memory camcorder

MPEG4 Encoding

Records enhanced quality video in MPEG4 ASP(Advanced Simple Profile) format (720 x 480) onto memory cards at 30 fps for high resolution, life-like images.

High-capacity embedded Flash Memory (4GB) (SC-MX10A/MX10AU only)

The camcorder has built-in high capacity flash memory that allows you to record movie images.

Various Recording Media


In addition to the built-in flash memory (SC-MX10A/MX10AU only), this memory camcorder supports various storage media such as SDHC (Secure Digital High Capacity) and MMCplus. (128 MB ~ 8 GB)

2.7" Wide (16:9) LCD Display (112K Pixels)

You can see the bigger picture by enlarging the 4:3 aspect ratio into 16:9 wide screen with the 2.7" wide (16:9) LCD screen. The 112K pixel LCD monitor rotates up to 270 degrees for flexible viewing angles and provides sharp, detailed image for monitoring and playback.

Capture Visions Farther Than The Eye Can See (34x Optical/1200x Digital Zoom)



Samsung's powerful optical zoom lenses bring the world closer without sacrificing image quality. In addition, Digital Zoom interpolation means that extreme digital zooming is clearer, with less distortion than previous types of digital zooms.



Various Recording Features

The memory camcorder supports Anti-Shake(EIS) (Electronic Image Stabilizer), Digital Effects and a wide range of other functions that you can select according to the scene you are recording.

➡ pages 48 ~ 56



Enjoying Various Playback Features

Unlike tape operation, playback is simple and easy in this memory camcorder since no time is needed for rewinding or fast forward operations. Various functions are available for enjoying many different types of playback.


➡ page 58 ~ 61

Play back on your PC

USB 2.0 enables the smooth transfer of movies you've recorded to a computer.

With the bundled software, you can easily transfer and play back movies on your PC.

➡ page 75




PC Cam for multi-entertaining

Connect the memory camcorder to a PC via a USB 2.0 cable and instantly communicate via live video with business associates, friends and family wherever you are.





Versatile 16:9 Wide & 4:3 Display option

You can easily select the display option when recording or playback (16:9 Wide/4:3). Samsung's 16:9 Wide display option lets you monitor more widely on the 2.7" wide LCD screen when recording or playback with your memory camcorder. Ensure your entire movies are recorded in 4:3 aspect ratio regardless of the display option (16:9 Wide/4:3 aspect ratio).





safety warnings

What the icons and signs in this user manual mean :

 WARNING	Means that death or serious personal injury is a risk.
 CAUTION	Means that there is a potential risk for personal injury or material damage.
 CAUTION	To reduce the risk of fire, explosion, electric shock, or personal injury when using your memory camcorder, follow these basic safety precautions:
	Means hints or referential pages that may be helpful when operating the memory camcorder.

These warning signs are here to prevent injury to you and others.
Please follow them explicitly. After reading this section, keep it in a safe place for future reference.

important safety instructions

	CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN	
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.		



This symbol indicates that dangerous voltage consisting a risk of electric shock is present within this unit.



This symbol indicates that there are important operating and maintenance instructions in the literature accompanying this unit.

Warning

To Reduce The Risk Of Fire Or Electric Shock, Do Not Expose This Apparatus To Rain Or Moisture.

Caution

Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

To disconnect the apparatus from the mains, the plug must be pulled out from the mains socket, therefore the mains plug shall be readily operable.

iv_English

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachment/accessories specified by the manufacturer.

12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as powersupply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
16. VENTILATION:
Slots and openings in the cabinet are provided for ventilation to ensure reliable operation of the CAMCORDER and to protect it from overheating. These openings must not be blocked or covered. Never place your CAMCORDER on a bed, sofa, rug, or other similar surface: on or near a radiator or heat register. This CAMCORDER should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

important safety instructions

17. POWER SOURCES:

The CAMCORDER should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supply at your home, consult your appliance dealer or local power company. A CAMCORDER is intended to be operated from battery power, or other sources, refer to the operating instructions.

18. GROUNDING OR POLARIZATION:

This CAMCORDER may be equipped with either a polarized 2-wire AC line plug (a plug having one blade wider than the other) or a 3-wire grounding type plug, a plug having a third (grounding) pin. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug still fails to fit, contact your electrician to replace your outlet. Do not defeat the safety purpose of the polarized plug.

19. POWER-CORD PROTECTION:

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords or plugs, convenient receptacles, and the point where they exit from the unit.


20. OUTDOOR ANTENNA GROUNDING:

CAMCORDER, be sure the antenna or cable system is grounded to provide some protection against voltage surges and built-up static charges, Section 810 of the National Electrical Code, ANSI/NFPA No.

vi_English

70-1984, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire and supporting structure, grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding to conductors, location of antenna-discharge unit, connection to grounding electrodes and requirements for the grounding electrode.

See figure below.



21. LIGHTNING:

For added protection of this CAMCORDER during a lightning storm or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the CAMCORDER due to lightning and powerline surges.

22. POWER LINES:

An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

23. OVERLOADING:

Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

24. OBJECTS AND LIQUIDS:

Never push objects of any kind into this CAMCORDER through openings as they may touch dangerous voltage points or short out a part that could result in a fire or electric shock. Never spill liquids of any kind onto the CAMCORDER. Should spillage occur, unplug unit and have it checked by a technician before use.

25. SERVICING:

Do not attempt to service this CAMCORDER yourself. Opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

26. DAMAGE REQUIRING SERVICE:

Unplug this CAMCORDER from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- a. When the power-supply cord or plug is damaged.
- b. If any liquid has been spilled onto, or objects have fallen into the CAMCORDER.
- c. If the CAMCORDER has been exposed to rain or water.
- d. If the CAMCORDER does not operate normally by following the operating instructions, adjust only those controls that are covered by the operating instructions. Improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the CAMCORDER to its normal operation.
- e. If the CAMCORDER has been dropped or the cabinet has been damaged.
- f. When the CAMCORDER exhibits a distinct change in performance, this indicates a need for service.

27. REPLACEMENT PARTS:

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer and having the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

28. SAFETY CHECK:

Upon completion of any service or repairs to this CAMCORDER, ask the service technician to perform safety checks to determine that the CAMCORDER is in safe operating order.

important safety instructions

29. To prevent damage which may result in fire or shock hazard, do not expose this appliance to rain or moisture.
30. If this power supply is used at 240V ac, a suitable plug adapter should be used.
31. This product is covered by one or more of the following U.S. patents:
5,060,220 5,457,669 5,561,649 5,705,762 5,987,417
6,043,912 6,222,983 6,272,096 6,377,524 6,377,531
6,385,587 6,389,570 6,408,408 6,466,532 6,473,736
6,477,501 6,480,829 6,556,520 6,556,521 6,556,522
6,578,163 6,594,208 6,631,110 6,658,588 6,674,697
6,674,957 6,687,455 6,697,307 6,707,985 6,721,243
6,721,493 6,728,474 6,741,535 6,744,713 6,744,972
6,765,853 6,765,853 6,771,890 6,771,891 6,775,465
6,778,755 6,788,629 6,788,630 6,795,637 6,810,201
6,862,256 6,868,054 6,894,963 6,937,552

USER INSTALLER CAUTION:

Your authority to operate this FCC certified equipment could be voided if you make changes or modifications not expressly approved by this party responsible for compliance to part 15 FCC rules.

NOTE:

- (Hg) LAMP(S) INSIDE THIS PRODUCT CONTAIN MERCURY AND MUST BE RECYCLED OR DISPOSED OF ACCORDING TO LOCAL, STATE OR FEDERAL LAWS. For details see lamprecycle.org, eiae.org, or call 1-800-Samsung (7267864)

CALIFORNIA USA ONLY

This Perchlorate warning applies only to primary CR (Manganese Dioxide) Lithium coin cells in the product sold or distributed ONLY in California USA
" Perchlorate Material - special handling may apply,
See www.dtsc.ca.gov/hazardouswaste/perchlorate."

viii_English

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help and for additional suggestions.

The user may find the following booklet prepared by the Federal Communications Commission helpful: "How to Identify and Resolve Radio-TV Interference Problems."

This Booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402, Stock No. 004-000-00345-4.

FCC Warning

The user is cautioned that changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

This device complies with Part 15 of FCC Rules.

Operation is subject to the following two conditions;

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

precautions

Warning!

This camcorder should always be connected to an AC outlet with a protective grounding connection.

Caution

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type.

If this power supply is used at 240V ac, a suitable plug adaptor should be used.

**CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
LUOKAN 1 LASER LAITE
KLASS 1 LASER APPARAT
PRODUCTO LASER CLASE 1**

important information on use

BEFORE USING THIS CAMCORDER

- **This memory camcorder records video in MPEG4 format and at Standard Resolution (SD-VIDEO).**
- **Please note that this memory camcorder is not compatible with other digital video formats.**
- **Before recording important video, make a trial recording.**
 - Play back your trial recording to make sure the video and audio have been recorded properly.
 - Samsung cannot compensate for any damage caused when a recording cannot be played back because of a defect in the memory camcorder or memory card. Samsung cannot be responsible for your recorded video and audio.
 - Recorded contents may be lost due to a mistake when handling this memory camcorder or memory card, etc. Samsung shall not be responsible for compensation for damages due to the loss of recorded contents.
- **Make a backup of important recorded data**
 - Protect your important recorded data by copying the files to a PC. We also recommend you copy it from your PC to other recording media for storage. Refer to the software installation and USB connection guide.
- **Copyright: Please note this memory camcorder is intended for individual use only.**
 - Data recorded on the card in this memory camcorder using other digital/analog media or devices is protected by the copyright act and cannot be used without permission of the owner of copyright, except for personal enjoyment. Even if you record an event such as a show, performance or exhibition for personal enjoyment, it is strongly recommended that you obtain permission beforehand.

precautions on use

IMPORTANT NOTE

- **Handle the liquid crystal display (LCD) with care:**
 - The LCD is a very delicate display device: Do not press its surface with excessive force, hit it or prick it with a sharp object.
 - If you push the LCD surface, unevenness in display may occur. If unevenness does not disappear, turn the camcorder off, wait for a few moments, and then turn it on again.
 - Do not place the camcorder with the open LCD screen down.
 - Close the LCD monitor when not using the camcorder
- **Liquid crystal display:**
 - The LCD screen is a product of high precision technology. Out of the total pixels (approx. 112,000 pixels of an LCD monitor), 0.01% or less pixels may be out (black dots) or may remain lit as colored dots (red, blue, and green). This shows the limitations of the current technology, and does not indicate a fault that will interfere with recording.
 - The LCD screen will be slightly dimmer than usual when the camcorder is at low temperature, as in cold areas, or right after the power is turned on. Normal brightness will be restored when the temperature inside the camcorder rises. This has no effect on the images in the storage media, so there is no cause for concern.
- **Hold the memory camcorder correctly:**
 - Do not hold the memory camcorder by the LCD monitor when lifting it: the LCD monitor could detach and the memory camcorder may fall.
- **Do not subject the memory camcorder to impact:**
 - This memory camcorder is a precision machine. Take great care that you do not strike it against a hard object or let it fall.
 - Do not use the memory camcorder on a tripod in a place where it is subject to severe vibrations or impact.
- **No sand or dust!**
 - Fine sand or dust entering the memory camcorder or AC power adaptor could cause malfunctions or defects.

precautions on use

- **No water or oil!**
 - Water or oil entering the memory camcorder or AC power adaptor could cause electric shock, malfunctions or defects.
- **Heat on surface of product:**
 - The surface of the memory camcorder will be slightly warm when in use, but this does not indicate a fault.
- **Be careful of unusual ambient temperature:**
 - Using the memory camcorder in a place where the temperature is over 140°F (40°C) or lower than 32°F (0°C) may result in abnormal recording/playback.
 - Do not leave the memory camcorder on a beach or in a closed vehicle where the temperature is very high for a long time: This could cause a malfunction.
- **Do not point directly at the sun:**
 - If direct sunlight strikes the lens, the memory camcorder could malfunction or a fire could occur.
 - Do not leave the memory camcorder with the LCD screen exposed to direct sunlight: This could cause a malfunction.
- **Do not use the memory camcorder near TV or radio:**
 - This could cause noise to appear on the TV screen or in radio broadcasts.
- **Do not use the memory camcorder near strong radio waves or magnetism:**
 - If the memory camcorder is used near strong radio waves or magnetism, such as near a radio transmitter or electric appliances, noise could enter video and audio that are being recorded. During playback of normally recorded video and audio, noise may also be present in picture and sound. At worst the memory camcorder could malfunction.

- **Do not expose the memory camcorder to soot or steam:**
 - Thick soot or steam could damage the memory camcorder case or cause a malfunction.
- **Do not use the memory camcorder near corrosive gas:**
 - If the memory camcorder is used in a place where there is dense exhaust gas generated by gasoline or diesel engines, or corrosive gas such as hydrogen sulfide, the external or internal terminals could corrode, disabling normal operation, or the battery connection terminals could corrode, so that power will not turn on.
- **Do not use the memory camcorder near an ultrasonic humidifier:**
 - Calcium and other chemicals dissolved in water could scatter in the air, and white particles could adhere to the optical head of the memory camcorder, which could cause it to operate abnormally.
- **Do not clean the memory camcorder body with benzene or thinner:**
 - The coating of exterior could peel off or the case surface could deteriorate.
 - When using a chemical cleaning cloth, follow the instructions.
- **Keep the memory card out of reach of children to prevent swallowing.**

precautions on use

ABOUT THIS USER MANUAL

- **This User Manual covers models SC-MX10, SC-MX10P, SC-MX10A and SC-MX10AU.**
The SC-MX10A and SC-MX10AU have a built-in 4 GB flash memory, but also use Memory cards. The SC-MX10, SC-MX10P does not have built-in flash memory and uses Memory cards exclusively.
Although some features of SC-MX10, SC-MX10P, SC-MX10A and SC-MX10AU are different, they operate in the same way.
- Illustrations of model SC-MX10A are used in this user manual.
- The displays in this user manual may not be exactly the same as those you see on the LCD screen.
- Designs and specifications of storage media and other accessories are subject to change without any notice.

NOTES REGARDING A TRADEMARK

- All the trade names and registered trademarks mentioned in this manual or other documentation provided with your Samsung product are trademarks or registered trademarks of their respective holders.
- Windows® is registered trademark or trademark of Microsoft Corporation, registered in the United States and other countries.
- Macintosh is trademark of Apple Computer, Inc.
- All the other product names mentioned here in may be the trademark or registered trademarks of their respective companies.
- Furthermore, "TM" and "R" are not mentioned in each case in this manual.

contents


GETTING TO KNOW YOUR MEMORY CAMCORDER

06

- 06 Quick Start Guide
- 07 What's included with your memory camcorder
- 08 Front & left view
- 09 Side & bottom view

PREPARATION

10

- 10 Using the accessories
- 12 Connecting a power source
- 20 Button type battery installation
- 21 Basic operation of your memory camcorder
- 22 LCD screen indicators
- 25 Turning the screen indicators on/off ( / **i**CHECK)
- 26 Using the LCD enhancer
- 27 Adjusting the LCD screen
- 27 Using the MENU button
- 28 Using the Control buttons
- 29 Shortcut menu (OK Guide)
- 30 Initial setting : OSD Language & date and time

ABOUT THE STORAGE MEDIA

32

- 32 Selecting the storage media
(SC-MX10A/MX10AU only)
- 33 Inserting / ejecting the memory card
- 34 Selecting the suitable memory card
- 36 Recordable time and capacity

RECORDING

38

- 38 Recording movie images
- 40 Recording with ease for beginners (EASY.Q mode)
- 41 Zooming In and out

PLAYBACK

- 42 Movie Images playback

contents

RECORDING OPTIONS

45

- 45 Changing the menu settings
- 47 Menu items
- 48 Recording menu items
 - 48 Scene Mode (AE)
 - 49 White Balance
 - 50 Exposure
 - 51 Anti-shake(EIS)
 - 52 Digital Effects
 - 53 Focus
 - 54 Back Light
 - 55 16:9 Wide
 - 55 Quality
 - 56 Resolution
 - 56 Digital Zoom

PLAY BACK OPTIONS

57

- 57 Setting the play option
- 58 Deleting movie images
- 59 Protecting movie images
- 60 Copying movie images (SC-MX10A/MX10AU only)
- 61 16:9 Wide
- 61 File Information


SETTING OPTIONS

62

- 62 Changing the menu settings in "Settings"
- 63 Setting menu items
 - 64 Date/Time set
 - 64 Date format
 - 64 Time format
 - 64 Date/Time
 - 65 LCD Brightness
 - 65 LCD color
 - 65 Auto Power Off
 - 66 Beep Sound

	66	File no.
	66	Memory type (SC-MX10A/MX10AU only)
	67	Memory info
	67	Format
	68	Default set
	68	Version
	68	Language
	68	USB Connect
	68	Demo
USB INTERFACE	69	System requirements
	71	Installing the software
	73	Connecting the USB cable
	74	Viewing the contents of storage media
	75	Transferring files from the memory camcorder to your PC
	76	Using the PC Cam function
CONNECTION	77	Viewing on TV Screen
	78	Recording (Dubbing) Images on Other Video Devices
MAINTENANCE & ADDITIONAL INFORMATION	79	Maintenance
	80	Additional information
TROUBLESHOOTING	81	Troubleshooting
SPECIFICATIONS	93	
WARRANTY (SEA USERS ONLY)	94	

quick start guide




- This chapter introduces you to the basic features of your memory camcorder.
- See the reference pages for more information.

Step1

Preparation


- Connecting a power source ➔page 12
- Check out the storage media ➔page 32
- Setting the Date/Time and OSD Language ➔page 30



Step2

Recording


- Recording the movie ➔page 38



Step3

Playing back

- Selecting an image to play back from the thumbnail index views ➔page 42
- Viewing playback from your camcorder on your PC or TV
➔page 73, 77



getting to know your memory camcorder

WHAT'S INCLUDED WITH YOUR MEMORY CAMCORDER

Your new memory camcorder comes with the following accessories. If any of these items is missing from your box, call Samsung's Customer Care Center.

✦ **The exact shape of each item may vary by model.**




Battery pack
(IA-BP85ST)
AD43-00180A




AC power adapter
(AA-E9 type)
AD44-00116A



Multi-AV cable
AD39-00119B



USB cable
AD39-00132A



Software CD
AD46-00093A,
AD46-00097A



User manual
AD68-01307A




Button type battery
(type: CR2025)
AD43-10130H



Lens cover
AD97-13002A



Lens cover strap
AD72-00049A



Quick start guide
AD68-01310A



Pouch
AD69-00932A



SD Card
1109-001375



Cradle*
AD97-13017A




- The contents may vary depending on the sales region.
- Parts and accessories are available at your local Samsung dealer.
- A memory card is not included. See page 34 for memory cards compatible with your memory camcorder.

*: The Cradle is not supplied with your camcorder. To buy this optional accessory, contact your nearest Samsung dealer.

getting to know your memory camcorder

FRONT & LEFT VIEW



1 Lens

2 Internal microphone

3 MENU button

4 OK button

5 Control button (←/→/⏏/⏪/⏩/⏹)

6 Recording start/stop button

7 LCD screen


8 Built-in speaker

9 iCHECK button


10 LCD ENHANCER (Z) button

11 Zoom lever (W/T)

SIDE & BOTTOM VIEW



- 1 MODE indicator (record (📹) / player (▶))
- 2 Multi cable jack (AV/S)
- 3 USB jack (USB)
- 4 DC IN jack (DC IN)
- 5 EASY.Q button
- 6 Charging indicator (CHG)
- 7 POWER switch
- 8 MODE button



- 9 Recording start/stop button
- 10 Grip belt
- 11 Swivel Hand-grip
- 12 Grip belt hook
- 13 Tripod receptacle
- 14 Cradle receptacle
- 15 Memory card /Battery slot cover
- 16 Button type battery slot


preparation

This section provides information on using this memory camcorder : such as how to use the provided accessories, how to charge the battery, how to setup the operation mode and initial setup.

USING THE ACCESSORIES


Attaching a Grip Belt

- Insert your right hand from the bottom of memory camcorder up to the base of your thumb.
 - Put your hand in a position where you can easily operate the **Recording start/stop** button and the **Zoom** lever.
 - Adjust the length of grip belt so that the memory camcorder is stable when you press the **Recording start/stop** button with your thumb.
1. Detach the belt.
 2. Adjust the length of grip belt.
 3. Attach the belt.



Angle Adjustment


- Rotate the swivel hand-grip at the most convenient angle.
- You can rotate it downward upto 150 degrees.



Attaching a Lens Cap


Pass the provided string through the hole in the grip belt attachment part and pass it through the hole in the lens cap.

1. Attach the lens cap string to lens cap.
Shorter side is for the lens cap.
2. Attach the string to the attachment hole of memory camcorder.
Detaching the grip belt makes things easier.
3. Push both sides of cap inward and attach it over the lens.



Using the cradle (optional accessory)

The Cradle is a connection plate which can be used to make the camcorder more stable when charging the battery, or connecting to a TV or a PC.



preparation

CONNECTING A POWER SOURCE

- There are two types of power source that can be connected to your memory camcorder.
- Do not use provided power supply units with other equipment.
 - The battery pack: used for outdoor recording.
 - The AC power adapter : used for indoor recording. ➔page 19

To Charge the Battery Pack

- Be sure to charge the battery pack before you start using your memory camcorder.

Battery Pack installation / ejection


It is recommended you purchase one or more additional battery packs to allow continuous use of your memory camcorder.

Inserting the battery pack

1. Slide and open the battery slot cover as shown in the figure.
2. Insert the battery pack into the battery slot until it softly clicks.
 - Make sure that the SAMSUNG logo is facing up and the camcorder is placed as shown in the figure.
3. Slide and close the battery slot cover

Ejecting the battery pack

1. Slide and open the battery slot cover and push the battery lock.
 - Gently push the battery lock in the direction as shown in the figure to eject the battery out.
2. Pull the ejected battery out in the direction as shown in the figure.
3. Slide and close the battery slot cover.



About battery packs

- The battery pack should be recharged in an environment that is between 32°F (0°C) and 104°F (40°C). However, when it is exposed to cold temperatures (below 32°F (0°C)), its usage time becomes reduced and it may cease to function. If this happens, place the battery pack in your pocket or other warm, protected place for a short time, then reattach it to the memory camcorder.
- The recording time shortens dramatically in a cold environment. The continuous recording times in the operating instructions are measured using a fully charged battery pack at 77 °F (25 °C). As the environmental temperature and conditions vary, the remaining battery time may differ from the approximate continuous recording times given in the instructions.

On handling a battery pack

- To preserve battery power, keep your memory camcorder turned off when you are not operating it.
- For power saving purposes, the memory camcorder automatically turns off after 5 minutes in standby mode. (Only if you set **"Auto Power Off"** from the menu to **"On"** (5 min).)
- Do not touch or let metallic objects come into contact with the terminals.
- Make sure that the battery pack fits firmly into place. Do not drop the battery pack as it may cause damage.
- Be careful to keep the battery pack out of the reach of children. There is danger that a child might swallow it.
- Frequent use of the LCD screen or using the fast forward or rewind buttons wears out the battery pack faster.

preparation

- The recording time is affected by temperature and environmental conditions.
- We recommend only using the original battery pack that is available from your Samsung retailer. When the battery reaches the end of its life, please contact your local dealer. The batteries have to be dealt with as chemical waste.
- Clean the terminals to remove any foreign substances before inserting the battery.
- Do not put the battery pack near any heat source (i.e. fire or a heater).
- Do not disassemble, apply pressure to, or heat the battery pack.
- Do not allow the + and - terminals of the battery pack to be short-circuited.
It may cause leakage, heat generation, induce overheating or fire.
- Do not expose the battery pack to water. The battery pack is not water resistant.
- When fully discharged, a battery pack damages the internal cells.
The battery pack may be prone to leakage when fully discharged.
- Remove the battery from the camcorder when it is not in use. Even when the power is switched off, the battery pack will still discharge if it is left attached to the memory camcorder.
- **When not using the memory camcorder for an extended period:**
It is recommended that you fully charge the battery pack once a year, attach it to memory camcorder and use it up : then remove the battery pack and store it in a cool place again.

About the battery life

- Battery capacity decreases over time and through repeated use. If decreased usage time between charges becomes significant, it is probably time to replace it with a new one.
- Each battery's life is affected by storage, operating and environmental conditions.

Use only Samsung-approved battery packs. Do not use batteries from other manufacturers. Otherwise, there is a danger of overheating, fire or explosion. Samsung is not responsible for problems occurring due to using unapproved batteries.

**Charging, recording and playback times with fully charged battery pack
(with no zoom operation, etc.)**

- For your reference, the approximate time with fully charged battery pack:

Battery type		IA-BP85ST		
Charging time		approx. 2 hr.		
Media	Mode	Super Fine	Fine	Normal
Built-in memory	Continuous recording time	approx. 115min.	approx. 120min.	approx. 125min.
	Playback time	approx. 230min.	approx. 230min.	approx. 230min.
SDHC/ MMCplus	Continuous recording time	approx. 120min.	approx. 125min.	approx. 130min.
	Playback time	approx. 230min.	approx. 230min.	approx. 230min.

- The time is only for reference. Figures show above are measured under Samsung's test environment, and may differ from your actual use.

Continuous Recording (without zoom)

The continuous recording time of memory camcorder in the table shows the available recording time when the memory camcorder is in the recording mode without using any other functions.

In actual recording, the battery pack may discharge 2-3 times faster than this reference since the record start/stop and zoom are being operated, and playback is performed. Assume that the recordable time with a fully charged battery pack is between 1/2 and 1/3 of the time in the table, and prepare type and number of battery packs to allow for the time you are planning to record on the memory camcorder.




Note that the battery pack discharges faster in cold environment.







The charging time will vary depending on the remaining battery level.


preparation

To check the remaining battery charge

- When the camcorder is turned off (battery is installed) press and release the  / **iCHECK** button to display the remaining capacity of the battery capacity.
- When the camcorder is turned on (battery is installed) press and hold the  / **iCHECK** button for more than 2-3 seconds to display the remaining battery capacity. Press the  / **iCHECK** button again or any other button to return to the initial OSD while the battery information is displayed.



-  • When the battery is installed and the AC adapter is connected, if you press  / **iCHECK** button, the remaining battery capacity is displayed.
- When the AC adapter alone is connected, pressing the  / **iCHECK** button will display "**No Battery**" message.










Recording capacity (approx.)

Remaining battery(approx.)

Battery Level Display

The Battery Level Display shows the amount of battery power remaining in the battery pack.

Battery Level Indicator	State	Message
	Fully charged	-
	20~40% used	-
	40~60% used	-
	60~80% used	-
	80~95% used	-
	Exhausted(flickers): The device will soon turn off. Change the Battery Pack as soon as possible.	-
	(flickers): The device will be forced to turn off after 5 seconds.	"Low battery"



preparation

Charging the Battery Pack

The IA-BP85ST battery pack provided with this memory camcorder may be charged a little at purchase time: Charge it fully before using the memory camcorder.




- Use IA-BP85ST battery pack only.
1. Slide the **POWER** switch downward to turn off the power.
 2. Insert the battery pack.
 3. Open the LCD screen and jack cover.
 4. Connect the AC power adaptor to the DC IN jack of your memory camcorder.
 5. Connect the AC power adaptor to a wall socket.
 - The charging indicator will start to blink, showing that the battery pack is charging.
 6. When the battery pack is fully charged, disconnect the AC power adaptor from the memory camcorder.



Even if your camcorder is turned off, AC power (house current) is still supplied to it while connected to the wall outlet via the AC power adaptor.



- Do not use the AC adaptor placed in a narrow space, such as between a wall and furniture.
- Before detaching the power source, make sure that the camcorder's power is turned off. Failure to do so can result in camcorder malfunction.
- Use a nearby wall outlet when using the AC power adaptor. Disconnect the AC power adaptor from the wall outlet immediately if any malfunction occurs while using your camcorder.




Charging indicator

Tips for battery identification

- The color of the LED indicates charging status.
 - If the battery has been fully charged, the charge indicator is green.
 - If you are charging the battery, the color of the charge indicator is orange.
 - The charge indicator flickers if the battery is abnormal.

Color	Charging state
Orange	Charging
Green	Fully Charged




Using memory camcorder with AC power adaptor

It is recommended that you use the AC power adaptor to power the memory camcorder from a household AC outlet when you perform settings on it, play back, or use it indoors.

- Make the same connections as you do when charging the battery pack.

➡page 18



- Be sure to use the provided AC power adaptor to power the memory camcorder. Using other AC power adaptors could cause electric shock or result in fire.
- The AC power adaptor can be used around the world. An AC plug adaptor is required in some foreign countries. If you need one, purchase it from an electronics store.

preparation

BUTTON TYPE BATTERY INSTALLATION

- The button type battery maintains the clock function and preset contents of the memory : even if the battery pack or AC power adapter is removed.
1. Insert the button type battery in the battery slot on the bottom of the memory camcorder.
 2. Position the button type battery with the positive (⊕) terminal face down in the button type battery slot.

Precautions regarding the button type battery

- There is a danger of explosion if button type battery is incorrectly replaced. Replace only with the same or equivalent type.


Battery installation for the internal clock

The button type battery for the memory camcorder lasts about 6 months under normal operation from the time of installation.

When the button type battery becomes weak or dead, the date/time indicator will display "2007/01/01 12:00AM " when you turn the date and time display on.



Keep the button type battery out of reach of children.
Should a battery be swallowed, consult a doctor immediately.



BASIC OPERATION OF YOUR MEMORY CAMCORDER

This section explains the basic techniques of recording movies, and also basic settings on your memory camcorder. Set the appropriate operation mode according to your preference using **POWER** switch and **MODE** button.


Turning memory camcorder on or off

You can turn the power on or off by sliding the **POWER** switch down.

- Slide the **POWER** switch repeatedly to toggle the power on or off.




- Power saving function
 - In the setting at the time of purchase, the power turns off automatically if you leave your camcorder without any performing any operation for approximately 5 minutes, to save the battery power. ➔page 65
 - If warning messages appear on the screen, follow the instructions. ➔page 81




Setting the operating modes

- You can switch the operating mode in the following order each time you press the **MODE** button.
- Movie Record mode (📹) → Movie Play mode (▶) → Movie Record mode (📹)
- Each time the operational mode changes, the respective mode indicator lights up.
 - Movie Record mode (📹): To record movie images.
 - Movie Play mode (▶): To play movie images.



preparation

LCD SCREEN INDICATORS




- The above screen is an example for explanation: The displays in this user manual may not be exactly the same as those you see on the LCD screen.
- The OSD indicators are based on memory capacity of 2GB(MMC plus).
- Functions marked with * won't be kept when the memory camcorder is shut down.
- For enhanced performance, the display indications and the order are subject to change without prior notice.

Movie Record mode


- | | |
|----|---|
| 1 | Movie Record mode |
| 2 | Operating status
([STBY](standby) or [●] (recording)) |
| 3 | Time counter
(movie recording time: remaining recordable time) |
| 4 | Storage media
(Built-in memory (SC-MX10A/MX10AU only)
or memory card) |
| 5 | Battery info.(Remaining battery level/time) |
| 6 | LCD Enhancer * |
| 7 | Anti-Shake(EIS) (Electronic Image Stabilizer) |
| 8 | Focus * |
| 9 | Back Light * |
| 10 | Digital Effect |
| 11 | EASY.Q * |
| 12 | Zoom (Optical zoom / Digital zoom) |
| 13 | Date/Time |
| 14 | White balance |
| 15 | Scene Mode (AE) / Exposure (Manual) * |
| 16 | Video quality |
| 17 | Resolution |

LCD SCREEN INDICATORS



Movie Record mode: Shortcut menu (OK Guide)

- | | |
|---|--|
| 1 | Screen size (16:9 Wide/4:3) |
| 2 | Focus (Auto Focus/Manual Focus) * |
| 3 | Shortcut menu (OK Guide) / Return |
| 4 | White balance * |
| 5 | Exposure (Auto Exposure/Manual Exposure) |





Movie Play mode

- | | |
|----|---|
| 1 | Movie Play mode |
| 2 | Menu name (Delete, Protect, Copy) |
| 3 | Protect |
| 4 | File Name |
| 5 | Storage media
(Built-in memory (SC-MX10A/MX10AU only)
or memory card) |
| 6 | Battery info. (Remaining battery level/time) |
| 7 | Copy Selected (SC-MX10A/MX10AU only) |
| 8 | Scroll bar |
| 9 | Button Guide |
| 10 | Delete Selected |

preparation

LCD SCREEN INDICATORS



Movie Play mode

- 1 Movie Play mode
- 2 Play Status
- 3 Time code (Elapsed time / Recorded time)
- 4 Storage media (Built-in memory (SC-MX10A/MX10AU only) or memory card)
- 5 Battery info.(Remaining battery level/time)
- 6 LCD Enhancer *
- 7 Protect
- 8 File Name
- 9 Date/Time
- 10 Volume
- 11 Play Option
- 12 Resolution


Movie Record mode: Shortcut menu (OK Guide)

- 1 FF(fast forward)
- 2 Volume Down
- 3 Button Guide
- 4 Play/Pause
- 5 REW(rewind)
- 6 Volume Up

TURNING THE SCREEN INDICATORS ON/OFF (/ *i*CHECK)

Switching the information display mode



- You can switch the display mode of on-screen information:



Press the  / *i*CHECK button.

The full and minimum display modes will alternate.

- Full display mode:** All types of information will appear.
- Minimum display mode:** Only operating status indicator will appear.

Checking the remained battery and memory capacity

- When the camcorder is turned off (battery is installed) press and release the  / *i*CHECK button to display the remaining capacity of the battery capacity.
- When the camcorder is turned on (battery is installed) press and hold the  / *i*CHECK button for more than 2-3 seconds to display the remaining battery capacity.
- The approximate recordable time in the selected storage (Internal Memory or Memory Card) and battery information appear for about 10 seconds.








Recording capacity (approx.)

Remaining battery (approx.)

preparation

USING THE LCD ENHANCER

- Contrast is enhanced for a clear and bright image on the LCD screen. This effect is also implemented outdoors in bright daylight.
1. Press the **LCD ENHANCER** () button. The selected function icon is displayed.
 2. To exit LCD ENHANCER, press the **LCD ENHANCER** () button again.
-  LCD ENHANCER function does not affect the quality of the image being recorded.



LCD POWER SAVING FUNCTION

- The LCD screen is turned off after a certain period of time has passed (see below) in each mode in order to prevent unnecessary battery power consumption.
- Press any button to go back and turn on the LCD screen.

Mode	Movie					Settings	USB	
Sub-mode	STBY Mode	While Recording	Play (single view)	Play (thumbnail view)	Demo Mode		PC Camera	Mass Storage
Time	10 min	None	None	10 min	None	60 sec	60 sec	60 sec

ADJUSTING THE LCD SCREEN


1. Open up the LCD screen 90 degrees with your finger.
2. Rotate it to the best angle to record or play.
 - If you rotate the LCD screen 180 degrees to the lens side, you can close the LCD screen with it facing out. This is convenient during playback.



- See page 65 to adjust brightness and color of the LCD screen.
- Over-rotation may cause damage to the inside of the hinge that connects the LCD screen to the memory camcorder.



Do not lift the memory camcorder with holding the LCD screen. It can be a cause of sudden fall.




USING THE MENU BUTTON

1. Set the desired mode by pressing the **MODE** button.
2. Press the **MENU** button.
3. Move the cursor by pressing the **Control** button (**▲/▼/◀/▶**), to select desired menu item, and then press **Control** button **OK** to confirm.
4. Press the **MENU** button to finish.



MENU button dose not operate in the EASY.Q mode.





preparation

USING THE CONTROL BUTTONS








Used for playback, pausing, fast forwarding, and rewinding. Also used as directional buttons (up, down, left, right) and to make a selection when selecting movie images or menus.

1. Press the **Control** button (< / >) to move left / right.
2. Press the **Control** button (^ / v) to move up / down.
 - Confirm your selection by pressing the **OK** button.

-  • **Control** button (**OK** / (< / >)) does not operate in the EASY.Q mode.
- Using the **OK** button, you may directly access the shortcut menu.
 - ➔ page 29





Using the Control button

Button	Movie Record() mode	Movie Play() mode	Menu selection
	Access the Shortcut menu	Playback /Pause	Confirms selection
	Zoom (wide)	Increases the volume	Moves the cursor up
	Zoom (tele)	Decreases the volume	Moves the cursor down
	-	- Search playback RPS (Reverse Playback Search) rate: x2→x4→x8→x16→x32→x64 - Skip Playback	Moves to the previous menu
	-	- Search playback FPS (Forward Playback Search) rate: x2→x4→x8→x16→x32→x64 - Skip Playback - Frame-by-frame playback	Moves to the next menu








SHORTCUT MENU (OK GUIDE)

Shortcut menu (OK guide) represents the most frequently accessed functions according to the selected mode.

1. Press the **OK** button.
 - Shortcut menu (OK guide) is displayed.
2. Press the **Control** button (▲/▼/◀/▶) to control the setting.
3. Press the **OK** button to confirm your selection.
 - Press the **OK** button to exit the shortcut menu.



Shortcut function using the Control buttons

Button	Movie Record()mode	Movie Play() mode
	- Access the shortcut menu - Confirm selection - Exit the shortcut menu	- Shortcut menu (OK guide) is displayed - Playback /Pause
	Exposure (Auto / Manual)	Increases the volume
	Focus (Auto / Manual)	Decreases the volume
	White Balance (Auto ~ Custom WB)	- Search playback RPS (Reverse Playback Search) rate: x2→x4→x8→x16→x32→x64 - Skip Playback
	16 : 9 Wide (Off / On)	- Search playback FPS (Forward Playback Search) rate: x2→x4→x8→x16→x32→x64 - Skip Playback - Frame-by-frame playback



OK button dose not operate in the EASY.Q mode.


preparation

INITIAL SETTING : OSD LANGUAGE & DATE AND TIME

- Initial setting is available in all operating modes.
- To read the menus or messages in your desired language, set the OSD language.
To store the date and time during recording, set the date/time.

How to set the settings mode


1. Slide the **POWER** switch downward to turn on the memory camcorder.
2. Press the **MENU** button.
3. Press the **Control** button (< / >) to select "**Settings**".
4. Press the **OK** button.
 - The settings menu screen appears.



Selecting the OSD language

You can select the desired language to display the menu screen and the messages.

1. Set the "**Settings**" mode.
 - The settings menu screen appears.
 - Refer to "How to set the settings mode" for accessing to "**Settings**" mode.
 2. Press the **Control** button (< / >) to select "**Language**".
 3. Press the **Control** button (^ / v) to select the desired OSD language, and then press the **OK** button.
 - English / 한국어 / Français / Deutsch / Italiano / Español / Português / Nederlands / Svenska / Suomi / Norsk / Dansk / Polski / Magyar / Українська / Русский / 中文 / Türkçe
 4. Press the **MENU** button to exit the menu.
 - The OSD language is refreshed in the selected language.
-  • Even if the battery pack or AC power are removed, the language setting will be preserved.
- "**Language**" options may be changed without prior notice.



Setting Date and Time

Set the current date and time so that the date and time at which you make a recording can be recorded correctly.



The following procedure can also be used to correct the date and time you have already set.

1. Set the **"Settings"** mode.
 - The settings menu screen appears.
 - Refer to "How to set the settings mode" for accessing to **"Settings"** mode. ➡page 30.
2. Press the **Control** button (**< / >**) to select **"Date/Time Set"** and then press the **OK** button.
3. Set the desired value by moving the **Control** button (**^ / v**).
4. Move to the next item by moving the **Control** button (**< / >**), and then set values by moving the **Control** button (**^ / v**).
 - Items are displayed in the order of the date format.
 - By default, the Date/Time setting appears in the order of year, month, date, hour, minute and AM/PM.
5. After setting the last item, press the **OK** button to finish the setting.
 - Press the **MENU** button to exit the menu.

- You can set the year up to 2037.
- After setting, the date and time are automatically recorded on a special data area of the storage media.
- The button type battery maintains the clock function and preset contents of the memory : even if the battery pack or AC power adapter is removed. The button type battery for the memory camcorder lasts about 6 months under normal operation from the time of installation. When the button type battery becomes weak or dead, the date/time indicator will display **"2007/01/01 12:00AM"** when you turn the date and time display on. ➡page 20.

Turning the date and time display on/off

- To switch the date and time display on or off, access the menu and change the date/time mode. ➡page 64




about the storage media

SELECTING THE STORAGE MEDIA (SC-MX10A/MX10AU ONLY)

You can record moving on the built-in memory or a memory card, so you should select the desired storage media before starting recording or playback.

Selecting the storage media (SC-MX10A/MX10AU only)

- Selecting the recording medium is available in the Movie record / Movie Play modes.
Movie images can be stored and played back using the built-in memory or a memory card.
Set the memory type before recording and playing back images.
1. Press the **MENU** button.
 - The menu list will appear.
 2. Press the **Control** button (< / >) to select "**Settings**",
then press the **OK** button.
 3. Press the **Control** button (< / >) to select "**Memory Type**",
then press the **OK** button.
 4. Press the **Control** button (^ / v) to select "**Memory**" or "**Card**"
then press the **OK** button.
 5. Press the **MENU** button to exit.



Using the built-in memory (SC-MX10A/MX10AU only)

- This memory camcorder has an embedded 4GB memory which can be recorded on.

Using a memory card (not supplied)

- This memory camcorder has multi card slot for access to SDHC (Secure Digital High Capacity) and MMCplus.
 - Some cards are not compatible depending on the memory card manufacturer and memory card type.



- If you insert a memory card when the memory camcorder is on, the pop-up message will prompt you automatically to select the storage type.
- If there is no memory card inserted, only the built-in memory will be available.


INSERTING / EJECTING THE MEMORY CARD

Inserting a memory card

1. Turn the memory camcorder off.
2. Slide the memory card slot cover to the right to open the cover.
3. Insert the memory card into the memory card slot until it softly clicks in the direction of the arrow shown in the figure.
4. Close the cover.

Ejecting a memory card

1. Turn the memory camcorder off.
2. Slide the memory card slot cover to the right to open the cover.
3. Slightly push the memory card inwards to pop it out.
4. Pull the memory card out of the memory card slot and close the cover.




about the storage media

SELECTING A SUITABLE MEMORY CARD

A memory card is a compact portable storage media.

- **You can use SDHC and MMC plus cards.**
 - You can also use a SD memory card, but it must be less than 4GB.
 - **On this memory camcorder, you can use memory cards of the following capacity: 128MB ~ 8GB**
 - **Compatible recording media**
 - The following recording media have been guaranteed to work with this memory camcorder. Others are not guaranteed to work, so buy such products with caution.
- SDHC or SD memory cards:** Panasonic, SanDisk, and TOSHIBA,
MMC plus: Transcend
- If other media are used, they may fail to record data correctly, or they may lose data that has already been recorded.
 - For movie recording, use a memory card that support faster write speed(at least 1.25 MB/sec).



SDHC (Secure Digital High Capacity) Memory Card

- SDHC memory card complies with new SD specification Ver.**2.00**. This latest specification was established by SD Card Association to realize data capacity over **2GB**.
- The SDHC memory card supports a mechanical write protection switch. Setting the switch prevents accidental erasure of files recorded on the SDHC memory card. To enable writing, move the switch up to the direction of terminals. To set write protection, move the switch down.
- Due to change in File Allocation System and physical specifications, SDHC memory card can not be used with current SD enabled host devices. SDHC memory card can be used with only SDHC enabled host devices which carry SDHC logo on devices its self or on its operation manual.

MMCplus (Multi Media Card plus)

- In the case of MMCplus, they have no protection tab so please use the protect function in the menu.

Common cautions for memory card

- Damaged data may not be recovered. It is recommended you make a back-up of important data separately on the hard disk of your PC.
- Turning the power off or removing a memory card during operation such as formatting, deleting, recording, and playback may cause the data loss.
- After you modify the name of a file or folder stored in the memory card using your PC, your camcorder may not recognize the modified file.

Handling a memory card

It is recommended that you power off before inserting or removing the memory card to avoid data loss.

It is not guaranteed that you can use a memory card formatted by other devices.

Be sure to format your memory card using this camcorder.

- You have to format newly-purchased memory cards or memory cards with data that your camcorder cannot recognize or are saved by other devices. Note that formatting erases all data on the memory card.
- If you cannot use a memory card that has been used with another device, format it with your memory camcorder. Note that formatting erases all information on the memory card.
- A memory card has a certain life span. If you cannot record new data, you have to purchase a new memory card.
- Do not bend, drop, or cause a strong impact to your memory card.
- Do not use or store in a place that has high temperature and humidity or dusty environment.
- Do not place foreign substances on the memory card terminals. Use a soft dry cloth to clean the terminals if required.
- Do not paste anything other than exclusive label on label pasting portion.
- Be careful to keep memory card out of the reach of children, who might swallow it.



The memory camcorder supports SDHC and MMCplus memory cards for data storage.

- The data storage speed may differ, according to the manufacturer and production system.
 - SLC(single level cell) system: faster write speed enabled.
 - MLC(multi level cell) system: only lower write speed supported.
- The user using a lower write speed memory card for recording a movie may have difficulties storing the movie on the memory card. You can even lose your movie data during the recording.
- In an attempt to preserve any bit of the recorded movie, the memory camcorder forcibly stores the movie on the memory card and displays a warning: **"Low speed card. Please record at lower quality."**

To facilitate movie recording, you are recommended to use a memory card that supports faster write speed.

- If you are unavoidably using a low speed memory card, lower the recording quality by one level **"Fine"** → **"Normal"** or decrease the movie size to 352P to reduce the data size.
- You can have three quality options to record a movie with the memory camcorder : **"Super Fine"**, **"Fine"**, **"Normal"**
- You can record the same scene in three quality levels of **"Super Fine"**, **"Fine"**, **"Normal"**. However, the better the quality is, the bigger the data size is.
- **For optimal performance of the memory camcorder, ensure that you purchase a fast speed memory card.**

about the storage media

RECORDABLE TIME AND CAPACITY

Recordable time for movie images

Media	Capacity	Super Fine		Fine		Normal	
		352p	720i/720p	352p	720i/720p	352p	720i/720p
built-in memory	4GB	approx. 170min.	approx. 112min.	approx. 256min.	approx. 170min.	approx. 512min.	approx. 256min.
	SDHC/ MMCplus	1GB	approx. 43min.	approx. 28min.	approx. 64min.	approx. 43min.	approx. 128min.
	2GB	approx. 85min.	approx. 56min.	approx. 128min.	approx. 85min.	approx. 256min.	approx. 128min.
	4GB	approx. 170min.	approx. 112min.	approx. 256min.	approx. 170min.	approx. 512min.	approx. 256min.

1GB=1,000,000,000bytes : actual formatted capacity may be less as the internal firmware uses a portion of the memory.



- 352p, 720i/720p refer to resolutions the camcorder will record at.
- The above figures are measured under Samsung's standard recording test conditions and may differ depending on actual use.
- The memory camcorder provides three quality options for movie recordings:
 - **"Super Fine", "Fine", "Normal"**.
- The compression rate increases while lowering the quality (in the order of **"Fine", "Normal"**). The higher the compression rate is, the longer the recording time will be. However, the picture quality will be lower.
- The compression rate automatically adjusts to the recording image, and the recording time may vary accordingly.



- To facilitate the movie recording, it is recommended to use a memory card that supports faster write speed. (Write speed: 1.25 MB / sec or higher) If you use a low write-speed memory card, recording may stop with a message of "**Low speed card. Please record at lower quality**". If you inevitably use a low speed card, select a lower quality ("**Fine**" → "**Normal**") or set the movie size to **352p**.
- Memory cards of bigger than **8GB** in capacity may not work properly.
- The memory card that is used to store a movie can cause unwritable area, which may result in reduced recording time and free memory space.
- The maximum size of a movie (MPEG4) file that can be recorded at one time is 2GB.
- You can store up to 5000 movie images on a memory card.
- Movie image files recorded on other equipment are not playable on this memory camcorder.


To check capacity that remains memory



- Press the  /  CHECK button. ➔ page 16

recording

Basic procedures to record movie images described below.

RECORDING MOVIE IMAGES

- Memory camcorder provides two **Recording start/stop** buttons. One is on the rear side of the camcorder and the other one is on the LCD panel. Select the **Recording start/ stop** button that works best for you.
1. Turn the memory camcorder on.
 - Connect a power source to the memory camcorder. ➔ pages 12,18
(A battery pack or an AC power adapter)
 - Slide the **POWER** switch downward to turn on the power. ➔ page 21
 - Set the appropriate storage media : Internal Memory or Memory Card.
(SC-MX10A/MX10AU only)
(If you want to record on a memory card, insert the memory card.)
 2. Check the subject on the LCD screen.
 3. Press the **Recording start/stop** button.
 - The recording indicator (●) will display and recording will start.
 - Pressing the **Recording start/stop** button again during recording will set the memory camcorder to recording pause mode.
 4. When recording is finished, turn the memory camcorder off.
-  Setting the display option of "**16:9 Wide**" does not imply wide angle (wide aspect ratio) recording. Camera output, recording and playback signal is formatted to 4:3 aspect ratio.
 - Please note that all movies recorded with this memory camcorder have 4:3 aspect ratio regardless of the display option (16:9 Wide/4:3). When it is set to "**16:9 Wide**", the displayed picture may appear wider or rougher than that of 4:3 screen aspect ratio. ➔ pages 55,61









- Eject the battery pack when you have finished recording to prevent unnecessary battery power consumption.
- For on-screen information display. ➡ page 22
- For approximate recording time. ➡ page 36
- For various functions available when you record movie images. ➡ page 45~56
- If focusing is difficult, use the manual focus function. ➡ page 53
- During recording, some button operations are unavailable. (**MENU** button, etc.)
- Sound is recorded from the internal stereo microphone on the front of the memory camcorder. Take care that this microphone is not blocked.
- While recording, don't insert or eject the memory card as it may record noise. (SC-MX10A/MX10AU only)
- Do not operate the power switch or remove the memory card while accessing the storage media. Doing so may damage the storage media or the data on storage media.
- Before recording an important movie, make sure to test on the recording function to check if there is any problem with the audio and video recording.
- You can not use a locked memory card for recording. You will see a message saying recording is disabled due to the lock.
- If you press the **Recording start/stop** button while a menu operation is in process, the product returns to recording pause mode.

recording

RECORDING WITH EASE FOR BEGINNERS (EASY.Q MODE)

- With the EASY.Q function, most of the memory camcorder settings are automatically adjusted, which frees you from detailed adjustments.
- 1. Slide the **POWER** switch downward to turn on the memory camcorder.
- 2. Press the **MODE** button to set Movie Record mode (). → page 21
- 3. Press the **EASY.Q** button.
 - When you press the **EASY.Q** button, all functions on the memory camcorder will be set to off and the recording settings will be set to the following basic modes.
(Scene Mode (AE), White Balance, Auto Exposure, Anti-Shake (EIS), Digital Effect, Auto Focus and Back Light)
 - The EASY.Q and **Anti-Shake (EIS)** () indicator appear on the screen at the same time.
- 4. To record movie images, press the **Recording start/stop** button.
 - Recording will begin using the basic automatic settings.



To cancel EASY.Q mode

Press the **EASY.Q** button again.

- The EASY.Q and **Anti-Shake (EIS)** () indicators disappear from the screen.

Unavailable buttons during operation

- The following button and menu operations are unavailable because the items are automatically set. And the corresponding message (" **Release the EASY.Q** ") may appear if unavailable operations are attempted.
 - **MENU** button
 - **OK** button
 - etc.
- Cancel EASY.Q function if you want to add any effect or settings to the images.
- The EASY.Q mode settings are released when the memory camcorder is turned off.
- EASY.Q mode automatically sets the "**Anti-Shake(EIS)**" to "**On**" while using EASY.Q.

ZOOMING

Use the zoom function for close-up or wide-angle recording. This memory camcorder allows you to record using optical 34x power zoom and 1200x digital zoom.

- You can zoom with the Zoom lever or the zoom(W/T) button on the LCD panel.
- The further you slide the Zoom lever, the quicker the zoom action.

To zoom in

- Slide the Zoom lever towards **T** (telephoto).



To zoom out

- Slide the Zoom lever towards **W** (wide-angle).

- Zoom magnification over 34x is done through digital image processing, and is therefore called digital zoom. Digital zooming is possible up to 1200x. Set "**Digital Zoom**" to "**On**". ➔page 56



- Be sure to keep your finger on the Zoom lever. If you move your finger off the zoom lever, the operation sound of the Zoom lever may be also recorded.
- You can also zoom with the Zoom (W/T) button on the LCD panel.
- The minimum possible distance between camcorder and subject while maintaining sharp focus is about 1 cm (about 0.39 inch) for wide angle and 50 cm (about 19.68 inch) for telephoto.
- Focusing may become unstable during zooming. In this case, set the zoom before recording and lock the focus by using the manual focus, then zoom in or out during recording. ➔page 53
- Optical zoom preserves the movie quality, but during digital zoom the image quality may suffer.



playback




MOVIE IMAGES PLAYBACK

You can find a desired movie image quickly using thumbnail index view.

1. Turn the memory camcorder on.
 - Slide the **POWER** switch downward to turn on the power. ➔ page 21
 - Set the appropriate storage media :Internal Memory or Memory Card
➔ page 32 (SC-MX10A/MX10AU only)
(If you want to record on a memory card, insert the memory card.)
2. Open the LCD screen.
 - Adjust brightness or contrast of the LCD screen. ➔ page 65
3. Press the **MODE** button.
 - Switches to Movie Play mode.
 - The recorded movie images are displayed in thumbnail index view.
4. Use the **Control** button (▲/▼/◀/▶) to select the desired movie images, and the press the **OK** button.
 - Shortcut menu for playback will be displayed for a while.
 - Each time you press the **OK** button, play or pause is toggled.
 - If you move the zoom lever during playback, the camcorder switches to thumbnail index view.



Please note that all movies recorded with this memory camcorder have 4:3 aspect ratio regardless of the display option (16:9 Wide/4:3). When it is set to "**16:9 Wide**", the displayed picture may appear wider or rougher than that of 4:3 screen aspect ratio. ➔ pages 55,61







- During playback, pressing the **Recording start/stop** button will move to Movie Record mode.
- If there is no file stored to view, the message **"Empty"** appears.
- When the multi-AV cable is connected to the memory camcorder, the built-in speaker will automatically turn off.
- Depending on the amount of data to be played back, it may take some time for the playback images to appear.
- Image data edited on PC or certain types of image data may not be displayed on this memory camcorder.
- Image data recorded on another camcorder may not be playable on this memory camcorder.
- You can also play movie images on a TV screen by connecting the memory camcorder to a TV. ➔page 77
- A video codec is required to play the recorded movie images on a PC.
Install the software in the provided software CD to have the CODEC automatically installed in the system.
If you do not have the software CD, search the product model name in the download center on the Samsung Electronics home page (www.samsung.com) to get the CODEC installation file. ➔page 71
- For various functions available during playback, see **"playback options"**. ➔pages 57~61

Adjusting the volume

- You can hear the recorded sound from the built-in speaker.
- You can control the volume by using the **Control** button (▲/▼).
- The level can be adjusted anywhere between 0 and 10.
(If you close the LCD screen while playing, you will not hear the sound from the speaker.)

Press the **Control** button (▲/▼) to increase or decrease the volume.

- The volume bar disappears after 1~2 seconds.



playback

Various Playback Operations

Still playback (pause)

- Press the **OK** button during playback.
 - To resume normal playback, press the **OK** button again.

Search playback or movie




- During normal playback, press and hold the **Control** button (>) for forward search, or to the left for reverse search.
- Moving the **Control** button to (< / >) repeatedly increases the search speed for each direction.
 - FPS(Reverse Playback Search) rate: x2→x4→x8→x16→x32→x64
 - FPS(Forward Playback Search) rate: x2→x4→x8→x16→x32→x64
- To resume normal playback, press the **OK** button.

Skip playback of movie

- During playback, press the **Control** button (>) to locate the start point of next file. Pressing the **Control** button (>) repeatedly skips files in forward direction.
- During playback, press the **Control** button (<) to locate the start point of the current file, pressing the **Control** button (<) repeatedly skips files in reverse direction.
- Press the **Control** button (<) within 3 seconds from the start point, it skips to the first image of the previous file.

Frame-by-frame playback



- While playback is paused, press the **Control** button (>).
 - Pressing the **Control** button (>) repeatedly advances the still picture frame by frame.
 - While playback is paused, press and hold the **Control** button to (>), it plays back frame by frame just like slow motion playback.
 - To resume normal playback, press the **OK** button.



recording options



CHANGING THE MENU SETTINGS

You can change the menu settings to customize your memory camcorder. Access the desired menu screen by following the steps below, then change the various settings.

1. Slide **POWER** switch downward to turn the memory camcorder on.
 2. Select the operation mode.
 - For Movie Record Menus: Press **MODE** button to set Record (📹).
 - For Movie Play Menus: Press **MODE** button to set Play (▶).
 3. Press **MENU** button.
 - The menu screen appears.
 4. Select the desired sub menu and menu item with the **Control** buttons and the **OK** button.
 - To return to the normal screen, press **MENU** button.
 - Even if the menu item is displayed, some items cannot be set depending on the selected mode (movie recording/playback, settings). In this case, sub menu cannot be accessed or setting cannot be changed.
➡page 85
-  • You can also access the shortcut menu using the **OK** button. ➡page 29
-  • While the menu screen is displayed, pressing the **Recording start/stop** button will move to Movie Record mode.

Button Tips

- a. **MENU** button : Use it to enter or exit the menu.
- b. **Control** button (▲/▼/◀/▶) : Use it to move up/down/left/right
- c. **OK** button : Use it to select or confirm the menu.






recording options

🔗 Follow the instructions below to use each of the menu items listed after this page.

For example: setting the White Balance in Movie Record mode.

1. Slide the **POWER** switch downward to turn the memory camcorder on.
 2. Select the operation mode.
 - For Movie Record Menus:
Press **MODE** button to set Record (🎥).
 3. Press **MENU** button.
 - The menu screen appears.
 4. Press the **Control** button (◀ / ▶) to select "**White Balance**".
 5. Select the desired sub menu item with the **Control** button (▲ / ▼), and then press the **OK** button.
 6. Press **MENU** button to exit the menu.
- 📝 • The selected item is applied and the indicator is displayed.
In "Auto" mode, the item indicator may not displayed on the screen.
- While the menu screen is displayed, pressing the **Recording start/stop** button will move to Movie Record mode.
 - You can also change the menu setting, using the shortcut menu represents the most frequently accessed functions. ➡ page 29



MENU ITEMS

- Accessible items in menu can vary depending on the operation mode.
- For operation details, see the corresponding page. ➡ pages 45~46, 57~61

Menu items in Movie Record()

Items	Default value	Page
Scene Mode (AE)	Auto	48
White Balance	Auto	49
Exposure	Auto	50
Anti-Shake (EIS)	Off	51
Digital Effect	Off	52
Focus	Auto	53
Back Light	Off	54
16:9 Wide	On	55
Quality	Super Fine	55
Resolution	720x480i	56
Digital Zoom	Off	56

Menu items in Movie Play()

Items	Default value	Page
Play Option	Play All	57
Delete	OK	58
Protect	On	59
Copy (SC-MX10A/MX10AU only)	-	60
16:9 Wide	On	61
File Info	OK	61






recording options

RECORDING MENU ITEMS

You can setup the menu items for movie images recording.

Scene Mode (AE)

This memory camcorder automatically sets the shutter speed and aperture according to the subject brightness for optimum recording: You can also specify one of five modes depending on subject conditions, recording environment or purpose of filming.






item	contents	on-screen display
"Auto"	- Auto balance between the subject and the background. - To be used in normal conditions. - The shutter speed is automatically adjusted from 1/60 to 1/250 per second, depending on the scene.	None
"Sports"	- Reduces blurring when recording rapidly moving subjects such as in golf or tennis. If the Sports mode is used under a fluorescent light, the image may flicker. In this case, use the Auto mode for recording.	
"Portrait"	- Creates a shallow depth of field so that the person or subject appears against a softened background. - The portrait mode is most effective when used outdoors. - The shutter speed is automatically adjusted from 1/60 to 1/1000 per second.	
"Spotlight"	- Prevents overexposure of subject's face, etc. when strong light strikes the subject, as in a wedding or on stage.	
"Beach/Snow"	- Prevents under exposure of subject's face, etc. in a place where reflection of light is intense, such as at the seaside in midsummer or on a ski slope.	
"High Speed"	- For recording fast-moving subjects such as players in golf or tennis games.	





- If you set the Exposure to manual, "**Scene Mode (AE)**" will be disabled. ➡page 50
- This function will not operate in the EASY.Q mode.
- You can check the selected "**Scene Mode (AE)**" on the on-screen information display. However, nothing will appear in "**Auto**" mode.


White Balance

This memory camcorder automatically adjusts the color of subject. Change the white balance setting depending on the recording conditions.

item	contents	on-screen display
"Auto"	This option is generally used to control the white balance automatically.	None
"Daylight"	This controls the white balance according to the outdoor ambience, especially for close up and when the subject is of one dominant color.	
"Cloudy"	This option is used when you make a recording in cloudy weather.	
"Fluorescent "	This option is used when you make a recording under white fluorescent lights.	
"Tungsten"	This option is used when the surroundings are less than 3200K of tungsten light.	
"Custom WB"	You can manually adjust white balance to match the light source or situation.	

Setting the white balance manually:

- Select "Custom WB".
 - The indicator () and the message "Set White Balance" are displayed.
- Frame a white object such as a piece of paper so that it fills the screen. Use an object that is not transparent.
 - If the object that fills the screen is not focused, correct the focus using "Manual Focus" → page 53
- Press the **OK** button.
 - The white balance setting will be applied and indicator () is displayed.




recording options



- A subject can be recorded under various types of lighting conditions indoors (natural, fluorescent, candlelight, etc.). Because the color temperature is different depending on the light source, the subject tint will differ depending on the white balance settings. Use this function for a more natural result.
 - The white balance also can be set in the shortcut menu. ➔page 29.
 - The white balance can not be set use while EASY.Q is in use.
 - It is recommended that you specify "**Digital Zoom**" to "**Off**" before setting white balance. ➔page 56
 - Reset the white balance if lighting conditions change.
 - During normal outdoor recording, setting to auto may provide better results.
 - Do not use a colored object when setting white balance: The appropriate tint cannot be set.


Exposure

The memory camcorder usually adjusts the exposure automatically. You can also manually adjust the exposure depending on the recording conditions.


item	contents	on-screen display
"Auto"	This option automatically adjusts image brightness according to the environmental light conditions.	None
"Manual"	- You can adjust the brightness of an image manually. - Adjust the brightness when the subject is too bright or too dark.	

Setting the exposure manually:

- Press the **Control** button (< / >) to adjust the exposure while viewing the image on the LCD screen.
 - Confirm your selection by pressing the **OK** button.
 - Exposure value can be set between "**0**" and "**29**".
 - If you set exposure to manual, the higher the exposure, the brighter the recorded picture will be.




Manual exposure is recommended in situations listed below :


- When shooting using reverse lighting or when the background is too bright.
 - When shooting on a reflective natural background such as at the beach or when skiing.
 - When the background is overly dark or the subject is bright.
-  • The exposure also can be set in the shortcut menu. ➡ page 29
- EASY.Q mode automatically sets the **"Exposure"** to **"Auto"**.
 - If you manually change the exposure value when **"Scene Mode(AE)"** function is selected, manual changes are applied first.

Anti-Shake(EIS) (Electronic Image Stabilizer)

When you use zoom to record a magnified subject image, it will correct fuzziness in the recorded image.

item	contents	on-screen display
"Off"	Disables the function.	None
"On"	Compensates for unstable images caused by camera-shake, particularly at high magnification.	







Anti-Shake(EIS) provides a more stable image when:

- Recording while zooming
 - Recording small objects
 - Recording while walking or moving
 - Recording through the window of a moving vehicle
-  • EASY.Q mode automatically sets the **"Anti-Shake(EIS)"** to **"On"** while using EASY.Q.
- When **"Anti-Shake(EIS) : On"** is set, there will be a slight difference between the actual movement and the movement on screen.
 - Gross camcorder shake may not be entirely corrected even if **"Anti-Shake(EIS) : On"** is specified. Firmly hold the memory camcorder with both hands.
 - It is recommended that you specify **"Anti-Shake(EIS): Off "** when using the memory camcorder on a desk or tripod.
 - When you record pictures with 34x or more magnification and the **"Anti-Shake(EIS)"** is **"On"** in dim places, after-images may stand out. In this case, we recommend using a tripod and turning the **"Anti-Shake(EIS)"** to **"Off"**.

recording options


Digital Effect

- The digital effect enables you to give a creative look to your recording.
- Select the appropriate digital effect for the type of picture that you wish to record and the effect you wish to create.
- There are 6 different digital effect options.

item	contents	on-screen display
"Off"	Disables the function.	None
"Black&White"	Changes the images into Black and White.	
"Sepia "	This mode gives the images a reddish brown pigment.	
"Negative"	Reverses the colors, creating the look of a negative.	
"Art"	Adds artistic effects to your movie file.	
"Mosaic"	A mosaic overlay appears on your movie file.	
"Mirror"	This mode cuts the image in half using a Mirror effect.	



The digital effects can not use while EASY.Q is in use.




Black&White



Sepia




Negative



Art




Mosaic



Mirror

Focus

- The memory camcorder usually focuses on a subject automatically (auto-focus).
- You can also manually focus a subject depending on the recording conditions.

item	contents	on-screen display
"Auto"	This memory camcorder automatically focuses a subject at the center of screen (auto-focus). When the memory camcorder is turned on, auto-focus will always be set.	None
"Manual"	Manual focusing may be necessary under certain conditions that make automatic focusing difficult or unreliable.	

Focusing manually during recording

This memory camcorder automatically focuses a subject from close-up to infinity. However, the correct focus may not be obtained depending on the recording condition. In this case, use the manual focus mode.

1. Set **"Focus"** to **"Manual"**.
 - The manual focus adjustment indicator appears.
2. Use the zoom lever to zoom in on subject.
3. Press the **Control** button (**</>**) to adjust the focus, while viewing the subject on the LCD screen.

Focusing on a further subject

To focus on a further subject, press the **Control** button (**<**).

Focusing in a nearer subject


To focus on a nearer subject, press the **Control** button (**>**).

Manual focus is recommended in the following situations :


- a. A picture containing several objects, some close to the memory camcorder, others further away.
- b. A person enveloped in fog or surrounded by snow.
- c. Very shiny or glossy surfaces like a car.
- d. People or objects moving constantly or quickly like an athlete or a crowd.



- The focus also can be set in the shortcut menu. ➔ page 29
- EASY.Q mode automatically sets the **"Focus"** to **"Auto"**.
- Be sure to zoom in on your subject before manually focusing on it. If you bring the subject into focus at the **"W"** control side, focus will be faulty when you turn the zoom lever to the **"T"** control side to zoom in on the subject.



<Nearer subject >




<Further subject >

recording options

Back Light

When subject is lit from behind, this function will compensate for lighting so that the subject is not too dark.


item	contents	on-screen display
"Off"	Disables the function.	None
"On"	- Backlight compensation is executed. - Backlight compensation brightens the subject quickly.	

Back lighting influences recording when the subject is darker than the background:

- The subject is in front of a window.
- The subject is against a snowy background.
- The subject is outdoors and the background is overcast.
- The light sources are too bright.
- The person to be recorded is wearing white or shiny clothes and is placed against a bright background:
The person's face is too dark to distinguish his/her features.



<BLC off>





<BLC on>



The **"Back Light"** function can not use while EASY.Q is in use.

16:9 Wide

You can select the desired LCD display aspect ratio for recording or playback (16:9 Wide/4:3 aspect ratio).







item	contents	on-screen display
 "Off"	Disables the function. Displays the image in 4:3 aspect ratio. Select to use the standard display aspect ratio of 4:3 on the screen.	None
 "On"	Select to view movies of 4:3 aspect ratio by enlarging and fitting into 16:9 aspect ratio.	None



- 16:9 wide setting also can be set in the shortcut menu. ➡page 29.
- Please note that all movies recorded with this memory camcorder have 4:3 aspect ratio regardless of the display option (16:9 Wide/4:3). When it is set to "16:9 Wide", the displayed picture may appear wider or rougher than that of 4:3 screen aspect ratio.

Quality

You can select the quality of a movie to be recorded. This memory camcorder can record in the **SF** (super fine), **F** (fine) and **N** (normal) modes.

item	contents	on-screen display
 "Super Fine"	Records at the best quality.	
 "Fine"	Records at high quality.	
 "Normal"	Records at normal quality.	






- You can record a scene at three quality levels: "**Super Fine, Fine, or Normal**".
However, the better the quality is, the more memory is used.

recording options

Resolution

- You can select the resolution of a movie to be recorded.

item	contents	on-screen display
"720x480i"	Resolution of the movie played on a TV screen.	
"720x480p"	Higher resolution of the movie played on a PC screen.	
"352x240p"	Lower resolution of the movie played on a PC screen.	



- High resolution images use more memory than lower resolution images. Therefore the higher the resolution selected, the less recording time available.
- The recording times depend on the resolution. ➔ page 36
- When the screen size is set to 352(352x240p), it is played back in smaller size than 720(720x480p) on a PC.


Digital Zoom

- You can select the maximum zoom level in case you want to zoom to a level greater than 34x (the default setting) during recording. Up to 34x zoom is performed optically, and after that, up to 1200x zoom is performed digitally. Note that the image quality decreases when you use the digital zoom.

item	contents	on-screen display
"Off"	Only optical zoom is available up to 34x.	-
"On"	Digital zoom is available up to 1200x. Moving the zoom lever will display the digital zoom bar.	-



- You can also zoom with the zoom (W/T) button on the LCD panel.
- The image quality may deteriorate depending on how much you zoom in on the subject.
- Maximum zooming may result in lower image quality.



playback options


- You can manage recorded movie images in various ways.
- Each thumbnail image shown in the display represents the first frame of a separately recorded movie.

SETTING THE PLAY OPTION

- You can play all movies continuously or play the selected movie only.
 - You can also set the repeat option for all movies.
1. Slide the **POWER** switch downward to turn on the memory camcorder.
 - Set the appropriate storage media. (SC-MX10A/MX10AU only)
(If you want to record on a memory card, insert the memory card.)
 2. Press the **MODE** button. ➡ page 21
 - Switches to Movie Play mode.
The recorded movie thumbnail images, are displayed in a thumbnail index view.



3. Press the **MENU** button.
 - Press the **Control** button (< / >) to select "Play Option".
4. Press the **Control** button (^ / v) to select an option, and then press the **OK** button.




item	contents
"Play All"	Plays back from the selected movie to the last movie.
"Play One"	The selected movie will be played.
"Repeat All"	All movies will be played repeatedly.
"Repeat One"	The selected movie will be played repeatedly.

5. Press the **MENU** button to exit the menu.
 - During playback, the selected item is applied






- While the menu or thumbnail image screen is displayed, pressing the **Recording start/stop** button will move to the Movie Record mode.
- It operates identically in the full image display (single image displayed on the screen).






playback options

DELETING MOVIE IMAGES

- You can delete saved movie images.
- Slide the **POWER** switch downward to turn on the memory camcorder.
 - Set the appropriate storage media. (SC-MX10A/MX10AU only)
(If you want to record on a memory card, insert the memory card.)
 - Press the **MODE** button. ➡ page 21
 - Switches to Movie Play mode.
 - Select the desired movie thumbnail images, using the **Control** button.
 - Press the **MENU** button.
 - Press the **Control** button (< / >) to select "**Delete**".
 - Select an option by pressing the **Control** button (^ / v) and then press the **OK** button.

item	contents
"OK"	Deletes the selected movie.
"Multi Select"	Deletes the individual selected movies. - To delete individual movie images, select the desired thumbnail movie images for deletion by pressing the OK button. Then press the MENU button to delete. - The () indicator is displayed on the selected movie images. - Pressing the OK button toggles between the movie image being selected for deletion (() indicator appears on image) or not () indicator is removed from image).
"All"	Deletes all movie images.

- The pop-up selection menu will appear depending on the selected menu item. In this case, select the desired item with the **Control** buttons (< / >) and the **OK** button.
 - The deleted images also disappear in thumbnail image display.
-  • While the menu or thumbnail image screen is displayed, pressing the **Recording start/stop** button will move to Movie Record mode.
- It operates identically in the full image display (single image displayed on the screen).
 - Once deleted, a movie can not be restored.
 - Protected files (movies) will not be deleted.



PROTECTING MOVIE IMAGES




- You can protect saved important movies from accidental deletion.
 - Protected movies will not be deleted unless you release the protection or format the memory.
- Slide the **POWER** switch downward to turn on the memory camcorder.
 - Set the appropriate storage media. (SC-MX10A/MX10AU only)
(If you want to record on a memory card, insert the memory card.)
 - Press the **MODE** button. ➡page 21
 - Switches to Movie Play mode.
 - Select the desired movie thumbnail images, using the **Control** button.
 - Press the **MENU** button.
 - Menu screen appears.
 - Press the **Control** button (< / >) to select "**Protect**".
 - Select an option by pressing the **Control** button (^ / v) and then press the **OK** button.

item	contents
"On"	Protects the selected movie from deletion.
"Multi Select"	Protects individual selected movie from deletion. - To protect individual movies, select desired movie thumbnail images by pressing the OK button. Then press the MENU button to confirm. - The (🔒) indicator is displayed on the selected movie thumbnail images. - Pressing the OK button toggles between the movie image being selected for protection ((🔒) indicator appears on image) or not ((🔓) indicator is removed from image).
"All On"	Protects all movie images from deletion.
"All Off"	Cancels the protection for all movie images.

- The pop-up selection menu will appear depending on the selected menu item. In this case, select the desired item with the **Control** buttons (< / >) and the **OK** button.



- While the menu or thumbnail image screen is displayed, pressing the **Recording start/stop** button will move to Movie Record mode.
- It operates identically in the full image display (single image displayed on the screen).
- Protected movie images will show the protection indicator (🔒) when they are displayed.
- If the write protection tab on the memory card is set to lock, you cannot set image protection.



playback options

COPYING MOVIE IMAGES (SC-MX10A/MX10AU ONLY)

- Movie images are copied to the destination storage while leaving original movie images in the source storage.
- It copies from the currently-used memory to another. For example, if the built-in memory was used, it copies to a memory card.

1. Slide the **POWER** switch downward to turn on the memory camcorder.
 - Set the appropriate storage media. (SC-MX10A/MX10AU only)
(If you want to record on a memory card, insert the memory card.)
2. Press the **MODE** button. ➡ page 21
 - Switches to Movie Play mode.
 - Select the desired movie thumbnail images, using the **Control** button.
3. Press the **MENU** button.
 - Menu screen appears.
4. Press the **Control** button (< / >) to select "**Copy**".
5. Select an option by pressing the **Control** button (^ / v) and then press the **OK** button.




item	contents
"OK"	Copies the selected movie images.
"Multi Select"	Copies the individual selected movie images. - To copy individual movie images, select desired movie images by pressing the OK button. - The ([]) indicator is displayed on the selected movie thumbnail images. Press the MENU button to confirm. - Pressing the OK button toggles between the movie image being selected for copying ([]) indicator appears on image) or not ([]) indicator is removed from image).
"All "	Copies all the movies.

6. The pop-up selection menu will appear depending on the selected menu item. In this case, select the desired item with the **Control** buttons (< / >) and the **OK** button.



- While the menu or thumbnail image screen is displayed, pressing the **Recording start/stop** button will move to Movie Record mode.
- It operates identically in the full image display (single image displayed on the screen).
- If a memory card is not inserted, you can not perform the "**Copy**" function.


60_English



16:9 WIDE


You can select the desired LCD display aspect ratio for recording or playback (16:9 Wide/4:3 aspect ratio).





item	contents	on-screen display
"Off"	Disables the function. Displays the image in 4:3 aspect ratio. Select to use the standard display aspect ratio of 4:3 on the screen.	None
"On"	Select to view movies of 4:3 aspect ratio by enlarging and fitting into 16:9 aspect ratio.	None

 Please note that all movies recorded with this memory camcorder have 4:3 aspect ratio regardless of the display option (16:9 Wide/4:3). When it is set to "**16:9 Wide**", the displayed picture may appear wider or rougher than that of 4:3 screen aspect ratio.

FILE INFORMATION

You can see the image information for all images.

- Slide the **POWER** switch downward to turn on the memory camcorder.
 - Set the appropriate storage media. (SC-MX10A/MX10AU only)
(If you want to record on a memory card, insert the memory card.)
- Press the **MODE** button.  page 21
 - Switches to Movie Play mode.
- Select the desired movie thumbnail images, using the **Control** button.
- Press the **MENU** button.
- Press the **Control** button (**< / >**) to select "**File Info**".
- Press the **OK** button.
 - Press the **OK** button again after confirming.
 - The information of the selected file is displayed as shown below.
 - Date
 - Duration
 - Size



setting options


CHANGING THE MENU SETTINGS IN "SETTINGS"




You can change the menu settings to customize your memory camcorder. Access the desired menu screen by following the steps below and change the various settings.

1. Slide **POWER** switch downward to turn the memory camcorder on.
2. Press **MENU** button.
 - The menu screen appears.
3. Select "**Settings**" with the **Control** button (**</>**), and then press the **OK** button.
 - The menus in "**Settings**" mode will appear.
4. Select the desired sub menu and menu item with the **Control** buttons (**^/∇/←/→**) and the **OK** button.
 - To return to the normal screen, press **MENU** button.
 - Even if the menu item is displayed, some items cannot be set depending on the selected mode (movie recording/playback, settings). In this case, the sub menu cannot be accessed or a setting cannot be changed.

Button Tips

- a. **MENU** button : Use it to enter or exit the menu.
- b. **Control** button (**^/∇/←/→**) : Use it to move up/down/left/right
- c. **OK** button : Use it to select or confirm the menu.

 The pop-up selection menu will appear depending on the selected menu item. In this case, select the desired item with the Control buttons (**</>**) and the **OK** button.



You can setup the date/time, OSD language and display settings of the memory camcorder.

SETTING MENU ITEMS

Items	Default value	Page
Date/Time Set	2007/01/01 12:00 AM	64
Date Format	YY/MM/DD	64
Time Format	12 Hr	64
Date/Time	Off	64
LCD Brightness	40%	65
LCD Color	50%	65
Auto Power Off	Off	65
Beep Sound	On	66
File No.	Series	66
Memory Type (SC-MX10A/MX10AU only)	-	66
Memory Info	OK	67
Format	OK	67
Default Set	OK	68
Version	-	68
Language	English	68
USB Connect	Mass Storage	68
Demo	Off	68



These Items and Default values may be changed without notice.

setting options

Date/Time Set

Set the date and time so they can be recorded correctly. ➡ page 31

Date Format

You can select the date format to display.

settings	contents	on-screen display
"YY/MM/DD"	The date is displayed in the order of year / month / date.	-
"DD/MM/YY"	The date is displayed in the order of date / month / year.	-
"MM/DD/YY"	The date is displayed in the order of month / date / year.	-

Time Format

You can select the time format to display.

settings	contents	on-screen display
"12 Hr"	The time is displayed in 12 hour units.	-
"24 Hr"	The time is displayed in 24 hour units.	-

Date/Time

You can set the date and time to display on the LCD screen.

- Before you use the **"Date/Time"** function, you must set the date/time. ➡ page 31

settings	contents	on-screen display
"Off"	The date and time are not displayed.	None
"Date"	The date is displayed.	2007/01/01
"Time"	The time is displayed.	12:00AM
"Date & Time"	The date and time are displayed.	2007/01/01 12:00AM




The date/time will read **"2007/01/01 12:00 AM"** in the following conditions.
- When the button type battery becomes weak or dead.

LCD Brightness

- You can adjust the brightness of the LCD screen to compensate for ambient lighting conditions.
- Moving the **Control** button up will brighten the screen whereas moving it down will darken the screen.




- A brighter LCD screen setting consumes more battery power.
- Adjust the LCD brightness when the ambient lighting is too bright and the monitor is hard to see.
 - LCD Brightness does not affect the brightness of images to be stored.
 - You can adjust the LCD Brightness from 0% to 100%.



LCD Color

- You can adjust the LCD color from 0% to 100%.
- When you set color range, the higher the figures the brighter the LCD monitor will be.



Auto Power Off

To save battery power, you can set the **"Auto Power Off"** function which turns off the memory camcorder if there is no operation for a certain period of time.

settings	contents	on-screen display
"Off"	Cancels the "Auto Power Off" function.	None
"5 Min"	The memory camcorder automatically turns off when there is no operation for 5 min.	None



- The **"Auto Power Off"** will not function when you connect the AC power adapter to the memory camcorder. The **"Auto Power Off"** functions when the battery pack is the only power source.
 - If you connect the camcorder to the USB device (PC, etc.) through USB cable, the **"Auto Power Off"** will not function.

setting options

Beep Sound


You can set the beep sound to on/off. When on, the beep sounds when any operation is performed.

settings	contents	on-screen display
"Off"	Disables the function	None
"On"	The beep sounds when operate the menu settings, the power is turned on.	None

File No.



File numbers are assigned to movie images in the order they were recorded.

settings	contents	on-screen display
"Series"	Assigns file numbers in sequence even if the memory card is replaced with another one or after formatting, or after deleting all files. The file number is reset when a new folder is created.	None
"Reset"	Resets the file number to 0001 even after formatting, deleting all or inserting a new memory card.	None

 When you set "**File No.**" to "**Series**", each file is assigned with a different number so as to avoid duplicating file names. It is convenient when you want to manage your files on a PC.

Memory Type (SC-MX10A/MX10AU only)


You can record movie images on the built-in memory or a memory card, so you should select the desired storage media before starting recording or playback. ➡ page 32


settings	contents	on-screen display
"Memory"	Select the built-in memory for storage medium. So you can record or play back movie images on the built-in memory.	
"Card"	Select a memory card for storage medium. So you can record or play back movie images on memory card.	

Memory Info

It shows you the storage information. You can view the storage media, used memory space and available memory space, and the recordable time according to the quality.

settings	contents	on-screen display
"Memory"	It shows you the memory information of built-in storage media. (SC-MX10A/MX10AU only)	-
"Card"	It shows you the memory information of the inserted memory card.	-




 If there is no storage media inserted, it can not be selected and will be dimmed on the menu.
In case of model SC-MX10/MX10P, the information of the memory card appears by selecting "OK".

Format

The format function completely delete all files and options on the storage media, including protected files. You can format (initialize) recording data in the storage media. You have to format the pre-used storage media or newly purchased memory cards with this memory camcorder before using them. This enables stable speeds and operation when accessing the recording medium.

Be aware that all files and data including protected files will be erased.

settings	contents	on-screen display
"Memory"	Formats the built-in storage media. (SC-MX10A/MX10AU only)	None
"Card"	Formats the memory card.	None

-  • Make sure to format the recording medium on the memory camcorder.
- Do not remove the recording medium or perform any other operation (such as turning off the power) during format. Also, be sure to use the provided AC power adapter, as the recording medium may be corrupted if the battery becomes exhausted during formatting. If the recording medium becomes corrupted, format it again.
- A memory card with the protection tab set to lock will not be formatted. ➡ page 59
- In case of model SC-MX10/MX10P, the format is executed by selecting "OK".



Do not format the recording medium on the PC or a different device.

Make sure to format the recording medium on the memory camcorder.

setting options

Default Set

You can initialize the memory camcorder settings to the factory defaults (initial settings at the factory). Initializing the memory camcorder settings to factory defaults does not affect recorded images.



After resetting the memory camcorder, set **"Date/Time Set"**. ➡ page 31

Version

You can see the firmware version information.

Language

You can select a desired language to display the menu and messages. ➡ page 30

USB Connect

Connect the memory camcorder to a PC via a USB 2.0 cable and you can transfer your movie images from the storage media, or use this camcorder as a web camera.

settings	contents	on-screen display
"Mass Storage"	Transfers the data files with your memory camcorder and a PC. ➡ page 75	None
"PC Cam"	Uses your memory camcorder as a web camera. ➡ page 76	None



- The default setting is mass storage.
- Before connecting the USB cable, check if the appropriate USB mode you want to use is selected.

Demo

Demonstration automatically shows you the major features that are included with your memory camcorder so that you may use them more easily.

settings	contents	on-screen display
"Off"	Disables the function	None
"On"	Activates demonstration mode and shows various features on the LCD screen. - After it exit to the menu, the demonstration is automatically operated. - Demonstration mode will resume if you operate any other function in STBY mode for about 6minute.	None



"Auto Power Off " function does not operate during the demonstration mode.

USB interface

This chapter explains how to connect the camcorder to a PC using the USB cable for various functions.

- When connecting a USB cable to a PC, refer to the software installation instructions and PC specifications below.

SYSTEM REQUIREMENTS

Transferring a Digital Image through a USB Connection

- The memory camcorder supports USB 2.0 High speed. (Depends on the PC specification)
- You can transfer a recorded file in storage media to a PC via a USB connection.
- If you transfer data to a PC, you need to install the software (DV Driver, Video Codec, DirectX 9.0) supplied with the memory camcorder.

USB Connection Speed (depending on the System)

- High speed USB connection is supported by Microsoft (Windows) device drivers only.
- Windows 2000 - High speed USB on a system with Service Pack 4 or later installed.
- Windows XP - High speed USB on a system with Service Pack 1 or later installed.
- Windows Vista - High speed USB on a system with Service Pack 1 or later installed.



System Requirements

Windows operating systems

- CPU: Intel® Pentium 4™, 2GHz or higher, or the equivalent
- Operating systems: Windows® 2000/XP/Vista (32bit)
Standard installation is required. If you have upgraded your current operating system, we can not guarantee the proper operation of the product.
- Memory: 512MB RAM or higher
- Hard Disk: 2GB or higher
- Resolution: 1024x768 dots, 24bit color
- USB port: USB2.0 High Speed

- System requirements mentioned above are recommendations. Even on a system that satisfies the requirements operation is not ensured depending on the system.

- This memory camcorder is recognized just as a removable storage device on the Macintosh computer. (Mac OS 10.3 or above that support High Speed USB standards)


USB interface



- On a slower PC than recommended, movie playback may not be smooth or video editing may take a long time.
- On a slower PC than recommended, movie playback may skip frames or operate unexpectedly.
- If your OS is Windows 2000/XP/Vista (32bit), log in as the Administrator(administrator of the PC) (or a user with the equivalent privileges) to install the software.
- Check out the storage media of the memory camcorder before connecting USB cable. If no memory card or an unformatted memory card is inserted, the PC will not recognize your memory camcorder as a removable disk.
- If you disconnect the USB cable from the PC or the memory camcorder during the data transfer, the data transfer will stop and the data may be damaged.
- If you connect the USB cable to a PC using a USB HUB or with other devices at the same time, it may cause conflict and may not work properly. If this occurs, remove all other USB devices and try the connection again.
- Intel® Pentium III™ or Pentium 4™ is a trademark of the Intel Corporation.
- Windows® is a registered trademark of the Microsoft® Corporation.
- All other brands and names are property of their respective owners.

INSTALLING THE SOFTWARE

Installing DV Media Pro Program



You need to install DV Media Pro to play back recorded movie files or the transferred data from memory camcorder with the USB cable on your PC. When you install the DV Media Pro software on your Windows computer, you can enjoy the following operations by connecting your memory camcorder to your computer via a USB cable.


- View movie recordings on PC: **DV Driver - DirectX9.0 - Video Codec**
- PC camera/USB streaming function: **DV Driver - DirectX9.0 - Video Codec**

Before you start!

- Turn on your PC. Exit all other applications running.
- Insert the provided CD into the CD-ROM drive.
 - The setup screen appears automatically soon after the CD was inserted.
 - If the setup screen does not appear, click on "Start" on the bottom left corner and select "Run" to display a dialog. Type "D:\autorun.exe" and then press ENTER, if your CD-ROM drive is mapped to "D:Drive".

Installing Driver - DV Driver and DirectX 9.0

- DV Driver is a software driver that is required to support establishing connection to a PC. (If it is not installed, some functions will not be supported.)
1. Click on "DV Driver" on the setup screen.
 - Driver software required is installed automatically. Following drivers will be installed:
 - USB PC-CAMERA driver
 - USB streaming driver (USB video transfer)
 2. Click on "Confirm" to finish driver installation.
 3. If the "DirectX 9.0" is not installed, it is installed automatically after setting "DV Driver".
 - After installing DirectX 9.0, PC needs to be restarted.
 - If DirectX 9.0 is installed already, there is no need to restart the PC.




Application Installation - Video Codec

- Click on "Video Codec" on the setup screen.
Video Codec is required to play movie files recorded by this memory camcorder on a PC.

USB interface

Application Installation – Quick Time

1. Click "Quick Time" on the setup screen.
 - QuickTime is Apple's technology for handling movie, sound, animation, graphics, text, music, and even 360-degree virtual reality (VR) scenes.



CyberLink Power Director


- CyberLink Power Director is software for easily editing MPEG, AVI, and other video files, still images, and other contents for creating a movie. This software has an interface that allows editing in either time line or storyboard mode, maintains superior image quality, uses SVRT for high-speed rendering, and has a host of other advanced video editing features.

Setting up CyberLink Power Director

- After inserting another CD("Cyberlink Power Director"), the setup screen displays automatically. Follow the instruction to start installation. This manual only refers to software installation and PC connection. For more details on software, refer to the "Online help/Readme" on the CyberLink Power Director CD.



- Please install by using the Software CD that came with this memory camcorder. We do not guarantee compatibility with other CDs.
 - For movie playback on a PC, install software in this order :
DV Driver - DirectX 9.0 - Video Codec
 - For movie editing, use the **CyberLink Power Director**.
 - For PC Cam use, install software in this order:
DV Driver - DirectX 9.0 - Video Codec
 - You have to install "DV Driver", "Video Codec" and "DirectX 9.0" to run DV Media Pro properly.
 - During installation, if the Microsoft LOGO test warning is shown, just click 'Continue(C).'
 - If a message saying "Digital Signature not found" or something similar appears, ignore the message and continue with the installation.




CONNECTING THE USB CABLE

Connect the USB cable to copy movie images from the camcorder to the PC and vice versa.

You can use various other functions with USB connection.
(as a PC-camera, data storage, etc.)

1. Set the "USB Connect" to "Mass Storage." → page 68
2. Connect the memory camcorder to the PC with a USB cable.



- Don't apply excessive force when inserting or extracting a USB cable into/from a USB jack.
- We recommended using the camcorder's AC adapter as the power supply instead of the battery pack.
- When the USB cable is connected, turning the camcorder on or off the camcorder may cause the PC to malfunction.

Disconnecting the USB cable

Before loading or unloading recording mediums or turning off the PC, first disconnect the USB cable and turn off the memory camcorder.

After completing the data transmission, you must disconnect the cable in the following way:

1. Click the "Unplug or eject hardware" icon on the task tray.
2. Select "USB Mass Storage Device" or "USB Disk," and then click "Stop."
3. Click "OK."
4. Disconnect the USB cable from the memory camcorder and PC.



- If you disconnect the USB cable from the PC or the memory camcorder while transferring, the data transmission will stop and the data may be damaged.
- If you connect the USB cable to a PC via a USB HUB or simultaneously connect the USB cable along with other USB devices, the memory camcorder may not work properly. If this occurs, remove all USB devices from the PC and reconnect the memory camcorder.


USB interface

VIEWING THE CONTENTS OF STORAGE MEDIA

1. Slide the **POWER** switch downward to turn on the memory camcorder.
 - Select the desired recording medium. ➡ page 32 (SC-MX10A/MX10AU only)
 - Make sure that there is a memory card in the memory camcorder (SC-MX10/MX10P only).
2. Connect the memory camcorder to the PC with a USB cable. ➡ page 73
 - Check out the USB connection on the LCD monitor.
3. **When using Windows® XP, Vista version :**
 - The "Removable Disk" window appears on the PC's screen after a moment.
 - Select "Open folders to view files using Windows Explorer" and click "OK."

When using Windows® 2000:

- a. Doubleclick the "My Computer" icon on the desktop.
 - The "Removable Disk" icon which represents the storage media in the memory camcorder appears in the "My Computer" window.
 - b. Doubleclick the "Removable Disk" icon.
4. The folders in the storage media appear.
 - Different file types are stored in different folders.

 If the "Removable Disk" window does not appear, confirm the connection or perform the steps 1 and 2.

Structure of folders and files on the storage media

- The folder and file structure for built-in memory or memory card is as follows.
- Don't arbitrarily change or remove the folder or file name. It may not be playable.



Movie images file (1)

The SD-quality movie images have SDV_####.AVI format. The file number automatically increases when a new movie image file is created. When the number exceeds 9,999, a new folder is created and it is stored in SDV_0001.AVI.


General data file (2)

It is the place where the user can save general document files as a storage device.

74_English



Movie image
Setting data






- When 999 folders and 9,999 files are recorded, you cannot record any more. In this case, format your storage media. (memory card, etc.)
- You may modify the name of a file/folder stored in the memory card using a PC. This memory camcorder may not recognize modified files.

TRANSFERRING FILES FROM THE MEMORY CAMCORDER TO YOUR PC

You can copy the movie images to your PC.

1. Execute the procedure in "Viewing the contents of storage media." ➔page 74
The folders in the storage media appear.
2. Create a new folder, enter the folder name, and then double-click it.
3. Select the folder to copy, and then drag and drop it into the destination folder.
 - The folder is copied from the storage media (memory card (all models) or internal memory (SC-MX10A/MX10AU) to the PC.
 - Saving the wrong kinds of files in a recording medium or deleting files or folders from a recording medium can cause problems with the operation of the memory camcorder. When it is necessary to delete a file from a storage media (memory card (all models) or internal memory (SC-MX10A/MX10AU), delete it through the memory camcorder. Also, do not move or rename folders and files within the medium on PC.



Playing Back Files on the PC

Movie Images

Use the "DV Media Pro".

- You can install this software from the provided CD.
For more details of "Video Codec". ➔page 71



- When playing back a file in the recording medium on your PC, copy the file to your PC, and then play it back. If video file is played back directly from recording medium (i.e. the memory camcorder is connected through USB to your PC), it may be not played back properly due to the inadequate processing speeds or other problems.

USB interface



USING THE PC CAM FUNCTION

You can use your memory camcorder as a PC camera for video chatting, video conference and other PC camera applications.

Before you start!

For PC Cam use, you must install the DV Driver. ➔page 70

1. Slide the **POWER** switch downward to turn on the memory camcorder.
 - The Movie Record mode screen appears.
2. Press the **MENU** button and select the "**Settings**". ➔page 62
 - The Settings screen appears.
3. Press the **Control** button (< / >) to select "**USB Connect**".
4. Press the **Control** button (^ / v) to select "**PC Cam**" and then press the **OK** button.
5. Turn on your PC.
6. Connect the memory camcorder to your PC with the USB cable.
7. The memory camcorder can be used as a PC Cam for programs such as Windows Messenger.
 - Various applications take advantage of the "**PC Cam**" function.
 - Refer to respective product documentation for further details.
 - When finished, disconnect the USB cable.



- We recommended using the AC Power Adapter during data transfer to avoid unintended power outages.
- When the USB port connection is changed, it may require DV Driver re-installation. ➔page 71
- If you connect more than two USB devices to a single PC or use a hub for USB connection, the PC camera function may not work properly.
- You may see a popup message for compatibility confirmation, depending on the PC specification. Press "Continue" and follow the on-screen instructions to complete the installation.
- If the DV Media Pro is not properly installed on your PC, during connection, you may see the Found New Hardware Wizard on the screen during connection. Follow the on-screen instructions to complete the installation.

connection

You can view the recorded movies on a large screen by connecting the memory camcorder to a TV.

VIEWING ON TV SCREEN

To playback your recordings, the television must be NTSC compatible. ➡ page 80

Connecting to a TV

Use the provided multi-AV cable to connect the memory camcorder to a TV as follows:

1. Connect the end of the Multi AV cable with the single plug to the AV jack of the camcorder.
2. Connect the other end with S-Video or Video (yellow) and left(white)/ right(red) audio cables to the TV.





- Before connecting, make sure that the volume on TV is turned down: forgetting this may cause feedback from the TV speakers.
- Carefully connect the input and output cables to the corresponding connections on the device the memory camcorder is being used with.

Viewing on TV Screen

1. Turn on the TV and set the input selector to the Input connection the memory camcorder is connected to. This is often referred to as "line".
 - Refer to the TV instruction manual for how to switch the TV input.
2. Turn the memory camcorder on.
 - Slide the **POWER** switch downward and press the **MODE** button to set Player (▶). ➡ page 21
 - The image from the memory camcorder will appear on the TV screen.
 - You can also monitor the image on the LCD screen of the memory camcorder.
3. Perform playback. You can perform playback, recording or make settings in the menu while viewing on your TV screen.



- When a copy-protected movie is played back, no image will appear on TV screen.
- Information that the memory camcorder is recording will appear on the TV screen: You can also display only part of information or switch off the display. Refer to "TURNING THE SCREEN INDICATORS ON/OFF (▶)" on page 25, and press the **▶ / CHECK** button to switch the display status.



connection


RECORDING (DUBBING) IMAGES ON OTHER VIDEO DEVICES

You can record (dub) images played back on this memory camcorder, onto other video devices. Use the multi-AV cable(provided) to connect the memory camcorder to another video device as shown in the following figure:

1. Press the **MODE** button to set Player(▶),
→page 21
2. Choose the recorded (dubbed) movie on the thumbnail view and then press the **OK** button.
3. Press the record button on the connected device.
 - The memory camcorder will start playback and the recording device will record (dub) it.



- Using S-VIDEO will deliver clearer images.
- Be sure to use the AC adaptor to power the memory camcorder to prevent battery power from shutting off during recording on another video device.



maintenance & additional information

MAINTENANCE

Your memory camcorder is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you fulfill any warranty obligations and allow you to enjoy this product for many years.

- ✿ For safekeeping of the memory camcorder, turn off the memory camcorder.
 - Remove the battery pack and AC power adaptor. ➡page 13
 - Remove the memory card. ➡page 32

Cautions on Storing

- **Do not leave the memory camcorder in a place where the temperature is very high for a long period of time:**

The temperature inside a closed vehicle or trunk can become very high in a hot season. If you leave the memory camcorder in such a place, it could malfunction or the case could be damaged. Do not expose the memory camcorder to direct sunlight or place it near a heater.
- **Do not store the memory camcorder in a place where the humidity is high or in a dusty place:**

Dust entering the memory camcorder could cause malfunctions. If humidity is high, the lens could become moldy, and the memory camcorder could become inoperative. It is recommended that you put the memory camcorder in a box together with a desiccant when storing it in a closet, etc.
- **Do not store the memory camcorder in a place subject to strong magnetism or intense vibrations:**

This could cause malfunctions.
- **Detach the battery pack from the memory camcorder and store it in a cool place:**

Leaving the battery pack attached or storing it at high temperature could shorten its life.

Cleaning the memory camcorder

- ✿ **Before cleaning, turn off the memory camcorder and remove the battery pack and AC power adapter.**
- **To clean the exterior**

Wipe gently with a soft dry cloth. Do not apply excessive force when cleaning, gently rub the surface.

 - Do not use benzene or thinner to clean the camcorder. The coating of exterior could peel off or the case could deteriorate.

maintenance & additional information

- **To clean the LCD monitor**

Wipe gently with a soft dry cloth. Be careful not to damage the monitor.

- **To clean the lens**

Use an optional air blower to blow out dirt and other small object. Do not wipe the lens with cloth or your fingers.

If necessary, wipe gently with lens cleaning paper.

- Mold may form if the lens is left dirty.

- If the lens looks dimmer, turn off the memory camcorder and leave it for about 1 hour.

ADDITIONAL INFORMATION

Using your memory camcorder abroad

- **Each country or region has its own electric and color systems.**
- **Before using your memory camcorder abroad, check the following items.**

- **Power sources**

The provided AC adapter features automatic voltage selection in the AC range from 110 V to 240 V.

You can use your camcorder in any countries/regions using the AC power adaptor supplied with your camcorder within the AC 100 V to 240 V, 50/60 Hz range.

Use a commercially available AC plug adaptor, if necessary, depending on the design of the wall outlet.

- **About TV color systems**

Your camcorder is an **NTSC**-system-based camcorder.

If you want to view your recordings on a TV or to copy it to an external device, it must be an **NTSC**-system-based TV or an external device having the appropriate Audio/Video jacks. Otherwise, you may need to use a separate video format transcoder (NTSC-PAL format converter).

- **NTSC-Compatible Countries / Regions**

Bahamas, Canada, Central America, Japan, Mexico, Philippines, Korea, Taiwan, United States of America, etc.

- **PAL-Compatible Countries / Regions**

Australia, Austria, Belgium, Bulgaria, China, CIS, Czech Republic, Denmark, Egypt, Finland, France, Germany, Greece, Great Britain, Holland, Hong Kong, Hungary, India, Iran, Iraq, Kuwait, Libya, Malaysia, Mauritius, Norway, Romania, Saudi Arabia, Singapore, Slovak Republic, Spain, Sweden, Switzerland, Syria, Thailand, Tunisia, etc.

troubleshooting

TROUBLESHOOTING

- ❖ Before contacting a Samsung authorized service center, perform the following simple checks. They may save you the time and expense of an unnecessary call.

Warning indicators and messages

Power source

Message	Informs that...	Action
Low Battery	The battery pack is almost discharged.	Change to a charged one or use AC adaptor. Charge the battery pack.
Auto Power Off	If no button is pressed for about 5 minutes, the memory camcorder is automatically turned off . ("Auto Power Off").	To disable this option, change the setting of " Auto Power Off " to " Off " ➔page 65

troubleshooting

Storage media

Message	Informs that...	Action
Memory Full	There is not enough space to record on built-in memory.	Delete unnecessary files on the built-in memory. (SC-MX10A/MX10AU) Use a memory card.
Insert Card	There is no memory card inserted in the card slot.	Insert a memory card. Use the built-in memory. (SC-MX10A/MX10AU)
Card Full	There is not enough space to record on memory card.	Delete unnecessary files on the memory card. Use the built-in memory. (SC-MX10A/MX10AU)
Card Error	The memory card is corrupted.	Format the memory card or replace it with a new one.
Not Supported Card	The memory card is not supported in this camcorder.	Change the memory card that we recommended.

Editing files

Message	Informs that...	Action
Not Formatted	The memory card is not formatted.	Format the memory card.

Recording

Message	Informs that...	Action
Not Supported Format	The format is not supported.	The file format is not supported. Check the supported file.



When there is dew condensation, do not use the camcorder for a while

- What is dew condensation?

Dew condensation happens when a memory camcorder is moved to a place where there is a significant temperature difference from the previous place. In other words, the water vapor in the air turns into dew because of the temperature difference, and it condensates like dew on the external or internal lenses of the memory camcorder and on the reflection lens.

When this happens, you temporarily may not use the record or play functions of the memory camcorder. Also, it may cause a malfunction or damage to the memory camcorder when using the device with the power on while there is dew condensation.

- What can I do?

Turn the power off and detach the battery pack, and leave it in a dry area for 1~2 hours before using it.

- When does the dew condensation occur?

When the device is relocated to a place with a higher temperature than the previous location, or when using it in a hot area suddenly, it will cause condensation.

- When recording outside in cold weather during the winter and then using it in indoors.
- When recording outside in hot weather after being indoors or inside a car where the AC was running.

Note before sending your camcorder for repair.

- If these instructions do not solve your problem, contact your nearest Samsung authorized service center.
- Depending on the problem, current hard disk may need to be initialized or replaced and the data will be deleted. Be sure to back up the data on the hard disk on the other storage media before sending your camcorder to repair. Samsung cannot guarantee any loss of your data.

troubleshooting

- ❖ If you encounter any problem using your camcorder, check the following before requesting service. If these instructions do not solve your problem, contact the nearest Samsung authorized service center.

Symptoms and solutions

Power

Symptom	Explanation/Solution
The power does not turn on.	<ul style="list-style-type: none"> The battery pack may not be installed on your memory camcorder. Insert a battery pack to the memory camcorder. The inserted battery pack may be discharged. Charge the battery pack or replace it with a charged one. If you use an AC power adaptor, make sure it is properly connected to the wall outlet.
The power automatically turns off.	<ul style="list-style-type: none"> Your memory camcorder has been left for more than 5 minutes without any button operation. To turn on your memory camcorder, press the Record start/stop button. Is "Auto Power Off" set to "On"? If no button is pressed for about 5 minutes, the memory camcorder is automatically turned off ("Auto Power Off"). To disable this option, change the setting of "Auto Power Off" to "Off" ➔page 65 The battery pack is almost discharged. Charge the battery pack or replace it with a charged one.
Power cannot be turned off.	<ul style="list-style-type: none"> Remove the battery pack or unplug the AC power adaptor, and connect the power supply to the camcorder again before turning it on.
The battery pack is quickly discharged.	<ul style="list-style-type: none"> The temperature is too low. The battery pack is not fully charged. Charge the battery pack again. The battery pack reached its lifespan and cannot be recharged. Use another battery pack.

Displays

Symptom	Explanation/Solution
The screen of TV or LCD screen displays distorted images.	<ul style="list-style-type: none"> All movies recorded with this memory camcorder have 4:3 aspect ratio. - It can occur when recording or viewing a 16:9-ratio image on the LCD screen. For more details, see the display specifications. ➡ page 55, 61 - If you want to display properly on your TV, check out your TV type and set the proper screen mode (4:3 aspect ratio).
Unknown image appears on the LCD screen.	<ul style="list-style-type: none"> The memory camcorder is in "Demo" mode. Change the setting "Demo" to "Off". ➡ page 68 A warning indicator or message appears on the screen. ➡ page 81
The afterimage remains on the LCD screen.	<ul style="list-style-type: none"> This occurs if you disconnect the AC power adaptor or remove the battery pack before turning the power off.
The image on the LCD screen looks dark.	<ul style="list-style-type: none"> Ambient light is too bright. Adjust the brightness and angle of LCD.

Menu


Symptom	Explanation/Solution		
Menu items are grayed out.	<ul style="list-style-type: none"> You cannot select grayed items in the current recording/playback mode. There are some functions you cannot activate simultaneously. The following list shows examples of unworkable combinations of functions and menu items. If you want to set the desired functions, do not set the following items first. <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; vertical-align: top;"> <p><Cannot Use></p> <p style="padding-left: 20px;">Scene Mode(AE)</p> </td> <td style="width: 50%; vertical-align: top;"> <p><Because of the following setting></p> <p style="padding-left: 20px;">Exposure (Manual)</p> </td> </tr> </table> <ul style="list-style-type: none"> Most of menu items cannot be selected when you set the EASY.Q function. If there is no storage media inserted, it can not be selected and will be dimmed on the menu : "Memory Info", "Format", etc. 	<p><Cannot Use></p> <p style="padding-left: 20px;">Scene Mode(AE)</p>	<p><Because of the following setting></p> <p style="padding-left: 20px;">Exposure (Manual)</p>
<p><Cannot Use></p> <p style="padding-left: 20px;">Scene Mode(AE)</p>	<p><Because of the following setting></p> <p style="padding-left: 20px;">Exposure (Manual)</p>		

troubleshooting

Recording Media (Memory card, etc)

Symptom	Explanation/Solution
Memory card functions are not operable.	<ul style="list-style-type: none">• Insert a memory card into your camcorder properly. ➡page 33• If you use a memory card formatted on a computer, format it again directly on your camcorder. ➡page 67
Image cannot be deleted.	<ul style="list-style-type: none">• The recorded images are protected. Remove protection from the files and delete them. ➡page 59• You cannot delete images protected by another device. Release the protection of the image on the device.• Release the lock on the write-protect tab of the memory card (SDHC, standard SD memory card etc), if any. ➡page 34
You cannot format the memory card.	<ul style="list-style-type: none">• Release the lock on the write-protect tab of the memory card (SDHC, standard SD memory card, etc), if any. ➡page 34• Copy any important recorded files to your PC before formatting. Samsung shall not be responsible for any loss of data. (It is recommended that you copy the data to your PC or other storage media.)
The data file name is not indicated correctly.	<ul style="list-style-type: none">• The file may be corrupted.• The file format is not supported by your camcorder.• Only the file name is displayed, if the directory structure does not comply with the international standard.

Recording

Symptom	Explanation/Solution
<p>Pressing the Recording start/stop button does not start recording.</p>	<ul style="list-style-type: none"> • Press the MODE button to set Movie Record mode (). • There is not enough free space to record on the built-in memory or memory card. • Check if the memory card is write-protected or if SDHC memory card is inserted. • The internal temperature of your camcorder is unusually high. Turn off your camcorder and leave it for a while in a cool place. • Your camcorder is damp and moist inside (condensation). Turn off your camcorder and leave it for about 1 hour in a cool place. ➔ page 79
<p>The actual recording time is less than the estimated time.</p>	<ul style="list-style-type: none"> • The recording time is measured under Samsung's standard recording test conditions and may differ depending on actual use. • When you record an object that moves fast, the actual recording time may be shorten.
<p>The recording stops automatically.</p>	<ul style="list-style-type: none"> • If you make a frequent recording or deletion of files, the performance of the built-in flash memory will deteriorate. In this case, format the built-in memory again.
<p>When recording a subject illuminated by bright light, vertical lines appear.</p>	<ul style="list-style-type: none"> • This is not a malfunction.

troubleshooting


Symptom	Explanation/Solution
When the screen is exposed to direct sunlight during recording, the screen becomes red or black for an instant.	<ul style="list-style-type: none">This is not a malfunction.
During recording, the date/time does not display.	<ul style="list-style-type: none">"Date/Time" is set to "Off". Set the "Date/Time" to "On". ➡page 64
There is a time difference between the point where you press Recording start/stop button and the point where the recorded movie starts/stops.	<ul style="list-style-type: none">On your camcorder, there may be a slight time delay between the point when you press Recording start/stop button and the actual point where the recorded movie starts/stops. This is not an error.
The recording stops.	<ul style="list-style-type: none">The internal temperature of your camcorder is unusually high. Turn off your camcorder and leave it for a while in a cool place.Your camcorder is damp and moist inside (condensation). Turn off your camcorder and leave it for about 1 hour in a cool place. ➡page 79

Adjusting the image during recording

Symptom	Explanation/Solution
Focus does not adjust automatically.	<ul style="list-style-type: none"> Set "Focus" to "Auto". ➡page 53 The recording conditions are not suitable for auto focus. Adjust the focus manually. ➡page 53 The lens is dusty on the surface. Clear the lens and check the focus. Recording is being made in a dark place. Light up to brighten the place.
The image appears too bright or flickering, or changes in color.	<ul style="list-style-type: none"> This occurs when recording images under a fluorescent lamp, sodium lamp, or mercury lamp. Cancel "Scene Mode (AE)" to minimize this phenomena. ➡page 48
Color balance of image is not natural.	<ul style="list-style-type: none"> White balance adjustment is required. Set proper "White Balance". ➡page 49
Unknown indicator appears on the screen.	<ul style="list-style-type: none"> A warning indicator or message appears on the screen.
The backlight function does not function.	<ul style="list-style-type: none"> While recording in EASY.Q mode, the backlight function does not work.

troubleshooting

Playback on your camcorder

Symptom	Explanation/Solution
Pressing the Play/Pause button does not start playback.	<ul style="list-style-type: none">• Press the MODE button to set Movie Play mode. ()• Image files recorded using other device may not be played on your memory camcorder.• Select a proper recording medium.
The Skip or Search function does not work properly.	<ul style="list-style-type: none">• If the temperature inside the camcorder is too high, it can not function properly. Turn the camcorder off, wait for a few moments, and turn it on again.
Playback is interrupted unexpectedly.	<ul style="list-style-type: none">• Check the AC adaptor or battery pack is properly connected and stable.

Playback on other devices (TV, etc.)

Symptom	Explanation/Solution
You cannot view the image or hear the sound on the connected device.	<ul style="list-style-type: none">• Connect the audio line of the multi-AV cable to your camcorder or to the connected device (TV, DVD recorder, etc). (Red color- right, White color- left)• The multi-AV cable is not connected properly. Make sure that the multi-AV cable is connected to the proper jack. ➡page 77• When you are using the S-VIDEO cable, make sure to connect red and white plugs of your multi-AV cable separately since S-VIDEO cable does not support audio. ➡page 77
The image appears distorted on the 16:9 wide TV.	<ul style="list-style-type: none">• All movies recorded with this memory camcorder have 4:3 aspect ratio. So this happens when viewing recorded movies on a 16:9 wide screen TV.• If you want to display properly on your TV, check out your TV type and set the proper screen mode (4:3 aspect ratio).

Connecting/Dubbing with other devices (TV, DVD player, etc)

Symptom	Explanation/Solution
You cannot dub correctly using the multi-AV cable.	<ul style="list-style-type: none"> The multi-AV cable is not connected properly. Make sure that the multi-AV cable is connected to the proper jack, i.e. to the input jack of the device used for dubbing an image from your camcorder. ➡page 78

Connecting to a computer

Symptom	Explanation/Solution
The computer does not recognize your camcorder.	<ul style="list-style-type: none"> Install the provided software program. ➡page 71 Disconnect the USB devices other than the keyboard, the mouse and the camcorder from the computer. Disconnect the USB cable from the computer and camcorder, restart the computer, then connect it again correctly.
Cannot play a movie file properly on a PC.	<ul style="list-style-type: none"> A video codec is needed to play the file recorded on your memory camcorder. Install the software provided with your camcorder ➡page 71. Please install by using the software CD that came with this camcorder. We do not guarantee compatibility for different CD versions. Make sure you insert the connector in the correct direction, and connect the USB cable to the USB jack on your camcorder firmly. Disconnect the cable from the computer and camcorder, restart the computer. And connect it again properly.
Cannot use the provided software, "DV Media Pro", on a Macintosh computer.	<ul style="list-style-type: none"> You cannot use "DV Media Pro" for a Macintosh computer. This camcorder is recognized just as a removable storage device on the Macintosh computer. (Mac OS 10.3 or above supported.)

troubleshooting

Symptom	Explanation/Solution
"DV Media Pro" does not function properly.	<ul style="list-style-type: none">• Exit the "DV Media Pro" program, and restart the Windows computer.
The image or sound on your camcorder is not played on your computer properly.	<ul style="list-style-type: none">• Movie playback or sound may stop temporarily depending on your computer. The movie or sound copied to your computer is not affected.• If your camcorder is connected to a computer that does not support Hi-speed USB(USB2.0), the images or sound may not be played back correctly. The images and sound is copied to your computer is not affected.
The playback screen is paused or distorted.	<ul style="list-style-type: none">• Check the system requirements to play a movie. ➡ page 69• Exit other all applications running on the current computer.

Overall operations

Symptom	Explanation/Solution
The date and time are incorrect.	<ul style="list-style-type: none">• Has the camcorder been left unused for a long period of time? The backup memory battery (button-type battery) may be discharged: replace it with a new one. ➡ page 20

specifications

Model Name: SC-MX10/SC-MX10P/SC-MX10A/SC-MX10AU

System	
Video signal	NTSC
Picture compression format	MPEG4 ASP Format
Audio compression format	ADPCM
Recording quality	Super Fine (about 12Mbps), Fine (about 10Mbps), Normal (about 8Mbps)
Image device	CCD (Charge Coupled Device) (Max/Effective : 680K/350K pixels)
Lens	F1.6 to 4.3, 34x (Optical), 1200x (Digital) Electronic zoom lens
Focal Length	2.3~78.2mm
Minimum Illumination	3.0 Lux
Filter diameter	Ø30
LCD screen	
Size/dot number	2.7 inches wide, 112k
LCD screen method	1.6" interlaced scan, LCD panel/TFT active matrix system
Connectors	
S-Video output	Y:1V (p_p), 75Ω, analog C:0.286Vp_p, 75Ω, analog
Composite video out	1.0V (p_p), 75Ω, analog
Audio output	(-7.5dBm 47KΩ, analog, stereo)
USB output	mini USB-B type (USB2.0 High Speed)
General	
Power source	8.4V (Using AC adapter), 7.4V (Using Lithium Ion battery pack)
Power source type	Power supply (100V~240V) 50/60Hz, Lithium Ion battery pack
Power consumption (LCD on/LCD off)	2.96W, 0.4A / 2.4W (0.3A)
Operating temperature	0°~40°C (32°F~104°F)
Operating humidity	30%~80%
Storage temperature	-20°C ~ 60°C (-4°F ~ 140°F)
Dimensions (W x H x D)	Approx. 2.36" x 2.46" x 4.76" (60mm x 62.5mm x 121mm)
Weight	Approx. 0.61lbs (280g) (expect for battery pack or memory card)
Internal MIC	Omni-directional stereo microphone

These technical specifications and design may be changed without notice.

Warranty

SAMSUNG LIMITED WARRANTY

SAMSUNG Electronics America Inc. (SEA), warrants that this product is free from defective material and workmanship.

SEA further warrants that if product fails to operate properly within the specified warranty period and the failure is due to improper workmanship or defective material, SEA will repair or replace the product at it's option.

All warranty repairs must be performed by a SEA authorized service center. The name and address of the location nearest you can be obtained by calling toll free: 1-800 SAMSUNG (1-800-726-7864).

Labor

90 days carry-in

Parts

1 year

On carry-in models, transportation to and from the service center is the customer's responsibility.

The original dated sales receipt must be retained by the customer and is the only acceptable proof of purchase. It must be presented to the authorized service center.

EXCLUSIONS (WHAT IS NOT COVERED)

This warranty does not cover damage due to accident, fire, flood and/or other acts of God; misuse, incorrect line voltage, improper installation, improper or unauthorized repairs, commercial use, or damage that occurs in shipping. Exterior and interior finish, lamps, and glass are not covered under this warranty.

Customer adjustments which are explained in the instruction manual are not covered under the terms of this warranty. This warranty will automatically be voided for any unit found with a missing or altered serial number. This warranty is valid only on products purchased in the United States and Puerto Rico.

Some States do not allow the exclusions or limitations of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from State to State.

contact SAMSUNG world wide

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care center.

Region	Country	Customer Care Center	Web Site
North America	CANADA	1-800-SAMSUNG (7267864)	www.samsung.com/ca
	MEXICO	01-800-SAMSUNG (7267864)	www.samsung.com/mx
	U.S.A	1-800-SAMSUNG (7267864)	www.samsung.com
Latin America	ARGENTINE	0800-333-3733	www.samsung.com/ar
	BRAZIL	0800-124-421 /004-0900	www.samsung.com/br
	CHILE	800-726-7864 (SAMSUNG)	www.samsung.com/cl
	COSTA RICA	0-800-507-7267	www.samsung.com/latin
	ECUADOR	1-800-10-7267	www.samsung.com/latin
	EL SALVADOR	800-6225	www.samsung.com/latin
	GUATEMALA	1-800-299-0013	www.samsung.com/latin
	JAMAICA	1-800-234-7267	www.samsung.com/latin
	PANAMA	800-7267	www.samsung.com/latin
	PUERTO RICO	1-800-682-3180	www.samsung.com/latin
	REP. DOMINICA	1-800-751-2676	www.samsung.com/latin
	TRINIDAD & TOBAGO	1-800-7267-864	www.samsung.com/latin
VENEZUELA	0-800-100-5303	www.samsung.com/latin	
Europe	COLOMBIA	01-8000112112	www.samsung.com/co
	BELGIUM	02 201 2418	www.samsung.com/be
	CZECH REPUBLIC	844 000 844 Distributor pro Českou republiku :Samsung Zrt., česká organizační složka Vyskočilova 4, 14000 Praha 4	www.samsung.com/cz
	DENMARK	36 322 887	www.samsung.com/dk
	FINLAND	09 883 79 554	www.samsung.com/fi
	FRANCE	3280 SAMSUNG or 08 25 08 65 65 (€ 0.15/Min)	www.samsung.com/fr
	GERMANY	01805 - 121213 (€ 0.14/Min)	www.samsung.de
	HUNGARY	06-80-SAMSUNG (7267864)	www.samsung.com/hu
	ITALIA	800-SAMSUNG (7267864)	www.samsung.com/it
	LUXEMBURG	0032 (0)2 201 24 18	www.samsung.lu
	NETHERLANDS	0900 20 200 88 (€ 0.10/Min)	www.samsung.com/nl
	NORWAY	231 627 22	www.samsung.com/no
	POLAND	0 801 801 881	www.samsung.com/pl
	PORTUGAL	30 8 200 128	www.samsung.com/pt
	SLOVAKIA	0800-SAMSUNG (7267866)	www.samsung.com/sk
	SPAIN	902 10 11 30	www.samsung.com/es
	SWEDEN	08 585 367 87	www.samsung.com/se
	U.K	0870 SAMSUNG (7267864)	www.samsung.com/uk
	CIS	Republic of Ireland	0818 717 100
Switzerland		0800-7267864	www.samsung.com/ch
RUSSIA		8-800-200-0400	www.samsung.ru
KAZAHSTAN		8-800-080-1188	www.samsung.kz
UZBEKISTAN		8-800-120-0400	www.samsung.uz
UKRAINE		8-800-502-0900	www.samsung.com/ur
LITHUANIA		8-800-77777	www.samsung.lt
LATVIA		800-7267	www.samsung.com/lv/index.htm
ESTONIA		800-7267	www.samsung.ee
Asia Pacific	AUSTRALIA	1300 362 603	www.samsung.com/au
	CHINA	800-810-5858, 010-6475 1880	www.samsung.com/cn
	HONG KONG	3688-4888	www.samsung.com/hk
	INDIA	3030 6282, 1800 110011	www.samsung.com/in
	INDONESIA	0800-112-8888	www.samsung.com/id
	JAPAN	0120-327-527	www.samsung.com/jp
	MALAYSIA	1800-38-9999	www.samsung.com/my
	PHILIPPINES	1800-10-SAMSUNG (7267864)	www.samsung.com/ph
	SINGAPORE	1800-SAMSUNG (7267864)	www.samsung.com/sg
	THAILAND	1800-29-3232, 02-889-3232	www.samsung.com/th
	TAIWAN	0800-329-999	www.samsung.com/tw
Middle East & Africa	VIETNAM	1 800 588 889	www.samsung.com/vn
	SOUTH AFRICA	0800 7267864 (SAMSUNG)	www.samsung.com/za
	U.A.E	800SAMSUNG (7267864), 8000-4726	www.samsung.com/ma



If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care center Samsung Electronics America, inc.

1-800-SAMSUNG (726-7864)

www.samsung.com



RoHS compliant

Our product complies with "The Restriction Of the use of certain Hazardous Substances in electrical and electronic equipment", and we do not use the 6 hazardous materials- Cadmium(Cd), Lead (Pb), Mercury (Hg), Hexavalent Chromium (Cr +6), Poly Brominated Biphenyls (PBBs), Poly Brominated Diphenyl Ethers(PBDEs)- in our products.

Code No. AD68-01307A - 00