


SEARS

operator's
manual

MODEL NO.
358.796920



SEARS CRAFTSMAN

GAS POWER BLOWER

2 Cycle Engine

Fuel Mix 16:1

- Assembly
- Maintenance
- Operation
- Repair Parts

⚠ WARNING:

Carefully read and follow all Safety Rules, Precautions and Operating Instructions. Failure to do so can result in serious personal injury.

Sold by Sears, Roebuck and Co., Chicago, ILL 60684 U.S.A.

FULL ONE YEAR WARRANTY ON SEARS CRAFTSMAN GAS POWER BLOWER

If this Blower unit fails to perform properly due to a defect in material or workmanship within one year of purchase, Sears will repair it, free of charge.

If this Blower unit is used for commercial or rental purposes this warranty coverage applies for only 90 days from the date of purchase.

WARRANTY SERVICE IS AVAILABLE BY CONTACTING THE NEAREST SEARS SERVICE CENTER THROUGHOUT THE UNITED STATES. THIS WARRANTY APPLIES ONLY WHEN THIS PRODUCT IS IN USE IN THE UNITED STATES.


SEARS, ROEBUCK AND CO /DEPT 698/731A/SEARS TOWER/CHICAGO, IL 60684

TABLE OF CONTENTS

<p>SAFETY RULES AND PRECAUTIONS 3</p> <p>KNOW YOUR UNIT 4</p> <p>ASSEMBLY 5</p> <p>ENGINE INFORMATION 7</p> <p style="padding-left: 20px;">A. Fueling Your Unit 7</p> <p style="padding-left: 20px;">B. Pre-Operation Checks 7</p> <p style="padding-left: 20px;">C. Starting Instructions 8</p> <p style="padding-left: 20px;">D. Engine Adjustments 9</p> <p>USING YOUR UNIT AS A BLOWER 10</p> <p style="padding-left: 20px;">A. Operating Instructions 10</p> <p style="padding-left: 20px;">B. Operating Tips 10</p>	<p>USING YOUR UNIT AS A VACUUM 11</p> <p style="padding-left: 20px;">(Optional Accessory Kit)</p> <p style="padding-left: 40px;">A. Operating Instructions 11</p> <p style="padding-left: 40px;">B. Operating Tips 11</p> <p>GENERAL MAINTENANCE 12</p> <p style="padding-left: 20px;">A. Air Filter Care 12</p> <p style="padding-left: 20px;">B. Fuel Tank Upkeep 12</p> <p style="padding-left: 20px;">C. Starter Rope Repair 12</p> <p style="padding-left: 20px;">D. Storage 13</p> <p>ACCESSORIES 13</p> <p>PARTS LIST 14</p>
--	---

SPECIFICATIONS

ENGINE TYPE:	2 Cycle Air Cooled	MUFFLER:	Lo Tone
DISPLACEMENT:	28.0 cc	VELOCITY:	150 mph
OPERATING RPM:	7500-8200	AIR VOLUME:	340 cu. ft./min.
IGNITION:	Solid State	SPARK PLUG:	CJ-8 (Cat. No. 71-36403)
CARBURETOR:	All Position - Diaphragm	SPARK PLUG GAP:	.024" - .027"
ON/OFF SWITCH:	Positive Toggle Switch	MODULE AIR GAP:	.010" - .014"
STARTER:	Auto Rewind	LUBRICATION:	Gasoline/Oil Mixture — See Page 7
FUEL TANK:	400 cc (13.5 fl. oz.)		



SAFETY RULES & PRECAUTIONS

Failure to follow all Safety Rules and Precautions could result in serious personal injury.

A. KNOW YOUR UNIT

1. Read your Operator's Manual carefully until you completely understand and can follow all safety rules, precautions, and operating instructions before operating the unit.
2. Restrict your unit to users who understand and follow all safety rules, precautions, and operating instructions found in this manual.

B. PLAN AHEAD

1. *Always wear eye protection to prevent rocks or debris from being blown or ricocheting into eyes and face which can result in loss of vision or serious personal injury.*
2. Always wear a respirator or facemask when working with the blower in dusty environments.
3. Dress safely in long pants. Do not wear loose clothing, jewelry, short pants or sandals; or go barefoot.
4. Do not operate the unit when you are tired, ill, or upset; or if you are under the influence of alcohol, drugs, or medication.
5. Keep children, bystanders and animals away from the work area, a minimum of 30 feet (10 meters), when starting or operating the unit.
6. Inspect the area before starting the unit. Remove all debris and hard or sharp objects such as rocks, glass, wire, etc. that can be blown or cause damage during operation. As a vacuum, the unit is designed to pick up dry material such as leaves, grass, small twigs and bits of paper. Do not vacuum stones, gravel, metal, broken glass etc. to avoid severe damage to the impeller. Do not attempt to vacuum water or other liquids to avoid damage to the engine.

C. HANDLE FUEL WITH CAUTION

1. Eliminate all sources of sparks or flame (including smoking, open flames, or work that can cause sparks) in the areas where fuel is mixed, poured, or stored.
2. Mix and pour fuel in an outdoor area; store fuel in a cool, dry, well-ventilated place; and use an approved, marked container for all fuel purposes.
3. Do not smoke while handling fuel or while operating the unit.
4. Do not fill the fuel tank while the engine is running or strapped to the operator.
5. Wipe up all spills before starting the engine.
6. Move at least 10 feet (3 meters) away from fuel and fueling site before starting the engine.

D. OPERATE YOUR UNIT SAFELY

1. Stop the engine before opening the vacuum inlet door or attempting to insert or remove the suction tube. The engine must be stopped and the impeller blades no longer turning to avoid contact with the rotating blades.
2. Inspect the entire unit before each use for worn, loose, or damaged parts. Do not use until the unit is in proper working order.
3. Keep the outside surfaces free of oil and fuel.
4. Never start or run the engine inside a closed room or building. Exhaust fumes contain dangerous carbon monoxide.
5. Do not wear rubber or any other insulated gloves when using the unit as a vacuum to avoid static electricity shock.

6. Do not set the unit on the ground to start the engine or while the engine is running. Debris such as gravel, sand, dust, grass, etc. could be picked up by the air intake and thrown out through the discharge opening, damaging the unit, property or causing serious personal injury to bystanders or the operator.
7. Avoid dangerous environments. Do not use in unventilated areas or where explosive vapors or carbon monoxide build up could be present.
8. Do not overreach or use from unstable surfaces such as ladders, trees, steep slopes, rooftops, etc. Keep firm footing and balance at all times.
9. Never place objects inside the blower tubes; always direct the blowing debris away from people, animals, glass, and solid objects such as trees, automobiles, walls, etc. The force of air can cause rocks, dirt, or sticks to be thrown or to ricochet which can hurt people or animals, break glass or cause other damage.
10. Never place any object in the air intake opening as this could restrict proper air flow and cause damage to the unit.
11. Never run the unit without the proper equipment attached. When used as a blower, always install a blower tube. When used as a vacuum, always install the suction tube and collection bag. Make sure the collection bag assembly is completely zipped when the unit is running to avoid flying debris.
12. Always use the shoulder strap attached to the collection bag when vacuuming to avoid loss of control.
13. Never use for spreading or misting chemicals, fertilizers or toxic substances.
14. Avoid situations that could catch the collection bag on fire. Do not operate near an open flame. Do not vacuum warm ash from fireplaces, barbecue pits, brush piles, etc. Do not vacuum discarded cigars or cigarettes unless cinders are completely cool.
15. Use only for jobs explained in this manual.

E. MAINTAIN YOUR UNIT PROPERLY

1. Maintain the unit according to recommended procedures.
2. Disconnect spark plug before performing maintenance except for carburetor adjustment.
3. Use only genuine replacement parts as recommended by Sears to avoid creating a hazard and/or voiding your warranty.
4. Check air intake openings and blower tubes frequently, always with the engine stopped. Keep vents and tubes free of debris which can accumulate and restrict proper air flow.
5. Never make engine adjustments with the unit strapped to the operator.
6. Drain fuel from the fuel tank before storing for 30 or more days.
7. Do not use any accessory or attachment other than those supplied by Sears for use with this particular unit.
8. Do not store the unit or fuel in a closed area where fuel vapors can reach sparks or an open flame from hot water heaters, furnaces, etc.
9. Store in a dry area out of the reach of children.

KNOW YOUR UNIT

A. INTRODUCTION

Your unit is a high performance product designed for tough jobs.

Special Features Include:

- One-handed Operation
- Direct Drive
- Vibration Dampened Handle
- Weight - 11.5 lbs.
- Convenient Upright Storage
- Easy Conversion to Vacuum Capability with the Optional Accessory Kit #71-79991.





B. UNPACKING INSTRUCTIONS

Your unit has been carefully packed at the factory to prevent damage during shipping and storage. Carefully unpack the carton as follows:

1. Remove contents from the carton.
2. Check parts against the list below.
3. Examine parts for damage.
4. *Notify your Sears Store immediately if a part is missing or damaged.*

CARTON CONTENTS:

KEY NO.		QTY.
1	Engine Assembly	1
2	Blower Tube	1
3	Nozzle	1
4	8 oz. 2-cycle Engine Oil	1
—	Operator's Manual - (Not Shown)	1



SPECIAL NOTICE

For users on U.S. Forest Land and in the states of California, Maine, Oregon and Washington. All U.S. Forest Land and the states of California (Public Resources Codes 4442 and 4443), Oregon and Washington require, by law, that certain internal combustion engines operated on forest, brush and/or grass-covered areas be equipped with a spark arrester, maintained in effective working order, or the engine be constructed, equipped and maintained for the prevention of fire. Check with your state or local authorities for regulations pertaining to these requirements. Failure to follow these requirements could subject you to liability or to a fine. **This unit is not factory-equipped with a spark arrester.** If these items are required in your area, ask your dealer to install Part # 69207.

ASSEMBLY

A. PREPARATION

Your Operator's Manual has been developed to help you assemble the unit and to understand its safe operation. It is important that you read your manual completely to become familiar with the unit *before* you begin assembly.

1. READ YOUR OPERATOR'S MANUAL.
2. No tools are required to assemble your blower.

B. BLOWER ASSEMBLY

1. Thread the nozzle onto the blower tube and firmly tighten.
2. Slide the blower tube and nozzle assembly into the engine housing until it bottoms out (approximately 2-1/2 inches). Figure 1.
3. Align the blower assembly so that it is pointing up toward the handle as shown in Figure 1.
4. Secure the blower assembly by tightening the knob shown in Figure 1 until hand-tight.





Figure 1

C. VACUUM CONVERSION

Your blower engine can be adapted to vacuum capability with the proper installation of the optional Vac Attachment Kit, Stock No. 71-79991, available through your Sears Store. Follow the assembly instructions below:

- **Kit Contents:**
 - Suction Tube
 - Clamp w/Screw
 - 2 Bushel, Heavy Duty Collection Bag w/Shoulder Strap
 - Adjustable Shoulder Strap (for engine)
- **The only tool you will need is a slotted screwdriver.**
 - 

⚠ WARNING

Stop engine before opening the vacuum inlet door or attempting to insert or remove the suction tube. The engine must be stopped and the impeller blades no longer turning to avoid contact with the rotating blades.




Figure 2

1. Stop Engine.
2. Loosen the knob (Figure 1) and remove the blower tube from the engine.
3. Set the unit on a flat surface as shown in Figure 2, and unthread the thumb nut holding the vacuum inlet door closed.
4. Using a screwdriver, unthread the screw holding the clamp together and separate the ends of the clamp.
5. Hold open the vacuum inlet door and slide one end of the open clamp under the vacuum inlet door hinge and around the clamping ring on the housing as shown in Figure 3.




Figure 3

- Reinstall the loose end of the clamp and turn the clamp screw with a screwdriver to loosely secure the clamp onto the unit.

NOTE: Observe that one end of the suction tube is cut at an angle and the other end is straight.

- Hold open the vacuum inlet door and slide the straight end of the suction tube into the opening until it bottoms out (about 3/4 inch). Figure 4.

NOTE: Make sure the warning decal and shorter angle of the suction tube is aligned with the blower outlet as shown in Figure 4.

- Secure the suction tube by tightening the clamp screw with a screwdriver.
- Slide the collection bag tube into the blower opening until it bottoms out (about 2-1/2 inches). Figure 5.
- Align the notch on the collection bag tube with the center seam of the blower outlet as shown in Figure 5, then secure the collection bag tube to the engine with the knob until hand-tight.
- Shoulder Strap Adjustments**
 - It is easier to put on the collection bag strap first, then the engine strap, clipping the strap to the engine last. Figure 6.
 - Try on both the collection bag and the engine shoulder straps and adjust for comfort before starting the engine.
 - Make sure the collection bag strap is adjusted to allow a free flow of air from the elbow tube as shown in Figure 7. If the bag is kinked, the unit will not operate properly.
 - Adjust the engine strap to support the weight of the engine leaving the hands free to guide the unit.

NOTE: The controls on the engine are directed forward when the unit is used as a vacuum. See operating position in Figure 14, page 11.




Figure 4




Figure 5




Figure 6

⚠ WARNING

Do not use the unit as a vacuum without the suction tube and collection bag properly attached to avoid flying debris and/or impeller contact which can cause serious personal injury. Always make sure the collection bag is completely zipped before the engine is started.

D. BLOWER CONVERSION

- Stop engine.
- Loosen the screw and knob on the clamps, then remove suction tube and collection bag assembly.
- Secure the vacuum inlet door closed by aligning the thumb nut on the door over the threaded stud on the engine housing and turning the thumb nut until finger-tight.
- Reinstall blower tube as shown on page 5

CAUTION: Over tightening the clamp screw can break the housing clamping ring. Retighten the clamp screw just enough to snugly secure the clamp on the housing.




Figure 7


ENGINE INFORMATION

A. FUELING YOUR UNIT (See "Specifications, page 2, for location of Fuel Cap.)

1. FUEL MIXTURE

- Your unit is powered by a 2-cycle engine which requires a fuel mixture of regular, unleaded gasoline and a high quality engine oil specially made for 2-cycle, air-cooled engines. The internal design of the 2-cycle engine requires lubrication of moving parts. Lubrication is provided when you use the recommended mixture of gasoline and oil.
- Gasoline must be clean and not over two months old. After a short period of time, gasoline begins to chemically break down and will form compounds that can cause hard starting and damage in 2-cycle engines.
- The correct measure of gasoline to oil is very important. Too much oil will foul the spark plug. Too little oil will cause the engine to overheat and freeze up.
- Always mix the fuel thoroughly in a container since gasoline and oil do not readily combine. *Do not try to mix fuel directly in the fuel tank.*

2. USE THE FOLLOWING:



3. HOW TO MIX FUEL

- a. Pour one-half of the gasoline into an approved marked container. *Do not try to mix fuel directly in the fuel tank.*
- b. Add entire measure of 2-cycle Engine Oil.
- c. Mix.
- d. Add remainder of gasoline.
- e. Mix thoroughly for one minute.

4. DO NOT USE:

- **BIA OIL (Boating Institute of America)** — Does not have proper additives for air-cooled, 2-cycle engines and could cause damage.
- **AUTOMOTIVE OIL** — Does not have proper additives for 2-cycle engines and could cause damage.
- **GASOLINE CONTAINING ALCOHOL (High Test, Premium or Gasohol)** — Stiffens critical carburetor fuel metering elements and causes engine damage from overheating. — Increases vapor lock (causes hard starting). — Attracts water causing corrosion damage.

5. IMPORTANT POINTS TO REMEMBER

- a. Use only recommended fuel mixtures.
- b. Eliminate all sources of sparks or flame in the areas where fuel is mixed, poured, or stored. There should be no smoking, open flames or work that can cause sparks.
- c. Use an approved, marked container for all fuel purposes.
- d. Mix and pour fuel in an outdoor area. Store fuel in a cool, dry, well-ventilated place. Gasoline vapors are harmful to your health and can cause serious hazards, such as explosion and fire. Use a funnel or spout when pouring fuel.
- e. Wipe up all fuel spills before starting the engine.
- f. Move at least 10 feet (3 meters) away from fuel and fueling site before starting the engine.

B. PRE-OPERATION CHECKS

Before operating your unit, always:

1. ✓ **CHECK OVER SAFETY RULES AND PRECAUTIONS** in this Operator's Manual. Make certain you completely understand and follow each one.
2. ✓ **CHECK THE AIR FILTER.** Clean the filter *before* operating the unit. See Figure 15.

3. ✓ CHECK THE UNIT FOR LOOSE BOLTS, NUTS, OR FITTINGS.

Tighten, repair or replace parts as necessary. Use only genuine replacement parts.

4. ✓ CHECK THE FUEL TANK.

Fill with a clean, fresh fuel mixture according to instructions in fuel mixture section.

A. STARTING INSTRUCTIONS (Refer to "Specifications," page 2, for location of controls.)

⚠ WARNING

Hold the unit for starting as shown in Figure 8. Do not set the unit on the ground to start the engine or while the engine is running. Debris such as gravel, sand, dust, grass, etc. could be picked up by the air intake and thrown out through the discharge opening, damaging the unit or property or causing serious personal injury to bystanders or the operator.

1. STARTING PROCEDURE

- Hold the unit in the starting position as shown in Figure 8. Make sure the end of the unit is directed away from people, animals, glass and solid objects.
- Move the ignition switch to the "On" position. Figure 9.
- Turn the throttle control knob clockwise to the "Fast" position. Figure 10.
- Turn choke knob to "On" position. Figure 11.
- Hold handle with your right hand and pull starter handle with your left hand until the engine fires (attempts to run).

NOTE: Do not let the starter rope snap back between pulls. Hold the handle and let the rope rewind slowly.

- Turn choke knob to "Half" position and pull starter handle until engine runs. Figure 11.
- Allow engine to warm-up as indicated below, then turn choke knob to the "Off" position. Figure 11
— Above 40°F, warm-up 10-20 seconds
— Below 40°F, warm-up 45-60 seconds.
- Stop engine by moving ignition switch to the "Off" position. Figure 9.

2. IMPORTANT POINTS

- When starting the engine, always pull the starter rope sharply and quickly, but not more than 10 times to avoid flooding the engine. If flooding occurs, turn choke to the "Off" position (Figure 11) and pull starter rope until engine starts.
- Start a cold engine with the choke at the "On" position. Figure 11.
- Start a warm engine with the choke at the "Off" position. If unit fails to start within 2 pulls, move choke to the "Half" position. Figure 11.



Figure 8




Figure 9

Figure 10








Figure 11

D. ENGINE ADJUSTMENTS

1. CARBURETOR ADJUSTMENTS

The carburetor has been carefully adjusted at the factory. Due to changes in altitude and operating conditions, your carburetor may require adjusting. To make the adjustment follow the procedure below very carefully:

a. PREPARATION

- 1.) Use fresh fuel mix. See Fuel Mixture page 7.
- 2.) Remove air filter.
- 3.) Turn mixture screw clockwise  until fully closed, but **do not overtighten**. Figure 12. Unscrew mixture screw one full turn counterclockwise .
- 4.) Turn **Idle Speed Screw** clockwise  until it stops. **Do not overtighten**. Open screw three full turns counterclockwise .










Figure 12

b. IDLE SPEED ADJUSTMENT


- 1.) Start the engine and turn throttle control to halfway between "Fast" and "Slow".
- 2.) Operate the unit for 3 minutes to warm up engine.
- 3.) Turn throttle control counterclockwise  to slow setting.
- 4.) Adjust **Idle Speed Screw**:
Clockwise  if the engine stalls:
Counterclockwise  to slow engine down.
- 5.) Adjust the **Idle Speed Screw** until the engine idles as slow as possible without the engine stalling.

CAUTION: The mixture setting is a highly critical adjustment. If set incorrectly, permanent damage will occur to the engine. Do not operate engine at fast throttle for prolonged periods while making the mixture adjustment.

c. MIXTURE ADJUSTMENT:

- 1.) Adjust throttle knob to "Fast" position.
- 2.) Turn the **Mixture Screw** slowly clockwise  until the engine speed is reduced. Note position.
- 3.) Turn the screw slowly counterclockwise . Stop when the engine just begins to run rough.
- 4.) Turn the screw slowly the **minimum amount** clockwise  until the engine runs smoothly.

NOTE 1: The mixture screw should be in the range of 3/4 to 1-1/4 turns open.

NOTE 2: For the best engine performance, it is better to run a slightly rich mixture setting (counterclockwise ) than too lean a setting.

d. REPLACE AIR FILTER

2. SPARK PLUG (Cat. No. 71-36403)

Check spark plug periodically and clean or replace as necessary. After cleaning, reset the electrode gap to ".025"

NOTES

USING YOUR UNIT AS A BLOWER

A. OPERATING INSTRUCTIONS

1. **Read your Operator's Manual.** Make certain you completely understand and can follow all safety rules, precautions, and operating instructions, before operating the unit.
2. **Always wear eye protection to prevent rocks or debris from being blown or ricocheting into eyes and face which can result in loss of vision or serious personal injury.**
3. **Always wear a respirator or facemask when working in dusty environments.**
4. **Dress safely in long pants.** Do not wear loose clothing, jewelry, short pants or sandals; or go barefoot.
5. **Check the unit before operation.** Look for worn, loose, or damaged parts. Do not use until the unit is in proper working order.
6. **Inspect the area before starting unit.** Remove all debris and hard objects such as rocks, glass, wire, etc that can be blown or cause damage during operation.
7. **Keep observers, children, bystanders, and animals safely away.** Before starting the engine and during operation, make certain children, animals and bystanders are away from the work area - a minimum of 30 feet (10 meters).
8. **Check air intake opening and blower tubes frequently, always with the engine stopped.** Keep vents and discharge tubes free of debris which can accumulate and restrict proper air flow.
9. **Use the correct operating position.** (Figure 13.) Do not overreach or use from unstable surfaces such as ladders, trees, steep slopes, roof tops, etc. Keep firm footing and balance at all times.
10. **Never place objects inside the blower tubes; always direct the blowing debris away from people, animals, glass, and solid objects such as trees, automobiles, walls, etc.** The force of air can cause rocks, dirt, or sticks to be thrown or to ricochet which may hurt people or animals, break glass, or cause other damage.



Figure 13

⚠ WARNING

Hold the unit for starting as shown in Figure 8. Do not set the unit on the ground to start the engine or while the engine is running. Debris such as gravel, sand, dust, grass, etc. could be picked up by the air intake and thrown out through the discharge opening, damaging the unit or property or causing serious personal injury to bystanders or the operator.

B. OPERATING TIPS

1. **Always work going away from solid objects such as walls, large stones, automobiles and fences.**
2. **Clean spaces with corners by starting in corners and moving outward to straight areas** to prevent an accumulation of debris which could fly into face.
3. **Be careful when working near valuable plants.** The force of the air could damage tender plants.
4. **Direct air flow by adjusting the nozzle.**
5. **Run the engine at full throttle for full air power.**
6. **Vary or reduce the air flow by setting the throttle knob at any position from "Fast" to "Slow."**
7. **Use the handle located on the bottom of the unit below the control panel when working above the waist or when a two-handed grip is desired.** Refer to the unit drawing, page 2, and Figure 13, this page.

⚠ WARNING

Always wear eye protection to prevent rocks or debris from being blown or ricocheting into the eyes and face which can result in loss of vision or serious personal injury.

8. Uses For Your Blower:

- a. Sweeping debris or grass clippings from driveways, sidewalks, patios, park, parking lots, barns, stadiums, etc
- b. Gathering grass clippings, straw or leaves into piles.
- c. Fast drying wet, outdoor areas such as a patio
- d. Removing debris from corners, around joints and between bricks
- e. Blowing light snow from driveways, sidewalks or patios.

USING YOUR UNIT AS A VACUUM — Optional Accessory Kit

A. OPERATING INSTRUCTIONS

As a vacuum, the unit is designed to pick up dry material such as leaves, grass, small twigs and bits of paper. Do not attempt to vacuum stones, gravel, metal, broken glass, etc. to avoid severe damage to the impeller.

1. **Read your Operator's Manual.** Make certain you completely understand and can follow all safety rules, precautions, and operating instructions, before operating the unit
2. **Always wear eye protection to prevent rocks or debris from being blown or ricocheting into eyes and face which can result in loss of vision or serious personal injury.**
3. **Dress safely in long pants.** Do not wear loose clothing, jewelry, short pants or sandals; or go barefoot.
4. **Check the unit before operation.** Look for worn, loose, or damaged parts. Do not use until the unit is in proper working order.
5. **Inspect the area before starting the unit.** Remove all debris and objects such as rocks, glass, wire, large sticks, etc. that can cause damage during operation.
6. **Keep observers, children, bystanders, and animals safely away.** Before starting the engine and during operation make certain people and animals are away from the work area - a minimum of 30 feet (10 meters).
7. **Check air intake opening and collection bag tube frequently, always with the engine stopped.** Engine RPM will increase significantly when the suction or collection bag tube is clogged. Keep vents and tubes free of debris which can accumulate and restrict proper air flow.
8. **Use the correct operating position.** (Figure 14.) Do not overreach or use from unstable surfaces such as ladders, trees, steep slopes, roof tops, etc. Keep firm footing and balance at all times.
9. **Do not wear rubber or any other insulated gloves to avoid static electricity shock.**

10. **Never run the unit without the proper equipment attached.** Always install the suction tube and collection bag. Make sure the collection bag assembly is completely zipped when the unit is in use to avoid flying debris.
11. **Always use the collection bag and engine shoulder straps to avoid loss of control.**

⚠ WARNING

Do not insert or remove suction tube with engine running to avoid serious personal injury. Always stop the engine before unclogging the unit or performing any maintenance on the collection bag.




Figure 14

B. OPERATING TIPS

1. **Move the unit slowly back and forth over debris to be vacuumed.** Avoid forcing the suction tube into a pile of debris as this can clog the unit.
2. **If the unit becomes clogged:**
 - a. Stop the engine and disconnect the spark plug. Do not attempt to remove obstructions with engine running.
 - b. Wait until the impeller has completely stopped turning, then remove the suction tube.
 - c. Carefully reach into the vacuum opening and clear out debris
3. **The collection bag must be properly emptied and maintained to avoid deterioration and obstructing air flow which will reduce the performance of the vacuum.**
 - a. Empty the bag after each use. Do not store bag containing wet grass, leaves, etc.
 - b. Clean the bag after every three uses by turning the bag inside out after initial emptying and vigorously shaking out dust and excess debris.
 - c. Wash the bag once a year
 - 1). Turn bag inside out
 - 2). Hang up
 - 3). Hose down thoroughly
 - 4). Hang to dry

GENERAL MAINTENANCE

A. AIR FILTER CARE

A dirty air filter decreases engine performance and increases fuel consumption.

Clean the Air Filter:

- Frequently,
- Always clean after 5 tanks of fuel or 5 hours of operation, whichever is less.

Follow these steps:

1. Remove the air filter (located above the control panel; see Figure 15).
2. Wash in soap and water.

CAUTION: Do not clean filter in gasoline or other flammable solvent to avoid creating a fire hazard.

3. Squeeze filter dry.
4. Add a small amount of oil to coat the filter.

NOTE: Avoid soaking the filter with oil.

5. Squeeze out excess oil.
6. Replace the air filter.

NOTE: Make sure the filter is properly fitted into the housing, paying particular attention to the corners.

B. FUEL TANK UPKEEP

Never use gasoline that is more than 2 months old in a fuel mixture. Gasoline begins to break down after a short period of time and will form compounds that cause hard starting and damage in 2-cycle engines.

1. Inspect the unit for fuel leaks each time it is used. Repair or replace parts as necessary.
2. Always begin operation with a clean, fresh mixture of fuel.
3. Drain all fuel from the unit or allow unit to run out of fuel before storing for 30 or more days.

C. STARTER ROPE REPAIR

- Repair the starter rope if the rope breaks next to the pulley.
- Replace the starter rope if the rope breaks more than 2-3 inches away from the pulley as the rope will be too short to repair properly.

⚠ WARNING

Always wear eye protection when servicing the starter rope. The recoil spring, located beneath the pulley, is under tension. If the spring pops out, serious personal injury can result.

- To repair or replace:
 1. Disconnect the spark plug wire and remove the 6 screws from the fan housing. Figure 16.
 2. Separate the fan housing completely from the shroud.




Figure 15




Figure 16

- If the starter rope is not broken, release the spring's tension by pulling about 10 inches of rope from the pulley and catching the rope in the notch as shown. Figure 17. If the rope is broken, remove the broken piece.

NOTE: The tension on the starter spring will be released if the rope is broken.

- Remove screw and pulley very carefully. Figure 17. **The recoil spring which lies beneath the pulley must stay in the housing, flat against the bottom. If the spring is disturbed, it will require considerable time and effort to reinstall.** Twist the pulley gently counter clockwise ← as you pull up to release the spring.
- Move away from the fuel tank and melt the end of the rope to go into the pulley.
- Allow the melted end to drip once; then while the rope is still hot, pull the melted end through a rag to obtain a smooth, pointed end
- Insert rope through the rope exit hole in the fan housing.
- Snake rope inside the pulley, then through topside pulley hole by pushing the rope from the underside hole with a small round object such as a Phillips screwdriver. See Insert, Figure 18.
- Wrap rope counterclockwise ← around pulley ratchet and tuck loose end back under rope leaving a 3/8 to 1/4 inch tail. Figure 18. Pull tightly.
- Wind all but about 10 inches of the rope counter clockwise ← around pulley.
- Replace pulley in the housing. Be sure the pulley is all the way down and the spring is secured.
- Replace and tighten pulley screw. Figure 17.
- Hold the 10 inch slack in the rope and catch rope in pulley notch. Figure 19.
- Hold the rope taut and make 2 complete turns of the pulley counterclockwise ← to place tension on the pulley. Hold the pulley to retain tension.

- Align pulley notch with rope exit hole, pull starter handle to the full extent of the rope and allow the rope to slowly wind around the pulley
- Reinstall the fan housing to the shroud.




Figure 17




Figure 18




Figure 19

D. STORAGE


- Clean the unit before storing.** Pay particular attention to the air intake area, keeping it free of debris. Use a mild detergent and sponge to clean the plastic surfaces.
- Do not store the unit or fuel in a closed area where fuel vapors can reach sparks or an open flame from hot water heaters, furnaces, etc.**
- Store in a dry area out of reach of children.**

ACCESSORIES

VACUUM ATTACHMENT KIT	71-79991
2-CYCLE ENGINE OIL	71-36555
SPARK PLUG	71-36403
SHOULDER STRAP KIT (for Engine)	71-85783

SEARS BLOWER PARTS LIST — MODEL 358.796920

Figure 1



SEARS BLOWER PARTS LIST — MODEL 358.796920

Figure 1


KEY NO.	PART NO.	QTY.	DESCRIPTION	KEY NO.	PART NO.	QTY.	DESCRIPTION
1	10828	1	Ass'y - Handle (Incl. #2)	31	26776	1	Deflector - Heat
2	15635	2	Screw - 10 - 14 x 11/16 Bind. Hd. - Handle	32	10824*	1	Shroud - (Incl. #12 & 45)
5	24256	3	Isolator - Handle	33	10835	1	Ass'y - Blower Hsg. (Incl. 9 of #38)
6	15343	1	Spacer - Isolator (Front)	34	94215	1	Impeller
7	26163	6	Cup - Isolator	35	15661	1	Screw - 10 - 14 x 88 - Blower Hsg./Inlet Door
8	15629	2	Washer #8 - Front	37	15064	1	Nut - 10 - 24
9	15628	2	Screw - 8 - 32 x 7/16 Bind Hd. - Fan Hsg /Crankcase	38	15367	10	Screw - 10 - 14 x 3/4 Pivot Pin/Blower Hsg
10	15561	2	Screw - 12 - 11 x 2	39	15644	1	Nut - Impeller
11	15342	2	Spacer - Isolator (Rear)	40	15441	1	Washer - Conical - Impeller
12	32091*	1	Bearing-Ball (Shroud)	41	15626	1	Washer - Flat - Impeller
13	15678	2	Screw - 10 - 24 x 5/8 Bind Hd. - Fan Hsg /Crankcase	42	15632	4	Screw - 1/4 - 20 x 7/8 - Blower Hsg /Shroud
14	24371	1	Air Filter	43	15682	4	Washer - Blower Hsg /Shroud
15	15676	4	Screw - 10 - 24 x 7/8 - Fan Housing	44	15168	4	Screw - 10 - 24 x 5/8 - Shroud/Crankcase
16	15677	4	Washer - Fan Hsg	45	1516	1	Retainer-Bearing-Shroud
17	10821	1	Fan Housing	46	15667	1	Spring - Tension (Right)
18	42023	1	Spring - Starter Pulley	47	15647	1	Pin - Pivot
19	26780	1	Baffle - Air	48	15672	1	Spring - Tension (Left)
20	28626	1	Pulley Starter	49	94241	1	Ass'y - Inlet Door
21	15479	1	Screw - 10 - 3/4 Hex Hd. - Pulley	50	15638	1	Screw - 1/4 x 20 1/2 - Retainer
22	15123	1	Washer - Starter Pulley	51	15637	1	Retainer - Fuel Tank
23	15544	4	Screw - 10 x 3/8 Pan Hd. - Air Baffle	52	26781	1	Cushion - Fuel Tank
24	22289	1	Rope (3 ft)	53	91878	1	Ass'y - Fuel Pick-up
25	26735	1	Handle - Starter Rope	54	21058	1	Line - Fuel - Tank
27	15664	1	Bolt - 1/4 - 20 x 1-1/2 - Clamp	56	10729	1	Ass'y - Fuel Cap w/Retainer
28	94222	1	Clamp - Blower Tube	57	10815	1	Ass'y - Fuel Tank
29	94242	1	Knob - Clamp				(Incl #53, 54 & 56)
30	15636	3	Screw - 10 - Heat Deflector	DECALS			
				101	26778	1	Decal - Instruction
				102	26777	2	Decal - (Left & Right) Fan Housing
				103	26925	1	Decal - Warning-Blower Hsg

Key Nos. Excluded: #3, 4, 26, 36 & 55

*When removing or installing the bearing (#32091), the area of the shroud (#10824) receiving the bearing must be heated to approximately 300°F. to avoid damaging the shroud.

SEARS BLOWER PARTS LIST — MODEL 358.796920

Figure 2



SEARS BLOWER PARTS LIST — MODEL 358.796920

Figure 2


KEY NO.	PART NO.	QTY.	DESCRIPTION	KEY NO.	PART NO.	QTY.	DESCRIPTION
1	12112	1	Cylinder	42	15676	1	Screw - 10-24x7/8- Carburetor
2	19111	1	Gasket - Cylinder	43	35196	1	Carburetor
3	26681	2	Ring - Piston 28cc	44	15254	1	Washer - Wave - Carburetor
4	15162	2	Retainer - Wrist Pin	45	15673	1	Spacer - Carburetor
5	15239	2	Screw - 1/4 - 20 x 3/4 - Hex Soc Hd. - Cylinder	46	15630	1	Screw - 10 - 24 x 2 3/8 - Carb. Shoulder
6	26949	1	Diffuser - Muffler	47	15654	1	Ring - External Retaining - Throttle
7	10809	1	Ass'y - Body-Muffler	48	15147	1	Washer - Wave - Throttle
8	24361	1	Cover - Muffler	49	15407	1	Screw - 8 - 32 x 5/16 Pan Hd. - Choke Knob
9	24903	2	Spring - Muffler Attachment	50	26773	1	Actuator - Choke
10	69203	1	Piston Kit (Incl.#3, 4 & Pin)	51	15147	1	Washer - Wave - Choke
11	94219	1	Shaft - Arbor	52	26764	1	Cover - Carb. Case
12	94218	2	Coupling - Shaft	53	23807	1	Knob - Choke
13	94243	1	Coupling - Plastic	54	15675	4	Screw - 8 - 18 x 5/8 Phil.
14	626605	1	Nut - Flywheel - 5/16 x 24	55	15660	1	Screw 10 - 14 x 3/8 - Throttle
15	23817	2	Spring - Starter Dog	56	15658	1	Washer - Flat Throttle
18	26765	1	Ass'y - Crankshaft & Rod	57	15614	1	Knob - Throttle
19	32057	1	Bearing - Wrist Pin	58	23575	1	Nut - Grounding Switch
20	15351	2	Washer - Thrust - Crankcase	59	24569	1	Washer - Ground
21	32058	2	Bearing - Crankshaft	60	26766	1	Switch Toggle (Incl. #58, 59, 62, 63)
22	10819	1	Crankcase Ass'y. (Incl. #21 & 23)	61	26771	1	Ass'y - Throttle Wire
23	19059	2	Seal - Crankcase	62	26950	1	Wire - Ignition
26	15377	1	Washer - Coupling	63	26829	1	Wire - Ground
27	15126	1	Key - Flywheel	64	24435	1	Grommet - Plug Wire
28	15168	4	Screw - 10 - 24 x 5/8 Fil. Hd. Crankcase	65	15128	2	Screw - 8 - 32 x 3/4 Fil. Hd. - Ignition Module
29	39111	1	Flywheel Assembly (Incl. #15)	66	39124	1	Ignition Module
30	15127	1	Washer - Flywheel	67	STD360946	1	Spark Plug (CJ-8) - (Cat. No. 71-36403)
31	24438	1	Reed Valve	68	3933	1	Connector - Spark Plug Lead
32	19108	1	Gasket - Carburetor Case to Crankcase	69	3934	1	Boot - Spark Plug
33	19105	1	Seal - Carburetor Case	70	39082	1	High Tension Lead Wire
34	15241	1	Screw - 6 - 19 x 5/16 - Pan Hd. - Reed Valve	71	39103	1	High Tension - Lead Assembly - (Incl. #68, 69, & 70)
35	23367	1	Washer - Reed Valve Screw	72	30054	1	Sealant - Crankcase - (Not Supplied With Unit)
36	26818	1	Case - Carburetor	73	69207	1	Spark Arrestor-Kit (Not Supplied With Unit)
37	19115	1	Gasket - Carburetor				
38	25472	1	Fitting - Fuel Line				
39	21056	1	Line - Fuel - Carburetor				
40	26797	1	Guide Plate - Choke				
41	26772	1	Shutter - Choke				

Key Nos. Excluded: #16, 17, 24, & 25

SEARS BLOWER PARTS LIST — MODEL 358.796920

CARBURETOR ASSEMBLY — #35196


Figure 3



KEY NO.	PART NO.	DESCRIPTION
1	35197	Valve Throttle
2	35015	Screw-Throttle Valve
3	35132	Shaft Assembly-Throttle
4	35156	Idle Speed Screw
5	35138	Spring-Throttle Return
7	35200	Spring-High Speed Mixture Needle
8	35198	Needle-High Speed Mixture
9	35162	* Plug-5/16 Dia Welch
11	35017	Screw-Pump Cover
12	35191	Cover-Fuel Pump
13	35164	+* Gasket-Fuel Pump
14	35166	+* Diaphragm-Fuel Pump
15	35178	Screen-Fuel Inlet
18	35007	Ring-Throttle Retainer
19	35008	* Valve-Inlet Needle
20	35139	* Spring-Metering Lever
21	35031	* Lever-Metering
22	35028	* Pin-Metering Lever
23	35016	* Screw-Metering Lever Pin
24	35151	+* Gasket-Metering Diaphragm
25	35014	+* Diaphragm-Metering
26	35003	Cover-Metering Diaphragm
27	35021	Screw Assembly-Metering Cover
—	35199	Kit-Repair (includes parts marked*)
—	35186	Kit-Gasket/Diaphragm (includes parts marked +)


SEARS BLOWER PARTS LIST — MODEL 358.796920

Figure 4



KEY NO.	QTY.	PART NO.	DESCRIPTION
1	1	94225	Nozzle - Blower
2	1	94224	Tube - Blower (Upper)
3	1	66517	Operator's Manual

VACUUM KIT #71-79991 (Optional Accessory Kit)



KEY NO.	QTY.	PART NO.	DESCRIPTION
1	1	94394	Strap-Shoulder-Engine
2	1	94231	Tube-Collection Bag
3	1	94227	Bag-Collection w/Strap
4	1	15671	Strap-Tie
5	1	94230	Clamp-Suction Tube
6	1	94232	Tube-Suction
		Decal	
101	1	26937	Decal - Suction Tube

SEARS operator's manual

MODEL NO.
358.796920

How to Order Repair Parts

**SEARS SERVICE
IS AT YOUR SERVICE**


The Model Number will be found under the handle with the Serial Number. Always mention the Model Number when requesting service or repair parts for your unit.

All parts listed herein may be ordered from any Sears Service Center and most Sears Stores

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION AS SHOWN IN THIS LIST.

- | | |
|---|---|
| 1 The PART NUMBER | 3 The PART DESCRIPTION |
| 2 The MODEL NUMBER
358.796920 | 4 The NAME OF ITEM —
GAS POWER BLOWER |

If the parts you need are not stocked locally, your order will be electronically transmitted to a Sears Repair Parts Distribution Center for expedited handling.



When you buy merchandise from Sears you get an extra something that nobody else can offer. Sears Service.

Across town or across the country, Sears Service follows you, providing trustworthy, competent service technicians using only Sears specified factory parts

Your Sears Merchandise takes on added value when you discover that Sears has Service Units throughout the country. Each is staffed by Sears-Trained, professional technicians using Sears approved methods.

Sears, Roebuck and Co., Chicago, ILL. 60684 U.S.A.