

# SHARP®

## MODELS

**R-230B**

**R-220B**

**R-209B**

**R-204C**

K= black

W= white

## MICROWAVE OVEN OPERATION MANUAL

### CONTENTS

- For Customer Assistance ..... Inside Front Cover
- Precautions to Avoid Possible Exposure to Excessive Microwave Energy ..... Inside Front Cover
- Product Information Card ..... 1
- Consumer Limited Warranty ..... 1
- Important Safety Instructions ..... 2
- Unpacking and Installation Instructions ..... 3
- Grounding Instructions ..... 3
- Information You Need to Know ..... 4
- Part Names ..... 7
- Control Panel Illustrations ..... 8
- Before Operating ..... 9
- Manual Operation ..... 9
- Special Features ..... 10
- Other Convenient Features ..... 12
- Cleaning and Care ..... 14
- Service Call Check ..... 15
- Specifications ..... 15
- Cooking Reference ..... 16
- Guia Auto-Touch ..... Parte Interior de la Cubierta Trasera
- Auto-Touch Guide ..... Back Cover

**Read all instructions carefully before using your oven.**

## FOR CUSTOMER ASSISTANCE

To aid in reporting this microwave oven in case of loss or theft, please record below the model number and serial number located on the unit. We also suggest you record all the information listed and also save the original sales receipt for future reference.

MODEL NUMBER \_\_\_\_\_ SERIAL NUMBER \_\_\_\_\_  
DATE OF PURCHASE \_\_\_\_\_  
Dealer \_\_\_\_\_ Telephone \_\_\_\_\_  
Servicer \_\_\_\_\_ Telephone \_\_\_\_\_

TO PHONE: DIAL 1 - 800 - BE - SHARP ( 237 - 4277 ) for :

SERVICE (for your nearest Sharp Authorized Servicer)

PARTS (for your authorized parts distributor)

ADDITIONAL CUSTOMER INFORMATION

DIAL 1-800-642-2122 for :

ACCESSORIES and COOKBOOK

DIAL (201)529-8703 for :

COOKING ASSISTANCE

TO WRITE:

For cooking and operation questions:

Susan Edwards/Test Kitchen  
Sharp Electronics Corporation  
Sharp Plaza, Box 650  
Mahwah, NJ 07430-2135

For service problems, warranty information, missing items and other assistance:

Sharp Electronics Corporation  
Customer Assistance Center  
1300 Naperville Drive  
Romeoville, IL 60446-1091

Please provide the following information when you write or call: model number, serial number, date of purchase, your complete mailing address (including zip code), your daytime telephone number (including area code) and description of the problem.

## PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not attempt to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.
- (b) Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- (c) Do not operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- (d) The oven should not be adjusted or repaired by anyone except properly qualified service personnel.

# CONSUMER LIMITED WARRANTY

SHARP ELECTRONICS CORPORATION warrants to the first consumer purchaser that this Sharp brand product (the "Product"), when shipped in its original container, will be free from defective workmanship and materials, and agrees that it will, at its option, either repair the defect or replace the defective Product or part thereof with a new or remanufactured equivalent at no charge to the purchaser for parts or labor for the time period(s) set forth below.

This warranty does not apply to any appearance items of the Product nor to the additional excluded item(s) set forth below nor to any Product the exterior of which has been damaged or defaced, which has been subjected to improper voltage or other misuse, abnormal service or handling, or which has been altered or modified in design or construction.

In order to enforce the right under this limited warranty, the purchaser should follow the steps set forth below and provide proof of purchase to the servicer.

The limited warranty described herein is in addition to whatever implied warranties may be granted to purchasers by law. ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD(S) FROM THE DATE OF PURCHASE SET FORTH BELOW. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein, or to extend the duration of any warranties beyond the time period described herein on behalf of Sharp.

The warranties described herein shall be the sole and exclusive warranties granted by Sharp and shall be the sole and exclusive remedy available to the purchaser. Correction of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of Sharp to the purchaser with respect to the Product, and shall constitute full satisfaction of all claims, whether based on contract, negligence, strict liability or otherwise. In no event shall Sharp be liable, or in any way responsible, for any damages or defects in the Product which were caused by repairs or attempted repairs performed by anyone other than an authorized servicer. Nor shall Sharp be liable or in any way responsible for any incidental or consequential economic or property damage. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

Your Product Model Number : R-230B, R-220B, R-209B, or R-204C. Home Use Carousel Microwave  
& Description Oven  
(Be sure to have this information available when you need service for your Product.)

Warranty Period for this Product: One (1) year parts and labor. The warranty period continues for an additional four (4) years, for a total of five (5) years, with respect to the magnetron tube in the Product for parts only; labor and service are not provided free of charge for this additional period.

Additional Items Excluded from Warranty Coverage: Non-functional accessories, turntable and light bulb.

Where to Obtain Service: From a Sharp Authorized Servicer located In the United States. To find the location of the nearest Sharp Authorized Servicer, call Sharp toll free at 1-800-BE-SHARP. (1-800-237-4277)

What to do to Obtain Service: Ship (prepaid) or carry in your Product to a Sharp Authorized Servicer. Be sure to have **Proof of Purchase** available. If you ship or mail the Product, be sure it is insured and packaged securely.

TO OBTAIN SUPPLY, ACCESSORY OR PRODUCT INFORMATION, CALL **1-800-BE-SHARP**  
OR VISIT **www.sharp-usa.com**.

Save the proof of purchase as it is needed should your oven ever require warranty service.

## PRODUCT INFORMATION CARD

The product information card which is on the inside of the microwave oven carton should be completed within ten days of purchase and returned. We will keep it on file and help you access the information in case of loss, damage or theft. This will also enable us to contact you in the unlikely event that any adjustments or modifications are ever required for your oven.

# **IMPORTANT SAFETY INSTRUCTIONS**

When using electrical appliances basic safety precautions should be followed, including the following:

**WARNING** - To reduce the risk of burns, electric shock, fire, injury to persons or exposure to excessive microwave energy:


1. Read all instructions before using the appliance.
2. Read and follow the specific "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY" on inside front cover.
3. This appliance must be grounded. Connect only to properly grounded outlet. See "GROUNDING INSTRUCTIONS" on page 3.
4. Install or locate this appliance only in accordance with the provided installation instructions.
5. Some products such as whole eggs and sealed containers -- for example, closed glass jars - - may explode and should not be heated in this oven.
6. Use this appliance only for its intended use as described in this manual. Do not use corrosive chemicals or vapors in this appliance. This type of oven is specifically designed to heat, cook or dry food. It is not designed for industrial or laboratory use.
7. As with any appliance, close supervision is necessary when used by children.
8. Do not operate this appliance if it has a damaged cord or plug, if it is not working properly or if it has been damaged or dropped.
9. This appliance should be serviced only by qualified service personnel. Contact nearest Sharp Authorized Servicer for examination, repair or adjustment.
10. Do not cover or block any openings on the appliance.
11. Do not store or use this appliance outdoors. Do not use this product near water--for example, near a kitchen sink, in a wet basement or near a swimming pool, and the like.
12. Do not immerse cord or plug in water.
13. Keep cord away from heated surfaces.
14. Do not let cord hang over edge of table or counter.
15. See door surface cleaning instructions on page 14.
16. To reduce the risk of fire in the oven cavity:
  - a. Do not overcook food. Carefully attend appliance if paper, plastic or other combustible materials are placed inside the oven to facilitate cooking.
  - b. Remove wire twist-ties from paper or plastic bags before placing bag in oven.
  - c. **If materials inside the oven should ignite, keep oven door closed, turn oven off, and disconnect the power cord or shut off power at the fuse or circuit breaker panel.**
  - d. Do not use the cavity for storage purposes. Do not leave paper products, cooking utensils or food in the cavity when not in use.
17. If the oven light fails, consult a SHARP AUTHORIZED SERVICER.

## **SAVE THESE INSTRUCTIONS**

# UNPACKING AND INSTALLATION INSTRUCTIONS

## Unpacking and Examining Your Oven

Remove:



1. all packing materials from inside the oven cavity; however, **DO NOT REMOVE THE WAVEGUIDE COVER**, which is located on the right side in the oven cavity. Read enclosures and **SAVE** the Operation Manual.
2. the feature sticker from the outside of the door, if there is one.

Check the oven for any damage, such as misaligned or bent door, damaged door seals and sealing surfaces, broken or loose door hinges and latches and dents inside the cavity or on the door. If there is any damage, do not operate the oven and contact your dealer or SHARP AUTHORIZED SERVICER.

## Choosing a Location for Your Oven

You will use the oven frequently so plan its location for ease of use. It's wise, if possible, to have counter space on at least one side of the oven. Allow at least 2 inches on the sides, top and at the rear of the oven for air circulation.

Do not place or install the oven in any area where heat and steam are generated; for example, next to or above a conventional gas or electric range or above a conventional wall oven. Heat and steam may damage the electronics or the mechanical parts of the oven.

# GROUNDING INSTRUCTIONS

This appliance must be grounded. This oven is equipped with a cord having a grounding wire with a grounding plug. It must be plugged into a wall receptacle that is properly installed and grounded in accordance with the National Electrical Code and local codes and ordinances. In the event of an electrical short circuit, grounding reduces risk of electric shock by providing an escape wire for the electric current.

**WARNING** – Improper use of the grounding plug can result in a risk of electric shock.

## Electrical Requirements

The electrical requirements are a 120 volt 60 Hz, AC only, 15 amps. or more protected electrical supply. It is recommended that a separate circuit serving only this appliance be provided.

The oven is equipped with a 3-prong grounding plug. It must be plugged into a wall receptacle that is properly installed and grounded. Should you only have a 2-prong outlet, have a qualified electrician install a correct wall receptacle.

A 3-prong adapter may be purchased and used temporarily if local codes allow. Follow package directions.

A short power-supply cord is provided to reduce risk of becoming entangled in or tripping over a longer cord.

## Extension Cord

If it is necessary to use an extension cord, use only a 3-wire extension cord that has a 3-blade grounding plug and a 3-slot receptacle that will accept the plug on the microwave oven. The marked rating of the extension cord should be AC 115-120 volt, 15 amps. or more.

Be careful not to drape the cord over the countertop or table where it can be pulled on by children or tripped over accidentally.


Notes:

1. If you have any questions about the grounding or electrical instructions, consult a qualified electrician or serviceworker.
2. Neither Sharp nor the dealer can accept any liability for damage to the oven or personal injury resulting from failure to observe the correct electrical connection procedures.


## Radio or TV Interference

Should there be any interference caused by the microwave oven to your radio or TV, check that the microwave oven is on a different electrical circuit, relocate the radio or TV as far away from the oven as feasible or check position and signal of receiving antenna.

### Permanent and Correct Installation



### Temporary Use



# INFORMATION YOU NEED TO KNOW

## About Your Oven

This Operation Manual is valuable: read it carefully and always save it for reference;

A good microwave cookbook is a valuable asset. Check it for microwave cooking principles, techniques, hints and recipes. See ordering information on page 16 for the Ultimate Accessory, the SHARP CAROUSEL MICROWAVE COOKBOOK.

**NEVER** use the oven without the turntable and support nor turn the turntable over so that a large dish could be placed in the oven. The turntable will turn both clockwise and counterclockwise.

**ALWAYS** have food in the oven when it is on to absorb the microwave energy.

When using the oven at power levels below 100%, you may hear the magnetron cycling on and off. It is normal for the exterior of the oven to be warm to the touch when cooking or reheating.

Condensation is a normal part of microwave cooking. Room humidity and the moisture in food will influence the amount of moisture that condenses in the oven. Generally, covered foods will not cause as much condensation as uncovered ones. Vents on the oven back must not be blocked.

The oven is for food preparation only. It should not be used to dry clothes or newspapers.

Your oven is rated 700 watts. In using recipes or package directions, check food a minute or two before the minimum time and add time accordingly.

## About Food

	DO	DON'T
Eggs, sausages, nuts, seeds, fruits & vegetables	<ul style="list-style-type: none"> <li>* Puncture egg yolks before cooking to prevent "explosion".</li> <li>* Pierce skins of potatoes, apples, squash, hot dogs and sausages so that steam escapes.</li> </ul>	<ul style="list-style-type: none"> <li>* Cook eggs in shells.</li> <li>* Reheat whole eggs.</li> <li>* Dry nuts or seeds in shells.</li> </ul>
Popcorn	<ul style="list-style-type: none"> <li>* Use specially bagged popcorn for the microwave oven.</li> <li>* Listen while popping corn for the popping to slow to 1 or 2 seconds or use special POPCORN pad.</li> <li>* Place carefully so bag does not touch oven walls. The corners of the bag may be folded down.</li> </ul>	<ul style="list-style-type: none"> <li>* Pop popcorn in regular brown bags or glass bowls.</li> <li>* Use bags with weight over 3.5 oz.</li> <li>* Exceed maximum time on popcorn package.</li> </ul>
Baby food	<ul style="list-style-type: none"> <li>* Transfer baby food to small dish and heat carefully, stirring often. Check temperature before serving.</li> <li>* Put nipples on bottles after heating and shake thoroughly. "Wrist" test before feeding.</li> </ul>	<ul style="list-style-type: none"> <li>* Heat baby food in original jars.</li> <li>* Heat disposable bottles.</li> <li>* Heat bottles with nipples on.</li> </ul>
General	<ul style="list-style-type: none"> <li>* Cut baked goods with filling after heating to release steam and avoid burns.</li> <li>* Stir liquids briskly before and after heating to avoid "eruption".</li> <li>* Use deep bowl, when cooking liquids or cereals, to prevent boilovers.</li> </ul>	<ul style="list-style-type: none"> <li>* Heat or cook in closed glass jars or air tight containers.</li> <li>* Can in the microwave as harmful bacteria may not be destroyed.</li> <li>* Deep fat fry.</li> <li>* Dry wood, gourds, herbs or wet papers.</li> </ul>

## About Utensils and Coverings

It is not necessary to buy all new cookware. Many pieces already in your kitchen can be used successfully in your new microwave oven.

Use these utensils for safe microwave cooking and reheating:

- \* glass ceramic (Pyroceram®), such as Corningware®.
- \* heat-resistant glass (Pyrex®)
- \* microwave-safe plastics (Some microwave-safe plastics are not suitable for cooking foods with high fat and sugar content.)
- \* paper plates
- \* microwave-safe pottery, stoneware and porcelain
- \* browning dish (Do not exceed recommended preheating time. Follow manufacturer's directions.)

These items can be used for short time reheating of foods that have little fat or sugar in them:

- \* wood, straw, wicker

### DO NOT USE

- \* metal pans and bakeware
- \* dishes with metallic trim
- \* non-heat-resistant glass
- \* non-microwave-safe plastics (margarine tubs)
- \* recycled paper products
- \* brown paper bags
- \* food storage bags
- \* metal twist-ties

Should you wish to check if a dish is safe for microwaving, place the empty dish in the oven and microwave on HIGH for 30 seconds. A dish which becomes very hot should not be used.

Should you have questions about utensils or coverings, check a good microwave cookbook or follow recipe suggestions.

**ACCESSORIES** There are many microwave accessories available for purchase. Evaluate carefully before you purchase so that they meet your needs. A microwave-safe thermometer will assist you in determining correct doneness and assure you that foods have been cooked to safe temperatures. Sharp is not responsible for any damage to the oven when accessories are used.

## About Children and the Microwave

Children below the age of 7 should use the microwave oven with a supervising person very near to them. Between the ages of 7 and 12, the supervising person should be in the same room.

The child must be able to reach the oven comfortably; if not, he/she should stand on a sturdy stool.

At no time should anyone be allowed to lean or swing on the oven door.

The following coverings are ideal:

- \* Paper towels are good for covering foods for reheating and absorbing fat while cooking bacon.
- \* Wax paper can be used for cooking and reheating.
- \* Plastic wrap that is specially marked for microwave use can be used for cooking and reheating. DO NOT allow plastic wrap to touch food. Vent so steam can escape.
- \* Lids that are microwave-safe are a good choice because heat is kept near the food to hasten cooking.
- \* Oven cooking bags are good for large meats or foods that need tenderizing. DO NOT use metal twist ties. Remember to slit bag so steam can escape.

How to use aluminum foil in your microwave oven:

- \* Small flat pieces of aluminum foil placed smoothly on the food can be used to shield areas that are either defrosting or cooking too quickly.
- \* Foil should not come closer than one inch to any surface of the oven.

Make sure the utensil does not touch the interior walls during cooking.

Children should be taught all safety precautions: use potholders, remove coverings carefully, pay special attention to packages that crisp food because they may be extra hot.

Don't assume that because a child has mastered one cooking skill he/she can cook everything.

Children need to learn that the microwave oven is not a toy. See page 13 for Safety Lock feature.

## About Microwave Cooking

- \* Arrange food carefully. Place thickest areas toward outside of dish.
- \* Watch cooking time. Cook for the shortest amount of time indicated and add more as needed. Foods severely overcooked can smoke or ignite.
- \* Cover foods while cooking. Check recipe or cookbook for suggestions: paper towels, wax paper, microwave plastic wrap or a lid. Covers prevent spattering and help foods to cook evenly.
- \* Shield with small flat pieces of aluminum foil any thin areas of meats or poultry to prevent overcooking before dense, thick areas are cooked thoroughly.
- \* Stir foods from outside to center of dish once or twice during cooking, if possible.
- \* Turn foods over once during microwaving to speed cooking of such foods as chicken and hamburgers. Large items like roasts must be turned over at least once.
- \* Rearrange foods like meatballs halfway through cooking both from top to bottom and from the center of the dish to the outside.
- \* Add standing time. Remove food from oven and stir, if possible. Cover for standing time which allows the food to finish cooking without overcooking.
- \* Check for doneness. Look for signs indicating that cooking temperatures have been reached.
  - Doneness signs include:
    - Food steams throughout, not just at edge.
    - Center bottom of dish is very hot to the touch.
    - Poultry thigh joints move easily.
    - Meat and poultry show no pinkness.
    - Fish is opaque and flakes easily with a fork.

## About Safety

- \* Check foods to see that they are cooked to the United States Department of Agriculture's recommended temperatures:

TEMP	FOOD
160°F	... for fresh pork, ground meat, boneless white poultry, fish, seafood, egg dishes and frozen prepared food.
165°F	... for leftover, ready-to-reheat refrigerated, and deli and carry-out "fresh" food.
170°F	... white meat of poultry.
180°F	... dark meat of poultry.


To test for doneness, insert a meat thermometer in a thick or dense area away from fat or bone. NEVER leave the thermometer in food during cooking, unless it is approved for microwave oven use.

- \* Always use potholders to prevent burns when handling utensils that are in contact with hot food. Enough heat from the food can transfer through utensils to cause skin burns.
- \* Avoid steam burns by directing steam away from the face and hands. Slowly lift the farthest edge of a dish's covering and carefully open popcorn and oven cooking bags away from the face.
- \* Stay near the oven while it's in use and check cooking progress frequently so that there is no chance of overcooking food.
- \* NEVER use the cavity for storing cookbooks or other items.
- \* Select, store and handle food carefully to preserve its high quality and minimize the spread of foodborne bacteria.
- \* Keep wave guide cover clean. Food residue can cause arcing and/or fires.
- \* Use care when removing items from the oven so that the utensil, your clothes or accessories do not touch the safety door latches.




# PART NAMES

## Microwave Oven Parts




- ① Oven door with see-through window
- ② Safety door latches  
The oven will not operate unless the door is securely closed.
- ③ Door hinges
- ④ Door seals and sealing surfaces
- ⑤ Turntable motor shaft
- ⑥ Removable turntable support
- ⑦ Removable turntable  
Place the turntable on the turntable support securely. The turntable will rotate clockwise or counterclockwise. Only remove for cleaning.
- ⑧ Ventilation openings (rear)
- ⑨ Oven light  
It will light when oven is operating.
- ⑩ Waveguide cover  
DO NOT REMOVE


## Display




# CONTROL PANEL ILLUSTRATIONS




**R-230B**



**R-220B**



**R-209B**



**R-204C**




Number next to the control panel illustration indicates page on which there are a feature description and usage information.

# BEFORE OPERATING

- \* Before operating your new microwave oven make sure you read and understand this operation manual completely.
- \* Before the oven can be used, follow these procedures:
  - 1) Plug in the oven. Close the door. The oven display will then begin flashing **88:88**.
  - 2) Touch the STOP/CLEAR pad. **00:00** will appear.
  - 3) Touch CLOCK pad, to set clock.

## To Set the Clock

- \* Suppose you want to enter the correct time of day 12:30 (A.M. or P.M.)

Procedure	
1. 	Touch CLOCK pad.
2. 	Enter the correct time of day by touching the numbers in sequence.
3. 	Touch CLOCK pad again.

This is a 12 hour clock. If you attempt to enter an incorrect clock time, **EE** will appear in the display. Touch the STOP/CLEAR pad and re-enter the time.

- \* If the electrical power supply to your microwave oven should be interrupted, the display will intermittently show **88:88** after the power is reinstated. If this occurs during cooking, the program will be erased. The time of day will also be erased. Simply touch STOP/CLEAR pad and reset the clock for the correct time of day.

## Stop/Clear

Touch the STOP/CLEAR pad to:



1. Erase if you make a mistake during programming.
2. Cancel timer.
3. Stop the oven temporarily during cooking.
4. Return the time of day to the display.
5. Cancel a program during cooking, touch twice.

# MANUAL OPERATION

## Time Cooking

Your oven can be programmed for 99 minutes 99 seconds (99.99). Always enter the seconds after the minutes, even if they are both zeros.

- \* Suppose you want to cook for 5 minutes at 100%.




Procedure	
1. 	Enter cooking time.
2. 	Touch START pad.

## To Set Power Level

There are eleven preset power levels. Using lower power levels increases the cooking time which is recommended for foods such as cheese, milk and long slow cooking of meats. Consult cookbook or recipes for specific recommendations.

Touch POWER LEVEL Pad Once, then Touch	Approximate Percentage of Power	Common Words for Power Levels
POWER LEVEL		
9	100%	High
8	90%	
7	80%	Medium High
6	70%	
5	60%	Medium
4	50%	
3	40%	Med. Low/Defrost
2	30%	
1	20%	
0	10%	Low
0	0%	

- \* Suppose you want to defrost for 5 minutes at 30%.

Procedure	
1. 	Enter defrosting time.
2. 	Enter power level.
3. 	Touch START pad.

# SPECIAL FEATURES





## Compu Defrost (R-230B, R-204C)

## Express Defrost (R-220B, R-209B)


CompuDefrost and Express Defrost automatically defrost ground meat, steaks, chops, fish and chicken pieces.

\* Suppose you want to defrost a 2.0 lb steak.


### R-230B, R-204C

Procedure	
1.  x 2	Select desired food by touching COMPU DEFROST pad until the display shows the desired food number. (Ex. touch twice for Steak/chops.)
2.  	Enter weight by touching the number pads 2 and 0. (Ex. 2.0 lbs steak)
3. 	Touch START pad.
The oven will stop so that the food can be checked.	
4. After the 1st stage, open the door. Turn steak over and shield any warm portions. Close the door. Touch START pad.	
5. After the 2nd stage, open the door. Shield any warm portions. Close the door. Touch START pad.	
6. After defrost cycle ends, cover and let stand as indicated in chart below.	

### R-220B, R-209B

Procedure	
1.  x 4	To enter weight, touch the EXPRESS DEFROST pad for a .5 lb increase per touch. Quickly touch EXPRESS DEFROST pad 4 times for 2.0 lbs because the oven starts automatically.
The oven will stop so that the food can be checked.	
2. After the 1st stage, open the door. Turn steak over and shield any warm portions. Close the door. Touch START pad.	
3. After the 2nd stage, open the door. Shield any warm portions. Close the door. Touch START pad.	
4. After defrost cycle ends, cover and let stand as indicated in chart below.	

#### NOTE:

- If you attempt to enter more or less than the allowed amount (0.5–4.0 lbs),  will appear in the display.
- CompuDefrost and Express Defrost can be programmed with More or Less Time Adjustment. See page 12.
- To defrost other foods or foods above or below the weights allowed on Defrost Chart below, use time and 30% power. See Manual Defrost on page 11.

#### SPECIAL NOTE for R-209B-, R-220B-:

- Round the weight to the nearest half pound. (Ex. if the steak's actual weight is 2.2 lbs round to 2.0 lbs. If the steak's weight is 2.4 lbs round to 2.5 lbs.)
- You may choose to enter the weight in tenths of pounds. This procedure may be easier with larger weights such as 4 pounds because it requires fewer touches. To program, touch EXPRESS DEFROST and enter weight by touching the number pads. Example: touch EXPRESS DEFROST then 4 and 0 for a weight of four pounds.

## COMPU DEFROST/EXPRESS DEFROST CHART

Food	Amount	Procedure
1. Ground meat	.5–3.0 lbs	Remove any thawed pieces after each stage. Let stand, covered, 5–10 minutes.
2. Steaks, chops (fish)	.5–4.0 lbs	After each stage of defrost cycle, rearrange and if there are warm or thawed portions, shield with small flat pieces of aluminum foil. Remove any meat or fish that is nearly defrosted. Let stand, covered, 10–20 minutes.
3. Chicken pieces	.5–3.0 lbs	After each stage of defrost cycle, if there are warm or thawed portions, rearrange or remove. Let stand, covered, 10–20 minutes.

NOTE: Check foods when oven signals. After final stage, small sections may still be icy. Let stand to continue thawing. Do not defrost until all ice crystals are thawed. Shielding prevents cooking from occurring before the center of the food is defrosted. Use small smooth strips of aluminum foil to cover edges and thinner sections of the food.

## Manual Defrost

If the food that you wish to defrost is not listed on the COMPU DEFROST/EXPRESS DEFROST CHART or is above or below the limits in the "Amount" column on the COMPU DEFROST/EXPRESS DEFROST CHART, you need to defrost manually.

You can defrost any frozen food, either raw or previously cooked, by using Power Level 3. See page 9. Estimate defrosting time and press 3 for 30% when you select the power level.

For either raw or previously cooked frozen food the rule of thumb is approximately 5 minutes per pound. For example, defrost 5 minutes for 2-3 cups of casserole or 1 pound of frozen spaghetti sauce.

Always stop the oven periodically to remove or separate the portions that are defrosted. If food is not defrosted at the end of the estimated defrosting time, program the oven in 1 minute increments on Power Level 3 until totally defrosted.

When using plastic containers from the freezer, defrost only long enough to remove from the plastic in order to place in a microwave-safe dish.

## Instant Start

Instant Start allows you to cook or reheat many of your favorite foods by touching just one pad.

\* Suppose you want to cook a baked potato.

Procedure	
1.	<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-right: 10px;">BAKED POTATO</div> Touch BAKED POTATO pad once. The oven starts automatically.

To cook double quantity, touch the same pad twice within 1 second.

Instant Start can only be entered within 1 minute after cooking, opening and closing the door or touching the STOP/CLEAR pad.

Instant Start can be programmed with More or Less Time adjustment. See page 12.

TIPS: Foods can be covered with wax paper or vented plastic wrap. Temperatures of foods covered with plastic wrap tend to be slightly higher than those covered with wax paper.

Slice meat for reheating on dinner plate.

Stir items after removing from oven, if possible.

## INSTANT START CHART

Setting/Amount	Procedure
<b>SNACKS</b>	This setting works well with most brands of microwave popcorn. Try several brands to decide which is most acceptable for your taste. Place bag with only one fold slightly off center and place bag with two folds in the center of the turntable. You may also fold down the corners of the bag so it turns freely.
POPCORN 1 bag	Touch POPCORN pad once for regular. <input type="text" value="1"/> .
3.5 oz bag 3.0 or 3.5 oz bag (Light)	Touch POPCORN pad twice within 2 seconds for light regular. <input type="text" value="2"/> .
1.75 oz	Touch POPCORN pad three times within 3 seconds for snack. <input type="text" value="3"/> .
1.5 or 1.75 oz (Light)	Touch POPCORN pad four times within 4 seconds for light snack. <input type="text" value="4"/> .
<b>BEVERAGE</b> .5 - 1 mug	This setting is good for restoring cooled beverage to a better drinking temperature. Stir after heating. Use More Time Adjustment (See page 12.) for heating COLD TAP WATER to a temperature somewhat below the boiling point to make instant coffee or tea. Stir liquid briskly before and after heating to avoid "eruption".
<b>COOKING</b>	
BAKED POTATO 1 - 2 med.	Pierce with fork in several places. Place on paper towel on turntable. After cooking, remove from oven and let stand wrapped in foil for 5 to 10 minutes.
FRESH VEGETABLES 1 - 2 cups	For beans, carrots, corn and peas, add 1 tablespoon of water per cup. For broccoli, Brussel sprouts, cabbage and cauliflower, cook immediately after washing with no additional water. If you like tender crisp vegetables, double measured quantity per setting. For example, use 2 cups cauliflower but touch FRESH VEGETABLES only once. After cooking, remove from oven, stir, cover and let stand 3 to 5 minutes before serving.
<b>REHEATING</b>	
DINNER PLATE 1 plate	Place meaty portions and bulky vegetables to outside of plate. Cut large items like baked potatoes into smaller pieces. Flatten foods such as mashed potatoes and other dense foods. Cover with wax paper or plastic wrap. <b>NO DOUBLE QUANTITY.</b> After cooking, check that food is very hot throughout and that the bottom center of the plate is very hot. If not, continue heating using time and power level. Allow to stand, covered, 1 to 2 minutes.
ROLL, MUFFIN 1 - 2 pcs.	Arrange on plate with paper towel; cover with another towel. Use More Time Adjustment for frozen rolls and muffins.

# OTHER CONVENIENT FEATURES

## Multiple Sequence Cooking

The oven can be programmed for up to 3 automatic cooking sequences, switching from one power level setting to another automatically.

Sometimes cooking directions tell you to start on one power level and then change to a different power level. Your oven can do this automatically.

\* Suppose you want to cook roast beef for 5 minutes at 100% and then continue to cook for 30 minutes at 50%

Procedure							
1. <table border="1"><tr><td>5</td><td>0</td><td>0</td></tr></table> <table border="1"><tr><td>POWER LEVEL</td></tr></table> X 2	5	0	0	POWER LEVEL	First, enter cooking time. Then, touch POWER LEVEL pad twice for 100% power.		
5	0	0					
POWER LEVEL							
2. <table border="1"><tr><td>3</td><td>0</td><td>0</td><td>0</td></tr></table> <table border="1"><tr><td>POWER LEVEL</td></tr></table> <table border="1"><tr><td>5</td></tr></table>	3	0	0	0	POWER LEVEL	5	Then, enter second cooking time and touch POWER LEVEL pad. Touch number pad 5 for 50% power.
3	0	0	0				
POWER LEVEL							
5							
3. <table border="1"><tr><td>START</td></tr></table>	START	Touch START pad.					
START							

- Note:
1. If POWER LEVEL pad is touched twice, **P-HI** will be displayed.
  2. If 100% is selected as the final sequence, it is not necessary to touch the POWER LEVEL pad.
  3. If you wish to know power level, simply touch the POWER LEVEL pad. As long as your finger is touching the POWER LEVEL pad, the power level will be displayed.

## Minute Plus

Minute Plus allows you to cook for a minute at 100% by simply touching the MINUTE PLUS pad. You can also extend cooking time in multiples of 1 minute by repeatedly touching the MINUTE PLUS pad during manual cooking.

\* Suppose you want to heat a cup of soup for one minute.

Procedure			
1. <table border="1"><tr><td>MINUTE PLUS</td></tr></table> <table border="1"><tr><td>START MINUTE PLUS</td></tr></table>	MINUTE PLUS	START MINUTE PLUS	Touch MINUTE PLUS pad.
MINUTE PLUS			
START MINUTE PLUS			

- NOTE:
1. To use Minute Plus touch pad within 1 minute after cooking, closing the door, touching the STOP/CLEAR pad or during cooking.
  2. Minute Plus cannot be used with SPECIAL FEATURES.

## More or Less Time Adjustment

More
------

Should you discover that you like any of the Instant Start, CompuDefrost or Express Defrost settings slightly **more** done, touch the **POWER LEVEL** pad **once** after touching your choice of pads. The display will show **PLUS**.

Less
------

Should you discover that you like any of the Instant Start, CompuDefrost or Express Defrost settings slightly **less** done, touch the **POWER LEVEL** pad **twice** after touching your choice of pads. The display will show **LESS**.

The POWER LEVEL pad must be touched within 1 second of touching your choice of pads.

## Timer

\* Suppose you want to time a 3 minute long distance phone call.

Procedure	
1.	<input type="text" value="3"/> <input type="text" value="0"/> <input type="text" value="0"/> Enter time.
2.	<input type="button" value="TIMER&lt;br/&gt;CLOCK"/> Touch TIMER pad.

## Safety Lock

The Safety Lock prevents unwanted oven operation such as by small children.

The oven can be set so that the control panel is deactivated or locked. To set, touch CLOCK, the number  pad and then touch START pad and hold for 3 seconds. Should a pad be touched, *SR FE* will appear in the display.

To cancel, touch CLOCK, the number  and STOP/CLEAR pads.

## Audible Signal Elimination

If you wish to have the oven operate with no audible signals, touch CLOCK, the number  pad and then touch START pad and hold for 3 seconds.

To cancel and restore the audible signal, touch CLOCK, the number  and STOP/CLEAR pads.

## Demonstration Mode

To demonstrate, touch CLOCK,  pad and then touch START pad and hold for 3 seconds. *5:00* will appear in the display. Cooking operations and specific special features can now be demonstrated with no power in the oven. For example, touch MINUTE PLUS pad and the display will show *1:00* and count down quickly to 0 and the "End".

To cancel, touch CLOCK, then  and STOP/CLEAR pads. If easier, unplug the oven from the electrical outlet and re-plug.

# CLEANING AND CARE

## Exterior

The outside surface is painted. Clean the outside with mild soap and water; rinse and dry with a soft cloth. Do not use any type of household or abrasive cleaner.

## Door

Wipe the window on both sides with a damp cloth to remove any spills or splatters. Metal parts will be easier to maintain if wiped frequently with a damp cloth. Avoid the use of spray and other harsh cleaners as they may stain, streak or dull the door surface.

## Touch Control Panel

Care should be taken in cleaning the touch control panel. If the control panel becomes soiled, open the oven door before cleaning. Wipe the panel with a cloth dampened slightly with water only. Dry with a soft cloth. Do not scrub or use any sort of chemical cleaners. Close door and touch STOP/CLEAR.

## Interior

Cleaning is easy because little heat is generated to the interior surfaces; therefore, there is no baking and setting of spills or spattering. To clean the interior surfaces, wipe with a soft cloth and warm water. **DO NOT USE ABRASIVE OR HARSH CLEANERS OR SCOURING PADS.** For heavier soil, use baking soda or a mild soap; rinse thoroughly with hot water. **NEVER SPRAY OVEN CLEANERS DIRECTLY ONTO ANY PART OF THE OVEN.**

## Waveguide Cover


The waveguide cover is made from mica so requires special care. Keep the waveguide cover clean to assure good oven performance. Carefully wipe with a damp cloth any food splatters from the surface of the cover immediately after they occur. Built-up splashes may overheat and cause smoke or possibly catch fire. Do not remove the waveguide cover.

## Odor Removal


Occasionally, a cooking odor may remain in the oven. To remove, combine 1 cup water, grated peel and juice of 1 lemon and several whole cloves in a 2 cup glass measuring cup. Boil for several minutes using 100% power. Allow to set in oven until cool. Wipe interior with a soft cloth.

## Turntable/Turntable Support


The turntable and turntable support can be removed for easy cleaning. Wash them in mild, sudsy water; for stubborn stains use a mild cleanser and scouring sponge as described above. They are also dishwasher-proof. The turntable motor shaft is not sealed, so excess water or spills should be wiped up immediately.



Exterior



Interior



Turntable  
Turntable Support



# SERVICE CALL CHECK

Please check the following before calling for service:

Place one cup of water in a glass measuring cup in the oven and close the door securely.  
Operate the oven for one minute at HIGH 100%.

- A. Does the oven light come on? YES \_\_\_\_\_ NO \_\_\_\_\_
- B. Does the cooling fan work?  
(Put your hand over the rear ventilating openings.) YES \_\_\_\_\_ NO \_\_\_\_\_
- C. Does the turntable rotate?  
It is normal for the turntable to turn in either direction. YES \_\_\_\_\_ NO \_\_\_\_\_
- D. Is the water in the oven warm? YES \_\_\_\_\_ NO \_\_\_\_\_

If "NO" is the answer to any of the above questions, please check electrical outlet, fuse and/or circuit breaker. If they are functioning properly, CONTACT YOUR NEAREST SHARP AUTHORIZED SERVICER. A microwave oven should never be serviced by a "do-it-yourself" repair person.

NOTE: If time appearing in the display is counting down very rapidly, check Demonstration Mode on page 13 and cancel.

## SPECIFICATIONS

AC Line Voltage:	Single phase 120V, 60Hz, AC only
AC Power Required:	1100W 9.5 amps.
Output Power:	
Microwave* (IEC Test Procedure)	700W
Frequency:	2450 MHz
Outside Dimensions:	18 <sup>1</sup> / <sub>8</sub> "(W) x 11 <sup>3</sup> / <sub>8</sub> "(H) x 14 <sup>5</sup> / <sub>8</sub> "(D)
Cavity Dimensions:	12 <sup>3</sup> / <sub>8</sub> "(W) x 7 <sup>7</sup> / <sub>8</sub> "(H) x 12 <sup>5</sup> / <sub>8</sub> "(D)
Oven Capacity:	0.7 Cu.Ft.
Cooking Uniformity:	Turntable system
Weight:	Approx. 27 lbs.

- ★ The International Electrotechnical Commission's standardized method for measuring output wattage. This test method is widely recognized.

In compliance with standards set by:

**FCC** – Federal Communications Commission Authorized.

**DHHS** – Complies with Department of Health and Human Services (DHHS) rule, CFR, Title 21, Chapter I, Subchapter J.



– This symbol on the nameplate means the product is listed by Underwriters Laboratories, Inc.

# COOKING REFERENCE

<b>Meats, Poultry, Fish, Seafood</b>			<b>Reheating</b>		
Allow standing time after cooking.			Food should be very hot (165°F). Stir before serving, if possible.		
<b>Food</b>	<b>Power Level</b>	<b>Time</b>	<b>Food</b>	<b>Power Level</b>	<b>Time</b>
Bacon	High	¾ - 1¼ min./slice	Meat Slices	50%	1 - 3 min./slice
Frankfurter in Bun	70%	1 - 2 minutes	Non-Stirrable Casseroles (1 serving)	50%	5 - 8 minutes
Ground Beef for Casseroles (1 lb)	High	4 - 6 minutes	(2 servings)		9 - 12 minutes
Hamburger Patties(2)	High	1st side 2 minutes 2nd side 1½ to 2½ minutes	Pie (1 slice)	High	20 - 40 seconds
Ham slice (1 lb)	50%	6 - 9 minutes	Soup (1 serving)	High	2½ - 3½ minutes
Meatloaf (1½ lbs)	High	13 - 19 minutes	(2 servings)		4½ - 5½ minutes
Boneless Chicken Breasts	High	1st side 3 minutes 2nd side 2 - 4 minutes	Vegetables (1 serving)	High	¾ - 1½ minutes
Chicken Pieces	High	6 - 9 minutes/lb.	(2 servings)		1½ - 2½ minutes
Fish Fillets (1lb)	High	5 - 6 minutes	<b>Other</b>		
Fish Steaks	70%	7 - 9 minutes	Applesauce (4)	High	7 - 10 minutes
Scallops and Shrimp (1lb)	High	3½ - 5½ minutes	Baked Apples (4)	High	4 - 6 minutes
Check internal temperature after standing. See chart on page 6.			Chocolate (melt 1 square)	50%	1 - 2 minutes
			Eggs, scrambled (2)	High	1¼ - 1¾ minutes
			Hot Cereal (1 serving)	High	1½ - 5 minutes
			Nachos (large plate)	50%	1½ - 2½ minutes

## THE ULTIMATE ACCESSORY

★ **SHARP** CAROUSEL MICROWAVE COOKBOOK ★

- ★ Great recipes
- ★ Reliable microwave reference guide
- ★ Many color photos
- ★ Step-by-step instruction
- ★ Nutritional information for each recipe
- ★ Durable wipe-clean soft cover with 128 8 1/2 x 11 pages
- ★ Helpful tips and special techniques

**TO ORDER** \$10.25 plus tax, where applicable. (\$.44 per book in Illinois).
















Simply call this toll-free number : 1 800 642-2122. Have a credit card ready when you telephone.

**SATISFACTION GUARANTEED**

You must be completely satisfied with the Sharp Carousel Microwave Cookbook. If, within 14 days, you are dissatisfied for any reason, simply return the book and we'll gladly refund \$6.00 plus tax.
















# GUIA AUTO-TOUCH

Para mayor información y precauciones de seguridad, consulte el Manual de Operaciones.

<p><b>FIJACION DEL RELOJ</b> Si en la pantalla aparece 88:88, toque primero STOP/CLEAR.</p> <ol style="list-style-type: none"> <li>Toque el botón CLOCK.</li> <li>Ponga la hora correcta tocando los números en orden. (Ej: 12:30)</li> <li>Toque nuevamente el botón CLOCK.</li> </ol>	  	<p><b>OPERACION MANUAL</b> <b>Cocinando con energía alta</b></p> <ol style="list-style-type: none"> <li>Programe el tiempo para cocinar tocando los botones de números. (Ej: 1 min. 30 seg.)</li> <li>Toque START.</li> </ol> <p><b>Cocinando con energía variable</b></p> <ol style="list-style-type: none"> <li>Después del paso 1 anterior, toque el botón POWER LEVEL.</li> <li>Escoja el nivel de energía. (Ej: 50%)</li> <li>Toque START.</li> </ol>	    																						
<p><b>INSTANT START</b></p> <ol style="list-style-type: none"> <li>Toque el botón POPCORN una vez para palomitas de maíz regular.</li> </ol> <p>2 Veces - tamaño regular ligero 3 Veces - tamaño de snack 4 Veces - snack de tamaño ligero</p>		<p><b>EXPRESS DEFROST</b> (R-220B, R-209B)</p> <p>Toque el botón EXPRESS DEFROST para un aumento de 0,5 libras cada vez. (Ej: filete de 2,5 libras)</p> <p><b>COMPU DEFROST</b> (Para el R-230B, R-204C)</p> <ol style="list-style-type: none"> <li>Seleccione el nivel de descongelamiento rapido deseado con el botón COMPU DEFROST (Ej: tóquelo dos veces para filetes).</li> <li>Toque los botones número 2 y 5 para 2.5 libras. (Ej: filete de 2.5 libras)</li> <li>Toque START.</li> </ol>																							
<table border="1"> <thead> <tr> <th>Alimento</th> <th>Cantidad</th> </tr> </thead> <tbody> <tr> <td>POPCORN (Palomitas de maíz)</td> <td>3.5 onzas 3.0 or 3.5 onzas (ligero) 1.75 onzas 1.5 or 1.75 onzas (ligero)</td> </tr> <tr> <td>BEVERAGE (Bebida)</td> <td>.5 - 1 tazas</td> </tr> <tr> <td>BAKED POTATO (Papas al homo)</td> <td>1 - 2 medjano</td> </tr> <tr> <td>FRESH VEGETABLES (Verduras frescas)</td> <td>1 - 2 tazas</td> </tr> <tr> <td>DINNER PLATE (Plato de comida)</td> <td>1 plate de comida</td> </tr> <tr> <td>ROLL, MUFFIN (Pan fresco)</td> <td>1 - 2 pedazas</td> </tr> </tbody> </table>	Alimento	Cantidad	POPCORN (Palomitas de maíz)	3.5 onzas 3.0 or 3.5 onzas (ligero) 1.75 onzas 1.5 or 1.75 onzas (ligero)	BEVERAGE (Bebida)	.5 - 1 tazas	BAKED POTATO (Papas al homo)	1 - 2 medjano	FRESH VEGETABLES (Verduras frescas)	1 - 2 tazas	DINNER PLATE (Plato de comida)	1 plate de comida	ROLL, MUFFIN (Pan fresco)	1 - 2 pedazas		<table border="1"> <thead> <tr> <th>Alimentos</th> <th>Cantidad</th> </tr> </thead> <tbody> <tr> <td>1. Ground meat (Carne picada)</td> <td>.5 to 3.0 libras</td> </tr> <tr> <td>2. Steaks/chops (Filetes, chuletas)</td> <td>.5 to 4.0 libras</td> </tr> <tr> <td>3. Chicken pieces (Piezas de pollo)</td> <td>.5 to 3.0 libras</td> </tr> </tbody> </table>	Alimentos	Cantidad	1. Ground meat (Carne picada)	.5 to 3.0 libras	2. Steaks/chops (Filetes, chuletas)	.5 to 4.0 libras	3. Chicken pieces (Piezas de pollo)	.5 to 3.0 libras	   
Alimento	Cantidad																								
POPCORN (Palomitas de maíz)	3.5 onzas 3.0 or 3.5 onzas (ligero) 1.75 onzas 1.5 or 1.75 onzas (ligero)																								
BEVERAGE (Bebida)	.5 - 1 tazas																								
BAKED POTATO (Papas al homo)	1 - 2 medjano																								
FRESH VEGETABLES (Verduras frescas)	1 - 2 tazas																								
DINNER PLATE (Plato de comida)	1 plate de comida																								
ROLL, MUFFIN (Pan fresco)	1 - 2 pedazas																								
Alimentos	Cantidad																								
1. Ground meat (Carne picada)	.5 to 3.0 libras																								
2. Steaks/chops (Filetes, chuletas)	.5 to 4.0 libras																								
3. Chicken pieces (Piezas de pollo)	.5 to 3.0 libras																								
<p><b>MUNUTE PLUS</b></p> <p>Toque el botón de adición de un minuto (MINUTE PLUS) para un minuto al 100% de energía, o para añadir un minuto cuando cocine en el modo manual. Continúe tocándolo para añadir más minutos.</p>	 																								

# AUTO-TOUCH® GUIDE

For more complete information and safety precautions, refer to your Operation Manual.

<p><b>SET CLOCK</b></p> <p>If 88:88 is in display, first touch STOP/CLEAR.</p> <ol style="list-style-type: none"> <li>1. Touch CLOCK pad.</li> <li>2. Enter correct time of the day by touching numbers in sequence. (Ex. 12:30)</li> <li>3. Touch CLOCK pad again.</li> </ol>	  	<p><b>MANUAL OPERATION</b></p> <p><b>High Power Cooking</b></p> <ol style="list-style-type: none"> <li>1. Enter cooking time by touching number pads. (Ex: 1 min. 30 sec.)</li> <li>2. Touch START pad.</li> </ol> <p><b>Variable Power Cooking</b></p> <ol style="list-style-type: none"> <li>1. After Step 1 above, touch POWER LEVEL pad.</li> <li>2. Select power level. (Ex: 50%)</li> <li>3. Touch START pad.</li> </ol>	    																						
<p><b>INSTANT START</b></p> <ol style="list-style-type: none"> <li>1. Touch POPCORN pad once for a regular size. Twice - light regular size 3 times - snack size 4 times - light snack size</li> </ol>		<p><b>EXPRESS DEFROST</b> (R-220B, R-209B)</p> <p>Touch EXPRESS DEFROST pad for a .5 lb increase per touch. (Ex: 2.5 lbs steak)</p> <p><b>COMPU DEFROST</b> (R-230B, R-204C)</p> <ol style="list-style-type: none"> <li>1. Select desired Compu Defrost setting by touching COMPU DEFROST pad. (Ex: Touch twice for steak).</li> <li>2. Touch number pad 2 and 5 for 2.5 lbs (Ex: 2.5 lbs steak)</li> <li>3. Touch START pad.</li> </ol>																							
<table border="1"> <thead> <tr> <th>Food</th> <th>Amount</th> </tr> </thead> <tbody> <tr> <td>POPCORN</td> <td>3.5 oz. 3.0 or 3.5 oz. (Light) 1.75 oz. 1.5 or 1.75 oz. (Light)</td> </tr> <tr> <td>BEVERAGE</td> <td>.5 - 1 mug</td> </tr> <tr> <td>BAKED POTATO</td> <td>1 - 2 med.</td> </tr> <tr> <td>FRESH VEGETABLES</td> <td>1 - 2 cups</td> </tr> <tr> <td>DINNER PLATE</td> <td>1 plate</td> </tr> <tr> <td>ROLL, MUFFIN</td> <td>1 - 2 pcs.</td> </tr> </tbody> </table>	Food	Amount	POPCORN	3.5 oz. 3.0 or 3.5 oz. (Light) 1.75 oz. 1.5 or 1.75 oz. (Light)	BEVERAGE	.5 - 1 mug	BAKED POTATO	1 - 2 med.	FRESH VEGETABLES	1 - 2 cups	DINNER PLATE	1 plate	ROLL, MUFFIN	1 - 2 pcs.		<table border="1"> <thead> <tr> <th>Food</th> <th>Amount</th> </tr> </thead> <tbody> <tr> <td>1. Ground meat</td> <td>.5 to 3.0 lbs</td> </tr> <tr> <td>2. Steaks/chops (fish)</td> <td>.5 to 4.0 lbs</td> </tr> <tr> <td>3. Chicken pieces</td> <td>.5 to 3.0 lbs</td> </tr> </tbody> </table>	Food	Amount	1. Ground meat	.5 to 3.0 lbs	2. Steaks/chops (fish)	.5 to 4.0 lbs	3. Chicken pieces	.5 to 3.0 lbs	 x 5   x 2   
Food	Amount																								
POPCORN	3.5 oz. 3.0 or 3.5 oz. (Light) 1.75 oz. 1.5 or 1.75 oz. (Light)																								
BEVERAGE	.5 - 1 mug																								
BAKED POTATO	1 - 2 med.																								
FRESH VEGETABLES	1 - 2 cups																								
DINNER PLATE	1 plate																								
ROLL, MUFFIN	1 - 2 pcs.																								
Food	Amount																								
1. Ground meat	.5 to 3.0 lbs																								
2. Steaks/chops (fish)	.5 to 4.0 lbs																								
3. Chicken pieces	.5 to 3.0 lbs																								
<p><b>MINUTE PLUS</b></p> <p>Touch MINUTE PLUS pad for one minute at 100% power or to add a minute during manual cooking. Continue to touch for additional minutes.</p>	 																								

Carousel and Auto-Touch are registered trademarks of Sharp Corporation.

**SHARP®**

SHARP ELECTRONICS CORPORATION  
Sharp Plaza, Mahwah, New Jersey 07430-2135

TINSEA852WRRZ-D01 Printed in Thailand