

**48XP(N)**  
**Performance™ 13 SEER Single Packaged Air Conditioner**  
**and Gas Furnace System with Puron® (R-410A) Refrigerant**  
**Single and Three Phase**  
**2–5 Nominal Tons (Sizes 024–060)**



Turn to the Experts.™


# Installation Instructions

**NOTE:** Read the entire instruction manual before starting the installation.

**NOTE:** Installer: Make sure the Owner's Manual and Service Instructions are left with the unit after installation.

## TABLE OF CONTENTS

	PAGE
SAFETY CONSIDERATIONS .....	1
INTRODUCTION .....	2
RECEIVING AND INSTALLATION .....	2-13
Check Equipment .....	2
Identify Unit .....	2
Inspect Shipment .....	2
Provide Unit Support .....	2
Roof Curb .....	2
Slab Mount .....	2
Ground Mount .....	2
Field Fabricate Ductwork .....	2
Provide Clearances .....	2
Rig and Place Unit .....	4
Connect Condensate Drain .....	6
Install Flue Hood .....	7
Install Gas Piping .....	7
Install Duct Connections .....	9
Configuring Units for Downflow (Vertical)	
Discharge .....	9
Install Electrical Connections .....	10
High-Voltage Connections .....	10
Special Procedures for 208-V Operation .....	11
Control Voltage Connections .....	11
Easy Select™ .....	11
Transformer Protection .....	14
PRE-START-UP .....	14
START-UP .....	14-21
Check for Refrigerant Leaks .....	14
Unit Sequence of Operation .....	14
48XP Sequence of Operation .....	14
Start-Up Heating & Make Adjustments .....	15
Check Heating Control .....	15
Check Gas Input .....	15
Adjust Gas Input .....	15
Check Burner Flame .....	16
Airflow and Temperature Rise .....	16
Heating Sequence of Operation .....	16
Limit Switches .....	16
Rollout Switch .....	17
Start-Up Cooling & Make Adjustments .....	17
Checking Cooling Control Operation .....	17
Checking & Adjusting Refrigerant Charge .....	21
Indoor Airflow and Airflow Adjustments .....	21
MAINTENANCE .....	22-25
Air Filter .....	22
Evaporator Blower and Motor .....	22
Flue Gas Passageways .....	22



C99088

**Fig. 1 - Unit 48XP**

Combustion Air Blower .....	23
Limit Switch .....	23
Burner Ignition .....	23
Main Burners .....	23
Condenser Coil, Evaporator Coil, & Condensate	
Drain Pan .....	23
Condenser Fan .....	24
Electrical Controls and Wiring .....	24
Refrigerant Circuit .....	24
Gas Input .....	24
Evaporator Airflow .....	24
Puron® Items .....	25
TROUBLESHOOTING .....	26
START-UP CHECKLIST .....	26


## SAFETY CONSIDERATIONS

Improper installation, adjustment, alteration, service maintenance, or use can cause explosion, fire, electrical shock, or other conditions which may cause death, personal injury, or property damage. Consult a qualified installer, service agency, or your distributor or branch for information or assistance. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions packaged with the kits or accessories when installing.

Follow all safety codes. Wear safety glasses, protective clothing, and work gloves. Have a fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions included in literature and attached to the unit. Consult local building codes, the current editions of the National Fuel Gas Code

(NFGC) NFPA 54/ANSI Z223.1, and the National Electrical Code (NEC) NFPA 70.

In Canada refer to the current editions of the National Standards of Canada CAN/CSA-B149.1 and .2 Natural Gas and Propane Installation codes, and Canadian Electrical Code CSA C22.1

Recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury. Understand these signal words: DANGER, WARNING, and CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies hazards which **could** result in personal injury or death. CAUTION is used to identify unsafe practices which **may** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

48XP

## WARNING

### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Before installing or servicing system, always turn off and tag lockout main power to system. There may be more than one disconnect switch. Turn off accessory heater power switch if applicable.

## WARNING

### FIRE, EXPLOSION, ELECTRICAL SHOCK AND CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in personal injury, death or property damage.

A qualified installer or agency must use only factory-authorized kits or accessories when modifying this product.

## INTRODUCTION

The 48XP unit (see Fig. 1) is a fully self-contained, combination Category I gas heating/electric cooling unit designed for outdoor installation (See Fig. 2 and 3 for unit dimensions). All unit sizes have return and discharge openings for both horizontal and downflow configurations, and are factory shipped with all downflow duct openings covered. Units may be installed either on a rooftop, a cement slab, or directly on the ground, if local codes permit (See Fig. 4 for roof curb dimensions).

Models with an N in the fifth position of the model number are dedicated Low NOx units designed for California installations. These models meet the California maximum oxides of nitrogen (NOx) emissions requirements of 40 nanograms/joule or less as shipped from the factory and must be installed in California Air Quality Management Districts or any other regions in North America where a Low NOx rule exists.

## RECEIVING AND INSTALLATION

### Step 1 — Check Equipment

#### IDENTIFY UNIT

The unit model number and serial number are stamped on the unit information plate. Check this information against shipping papers.

#### INSPECT SHIPMENT

Inspect for shipping damage while unit is still on shipping pallet. If unit appears to be damaged or is torn loose from its anchorage, have it examined by transportation inspectors before removal. Forward claim papers directly to transportation company. Manufacturer is not responsible for any damage incurred in transit. Check all items against shipping list. Immediately notify the

nearest equipment distribution office if any item is missing. To prevent loss or damage, leave all parts in original packages until installation.

### Step 2 — Provide Unit Support

For hurricane tie downs, contact distributor for details and PE (Professional Engineering) Certificate if required.

#### ROOF CURB

Install accessory roof curb in accordance with instructions shipped with curb (See Fig. 4). Install insulation, cant strips, roofing, and flashing. Ductwork must be attached to curb.

**IMPORTANT:** The gasketing of the unit to the roof curb is critical for a water tight seal. Install gasketing material supplied with the roof curb. Improperly applied gasketing also can result in air leaks and poor unit performance.

Curb should be level to within 1/4 in. (6 mm). This is necessary for unit drain to function properly. Refer to accessory roof curb installation instructions for additional information as required.

#### SLAB MOUNT

Place the unit on a solid, level concrete pad that is a minimum of 4 in. (102 mm) thick with 2 in. (51 mm) above grade. The slab should be flush on the compressor end of the unit (to allow condensate drain installation) and should extend 2 in. (51 mm) on the three remaining sides of the unit. Do not secure the unit to the slab *except* when required by local codes.

#### GROUND MOUNT

The unit may be installed either on a slab or placed directly on the ground, if local codes permit. Place the unit on level ground prepared with gravel for condensate discharge.

### Step 3 — Field Fabricate Ductwork

Secure all ducts to roof curb and building structure on vertical discharge units. Do not connect ductwork to unit. For horizontal applications, unit is provided with flanges on the horizontal openings. All ductwork should be secured to the flanges. Insulate and weatherproof all external ductwork, joints, and roof openings with counter flashing and mastic in accordance with applicable codes.

Ducts passing through an unconditioned space must be insulated and covered with a vapor barrier.

If a plenum return is used on a vertical unit, the return should be ducted through the roof deck to comply with applicable fire codes.

A minimum clearance is not required around ductwork. Cabinet return-air static shall not exceed -.25 IN. W.C..


### Step 4 — Provide Clearances

The required minimum operating and service clearances are shown in Fig. 2 and 3. Adequate combustion, ventilation and condenser air must be provided in accordance with section 9.3, Air for Combustion and Ventilation, of the National Fuel Gas Code NFPA54/ANSI Z223.1 or applicable provisions of local building code. In Canada, follow section 8 of Can/CSA-B149.1 Installation Codes or applicable provisions of local building code.

**IMPORTANT:** Do not restrict outdoor airflow. An air restriction at either the outdoor-air inlet or the fan discharge may be detrimental to compressor life.

The condenser fan pulls air through the condenser coil and discharges it through the top grille. Be sure that the fan discharge does not recirculate to the condenser coil. Do not locate the unit in either a corner or under an overhead obstruction. The minimum clearance under a partial overhang (such as a normal house overhang) is 48-in. (1219 mm) above the unit top. The maximum horizontal extension of a partial overhang must not exceed 48-in. (1219 mm)

Do not place the unit where water, ice, or snow from an overhang or roof will damage or flood the unit. Do not install the unit on carpeting or other combustible materials. The unit may be installed on wood flooring or on Class A, B, or C roof covering materials.



UNIT	ELECTRICAL CHARACTERISTICS		UNIT WT.		UNIT HEIGHT			CENTER OF GRAVITY MM/IN		
			LBS.	KG.	"A"	X	Y	Z		
48XP024040/060	208-230-1-60		340	154	940.3[37.02]	558.8[22.0]	368.3[14.5]	406.4[16.0]		
48XP030040/060	208-230-1-60, 208/230-3-60		344	156	991.1[39.02]	558.8[22.0]	387.4[15.3]	447.0[17.6]		
48XP036060/090	208-230-1-60, 208/230-3-60		368	167	1041.9[41.02]	508.0[20.0]	355.6[14.0]	447.0[17.6]		

	CORNER WEIGHT LBS./KG.			
	"1"	"2"	"3"	"4"
024	51/23	68/31	102/46	119/54
030	52/23	69/31	103/47	120/55
036	55/24	74/33	110/50	129/58

**REQUIRED CLEARANCES TO COMBUSTIBLE MATL.**

	MILLIMETERS [IN]
TOP OF UNIT	355.6 [14.00]
DUCT SIDE OF UNIT	50.8 [2.00]
SIDE OPPOSITE DUCTS	355.6 [14.00]
BOTTOM OF UNIT	0.0 [0.00]
FLUE PANEL	914.4 [36.00]

**NEC. REQUIRED CLEARANCES.**

	MILLIMETERS [IN]
BETWEEN UNITS, POWER ENTRY SIDE	1066.8 [42.00]
UNIT AND UNGROUNDED SURFACES, POWER ENTRY SIDE	914.0 [36.00]
UNIT AND BLOCK OR CONCRETE WALLS AND OTHER GROUNDED SURFACES, POWER ENTRY SIDE	1066.8 [42.00]





**REQUIRED CLEARANCE FOR OPERATION AND SERVICING**


	MILLIMETERS [IN]
EVAP. COIL ACCESS SIDE	914.0 [36.00]
POWER ENTRY SIDE (EXCEPT FOR NEC REQUIREMENTS)	914.0 [36.00]
UNIT TOP	1219.2 [48.00]
SIDE OPPOSITE DUCTS	914.0 [36.00]
DUCT PANEL	304.8 [12.00]*

\*MINIMUM DISTANCES: IF UNIT IS PLACED LESS THAN 304.8 [12.00] FROM WALL SYSTEM, THEN SYSTEM PERFORMANCE MAYBE COMPROMISED.

DIMENSIONS IN [ ] ARE IN INCHES

Fig 2 - 48XP024-036 Unit Dimensions





UNIT	ELECTRICAL CHARACTERISTICS	UNIT WT.		UNIT HEIGHT "A"	CENTER OF GRAVITY MM/IN		
		LBS.	KG.		X	Y	Z
48XP042060/090	208-230-1-60, 208/230-3-60	412	187	1091.7[42.98]	495.3[19.5]	447.6[17.6]	457.2[18.0]
48XP048090/115/130	208-230-1-60, 208/230-3-60	462	210	1142.5[44.98]	495.3[19.5]	447.6[17.6]	457.2[18.0]
48XP060090/115/130	208-230-1-60, 208/230-3-60	507	230	1193.3[46.98]	533.4[21.0]	508.0[20.0]	442.0[17.6]

	CORNER WEIGHT LBS./KG.			
	"1"	"2"	"3"	"4"
042	62/28	82/37	124/56	144/65
048	69/31	92/42	139/63	162/73
060	76/35	101/46	152/69	178/80

**REQUIRED CLEARANCES TO COMBUSTIBLE MATL.**

	MILLIMETERS [IN]
TOP OF UNIT	355.6 [14.00]
DUCT SIDE OF UNIT	50.8 [2.00]
SIDE OPPOSITE DUCTS	355.6 [14.00]
BOTTOM OF UNIT	0.0 [0.00]
FLUE PANEL	914.4 [36.00]

**NEC. REQUIRED CLEARANCES.**

	MILLIMETERS [IN]
BETWEEN UNITS, POWER ENTRY SIDE	1066.8 [42.00]
UNIT AND UNGROUNDED SURFACES, POWER ENTRY SIDE	914.0 [36.00]
UNIT AND BLOCK OR CONCRETE WALLS AND OTHER GROUNDED SURFACES, POWER ENTRY SIDE	1066.8 [42.00]


**REQUIRED CLEARANCE FOR OPERATION AND SERVICING**

	MILLIMETERS [IN]
EVAP. COIL ACCESS SIDE	914.0 [36.00]
POWER ENTRY SIDE (EXCEPT FOR NEC REQUIREMENTS)	914.0 [36.00]
UNIT TOP	1219.2 [48.00]
SIDE OPPOSITE DUCTS	914.0 [36.00]
DUCT PANEL	304.8 [12.00]


\*MINIMUM DISTANCES: IF UNIT IS PLACED LESS THAN 304.8 [12.00] FROM WALL SYSTEM, THEN SYSTEM PERFORMANCE MAYBE COMPROMISED.

DIMENSIONS IN [ ] ARE IN INCHES

Fig. 3 - 48XP042-060 Unit Dimensions




48XP500009	REV 4.0
------------	---------





**Roof Curb for Small Cabinet**

Note A: When unit mounting screw is used, retainer bracket must also be used.



**Roof Curb for Large Cabinet**

Note A: When unit mounting screw is used, retainer bracket must also be used.



C00076

UNIT SIZE	CATALOG NUMBER	A IN. (MM)	B IN. (MM)	C IN. (MM)	D IN. (MM)
48XP024-036	CPRFCURB006A00	8 (203)	11 (279)	16-1/2 (419)	28-3/4 (730)
	CPRFCURB007A00	14 (356)	11 (279)	16-1/2 (419)	28-3/4 (730)
48XP042-060	CPRFCURB008A00	8 (203)	16-3/16 (411)	17-3/8 (441)	40-1/4 (1022)
	CPRFCURB009A00	14 (356)	16-3/16 (411)	17-3/8 (441)	40-1/4 (1022)

**NOTES:**


1. Roof curb must be set up for unit being installed.
2. Seal strip must be applied, as required, to unit being installed.
3. Roof curb is made of 16-gauge steel.
4. Attach ductwork to curb (flanges of duct rest on curb).
5. Insulated panels: 1-in. (25 mm) thick fiberglass 1 lb (.45 kg) density.
6. When unit mounting screw is used (see Note A), a retainer bracket must be used as well. This bracket must also be used when required by code for hurricane or seismic conditions. This bracket is available through Micrometl.

**Fig. 4 - Roof Curb Dimensions**

Unit	SMALL CABINET						LARGE CABINET						
	024		030		036		Unit	042		048		060	
	lb	kg	lb	kg	lb	kg		lb	kg	lb	kg	lb	kg
Rigging Weight	351	159	355	161	379	172	Rigging Weight	427	194	477	216	522	237

NOTE: See dimensional drawing for corner weights.

Fig. 5 - 48XP Rigging Weights



C99015

UNIT 48XP	A		B	
	in.	mm	in.	mm
024	22.0	558.5	14.50	368.3
030	22.0	558.5	14.50	368.3
036	22.0	558.5	15.30	388.6
042	20.0	508.0	21.25	539.8
048	21.5	546.1	16.3	414.0
060	23.5	596.9	16.3	414.3

Fig. 6 - Suggested Rigging

### Step 5 — Rig and Place Unit

Rigging and handling of this equipment can be hazardous for many reasons due to the installation location (roofs, elevated structures, etc.).

Only trained, qualified crane operators and ground support staff should handle and install this equipment.

When working with this equipment, observe precautions in the literature, on tags, stickers, and labels attached to the equipment, and any other safety precautions that might apply.

Use spreader bars or crate top when rigging the unit. The units must be rigged for lifting (See Fig. 6). Refer to Table 1 for operating weight. Use extreme caution to prevent damage when moving the unit. Unit must remain in an upright position during all rigging and moving operations. The unit must be level for proper condensate drainage; therefore, the ground-level pad or accessory roof curb must be level before setting the unit in place. When a field-fabricated support is used, be sure that the support is level and properly supports the unit. Lifting point should be directly over the center of gravity for the unit.

**⚠ WARNING**

**UNIT FALLING HAZARD**

Failure to follow this warning could result in personal injury or death.

Never stand beneath rigged units or lift over people.

**⚠ WARNING**

**PERSONAL INJURY HAZARD**

Failure to follow this warning could result in personal injury or death.

Never exceed 200 lb (91 kg) per bracket lifting force.

**⚠ WARNING**

**PERSONAL INJURY HAZARD**

Failure to follow this warning could result in personal injury/death.

Accessory lifting kit is only to be used with Small Packaged units which have a composite unit base with molded rigging holds.

### Step 6 — Connect Condensate Drain


**NOTE:** When installing condensate drain connection be sure to comply with local codes and restrictions.

Model 48XP disposes of condensate water through a 3/4 in. NPT fitting which exits through the compressor access panel (See Fig. 2 and 3 for location).

Condensate water can be drained directly onto the roof in rooftop installations (where permitted) or onto a gravel apron in groundlevel installations. Install a field-supplied condensate trap at end of condensate connection to ensure proper drainage. Make sure that the outlet of the trap is at least 1 in. (25 mm) lower than the drain-pan condensate connection to prevent the pan from overflowing (See Fig. 7). Prime the trap with water. When using a gravel apron, make sure it slopes away from the unit.

If the installation requires draining the condensate water away from the unit, install a 2-in. (51 mm) trap at the condensate connection to ensure proper drainage (See Fig. 7). Make sure that the outlet of the trap is at least 1 in. lower than the drain-pan condensate connection. This prevents the pan from overflowing.

Prime the trap with water. Connect a drain tube - using a minimum of 3/4-in. PVC or 3/4-in. copper pipe (all field-supplied) - at the outlet end of the 2-in. (51 mm) trap. Do not undersize the tube. Pitch the drain tube downward at a slope of at least 1-in. (25 mm) for every 10 ft (3 m) of horizontal run. Be sure to check the drain tube for leaks.



A08001

**Fig. 7 - Condensate Trap**

## Step 7 — Install Flue Hood

The flue hood assembly is shipped in the return section of the indoor blower compartment (See Fig. 9). Remove the return duct cover to locate the assembly.

Dedicated low NOx models **MUST** be installed in California Air Quality Management Districts where a Low NOx rule exists. These models meet the California maximum oxides of nitrogen (NOx ) emissions requirements of 40 nanograms/joule or less as shipped from the factory.

**NOTE:** Low NOx requirements apply only to natural gas installations.

### **⚠ WARNING**

#### **PERSONAL INJURY AND UNIT DAMAGE HAZARD**

Failure to follow this warning could result in personal injury or death and unit component damage.

The venting system is designed to ensure proper venting. The flue hood assembly must be installed as indicated in this section of the unit installation instructions.

Install the flue hood as follows:

1. This installation must conform with local building codes and with the National Fuel Gas Code (NFGC), NFPA 54/ANSI Z223.1 (in Canada, CAN/CSA B149.1, and B149.2) latest revision. Refer to Provincial and local plumbing or wastewater codes and other applicable local codes.
2. Remove flue hood from shipping location (inside the return section of the blower compartment—See Fig. 9). Place vent cap assembly over flue panel. Orient screw holes in vent cap with holes in the flue panel.
3. Secure flue hood to flue panel by inserting a single screw on the right side and the left side of the hood.

## Step 8 — Install Gas Piping

The gas supply pipe enters the unit through the access hole provided. The gas connection to the unit is made to the 1/2-in. FPT gas inlet on the manual shutoff or gas valve.

Install a gas supply line that runs to the heating section. Refer to Table 2 and the NFGC for gas pipe sizing. Do not use cast-iron pipe. It is recommended that a black iron pipe is used. Check the local utility for recommendations concerning existing lines. Size gas supply piping for 0.5 IN. W.C. maximum pressure drop. Never use pipe smaller than the 1/2-in. FPT gas inlet on the unit gas valve.

For natural gas applications, the gas pressure at unit gas connection must not be less than 4.0 IN. W.C. or greater than 13 IN. W.C. while the unit is operating. For propane applications, the gas pressure must not be less than 7.0 IN. W.C. or greater than 13 IN. W.C. at the unit connection.

An 1/8-in. NPT plugged tapping, accessible for test gage connection, must be installed immediately upstream of the gas supply connection to the gas valve.

When installing the gas supply line, observe local codes pertaining to gas pipe installations. Refer to the NFPA 54/ANSI Z223.1, in Canada CAN/CSA-B149.1 and B149.2 latest editions. In the

absence of local building codes, adhere to the following pertinent recommendations:

1. Avoid low spots in long runs of pipe. Grade all pipe 1/4 in. (6 mm) in every 15 ft (5 m) to prevent traps. Grade all horizontal runs downward to risers. Use risers to connect to heating section and to meter.
2. Protect all segments of piping system against physical and thermal damage. Support all piping with appropriate straps, hangers, etc. Use a minimum of one hanger every 6 ft (2 m). For pipe sizes larger than 1/2 in., follow recommendations of national codes.
3. Apply joint compound (pipe dope) sparingly and only to male threads of joint when making pipe connections. Use only pipe dope that is resistant to action of liquefied petroleum gases as specified by local and/or national codes. Never use Teflon tape.

48XP

**Table 1 – Physical Data - Unit 48XP**

UNIT SIZE 48XP	024040	024060	030040	030060	036060	036090	042060	042090
<b>NOMINAL CAPACITY (ton)</b>	2	2	2-1/2	2-1/2	3	3	3-1/2	3-1/2
<b>SHIPPING WEIGHT (lb)</b>	388	388	392	392	416	416	464	464
(kg)	176	176	178	178	189	189	210	210
<b>COMPRESSORS</b>	Scroll							
Quantity	1							
<b>REFRIGERANT (R-410A)</b>								
Quantity (lb)	7.3	7.3	8.0	8.0	9.5	9.5	10.7	10.7
(kg)	3.3	3.3	3.6	3.6	4.3	4.3	4.9	4.9
<b>REFRIGERANT METERING DEVICE</b>	TXV							
<b>CONDENSER COIL</b>								
Rows...Fins/in.	2...21	2...21	2...21	2...21	2...21	2...21	2...21	2...21
Face Area (sq ft)	11.95	11.95	11.95	11.95	13.7	13.7	15.4	15.4
<b>CONDENSER FAN</b>								
Nominal Cfm	2350	2350	2350	2350	2800	2800	2800	2800
Diameter (in.)	22	22	22	22	22	22	22	22
(mm)	559	559	559	559	559	559	559	559
Motor Hp (Rpm)	1/8 (825)	1/8 (825)	1/8 (825)	1/8 (825)	1/8 (825)	1/8 (825)	1/8 (825)	1/8 (825)
<b>EVAPORATOR COIL</b>								
Rows...Fins/in.	3...15	3...15	3...15	3...15	4...15	4...15	3...15	3...15
Face Area (sq ft)	3.7	3.7	3.7	3.7	3.7	3.7	3.7	3.7
<b>EVAPORATOR BLOWER</b>								
Nominal Airflow (Cfm)	770	770	960	960	1150	1150	1400	1400
Size (in.)	10x10	10x10	10x10	10x10	11x10	11x10	11x10	11x10
(mm)	254x254	254x254	254x254	254x254	279x254	279x254	279x254	279x254
Motor (hp)	1/2	1/2	1/2	1/2	3/4	3/4	3/4	3/4
<b>FURNACE SECTION*</b>								
Burner Orifice No. (Qty...Drill Size) Natural Gas	2...44	2...38	2...44	2...38	2...38	3...38	2...38	2...38
Burner Orifice No. (Qty...Drill Size) Propane Gas	2...50	2...46	2...50	2...46	2...46	3...46	2...46	2...46
<b>HIGH-PRESSURE SWITCH (psig)</b>	650 +/-15							
Cut-out Reset (Auto)	420 +/-25							
<b>LOSS-OF-CHARGE / LOW-PRESSURE SWITCH (Liquid Line) (psig)</b>	20 +/-5							
Cut-out Reset (auto)	45 +/-10							
<b>RETURN-AIR FILTERS Throwaway† (in.)</b>	20x24x1						24x30x1	
(mm)	508x610x25						610x762x25	

\*Based on altitude of 0 to 2000 ft (0-610 m).

†Required filter sizes shown are based on the larger of the ARI (Air Conditioning and Refrigeration Institute) rated cooling airflow or the heating airflow velocity of 300 ft/minute for high-capacity type. Air filter pressure drop for non-standard filters must not exceed 0.08 IN. W.C..

**Table 1 – Physical Data - Unit 48XP (Continued)**

UNIT SIZE 48XP	048090	048115	048130	060090	060115	060130
<b>NOMINAL CAPACITY (ton)</b>	4	4	4	5	5	5
<b>SHIPPING WEIGHT (lb)</b>	512	512	512	559	559	559
(kg)	232	232	232	254	254	254
<b>COMPRESSORS</b>	Scroll					
Quantity	1					
<b>REFRIGERANT (R-410A) Quantity (lb)</b>	11.25	11.25	11.25	13.2	13.2	13.2
(kg)	5.1	5.1	5.1	6.0	6.0	6.0
<b>REFRIGERANT METERING DEVICE</b>	TXV					
<b>CONDENSER COIL</b> Rows...Fins/in.	2...21	2...21	2...21	2...21	2...21	2...21
Face Area (sq ft)	17.4	17.4	17.4	19.3	19.3	19.3
<b>CONDENSER FAN</b>						
Nominal Cfm	3300	3300	3300	3300	3300	3300
Diameter (in.)	22	22	22	22	22	22
(mm)	559	559	559	559	559	559
Motor Hp (Rpm)	1/4 (1100)	1/4 (1100)	1/4 (1100)	1/4 (1100)	1/4 (1100)	1/4 (1100)
<b>EVAPORATOR COIL</b>						
Rows...Fins/in.	4...15	4...15	4...15	4...17	4...17	4...17
Face Area (sq ft)	4.7	4.7	4.7	5.7	5.7	5.7
<b>EVAPORATOR BLOWER</b>						
Nominal Airflow (Cfm)	1400	1400	1400	1710	1710	1710
Size (in.)	11x10	11x10	11x10	11x10	11x10	11x10
(mm)	279x254	279x254	279x254	279x254	279x254	279x254
Motor (hp)	3/4 (1075)	3/4 (1075)	3/4 (1075)	1.0 (1040)	1.0 (1040)	1.0 (1040)
<b>FURNACE SECTION*</b>						
Burner Orifice No. (Qty...Drill Size) Natural Gas	3...38	3...33	3...31	3...38	3...33	3...31
Burner Orifice No. (Qty...Drill Size) Propane Gas	3...46	3...42	3...41	3...46	3...42	3...41
<b>HIGH-PRESSURE SWITCH (psig)</b>	650 +/-15					
Cut-out Reset (Auto)	420 +/-25					
<b>LOSS-OF-CHARGE / LOW-PRESSURE SWITCH (Liquid Line) (psig)</b>	20 +/-5					
Cut-out Reset (auto)	45 +/-10					
<b>RETURN-AIR FILTERS Throwaway† (in.)</b>	24x30x1					
(mm)	610x762x25					

\*Based on altitude of 0 to 2000 ft (0-610 m).

†Required filter sizes shown are based on the larger of the ARI (Air Conditioning and Refrigeration Institute) rated cooling airflow or the heating airflow velocity of 300 ft/minute for high-capacity type. Air filter pressure drop for non-standard filters must not exceed 0.08 IN. W.C..

**48XP**




**Table 2 – Maximum Gas Flow Capacity\***

NOMINAL IRON PIPE, SIZE (IN.)	INTERNAL DIAMETER (IN.)	LENGTH OF PIPE, FT (m)†													
		10 (3)	20 (6)	30 (9)	40 (12)	50 (15)	60 (18)	70 (21)	80 (24)	90 (27)	100 (30)	125 (38)	150 (46)	175 (53)	200 (61)
1/2	.622	175	120	97	82	73	66	61	57	53	50	44	40	—	—
3/4	.824	360	250	200	170	151	138	125	118	110	103	93	84	77	72
1	1.049	680	465	375	320	285	260	240	220	205	195	175	160	145	135
1 1/4	1.380	1400	950	770	600	580	530	490	460	430	400	360	325	300	280
1 1/2	1.610	2100	1460	1180	990	900	810	750	690	650	620	550	500	460	430

\* Capacity of pipe in cu ft of gas per hr for gas pressure of 0.5 psig or less. Pressure drop of 0.5-IN. W.C. (based on a 0.60 specific gravity gas). Refer to Table 2 and the NFPA NFPA 54/ANSI Z223.1.

† This length includes an ordinary number of fittings.

4. Install sediment trap in riser leading to heating section (See Fig. 8). This drip leg functions as a trap for dirt and condensate.



**Fig. 8 - Sediment Trap**

C99020

5. Install an accessible, external, manual main shutoff valve in gas supply pipe within 6 ft (2 m) of heating section.
6. Install ground-joint union close to heating section between unit manual shutoff and external manual main shut-off valve.
7. Pressure-test all gas piping in accordance with local and national plumbing and gas codes before connecting piping to unit.

**NOTE:** Pressure test the gas supply system after the gas supply piping is connected to the gas valve. The supply piping must be disconnected from the gas valve during the testing of the piping systems when test pressure is in excess of 0.5 psig. Pressure test the gas supply piping system at pressures equal to or less than 0.5 psig. The unit heating section must be isolated from the gas piping system by closing the external main manual shutoff valve and slightly opening the ground-joint union.

⚠ **WARNING**

**FIRE OR EXPLOSION HAZARD**

Failure to follow this warning could result in personal injury, death and/or property damage.

- Connect gas pipe to unit using a backup wrench to avoid damaging gas controls.
- Never purge a gas line into a combustion chamber. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections.
- Use proper length of pipe to avoid stress on gas control manifold.
- If a flexible connector is required or allowed by authority having jurisdiction, black iron pipe shall be installed at furnace gas valve and extend a minimum of 2 in. (51 mm) outside furnace casing.
- If codes allow a flexible connector, always use a new connector. do not use a connector which has previously serviced another gas appliance.

48XP

8. Check for gas leaks at the field-installed and factory-installed gas lines after all piping connections have been completed. Use soap-and-water solution (or method specified by local codes and/or regulations).

**Step 9 — Install Duct Connections**

The unit has duct flanges on the supply- and return-air openings on the side and bottom of the unit. For downshot applications, the ductwork connects to the roof curb (See Fig. 2 and 3 for connection sizes and locations).

**CONFIGURING UNITS FOR DOWNFLOW (VERTICAL) DISCHARGE**


⚠ **WARNING**

**ELECTRICAL SHOCK HAZARD**

Failure to follow this warning could result in personal injury or death.


Before installing or servicing system, always turn off and tag lockout main power to system. There may be more than one disconnect switch.

1. Open all electrical disconnects before starting any service work.
2. Remove horizontal (metal) duct covers to access vertical (downflow) discharge duct knockouts in unit base.
3. Use a screwdriver and hammer to remove the panels in the bottom of the unit base (See Fig. 9 & 10).



**Fig. 9 - Supply and Return Duct Opening**

C99011



**Fig. 10 - Vertical Duct Cover Removed**

C99012

4. If unit ductwork is to be attached to vertical opening flanges on the unit base (jackstand applications only), do so at this time.



## CAUTION

### PROPERTY DAMAGE HAZARD

Failure to follow this caution may result in property damage. Collect ALL screws that were removed. **Do not** leave screws on rooftop as permanent damage to the roof may occur.

5. It is recommended that the base insulation around the perimeter of the vertical return-air opening be secured to the base with aluminum tape. Applicable local codes may require aluminum tape to prevent exposed fiberglass.
6. Cover both horizontal duct openings with the provided duct covers. Ensure opening is air- and watertight.
7. After completing unit conversion, perform all safety checks and power up unit.

**NOTE:** The design and installation of the duct system must be in accordance with the standards of the NFPA for installation of nonresidence-type air conditioning and ventilating systems, NFPA 90A or residence-type, NFPA 90B; and/or local codes and ordinances.

Adhere to the following criteria when selecting, sizing, and installing the duct system:

1. Units are shipped for horizontal duct installation (by removing duct covers).
2. Select and size ductwork, supply-air registers, and return-air grilles according to American Society of Heating, Refrigeration and Air Conditioning Engineers (ASHRAE) recommendations.
3. Use flexible transition between rigid ductwork and unit to prevent transmission of vibration. The transition may be screwed or bolted to duct flanges. Use suitable gaskets to ensure weather tight and airtight seal.
4. All units must have field-supplied filters or accessory filter rack installed in the return-air side of the unit. Recommended sizes for filters are shown in Table 1.
5. Size all ductwork for maximum required airflow (either heating or cooling) for unit being installed. Avoid abrupt duct size increases or decreases or performance may be affected.
6. Adequately insulate and weatherproof all ductwork located outdoors. Insulate ducts passing through unconditioned space, and use vapor barrier in accordance with latest issue of Sheet Metal and Air Conditioning Contractors National Association (SMACNA) and Air Conditioning Contractors of America (ACCA) minimum installation standards for heating and air conditioning systems. Secure all ducts to building structure.
7. Flash, weatherproof, and vibration-isolate all openings in building structure in accordance with local codes and good building practices.

## Step 10 — Install Electrical Connections

### ⚠ WARNING

#### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

The unit cabinet must have an uninterrupted, unbroken electrical ground. This ground may consist of an electrical wire connected to the unit ground screw in the control compartment, or conduit approved for electrical ground when installed in accordance with NEC, NFPA 70 National Fire Protection Association (latest edition) (in Canada, Canadian Electrical Code CSA C22.1) and local electrical codes.

### ⚠ CAUTION

#### UNIT COMPONENT DAMAGE HAZARD

Failure to follow this caution could result in damage to the unit being installed.

1. Make all electrical connections in accordance with NEC NFPA 70 (latest edition) and local electrical codes governing such wiring. In Canada, all electrical connections must be in accordance with CSA standard C22.1 Canadian Electrical Code Part 1 and applicable local codes. Refer to unit wiring diagram.
2. Use only copper conductor for connections between field-supplied electrical disconnect switch and unit. **DO NOT USE ALUMINUM WIRE.**
3. Be sure that high-voltage power to unit is within operating voltage range indicated on unit rating plate. On 3-phase units, ensure phases are balanced within 2 percent. Consult local power company for correction of improper voltage and/or phase imbalance.
4. Insulate low-voltage wires for highest voltage contained within conduit when low-voltage control wires are in same conduit as high-voltage wires.
5. Do not damage internal components when drilling through any panel to mount electrical hardware, conduit, etc.

#### HIGH-VOLTAGE CONNECTIONS

The unit must have a separate electrical service with a field-supplied, waterproof, disconnect switch mounted at, or within sight from, the unit. Refer to the unit rating plate for maximum fuse/circuit breaker size and minimum circuit amps (ampacity) for wire sizing.

The field-supplied disconnect switch box may be mounted on the unit over the high-voltage inlet hole when the standard power and low-voltage entry points are used (See Fig. 2 and 3 for acceptable location).

See unit wiring label and Fig. 11 for reference when making high voltage connections. Proceed as follows to complete the high voltage connections to the unit.

Single phase units:

1. Run the high-voltage (L1, L2) and ground leads into the control box.
2. Connect ground lead to chassis ground connection.
3. Connect L1 to pressure lug connection 11 of the compressor contactor.
4. Connect L2 to pressure lug connection 23 of the compressor contactor.




Fig. 11 - High and Control-Voltage Connections

A08476

Three-phase units:

1. Run the high-voltage (L1, L2, L3) and ground leads into the control box.
2. Connect ground lead to chassis ground connection.
3. Locate the black and yellow wires connected to the lines side of the contactor.
4. Connect field L1 to black wire on connection 11 of the compressor contactor.
5. Connect field wire L2 to yellow wire on connection 13 of the compressor contactor.
6. Connect field wire L3 to Blue wire from compressor.

#### SPECIAL PROCEDURES FOR 208-V OPERATION

### ⚠ WARNING

#### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Make sure the power supply to the unit is switched OFF before making any wiring changes. With disconnect switch open, move yellow wire from transformer (3/16 in.) terminal marked 230 to terminal marked 208. This retaps transformer to primary voltage of 208 vac.

### ⚠ WARNING

#### ELECTRICAL SHOCK FIRE/EXPLOSION HAZARD

Failure to follow this warning could result in personal injury or death and property damage.

Before making any wiring changes, **make sure** the gas supply is switched off first. *Then* switch off the power supply to the unit and install lockout tag.

#### CONTROL VOLTAGE CONNECTIONS

Do not use any type of power-stealing thermostat. Unit control problems may result.

Use no. 18 American Wire Gage (AWG) color-coded, insulated (35 C minimum) wires to make the control voltage connections between the thermostat and the unit. If the thermostat is located more than 100 ft (30 m) from the unit (as measured along the control voltage wires), use no. 16 AWG color-coded, insulated (35 C minimum) wires.

Locate the six low voltage thermostat leads in 24 volt splice box. See Fig. 11 for connection diagram. Run the low-voltage leads from the thermostat, through the control wiring inlet hole grommet (Fig. 2 and 3), and into the low-voltage splice box. Provide a drip loop before running wires through panel. Secure and strain relief all wires so that they do not interfere with operation of unit.

### Easy Select™ - 48XP

#### EASY SELECT™ CONFIGURATION TAPS FOR 48XP

Easy Select taps are used by the installer to configure a system. The ECM motor uses the selected taps to modify its operation to a pre-programmed table of airflows.

The unit must be configured to operate properly with system components with which it is installed. To successfully configure a basic system (see information printed on circuit board label located next to select pins), move the 6 select wires to the pins which match the components used (See Fig. 12).

- a. GAS HEAT/CFM-SELECT GAS HEAT INPUT SIZE  
Factory selected gas heat size should correspond to unit label.

- b. AC/HP SIZE- SELECT SYSTEM SIZE INSTALLED  
Factory selected air conditioner size should correspond to capacity of unit installed. Installer should verify air conditioner size to ensure that airflow delivered falls within proper range for the size unit installed. This applies to all operational modes.

- c. SYSTEM TYPE—SELECT SYSTEM TYPE INSTALLED

Factory selected on 48XP for AC-Air conditioner.  
For Gas Heat/Electric Cool Unit-AC must be selected.

- d. AC/HP CFM ADJUST-SELECT NOMINAL, LOW, OR HIGH AIRFLOW

The AC/HP CFM Adjust select is factory set to the NOM tap. The CFM Adjust selections NOM/LO will regulate airflow supplied for all operational modes, except non-heat pump heating modes. HI provides 15 percent airflow over nominal unit size selected and LO provides 10 percent airflow below nominal unit size selected. Adjust selection options are provided to adjust airflow supplied to meet individual installation needs for such things as noise, comfort, and humidity removal (See Fig. 12, D as indicated).

- e. ON/OFF DELAY- SELECT DESIRED TIME DELAY PROFILE

Four motor operation delay profiles are provided to customize and enhance system operation (See Fig. 12, E as indicated).

Selection options are:

- (1.) The standard 90 sec off delay (Factory Setting) at 100 percent airflow in cooling mode. In heating mode, IGC will control 45 sec on delay with no airflow and 45 sec off delay.
- (2.) A 30 sec cooling delay with no airflow/ 90 sec off delay at 100 percent airflow profile is used when it is desirable to allow system coils time to cool-down in conjunction with the airflow in heating mode.




Fig. 12 - Detail of SPP Printed-Circuit Board

C01039

- (3.) A no delay option used for servicing unit or when a thermostat is utilized to perform delay functions in cooling mode. In heating mode IGC will control 45 sec on delay with no airflow and 45 sec off delay.

- (4.) ENH- Not recommended for 48XP

- f. CONTINUOUS FAN—SELECT DESIRED FAN SPEED WHEN THERMOSTAT IS SET ON CONTINUOUS FAN

- (1.) LO speed-Factory setting, 50 percent cooling mode airflow.
- (2.) MED speed-Move connector to MED, 65 percent cooling mode airflow.
- (3.) HI speed-Move connector to HI, 100 percent cooling mode airflow (See Fig. 12, F as indicated).

- g. LOW-VOLTAGE CIRCUIT FUSING AND REFERENCE

The low-voltage circuit is fused by a board-mounted 5-amp automotive fuse placed in series with the transformer SEC2 and the R circuit. The C circuit of the transformer is referenced to chassis ground through a printed circuit run at SEC1 connected to metal standoff marked with ground symbol.

- h. BASIC UNIT CONFIGURATION

The following basic configuration of the indoor motor will provide ARI rated performance of the 48XP. This BASIC CONFIGURATION should be used when the rated ARI performance is required, or if system enhancements such as super dehumidify are not needed.

- (1.) HEAT-Factory selected to match heat input size.
- (2.) AC/HP Size-Factory selected to match system size, please verify.
- (3.) SYSTEM TYPE-Factory selected on 48XP system AC-AIR CONDITIONER.
- (4.) AC/HP CFM ADJUST-Select NOM.
- (5.) ON/OFF DELAY-Factory selected 0/90 profile.  
(Do Not Use ENH profile for Gas Packaged Units)

- (6.) CONTINUOUS FAN—Select desired fan speed when thermostat is set to continuous fan.
- i. COMFORT OPTIONS—SUPER DEHUMIDIFY (See Quick Reference Guide)  
The Super Dehumidify option is possible when this unit is installed with a field supplied Thermidstat™ control (SuperDehumidify does not require an outdoor temperature sensor). The following configuration is recommended for maximum cooling/dehumidifying comfort. This configuration will improve the comfort provided by the air conditioning system if more humidity removal is desired. While providing this improved comfort, the system will operate efficiently, but not at the published ARI SEER efficiency. During cool-to-dehumidify call, it provides maximum dehumidification by reducing airflow to a minimum. The actual super dehumidify command from Thermidstat control to the indoor unit is a “Y” signal without a “G” signal in addition to dehumidify signal. The indoor unit responds to this combination by reducing the airflow to a minimum. All other characteristics of cool to dehumidify are the same. The following system configuration is recommended for maximum cooling/dehumidifying comfort (See Fig. 12).

- (1.) HEAT—Factory selected to match gas heat size of unit installed.
- (2.) AC/HP Size—Factory selected to match system size, please verify.
- (3.) SYSTEM TYPE—Factory selected on 48XP system AC—AIR CONDITIONER.
- (4.) AC/HP CFM ADJUST—Select NOM.
- (5.) ON/OFF DELAY—Select “0/0” profile.
- (6.) CONTINUOUS FAN—Select desired fan speed when thermostat is set to continuous fan.
- (7.) DEHUMIDIFY MODE—Remove J1 jumper to activate.


**NOTE:** J1 jumper should only be removed when a Thermidstat, humidistat or capable zoning control is installed.

- (8.) LOW VOLTAGE CONNECTIONS—Make connections as shown in ELECTRICAL CONNECTIONS section.
- (9.) CONFIGURE THERMIDSTAT—Follow Thermidstat (or capable zoning system) installation instructions for Super Dehumidify operation.

**ACCESSORY INSTALLATION**


- a. AUXILIARY TERMINALS The AUX and HUM terminals on the Easy Select Board are tied directly to the G terminal, and provide a 24-v. signal whenever the G terminal is energized (See Fig. 12). During Super dehumidify mode, the G signal is not present and the auxiliary terminals are not energized. If the installation includes the use of this operating mode, do not use these terminals to control accessories. See Electronic Air Cleaner and Humidifier sections for further information.
- b. ELECTRONIC AIR CLEANER CONNECTIONS The AUX1 and AUX2 terminals are not always energized during blower operations, as described above. When using an electronic air cleaner with the unit, use Airflow Sensor (See Air Cleaner Price Pages for Part Number). The airflow sensor turns on electronic air cleaner when the blower is operating.

- c. HUMIDIFIER/HUMIDISTAT CONNECTIONS Easy Select Board terminals HUM1 and HUM2 are provided for direct connection to the low-voltage control of a humidifier through a standard humidistat (See Fig. 12). These terminals are energized with 24-v. when G thermostat signal is present (See Fig. 13 & 14). Alternately, the 24-v. signal may be sourced from the W and C on the 9 pin connector. When using a Thermidstat Control, Zone Comfort Plus or Comfort Zone II, the 24-v. signal may be sourced directly from the Thermidstat HUM terminal (See Fig. 12, 13 & 14).
- d. DEHUMIDIFY CAPABILITY WITH STANDARD HUMIDISTAT CONNECTION Latent capacities for this unit are better than average systems. If increased latent capacity is an application requirement, the ECM board provides connection terminals for use of a standard humidistat. The unit will detect the humidistat contacts opening on increasing humidity and reduce its airflow to approximately 80 percent of nominal cooling mode airflow. This reduction will increase the system latent capacity until the humidity falls to a level which causes the humidistat to close its contacts. When the contacts close, the airflow will return to 100 percent of selected cooling airflow. To activate this mode, remove jumper J1 and wire in a standard humidistat (See Fig. 14).
- e. DEHUMIDIFY AND SUPER DEHUMIDIFY CAPABILITIES This model unit is capable of responding to a signal from indoor system control (Thermidstat or capable zoning control) to operate in comfort control modes such as Super Dehumidify Mode. Consult literature provided with indoor system control to determine if these operating modes are available, and to see control set up instructions. No special setup or wiring of unit is required.



**Fig. 13 - Humidifier Wiring - 48XP**

A95317



**Fig. 14 - Humidistat Wiring for De-Humidify Mode - 48XP**

A95316

**TRANSFORMER PROTECTION**

The transformer is of the energy-limiting type. It is set to withstand a 30-sec. overload or shorted secondary condition.

## PRE-START-UP

### WARNING

#### FIRE, EXPLOSION, ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury, death or property damage.

1. Follow recognized safety practices and wear protective goggles when checking or servicing refrigerant system.
2. Do not operate compressor or provide any electric power to unit unless compressor terminal cover is in place and secured.
3. Do not remove compressor terminal cover until all electrical sources are disconnected and tagged.
4. Relieve and recover all refrigerant from system before touching or disturbing anything inside terminal box if refrigerant leak is suspected around compressor terminals.
5. Never attempt to repair soldered connection while refrigerant system is under pressure.
6. Do not use torch to remove any component. System contains oil and refrigerant under pressure. To remove a component, wear protective goggles and proceed as follows:
  - a. Shut off electrical power to unit and install lockout tag.
  - b. Relieve and reclaim all refrigerant from system using both high- and low-pressure ports.
  - c. Cut component connecting tubing with tubing cutter and remove component from unit.
  - d. Carefully unsweat remaining tubing stubs when necessary. Oil can ignite when exposed to torch flame.

48XP

Proceed as follows to inspect and prepare the unit for initial startup:

1. Remove access panel.
2. Read and follow instructions on all WARNING, CAUTION, and INFORMATION labels attached to, or shipped with, unit.
3. Make the following inspections:
  - a. Inspect for shipping and handling damages such as broken lines, loose parts, disconnected wires, etc.
  - b. Inspect for oil at all refrigerant tubing connections and on unit base. Detecting oil generally indicates a refrigerant leak.
  - c. Leak test all refrigerant tubing connections using electronic leak detector, halide torch, or liquid-soap solution. If a refrigerant leak is detected, see the Check for Refrigerant Leaks section.
  - d. Inspect all field- and factory-wiring connections. Be sure that connections are completed and tight.
  - e. Inspect coil fins. If damaged during shipping and handling, carefully straighten fins with a fin comb.
4. Verify the following conditions:

### WARNING


#### FIRE, EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death or property damage.

Do not purge gas supply into the combustion chamber. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections.

- a. Make sure gas line is free of air. Before lighting the unit for the first time, perform the following with the gas valve in the “OFF” position:

If the gas supply pipe was not purged before connecting the unit, it will be full of air. It is recommended that the ground joint union be loosened, and the supply line be allowed to purge until the odor of gas is detected. Never purge gas lines into a combustion chamber. Immediately upon detection of gas odor, retighten the union. Allow 5 minutes to elapse, then light unit.
- b. Make sure that condenser-fan blade is correctly positioned in fan orifice. Leading edge of condenser-fan blade should be 1/2 in. (13 mm) maximum from fan orifice.
- c. Ensure fan hub is 1/8 in. (3 mm) maximum from motor housing (See Fig. 15).
- d. Make sure that air filter(s) is in place.
- e. Make sure that condensate drain trap is filled with water to ensure proper drainage.
- f. Make sure that all tools and miscellaneous loose parts have been removed.



A08474

Fig. 15 - Fan Blade Clearance

## START-UP

### Step 1 — Check for Refrigerant Leaks

Proceed as follows to locate and repair a refrigerant leak and to charge the unit:

1. Locate leak and make sure that refrigerant system pressure has been relieved and reclaimed from both high- and low-pressure ports.
2. Repair leak following Refrigerant Service procedures.

**NOTE:** Install a filter drier whenever the system has been opened for repair.

3. Add a small charge of R-410A refrigerant vapor to system and leak-test unit.
4. Evacuate and recover refrigerant from refrigerant system if additional leaks are not found.
5. Charge unit with R-410A refrigerant, using a volume tri-charging cylinder or accurate scale. Refer to unit rating plate for required charge.

### Step 2 — Unit Sequence of Operation

#### 48XP Sequence of Operation

- a. CONTINUOUS FAN
  - (1.) Thermostat closes circuit R to G-The Blower runs at continuous fan airflow.
- b. COOLING MODE
  - (1.) If indoor temperature is above temperature set point and humidity is below humidity set point, thermostat closes circuits R to G, R to Y/Y2 and R to O-The unit delivers single speed cooling airflow.
- c. COOLING MODE-DEHUMIDIFICATION
  - (1.) If indoor temperature is above temperature set point and humidity is above humidity set point,

thermostat or Thermidistat closes circuits R to G, R to Y/Y2, R to O and humidistat or Thermidistat opens R to DH-The unit delivers airflow which is approximately 80 percent of the nominal cooling airflow to increase the latent capacity of the system.

d. COOLING MODE-SUPER DEHUMIDIFY  
OPERATION (SEE QUICK REFERENCE GUIDE)

**NOTE:** The indoor control used, such as a Thermidistat, must be capable of providing Super Dehumidify operation mode and control must be configured as outlined in its installation instructions. Consult indoor control literature to determine if control is capable of providing Super Dehumidify inputs and for configuration instruction.

- (1.) If the indoor temperature is below the temperature set point and the humidity is above the humidity set point, the Thermidistat closes circuit R to O, opens circuits R to DH and R to G, and closes circuit R to Y/Y2. If circuit R to G is closed (24-v.), the motor will deliver airflow at the full cooling or cooling plus dehumidify mode requested value. If circuit R to G is open (0-v.) for Super Dehumidify mode, the motor delivers reduced airflow to maximize the humidity removal of the system while minimizing over cooling.

e. GAS HEATING MODE

- (1.) Thermostat closes circuit R to W/W1-The unit delivers the selected gas heat airflow. The IGC will control a 45 sec. blower "On" delay and a 45 sec. "Off" delay.

### Step 3 — Start-Up Heating and Make Adjustments

**⚠ CAUTION**

**UNIT COMPONENT DAMAGE HAZARD**

Failure to follow this caution may result in damage to the unit being installed.

Complete the required procedures given in the Pre-Start-Up section before starting the unit. Do not jumper any safety devices when operating the unit.

Make sure that burner orifices are properly aligned. Unstable operation may occur when the burner orifices in the manifold are misaligned.

Follow the lighting instructions on the heating section operation label (located inside the burner or blower access door) to start the heating section.

**NOTE:** Make sure that gas supply has been purged, and that all gas piping has been checked for leaks.

#### CHECK HEATING CONTROL

Start and check the unit for proper cooling control operation as follows (see furnace lighting instructions located inside burner or blower access panel):

1. Place room thermostat SYSTEM switch in the HEAT position and the fan switch is placed in AUTO position.
2. Set the heating temperature control of the thermostat above room temperature.
3. The induced-draft motor will start.
4. After a call for heating, the main burner should light within 5 sec. If the burners do not light, there is a 22-sec. delay before another 5-sec. try. If the burners still do not light,

this sequence is repeated. If the burners do not light within 15 minutes from the initial call for heat, there is a lockout. To reset the control, break the 24-v power to W.

5. The evaporator fan will turn on 45 sec. after the flame has been established. The evaporator fan will turn off 45 sec. after the thermostat has been satisfied.

#### CHECK GAS INPUT

Check gas input and manifold pressure after unit start-up (See Table 3). If adjustment is required proceed as follows:

- The rated gas inputs shown in Table 3 are for altitudes from sea level to 2000 ft (610 m) above sea level. These inputs are based on natural gas with a heating value of 1050 Btu/ft<sup>3</sup> at 0.65 specific gravity, or propane gas with a heating value of 2500 Btu/ft<sup>3</sup> at 1.5 specific gravity.
- In the U.S.A. for elevations above 2000 ft (610 mm), reduce input 4% for each 1000 ft (305 m) above sea level. In Canada for elevations from 2001 ft (610 m) to 4500 ft (1372 m) above sea level reduce input 10%.
- When the gas supply being used has a different heating value or specific gravity, refer to national and local codes, or contact your distributor to determine the required orifice size.

**⚠ CAUTION**

**UNIT DAMAGE HAZARD**

Failure to follow this caution may result in reduced unit and/or component life.

**Do Not** redrill an orifice. Improper drilling (burrs, out-of-round holes, etc.) can cause excessive burner noise and misdirection of burner flame. Replace with correct sized orifices.

#### ADJUST GAS INPUT

The gas input to the unit is determined by measuring the gas flow at the meter or by measuring the manifold pressure. Measuring the gas flow at the meter is recommended for natural gas units. The manifold pressure must be measured to determine the input of propane gas units.


##### Measure Gas Flow (Natural Gas Units)

Minor adjustment to the gas flow can be made by changing the manifold pressure. The manifold pressure must be maintained between 3.4 and 3.6 IN. W.C.. If larger adjustments are required, change main burner orifices following the recommendations of national and local codes.

**NOTE:** All other appliances that use the same meter must be turned off when gas flow is measured at the meter. Proceed as follows:

1. Turn off gas supply to unit.
2. Remove pipe plug on manifold (See Fig. 16) and connect manometer. Turn on gas supply to unit.
3. Record number of seconds for gas meter test dial to make one revolution.
4. Divide number of seconds in Step 3 into 3600 (number of seconds in one hr).
5. Multiply result of Step 4 by the number of cu ft shown for one revolution of test dial to obtain ft<sup>3</sup> of gas flow per hr.
6. Multiply result of Step 5 by Btu heating value of gas to obtain total measured input in Btu. Compare this value with heating input shown in Table 3 (Consult the local gas supplier if the heating value of gas is not known).

48XP



MANIFOLD

PIPE PLUG

C99019

**Fig. 16 - Burner Assembly**

EXAMPLE: Assume that the size of test dial is 1 ft<sup>3</sup>, one revolution takes 32 sec., and the heating value of the gas is 1050 Btu/ft<sup>3</sup>. Proceed as follows:

1. 32 sec. to complete one revolution.
2.  $3600 \div 32 = 112.5$ .
3.  $112.5 \times 1 = 112.5$  ft<sup>3</sup> of gas flow/hr.
4.  $112.5 \times 1050 = 118,125$  Btuh input.

If the desired gas input is 115,000 Btuh, only a minor change in the manifold pressure is required.

Observe manifold pressure and proceed as follows to adjust gas input:

1. Remove cover screw over regulator adjustment screw on gas valve.
2. Turn regulator adjustment screw clockwise to increase gas input, or turn regulator adjustment screw counterclockwise to decrease input. Manifold pressure must be between 3.4 and 3.6 IN. W.C.. Unsafe operation of the unit may result if manifold pressure is outside this range. Personal injury or unit damage may result.

## **▲ WARNING**

### **FIRE AND UNIT DAMAGE HAZARD**

Failure to follow this warning could result in personal injury or death and/or property damage.

Unsafe operation of the unit may result if manifold pressure is outside this range.

3. Replace cover screw cap on gas valve.
4. Turn off gas supply to unit. Remove manometer from pressure tap and replace pipe plug on gas valve. Turn on gas to unit and check for leaks.

### Measure Manifold Pressure (Propane Units)

The main burner orifices on a propane gas unit are sized for the unit rated input when the manifold pressure reading matches the level specified in Table 3.


Proceed as follows to adjust gas input on a propane gas unit:

1. Turn off gas to unit.
2. Remove pipe plug on manifold and connect manometer (See Fig. 16).
3. Turn on gas to unit.

4. Remove cover screw over regulator adjustment screw on gas valve.
5. Adjust regulator adjustment screw to the correct manifold pressure, as specified in Table 3. Turn adjusting screw clockwise to increase manifold pressure, or turn adjusting screw counterclockwise to decrease manifold pressure.
6. Replace cover screw.
7. Turn off gas to unit. Remove manometer from pressure tap. Replace pipe plug on gas valve, then turn on gas to unit. Check for leaks.

### **CHECK BURNER FLAME**

With burner access panel removed, observe the unit heating operation. Watch the burner flames to see if they are light blue and soft in appearance, and that the flames are approximately the same for each burner. Propane will have blue flame with yellow tips (See Fig. 17). Refer to the Maintenance section for information on burner removal.



C99021

**Fig. 17 - Monoport Burner**

### **AIRFLOW AND TEMPERATURE RISE**

The heating section for each size unit is designed and approved for heating operation within the temperature-rise range stamped on the unit rating plate. Table 4 shows the approved temperature rise range for each heating input, and the air delivery cfm at various temperature rises. The heating operation airflow must produce a temperature rise that falls within the approved range. Refer to Indoor Airflow and Airflow Adjustments section to adjust heating airflow when required.

### **LIMIT SWITCHES**

Normally closed limit switch (LS) completes the control circuit through the thermostat R circuit. Should the leaving-air temperature rise above the maximum allowable temperature, the limit switch opens and the R control circuit "breaks." Any interruption in the R control circuit instantly closes the gas valve and stops gas flow to the burners and pilot. The blower motor continues to run until LS resets.

When the air temperature at the limit switch drops to the low-temperature setting of the limit switch, the switch closes and completes the R control circuit. The electric-spark ignition system cycles and the unit returns to normal heating operation.

### **AUXILIARY LIMIT SWITCH (ROLLOUT)**

The function of the switch is to close the main gas valve in the event of flame rollout. The switch is located above the main burners. When the temperature at the auxiliary switch reaches the maximum allowable temperature, the R control circuit trips, closing the gas valve and stopping gas flow to the burners. The indoor (evaporator) fan motor (IFM) and induced draft motor continue to run until switch is reset. The IGC LED will display FAULT CODE 7.



## Step 4 — Start-Up Cooling and Make Adjustments

### **WARNING**

#### UNIT DAMAGE HAZARD

Failure to follow this warning could result in unit component damage.

Complete the required procedures given in the Pre-Start-Up section before starting the unit. Do not jumper any safety devices when operating the unit. Do not operate the compressor when the outdoor temperature is below 55°F (13°C) (unless accessory low-ambient kit is installed). Do not rapid-cycle the compressor. To prevent compressor damage allow 5 minutes between “on” cycles.

### CHECKING COOLING CONTROL OPERATION

Start and check the unit for proper cooling control operation as follows:

1. Place room thermostat SYSTEM switch in OFF position. Observe that blower motor starts when FAN switch is placed in ON position and shuts down when FAN switch is placed in AUTO. position.
2. Place SYSTEM switch in COOL position and FAN switch in AUTO. position. Set cooling control below room temperature. Observe that compressor, condenser fan, and evaporator blower motors start. Observe that cooling cycle shuts down when control setting is satisfied. The evaporator fan will continue to run for the time selected on the Easy Select board.
3. When using an auto-changeover room thermostat, place both SYSTEM and FAN switches in AUTO positions. Observe that unit operates in Heating mode when temperature control is set to “call for heating” (above room temperature) and operates in Cooling mode when temperature control is set to “call for cooling” (below room temperature).

48XP

Table 3 – Heating Inputs

HEATING INPUT (BTUH)*	NUMBER OF ORIFICES	GAS SUPPLY PRESSURE (IN. W.C.)				MANIFOLD PRESSURE (IN. W.C.)	
		Natural		Propanet		Natural	Propanet
		Min	Max	Min	Max		
40,000	2	4.0	13.0	4.0	13.0	3.5	3.5
60,000	2	4.0	13.0	4.0	13.0	3.5	3.5
90,000	3	4.0	13.0	4.0	13.0	3.5	3.4
115,000	3	4.0	13.0	4.0	13.0	3.5	3.7
130,000	3	4.0	13.0	4.0	13.0	3.5	3.5

\* When a unit is converted to propane, different size orifices must be used. See separate, natural-to-propane conversion kit instructions.

† Based on altitudes from sea level to 2000 ft above sea level. For altitudes above 2000 ft, reduce input rating 4 percent for each additional 1000 ft (305 m) above sea level. In Canada, from 2000 ft (610 m) above sea level to 4500 ft (1372 m) above sea level, de-rate the unit 10 percent.

Table 4 – Air Delivery (CFM) at Indicated Temperature Rise and Rated Heating Input

HEATING INPUT (BTUH)	TEMPERATURE RISE °F										
	20	25	30	35	40	45	50	55	60	65	70
40,000	1500	1200	1000	857	750	667	600	545	500	—	—
60,000	2250	1800	1500	1286	1125	1000	900	818	750	692	—
90,000	—	—	2250	1929	1688	1500	1350	1227	1125	1038	964
115,000	—	—	—	2464	2156	1917	1725	1568	1438	1327	1232
130,000	—	—	—	2786	2438	2167	1950	1773	1625	1500	—

NOTE: Dashed areas do not fall within the approved temperature rise range of the unit.

Table 5 – LED Indications

ERROR CODE	LED INDICATION
Normal Operation	On
Hardware Failure	Off
Fan On/Off Delay Modified	1 Flash
Limit Switch Fault	2 Flashes
Flame Sense Fault	3 Flashes
Four Consecutive Limit Switch Faults	4 Flashes
Ignition Lockout Fault	5 Flashes
Induced-Draft Motor Fault	6 Flashes
Rollout Switch Fault	7 Flashes
Internal Control Fault	8 Flashes
Safety Critical Code Fault	9 Flashes

NOTES:

1. There is a 3-sec. pause between error code displays.
2. If more than one error code exists, all applicable error codes will be displayed in numerical sequence.
3. This chart is on the wiring diagram located inside the burner access panel.

Table 6 – Filter Pressure Drop (IN. W.C.)

FILTER SIZE in. (mm)	CFM																		
	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300
20X20X1 (508X508X25)	0.05	0.07	0.08	0.10	0.12	0.13	0.14	0.15	—	—	—	—	—	—	—	—	—	—	—
20X24X1 (508X610X25)	—	—	—	—	0.09	0.10	0.11	0.13	0.14	0.15	0.16	—	—	—	—	—	—	—	—
24X30X1 (610X762X25)	—	—	—	—	—	—	—	0.07	0.08	0.09	0.10	0.11	0.12	0.13	0.14	0.15	0.16	0.17	0.18

**Table 7 – 48XP Cooling Dry Coil ECM Airflow Small Cabinet**

UNIT SIZE	CFM ADJUST PIN SELECT	LO PIN			NOM PIN			HI PIN		
	EXTERNAL STATIC PRESSURE RANGE (IN. W.C.)	0.0–0.39	0.4–0.69	0.7–1.0	0.0–0.39	0.4–0.69	0.7–1.0	0.0–0.39	0.4–0.69	0.7–1.0
024	COOLING	800	725	–	885	805	730	990	930	855
	COOLING DEHUMIDIFY	715	670	–	715	695	645	795	775	745
030	COOLING	1010	920	825	1105	1030	930	1255	1160	1050
	COOLING DEHUMIDIFY	890	845	795	890	865	825	1010	980	925
036	COOLING	1110	1025	970	1235	1175	1115	1400	1355	1280
	COOLING DEHUMIDIFY	990	960	910	990	975	940	1125	1110	1085

**Table 8 – 48XP Cooling Dry Coil ECM Airflow Large Cabinet**

UNIT SIZE	CFM ADJUST PIN SELECT	LO PIN	NOM PIN	HI PIN
	EXTERNAL STATIC PRESSURE RANGE (IN. W.C.)	0.1–1.0	0.1–1.0	0.1–1.0
042	COOLING	1100	1225	1410
	COOLING DEHUMIDIFY	980	980	1125
048	COOLING	1260	1400	1610
	COOLING DEHUMIDIFY	1120	1120	1290
060	COOLING	1575	1750	2010
	COOLING DEHUMIDIFY	1400	1400	1610

**Table 9 – 48XP Gas Heating ECM Airflow Small Cabinet**

EASY SELECT™ BOARD SETTING (CFM)		700			800			1100			1250		
Unit Size	External Static Pressure (IN. W.C.)	0.0–0.4	0.4–0.7	0.7–1.0	0.0–0.4	0.4–0.7	0.7–1.0	0.0–0.4	0.4–0.7	0.7–1.0	0.0–0.4	0.4–0.7	0.7–1.0
	Gas Heat Size												
024	040	–	–	–	855	770	710	–	–	–	–	–	–
	060	–	–	–	–	–	–	1020	890	835	–	–	–
030	040	–	–	–	880	840	805	–	–	–	–	–	–
	060	–	–	–	–	–	–	1030	970	910	–	–	–
036	060	–	–	–	–	–	–	1035	995	955	–	–	–
	090	–	–	–	–	–	–	–	–	–	1170	1110	1025

**Table 10 – 48XP Gas Heating ECM Airflow Large Cabinet**

EASY SELECT™ BOARD SETTING (CFM)		1000	1250	1600	1750	1800
Unit Size	External Static Pressure (IN. W.C.)	0.0–1.0	0.0–1.0	0.0–1.0	0.0–1.0	0.0–1.0
	Gas Heat Size					
042	060	1000	–	–	–	–
	090	–	1250	–	–	–
048	090	–	1250	–	–	–
	115	–	–	1600	–	–
060	130	–	–	–	1750	–
	090	–	1250	–	–	–
	115	–	–	1600	–	–
	130	–	–	–	–	1800

**Table 11 – ECM Wet Coil Pressure Drop (IN. W.C.)**



UNIT SIZE	STANDARD CFM (SCFM)															
	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100
024	0.005	0.007	0.010	0.012	0.015	–	–	–	–	–	–	–	–	–	–	–
030	–	0.007	0.010	0.012	0.015	0.018	0.021	0.024	–	–	–	–	–	–	–	–
036	–	–	–	0.019	0.023	0.027	0.032	0.037	0.042	0.047	–	–	–	–	–	–
042	–	–	–	–	0.014	0.017	0.020	0.024	0.027	0.031	0.035	0.039	0.043	–	–	–
048	–	–	–	–	–	–	0.027	0.032	0.036	0.041	0.046	0.052	0.057	0.063	0.068	–
060	–	–	–	–	–	–	–	–	–	0.029	0.032	0.036	0.040	0.045	0.049	0.053

48XP

# SCHEMATIC 208/230-1-60

## LEGEND

- |   |         |                                |
|---|---------|--------------------------------|
| △ FIELD SPLICE                          | EQUIP   | EQUIPMENT                      |
| ○ TERMINAL (UNMARKED)                   | FS      | FLAME SENSOR                   |
| ○ SPLICE (UNMARKED)                     | FU      | FUSE                           |
| ○ SPLICE (MARKED)                       | GND     | GROUND                         |
| — FACTORY WIRING                        | GVR     | GAS VALVE RELAY                |
| - - - FIELD CONTROL WIRING              | HPS     | HIGH PRESSURE SWITCH           |
| - - - FIELD POWER WIRING                | HS      | HALL EFFECT SENSOR             |
| - - - ACCESSORY OR OPTIONAL WIRING      | HV TRAN | HIGH VOLTAGE TRANSFORMER       |
| - - - TO INDICATE COMMON POTENTIAL ONLY | I       | IGNITOR                        |
| - - - NOT TO REPRESENT WIRING           | ICM     | INTEGRATED CONTROL MOTOR       |
|   | IDM     | INDUCED DRAFT MOTOR            |
|   | IFM     | INDOOR FAN MOTOR               |
|   | IGC     | INTEGRATED GAS UNIT CONTROLLER |
|   | LPS     | LOW PRESSURE SWITCH            |
|   | LS      | LIMIT SWITCH                   |
|   | MGV     | MAIN GAS VALVE                 |
|   | OMP     | OUTDOOR FAN MOTOR              |
|   | QT      | QUADRUPLE TERMINAL             |
|   | CR      | COMBUSTION RELAY               |
|   | RS      | ROLLOUT SWITCH                 |
|   | TRAN    | TRANSFORMER                    |




48XP

Fig. 18 - 208/230-1-60 Wiring Diagram, Unit 48XP

48GP500258 9.0

A08462

SCHEMATIC  
208/230-3-60



48XP

48XP500149 6.0

A08463

Fig. 19 - 208/230-3-60 Wiring Diagram, Unit 48XP

Model Size	Required Subcooling of (°C)					Required Liquid Line Temperature for a Specific Subcooling (R-410A)											
	Outdoor Ambient Temperature					Préssure (psig)	Required Subcooling (°F)					Préssure (kPa)	Required Subcooling (°C)				
	75 (24)	82 (28)	85 (29)	95 (35)	105 (41)		5	10	15	20	25		3	6	8	11	14
024	10.3 (5.7)	9.8 (5.4)	9.4 (5.2)	9 (5)	8.6 (4.7)	189	61	56	51	46	41	1303	16	13	11	8	5
030	9.3 (5.2)	8.8 (4.9)	8.6 (4.8)	7.8 (4.3)	7 (3.9)	196	63	58	53	48	43	1351	17	15	12	9	6
036	17.6 (9.8)	16.8 (9.3)	16.5 (9.2)	15.4 (8.6)	14.3 (7.9)	203	66	61	56	51	46	1399	19	16	13	10	8
042	12.8 (7.1)	12.7 (7.1)	12.7 (7.1)	12.6 (7)	12.6 (7)	210	68	63	58	53	48	1448	20	17	14	11	9
048	17.5 (9.7)	16.9 (9.4)	16.6 (9.2)	15.7 (8.7)	14.8 (8.2)	217	70	65	60	55	50	1496	21	18	15	13	10
060	13.7 (7.6)	13 (7.2)	13 (7.2)	14.5 (8.1)	11.5 (6.4)	224	72	67	62	57	52	1544	22	19	16	14	11
<b>Charging Procedure</b>						231	74	69	64	59	54	1593	23	20	18	15	12
1- Measure Discharge line pressure by attaching a gauge to the service port.						238	76	71	66	61	56	1641	24	21	19	16	13
2- Measure the Liquid line temperature by attaching a temperature sensing device to it.						245	77	72	67	62	57	1689	25	22	20	17	14
3- Insulate the temperature sensing device so that the Outdoor Ambient doesn't affect the reading.						252	79	74	69	64	59	1737	26	23	21	18	15
4- Refer to the required Subcooling in the table based on the model size and the Outdoor Ambient temperature.						260	81	76	71	66	61	1792	27	25	22	19	16
5- Interpolate if the Outdoor ambient temperature lies in between the table values. Extrapolate if the temperature lies beyond the table range.						268	83	78	73	68	63	1848	29	26	23	20	17
6- Find the Pressure Value in the table corresponding to the the measured Pressure of the Compressor Discharge line.						276	85	80	75	70	65	1903	30	27	24	21	19
7- Read across from the Pressure reading to obtain the Liquid line temperature for a required Subcooling						284	87	82	77	72	67	1958	31	28	25	22	20
8- Add Charge if the measured temperature is higher than the table value.						292	89	84	79	74	69	2013	32	29	26	23	21
						300	91	86	81	76	71	2068	33	30	27	24	22
						309	93	88	83	78	73	2130	34	31	28	26	23
						318	95	90	85	80	75	2192	35	32	29	27	24
						327	97	92	87	82	77	2254	36	33	31	28	25
						336	99	94	89	84	79	2316	37	34	32	29	26
						345	101	96	91	86	81	2378	38	35	33	30	27
						354	103	98	93	88	83	2440	39	36	34	31	28
						364	105	100	95	90	85	2509	40	38	35	32	29
						374	107	102	97	92	87	2578	41	39	36	33	30
						384	108	103	98	93	88	2647	42	40	37	34	31
						394	110	105	100	95	90	2716	44	41	38	35	32
						404	112	107	102	97	92	2785	45	42	39	36	33
						414	114	109	104	99	94	2854	46	43	40	37	34
						424	116	111	106	101	96	2923	47	44	41	38	35
						434	118	113	108	103	98	2992	48	45	42	39	36
						444	119	114	109	104	99	3061	48	46	43	40	37
						454	121	116	111	106	101	3130	49	47	44	41	38
						464	123	118	113	108	103	3199	50	48	45	42	39
						474	124	119	114	109	104	3268	51	48	46	43	40
						484	126	121	116	111	106	3337	52	49	47	44	41
						494	127	122	117	112	107	3406	53	50	47	45	42
						504	129	124	119	114	109	3475	54	51	48	46	43
						514	131	126	121	116	111	3544	55	52	49	46	44
						524	132	127	122	117	112	3612	56	53	50	47	45
						534	134	129	124	119	114	3681	56	54	51	48	45

48XP

**Fig. 20 - Cooling Charging Table-Subcooling**

C03027

**IMPORTANT:** Three-phase, scroll compressor units are direction-oriented. These units must be checked to ensure proper compressor 3-phase power lead orientation. If not corrected within 5 minutes, the internal protector shuts off the compressor. The 3-phase power leads to the unit must be reversed to correct rotation. When turning backwards, scroll compressors emit elevated noise levels, and the difference between compressor suction and discharge pressures may be zero.

**CHECKING AND ADJUSTING REFRIGERANT CHARGE**

The refrigerant system is fully charged with R-410A refrigerant, tested, and factory-sealed.

**NOTE:** Adjustment of the refrigerant charge is not required unless the unit is suspected of not having the proper R-410A charge.

An accurate superheat, thermocouple- or thermistor-type thermometer, and a gauge manifold are required when using the subcooling charging method for evaluating the unit charge. Do not use mercury or small dial-type thermometers because they are not adequate for this type of measurement.

To Use Cooling Charging Charts

Take the liquid line temperature and read the manifold pressure gauges. Refer to the chart (See Fig. 20) to determine what the liquid line temperature should be.

**NOTE:** If the problem causing the inaccurate readings is a refrigerant leak, refer to the Check for Refrigerant Leaks section.

**INDOOR AIRFLOW AND AIRFLOW ADJUSTMENTS**

For cooling operation, the recommended airflow is 350 to 450 cfm for each 12,000 Btuh of rated cooling capacity. For heating operation, the airflow must produce a temperature rise that falls within the range stamped on the unit rating plate. Table 4 shows the temperature rise at various airflow rates. Table 7 & 8 show cooling airflows and Table 9 & 10 show heating airflows at the selection pin ranges (depending on external static pressure). Refer to these tables to determine the airflow for the system being installed.

**NOTE:** Be sure that all supply- and return-air grilles are open, free from obstructions, and adjusted properly.

**⚠ CAUTION**

**UNIT DAMAGE HAZARD**

Failure to follow this caution may result in unit damage.

When evaluating the refrigerant charge, an indicated adjustment to the specified factory charge must always be very minimal. If a substantial adjustment is indicated, an abnormal condition exists somewhere in the cooling system, such as insufficient airflow across either coil or both coils.

**⚠ WARNING**

**ELECTRICAL SHOCK HAZARD**

Failure to follow this warning could result in personal injury or death.

Before making any indoor wiring adjustments, shut off gas supply. Then disconnect electrical power to the unit.

Airflow can be changed by changing the selection pins on the Easy Select circuit board.

## MAINTENANCE

To ensure continuing high performance and to minimize the possibility of premature equipment failure, periodic maintenance must be performed on this equipment. This combination heating/cooling unit should be inspected at least once each year by a qualified service person. To troubleshoot cooling or heating of units, refer to Tables 12, 13 and 14.

**NOTE:** Consult your local dealer about the availability of a maintenance contract.

### **WARNING**

#### **PERSONAL INJURY AND UNIT DAMAGE HAZARD**

Failure to follow this warning could result in personal injury or death and unit component damage.

The ability to properly perform maintenance on this equipment requires certain expertise, mechanical skills, tools and equipment. If you do not possess these, do not attempt to perform any maintenance on this equipment, other than those procedures recommended in the Owner's Manual.

### **WARNING**

#### **ELECTRICAL SHOCK HAZARD**

Failure to follow these warnings could result in personal injury or death:

1. Turn off electrical power to the unit before performing any maintenance or service on this unit.
2. Use extreme caution when removing panels and parts.
3. Never place anything combustible either on or in contact with the unit.
4. Should overheating occur or the gas supply fail to shut off, turn off external main manual gas valve to the unit. Then shut off electrical supply.

### **CAUTION**

#### **UNIT OPERATION HAZARD**

Failure to follow this caution may result in improper operation.

Errors made when reconnecting wires may cause improper and dangerous operation. Label all wires prior to disconnecting when servicing.

The minimum maintenance requirements for this equipment are as follows:

1. Inspect air filter(s) each month. Clean or replace when necessary. Certain geographical locations may require more frequent inspections.
2. Inspect indoor coil, outdoor coil, drain pan, and condensate drain each cooling season for cleanliness. Clean when necessary.
3. Inspect blower motor and wheel for cleanliness at the beginning of each heating and cooling season. Clean when necessary. For first heating and cooling season, inspect blower wheel bi-monthly to determine proper cleaning frequency.
4. Check electrical connections for tightness and controls for proper operation each heating and cooling season. Service when necessary.
5. Check and inspect heating section before each heating season. Clean and adjust when necessary.
6. Check flue hood and remove any obstructions, if necessary.

## AIR FILTER

**NOTE:** Never operate the unit without a suitable air filter in the return-air duct system. Always replace the filter with the same dimensional size and type as originally installed. (See Table 1 for recommended filter sizes.)

Inspect air filter(s) at least once each month and replace (throwaway-type) or clean (cleanable-type) at least twice during each heating and cooling season or whenever the filter(s) becomes clogged with dust and/or lint.

## EVAPORATOR BLOWER AND MOTOR

**NOTE:** All motors are prelubricated. Do not attempt to lubricate these motors.

For longer life, operating economy, and continuing efficiency, clean accumulated dirt and grease from the blower wheel and motor annually.

### **CLEANING THE BLOWER MOTOR AND WHEEL**

1. Remove and disassemble blower assembly as follows:
  - a. Remove unit access panel.
  - b. Disconnect motor lead from blower relay (BR). Disconnect yellow lead from terminal L2 of the contactor.
  - c. On all units, remove blower assembly from unit. Remove screws securing blower to blower partition and slide assembly out. Be careful not to tear insulation in blower compartment.
  - d. Ensure proper reassembly by marking blower wheel and motor in relation to blower housing before disassembly.
  - e. Loosen setscrew(s) that secures wheel to motor shaft. Remove screws that secure motor mount brackets to housing, and slide motor and motor mount out of housing.
2. Remove and clean blower wheel as follows:
  - a. Ensure proper reassembly by marking wheel orientation.
  - b. Lift wheel from housing. When handling and/or cleaning blower wheel, be sure not to disturb balance weights (clips) on blower wheel vanes.
  - c. Remove caked-on dirt from wheel and housing with a brush. Remove lint and/or dirt accumulations from wheel and housing with vacuum cleaner, using soft brush attachment. Remove grease and oil with mild solvent.
  - d. Reassemble wheel into housing.
  - e. Reassemble motor into housing. Be sure setscrews are tightened on motor shaft flats and not on round part of shaft.
  - f. Reinstall unit access panel.
3. Restore electrical power to unit. Start unit and check for proper blower rotation and motor speeds during heating and cooling cycles.

## FLUE GAS PASSAGEWAYS

To inspect the flue collector box and upper areas of the heat exchanger:

1. Remove the combustion blower wheel and motor assembly according to directions in the Combustion-Air Blower section.
2. Remove the 3 screws holding the blower housing to the flue collector box cover (See Fig. 23).
3. Remove the 12 screws holding the flue collector box cover (See Fig. 24) to the heat exchanger assembly. Inspect the heat exchangers.
4. Clean all surfaces, as required, using a wire brush.

## **COMBUSTION-AIR BLOWER**

Clean periodically to assure proper airflow and heating efficiency. Inspect blower wheel every fall and periodically during the heating season. For the first heating season, inspect blower wheel bimonthly to determine proper cleaning frequency. To inspect blower wheel, remove draft hood assembly. Shine a flashlight into opening to inspect wheel. If cleaning is required, remove motor and wheel as follows:

1. Remove unit access panel (See Fig. 22).
2. Remove the 7 screws that attach induced-draft motor mounting plate to blower housing (See Fig. 23).
3. Slide the motor and blower wheel assembly out of the blower housing (See Fig. 23). Clean the blower wheel. If additional cleaning is required, continue with Steps 4 and 5.
4. To remove blower, remove 2 setscrews (See Fig. 23).
5. To remove motor and cooling fan assembly, remove 4 screws that hold blower housing to mounting plate.
6. To reinstall, reverse the procedure outlined above.

## **LIMIT SWITCH**

Remove unit access panel. Limit switch is located on the blower partition.

## **BURNER IGNITION**

Unit is equipped with a direct spark ignition 100 percent lockout system. Ignition module is located in the control box. Module contains a self-diagnostic LED. During servicing, refer to label diagram for LED interpretation.


If lockout occurs, unit may be reset by either momentarily interrupting power supply to unit or by turning selector switch to OFF position at the thermostat.

## **MAIN BURNERS**

At the beginning of each heating season, inspect for deterioration or blockage due to corrosion or other causes. Observe the main burner flames and adjust, if necessary.

Straighten bent fins with a fin comb. If coated with dirt or lint, clean the coils with a vacuum cleaner, using the soft brush attachment. Be careful not to bend the fins. If coated with oil or grease, clean the coils with a mild detergent-and-water solution. Rinse coils with clear water, using a garden hose. Be careful not to splash water on motors, insulation, wiring, or air filter(s). For best results, spray condenser coil fins from inside to outside the unit. On units with an outer and inner condenser coil, be sure to clean between the coils. Be sure to flush all dirt and debris from the unit base.

Inspect the drain pan and condensate drain line when inspecting the coils. Clean the drain pan and condensate drain by removing all foreign matter from the pan. Flush the pan and drain tube with clear water. Do not splash water on the insulation, motor, wiring, or air filter(s). If the drain tube is restricted, clear it with a "plumbers snake" or similar probe device. Ensure that the auxiliary drain port above the drain tube is also clear.



**Fig. 21 - Blower Housing and Flue Collector Box**

C99022

## **CAUTION**

### **UNIT DAMAGE HAZARD**

Failure to follow this caution may result in reduced unit and/or component life.

**Do Not** redrill an orifice. Improper drilling (burrs, out-of-round holes, etc.) can cause excessive burner noise and misdirection of burner flame. Replace with correct sized orifices.


## **REMOVAL OF GAS TRAIN**

To remove the gas train for servicing:

1. Shut off main gas valve.
2. Shut off power to unit.
3. Remove unit access panel (See Fig. 22).
4. Disconnect gas piping at unit gas valve.
5. Remove wires connected to gas valve. Mark each wire.
6. Remove ignitor and sensor wires at the ignitor module.
7. Remove the mounting screw that attaches the burner rack to the unit base (See Fig. 24).
8. Slide the burner rack out of the unit (See Fig. 21 and 24).
9. To reinstall, reverse the procedure outlined above.

## **CONDENSER COIL, EVAPORATOR COIL, AND CONDENSATE DRAIN PAN**

Inspect the condenser coil, evaporator coil, and condensate drain pan at least once each year. The coils are easily cleaned when dry; therefore, inspect and clean the coils either before or after each cooling season. Remove all obstructions, including weeds and shrubs, that interfere with the airflow through the condenser coil.



**Fig. 22 - Unit Access Panel**

C99091

## **WARNING**

### **ELECTRICAL SHOCK FIRE/EXPLOSION HAZARD**

Failure to follow this warning could result in personal injury or death and property damage.

Before making any wiring changes, **make sure** the gas supply is switched off first. *Then* switch off the power supply to the unit and install lockout tag.




Fig. 23 - Removal of Motor and Blower Wheel

C99085




Fig. 24 - Burner Rack Removed

C99086

### CONDENSER FAN

## ⚠ CAUTION

### UNIT OPERATION HAZARD

Failure to follow this caution may result in damage to unit components.

Keep the condenser fan free from all obstructions to ensure proper cooling operation. Never place articles on top of the unit.

1. Remove 6 screws holding condenser grille and motor to top cover.
2. Turn motor/grille assembly upside down on top cover to expose the fan blade.

3. Inspect the fan blades for cracks or bends.
4. If fan needs to be removed, loosen the setscrew and slide the fan off the motor shaft.
5. When replacing fan blade, position blade so the hub is 1/8 in. (3 mm) away from the motor end (1/8 in. [3 mm] of motor shaft will be visible, See Fig. 15).
6. Ensure that setscrew engages the flat area on the motor shaft when tightening.
7. Replace grille.

### ELECTRICAL CONTROLS AND WIRING

Inspect and check the electrical controls and wiring annually. Be sure to turn off the gas supply, and then the electrical power to the unit.

Remove access panel to locate all the electrical controls and wiring. Check all electrical connections for tightness. Tighten all screw connections. If any smoky or burned connections are noticed, disassemble the connection, clean all the parts, re-strip the wire end and reassemble the connection properly and securely.

After inspecting the electrical controls and wiring, replace the access panel. Start the unit, and observe at least one complete heating cycle and one complete cooling cycle to ensure proper operation. If discrepancies are observed in either or both operating cycles, or if a suspected malfunction has occurred, check each electrical component with the proper electrical instrumentation. Refer to the unit wiring label when making these checkouts.

**NOTE:** Refer to the heating and/or cooling sequence of operation in this publication as an aid in determining proper control operation

### REFRIGERANT CIRCUIT

Annually inspect all refrigerant tubing connections and the unit base for oil accumulations. Detecting oil generally indicates a refrigerant leak.

## ⚠ WARNING

### EXPLOSION, PERSONAL INJURY HAZARD

Failure to follow this warning could result in personal injury, death or property damage.

System under pressure. Relieve pressure and recover all refrigerant before system repair or final unit disposal. Use all service ports and open all flow-control devices, including solenoid valves.

If oil is detected or if low cooling performance is suspected, leak-test all refrigerant tubing using an electronic leak-detector, halide torch, or liquid-soap solution. If a refrigerant leak is detected, refer to the Check for Refrigerant Leaks section.

If no refrigerant leaks are found and low cooling performance is suspected, refer to the Checking and Adjusting Refrigerant Charge section.

### GAS INPUT

The gas input does not require checking unless improper heating performance is suspected. If a problem exists, refer to the Start-Up section.

### EVAPORATOR AIRFLOW


The heating and/or cooling airflow does not require checking unless improper performance is suspected. If a problem exists, be sure that all supply- and return-air grilles are open and free from obstructions, and that the air filter is clean. When necessary, refer to the Indoor Airflow and Airflow Adjustments section to check the system airflow.



# QUICK REFERENCE GUIDE

## SET-UP INSTRUCTIONS FOR EASY SELECT BOARD (SUPER HUMIDITY CONTROL IN COOLING)

### EASY SELECT BOARD



1. Configuration Taps  
(See Installation Instructions, for detailed description)
  - A. HEAT RANGE - Set for gas heat size (EX: 090 for unit 048090-->)
  - B. AC/HP SIZE - Set for size of outdoor unit (Cooling Size)
  - C. SYSTEM TYPE - Select "AC" for Gas Package Units
  - D. AC/HP CFM ADJUST - Select "NOM"
  - E. ON/OFF DELAY - Do not use "ENH" for this unit
  - F. CONTINUOUS FAN - Select desired speed
2. Remove Jumper J1 to activate all dehumidify modes
3. Complete wiring and install outdoor temperature sensor according to Installation Instructions

### THERMIDISTAT CONTROL SETTINGS

1. Set "DIP Switches" - Set the dip switches (back of Thermidistat Control Board) appropriately for specific system being installed.
2. Thermidistat Control Configurations  
(See Thermidistat Control Installation Instructions for detailed description)
  - \* Option 5 (Variable Speed Indoor Motor) - Set to ON
  - \* Option 7 (Super Dehumidify) - Set to ON
  - \* Option 17 - Select Programmable or non-programmable mode.
3. Set desired humidity level on front of Thermidistat (50 to 55 % RH recommended). For dehumidification in cooling, both "dhu" and "cool" must be displayed.

48XP

### ECM ID Blower Motor-quick Reference Guide

C01034G

#### **PURON ITEMS**

##### **METERING DEVICE** (Thermostatic Expansion Valve )

This metering device is a hard shutoff, balance port TXV. The TXV maintains a constant superheat at the evaporator exit resulting in higher overall system efficiency.

##### **PRESSURE SWITCHES**

Pressure switches are protective devices wired into control circuit (low voltage). They shut off compressor if abnormally high or low pressures are present in the refrigeration circuit. These pressure switches are specifically designed to operate with Puron (R-410A) systems. R-22 pressure switches must not be used as replacements for the Puron (R-410A) system.

##### **LOSS OF CHARGE SWITCH**

This switch is located on the liquid line and protects against low suction pressures caused by such events as loss of charge, low airflow across indoor coil, dirty filters, etc. It opens on a pressure drop at about 20 psig. If system pressure is above this, switch should be closed. To check switch:

1. Turn off all power to unit.
2. Disconnect leads on switch.
3. Apply ohm meter leads across switch. You should have continuity on a good switch.

**NOTE:** Because these switches are attached to refrigeration system under pressure, it is not advisable to remove this device for

troubleshooting unless you are reasonably certain that a problem exists. If switch must be removed, remove and recover all system charge so that pressure gauges read 0 psi. Never open system without breaking vacuum with dry nitrogen.

##### **HIGH-PRESSURE SWITCH**

The high-pressure switch is located in the discharge line and protects against excessive condenser coil pressure. It opens at 650 psig.

High pressure may be caused by a dirty outdoor coil, failed fan motor, or outdoor air recirculation. To check switch:

1. Turn off all power to unit.
2. Disconnect leads on switch.
3. Apply ohm meter leads across switch. You should have continuity on a good switch.

##### **COPELAND SCROLL COMPRESSOR (PURON REFRIG-ERANT)**

The compressor used in this product is specifically designed to operate with Puron (R-410A) refrigerant and cannot be interchanged.

The compressor is an electrical (as well as mechanical) device. Exercise extreme caution when working near compressors. Power should be shut off, if possible, for most troubleshooting techniques. Refrigerants present additional safety hazards.

## WARNING

### FIRE/EXPLOSION HAZARD

Failure to follow this warning could result in personal injury or death and/or property damage.

Wear safety glasses and gloves when handling refrigerants. Keep torches and other ignition sources away from refrigerants and oils.

The scroll compressor pumps refrigerant throughout the system by the interaction of a stationary and an orbiting scroll. The scroll compressor has no dynamic suction or discharge valves, and it is more tolerant of stresses caused by debris, liquid slugging, and flooded starts. The compressor is equipped with an anti-rotational device and an internal pressure relief port. The anti-rotational device prevents the scroll from turning backwards and replaces the need for a cycle protector. The pressure relief port is a safety device, designed to protect against extreme high pressure. The relief port has an operating range between 550 and 625 psi differential pressure.

## WARNING

### UNIT OPERATION AND SAFETY HAZARD

Failure to follow this warning could result in personal injury or equipment damage.

This system uses Puron (R-410A) refrigerant which has higher operating pressures than R-22 and other refrigerants. No other refrigerant may be used in this system. Gauge set, hoses, and recovery system must be designed to handle Puron. If you are unsure, consult the equipment manufacturer.

### REFRIGERANT SYSTEM

This information covers the refrigerant system of the 48XP, including the compressor oil needed, servicing systems on roofs containing synthetic materials, the filter drier and refrigerant charging.

#### Compressor Oil

The Copeland scroll compressor uses 3MAF POE oil. If additional oil is needed, use Uniqema RL32-3MAF. If this oil is not available, use Copeland Ultra 32 CC or Mobil Arctic EAL22 CC. This oil is extremely hygroscopic, meaning it absorbs water readily. This oil is extremely hygroscopic, meaning it absorbs water readily. POE oils can absorb 15 times as much water as other oils designed for HCFC and CFC refrigerants. Take all necessary precautions to avoid exposure of the oil to the atmosphere.

### SERVICING SYSTEMS ON ROOFS WITH SYNTHETIC-MATERIALS

POE (polyolester) compressor lubricants are known to cause long term damage to some synthetic roofing materials.

Exposure, even if immediately cleaned up, may cause embrittlement (leading to cracking) to occur in one year or more. When performing any service that may risk exposure of compressor oil to the roof, take appropriate precautions to protect roofing. Procedures which risk oil leakage include, but are not limited to, compressor replacement, repairing refrigerant leaks, replacing refrigerant components such as filter drier, pressure switch, metering device, coil, accumulator, or reversing valve.

#### Synthetic Roof Precautionary Procedure

1. Cover extended roof working area with an impermeable polyethylene (plastic) drip cloth or tarp. Cover an approximate 10 X 10 ft. (3 X 3 m) area.
2. Cover area in front of the unit service panel with a terry cloth shop towel to absorb lubricant spills and prevent run-offs, and protect drop cloth from tears caused by tools or components.
3. Place terry cloth shop towel inside unit immediately under component(s) to be serviced and prevent lubricant run-offs through the louvered openings in the unit base.
4. Perform required service.
5. Remove and dispose of any oil contaminated material per local codes.

#### LIQUID LINE FILTER DRIER

This filter drier is specifically designed to operate with Puron. Use only factory-authorized components. Filter drier must be replaced whenever the refrigerant system is opened. When removing a filter drier, use a tubing cutter to cut the drier from the system. Do not unsweat a filter drier from the system. Heat from unsweating will release moisture and contaminants from drier into system.

#### PURON (R-410A) REFRIGERANT CHARGING

Refer to unit information plate and charging chart. Some R-410A refrigerant cylinders contain a dip tube to allow liquid refrigerant to flow from cylinder in upright position. For cylinders equipped with a dip tube, charge Puron units with cylinder in upright position and a commercial metering device in manifold hose. Charge refrigerant into suction-line.

### TROUBLESHOOTING

Use the Troubleshooting Guides (See Tables 12-14) if problems occur with these units.

### START-UP CHECKLIST

Use Start-Up checklist to ensure proper start-up procedures are followed.

## PURON® (R-410A) QUICK REFERENCE GUIDE

- Puron refrigerant operates at 50-70 percent higher pressures than R-22. Be sure that servicing equipment and replacement components are designed to operate with Puron
- Puron refrigerant cylinders are rose colored.
- Recovery cylinder service pressure rating must be 400 psig, DOT 4BA400 or DOT BW400.
- Puron systems should be charged with liquid refrigerant. Use a commercial type metering device in the manifold hose when charging into suction line with compressor operating
- Manifold sets should be 700 psig high side and 180 psig low side with 550 psig low-side retard.
- Use hoses with 700 psig service pressure rating.
- Leak detectors should be designed to detect HFC refrigerant.
- Puron, as with other HFCs, is only compatible with POE oils.
- Vacuum pumps will not remove moisture from oil.
- Do not use liquid-line filter driers with rated working pressures less than 600 psig.
- Do not leave Puron suction line filter driers in line longer than 72 hrs.
- Do not install a suction-line filter drier in liquid line.
- POE oils absorb moisture rapidly. Do not expose oil to atmosphere.
- POE oils may cause damage to certain plastics and roofing materials.
- Wrap all filter driers and service valves with wet cloth when brazing.
- A factory approved liquid-line filter drier is required on every unit.
- Do NOT use an R-22 TXV.
- If indoor unit is equipped with an R-22 TXV or piston metering device, it must be changed to a hard shutoff Puron TXV.
- Never open system to atmosphere while it is under a vacuum.
- When system must be opened for service, recover refrigerant, evacuate then break vacuum with dry nitrogen and replace filter driers. Evacuate to 500 microns prior to recharging.
- Do not vent Puron into the atmosphere.
- Do not use capillary tube coils.
- Observe all **warnings**, **cautions**, and **bold** text.
- All indoor coils must be installed with a hard shutoff Puron TXV metering device.

**Table 12 – Troubleshooting Guide - Cooling**

SYMPTOM	CAUSE	REMEDY
<b>Compressor and condenser fan will not start.</b>	Power failure	Call power company
	Fuse blown or circuit breaker tripped	Replace fuse or reset circuit breaker
	Defective contactor, transformer, or high-pressure, loss-of-charge or low-pressure switch	Replace component
	Insufficient line voltage	Determine cause and correct
	Incorrect or faulty wiring	Check wiring diagram and rewire correctly
<b>Compressor will not start but condenser fan runs</b>	Thermostat setting too high	Lower thermostat setting below room temperature
	Faulty wiring or loose connections in compressor circuit	Check wiring and repair or replace
	Compressor motor burned out, seized, or internal overload open	Determine cause Replace compressor
	Defective run/start capacitor, overload, start relay	Determine cause and replace
<b>Three-phase scroll compressor makes excessive noise, and there may be a low pressure differential.</b>	One leg of 3-phase power dead	Replace fuse or reset circuit breaker Determine cause
	Scroll compressor is rotating in the wrong direction	Correct the direction of rotation by reversing the 3-phase power leads to the unit. Shut down unit to allow pressures to equalize.
<b>Compressor cycles (other than normally satisfying thermostat).</b>	Refrigerant overcharge or undercharge	Recover refrigerant, evacuate system, and recharge to capacities shown on rating plate
	Defective compressor	Replace and determine cause
	Insufficient line voltage	Determine cause and correct
	Blocked condenser	Determine cause and correct
	Defective run/start capacitor, overload or start relay	Determine cause and replace
	Defective thermostat	Replace thermostat
	Faulty condenser-fan motor or capacitor	Replace
	Restriction in refrigerant system	Locate restriction and remove
<b>Compressor operates continuously</b>	Dirty air filter	Replace filter
	Unit undersized for load	Decrease load or increase unit size
	Thermostat set too low	Reset thermostat
	Low refrigerant charge	Locate leak, repair, and recharge
	Air in system	Recover refrigerant, evacuate system, and recharge
	Condenser coil dirty or restricted	Clean coil or remove restriction
<b>Excessive head pressure</b>	Dirty air filter	Replace filter
	Dirty condenser coil	Clean coil
	Refrigerant overcharged	Recover excess refrigerant
	Air in system	Recover refrigerant, evacuate system, and recharge
	Condenser air restricted or air short-cycling	Determine cause and correct
<b>Head pressure too low</b>	Low refrigerant charge	Check for leaks, repair, and recharge.
	Restriction in liquid tube	Remove restriction
<b>Excessive suction pressure</b>	High heat load	Check for source and eliminate
	Refrigerant overcharged	Recover excess refrigerant
<b>Suction pressure too low</b>	Dirty air filter	Replace filter
	Low refrigerant charge	Check for leaks, repair and recharge
	Metering device or low side restricted	Remove source of restriction
	Insufficient evaporator airflow	Increase air quantity Check filter—replace if necessary
	Temperature too low in conditioned area	Reset thermostat
	Outdoor ambient below 55°F (12.7°C)	Install low-ambient kit
	Filter drier restricted	Replace filter

48XP


**Table 13 – Troubleshooting Guide–Heating**

SYMPTOM	CAUSE	REMEDY
<b>Burners will not ignite</b>	Water in gas line	Drain. Install drip leg.
	No power to furnace	Check power supply fuses, wiring or circuit breaker.
	No 20-v power supply to control circuit	Check transformer. NOTE: Some transformers have internal over-current protection that requires a cool-down period to reset.
	Mis-wired or loose connections	Check all wiring and wire nut connections
	Burned-out heat anticipator in thermostat	Replace thermostat
	Broken thermostat wire	Replace thermostat
	Burned-out heat anticipator in thermostat	Run continuity check. Replace wire if necessary.
	Misaligned spark electrodes	Check flame ignition and sense electrode positioning. Adjust as necessary
<b>Inadequate heating</b>	No gas at main burners	1. Check gas line for air. Purge as necessary. NOTE: After purging gas line of air, wait at least 5 minutes for any gas to dissipate before attempting to light unit. 2. Check gas valve.
	Dirty air filter	Clean or replace filter as necessary
	Gas input to furnace too low	Check gas pressure at manifold match with that on unit nameplate
	Unit undersized for application	Replace with proper unit or add additional unit
	Restricted airflow	Clean or replace filter. Remove any restriction.
	Blower speed too low	Use faster speed tap if available, or install alternate motor.
<b>Poor flame characteristics</b>	Limit switch cycles main burners	Check rotation of blower, temperature rise of unit. Adjust as necessary.
	Incomplete combustion results in: Aldehyde odors, carbon monoxide, sooting flame, floating flame	1. Tighten all screws around burner compartment 2. Cracked heat exchanger. Replace. 3. Unit over-fired. Reduce input (change orifices or adjust gas line or manifold pressure). 4. Check burner alignment.

**48XP**

**Table 14 – Troubleshooting Guide–LED Error Codes**

SYMPTOM	CAUSE	REMEDY
<b>Hardware failure (LED OFF)</b>	Loss of power to control module (IGC)*.	Check 5-amp fuse on IGC*, power to unit, 24-v circuit breaker, and transformer. Units without a 24-v circuit breaker have an internal overload in the 24-v transformer. If the overload trips, allow 10 minutes for automatic reset.
<b>Fan ON/OFF delay modified (LED/FLASH)</b>	High limit switch opens during heat exchanger warm-up period before fan-on delay expires. Limit switch opens within three minutes after blower-off delay timing in heating mode.	Ensure unit is fired on rate; ensure temperature rise is correct. Ensure unit's external static pressure is within application guidelines.
<b>Limit switch faults (LED 2 flashes)</b>	High temperature limit switch is open.	Check the operation of the indoor (evaporator) fan motor. Ensure that the supply-air temperature rise is in accordance with the range on the unit nameplate.
<b>Flame sense fault (LED 3 flashes)</b>	The IGC* sensed flame that should not be present.	Reset unit. If problem persists, replace control board.
<b>4 consecutive limit switch faults (LED 4 flashes)</b>	Inadequate airflow to unit.	Check the operation of the indoor (evaporator) fan motor and that supply-air temperature rise agrees with range on unit nameplate information.
<b>Ignition lockout (LED 5 flashes)</b>	Unit unsuccessfully attempted ignition for 15 minutes.	Check ignitor and flame sensor electrode spacing, gaps, etc. Ensure that flame sense and ignition wires are properly terminated. Verify that unit is obtaining proper amount of gas.
<b>Induced-draft motor fault (LED 6 flashes)</b>	IGC does not sense that induced-draft motor is operating.*	Check for proper voltage. If motor is operating, check the speed sensor plug/IGC Terminal J2 connection. Proper connection: PIN 1 - White PIN 2 - Red PIN 3 - Black
<b>Rollout switch fault (LED 7 flashes)</b>	Rollout switch has opened.	Rollout switch will automatically reset, but IGC* will continue to lockout unit. Check gas valve operation. Ensure that induced-draft blower wheel is properly secured to motor shaft. Reset unit at unit disconnect.
<b>Rollout control fault (LED 8 flashes)</b>	Microprocessor has sensed an error in the software or hardware.	If error code is not cleared by resetting unit power, replace the IGC*.
<b>Safety Critical fault (LED 9 flashes)</b>	If Safety Critical Software Redundant Variables Mismatch occurs then IGC will lockout (This fault will clear after 1 hr.)	Verify that flame sensor wire and spark ignitor wires are not touching or close together. Ensure unit has a good ground on the IGC board.

\*WARNING : If the IGC must be replaced, be sure to ground yourself to dissipate any electrical charge that may be present before handling new control board. The IGC is sensitive to static electricity and may be damaged if the necessary precautions are not taken.

**IMPORTANT:** Refer to Table 13-Troubleshooting Guide-Heating for additional troubleshooting analysis.

**LEGEND**

IGC—Integrated Gas Unit Controller

LED—Light-Emitting Diode

## START-UP CHECKLIST (Remove and Store in Job File)

### I. Preliminary Information

MODEL NO.: \_\_\_\_\_  
 SERIAL NO.: \_\_\_\_\_  
 DATE: \_\_\_\_\_  
 TECHNICIAN: \_\_\_\_\_

### II. PRE-START-UP (Insert checkmark in box as each item is completed)

- VERIFY THAT ALL PACKING MATERIALS HAVE BEEN REMOVED FROM UNIT
- REMOVE ALL SHIPPING HOLD DOWN BOLTS AND BRACKETS PER INSTALLATION INSTRUCTIONS
- CHECK ALL ELECTRICAL CONNECTIONS AND TERMINALS FOR TIGHTNESS
- CHECK GAS PIPING FOR LEAKS (WHERE APPLICABLE)
- CHECK THAT INDOOR (EVAPORATOR) AIR FILTER IS CLEAN AND IN PLACE
- VERIFY THAT UNIT INSTALLATION IS LEVEL
- CHECK FAN WHEEL, AND PROPELLER FOR LOCATION IN HOUSING/ORIFICE AND SETSCREW TIGHTNESS
- MAKE SURE THAT - (If Applicable) ON 060 SIZE PURON HEATPUMP ONLY, THE TWO WIRE TIES FASTEN TO THE OUTDOOR COILS AND REVERSING VALVE/ACCUMULATOR HAVE BEEN REMOVED

### III. START-UP

#### ELECTRICAL

SUPPLY VOLTAGE \_\_\_\_\_  
 COMPRESSOR AMPS \_\_\_\_\_  
 INDOOR (EVAPORATOR) FAN AMPS \_\_\_\_\_

#### TEMPERATURES

OUTDOOR (CONDENSER) AIR TEMPERATURE \_\_\_\_\_ DB  
 RETURN-AIR TEMPERATURE \_\_\_\_\_ DB \_\_\_\_\_ WB  
 COOLING SUPPLY AIR \_\_\_\_\_ DB \_\_\_\_\_ WB  
 HEAT PUMP SUPPLY AIR \_\_\_\_\_  
 GAS HEAT SUPPLY AIR \_\_\_\_\_  
 ELECTRIC HEAT SUPPLY AIR \_\_\_\_\_

#### PRESSURES

GAS INLET PRESSURE \_\_\_\_\_ IN. W.C.  
 GAS MANIFOLD PRESSURE \_\_\_\_\_ IN. W.C.  
 REFRIGERANT SUCTION \_\_\_\_\_ PSIG SUCTION LINE TEMP\* \_\_\_\_\_  
 REFRIGERANT DISCHARGE \_\_\_\_\_ PSIG DISCHARGE TEMP† \_\_\_\_\_

- VERIFY REFRIGERANT CHARGE USING CHARGING CHARTS

GAS HEAT TEMPERATURE RISE  
 TEMPERATURE RISE (See Literature) RANGE \_\_\_\_\_  
 MEASURED TEMPERATURE RISE \_\_\_\_\_

\*Measured at suction inlet to compressor  
 †Measured at liquid line leaving condenser.

### IV. EASY SELECT SETTINGS

FULL UNIT MODEL NUMBER: \_\_\_\_\_  
 ENTER AVAILABLE HEATSETTINGS \_\_\_\_\_  
 ENTER AVAILABLE AIRFLOW HEAT AIR PIN CONNECTION SETTING \_\_\_\_\_  
 ENTER AVAILABLE SIZES SIZE PIN CONNECTION SETTING \_\_\_\_\_  
 TYPE PIN CONNECTION SETTING \_\_\_\_\_  
 ADJUST PIN CONNECTION SETTING \_\_\_\_\_  
 DELAY PIN CONNECTION SETTING \_\_\_\_\_  
 (0/0 or 0/90 for gas/electric models)  
 CONTINUOUS FAN PIN CONNECTION SETTING \_\_\_\_\_

<b>EASY SELECT</b>			
Heat Settings			
AC HP Size			
System Type			
AC	HP-Comfort	HP.Eff	
AC/HP CFM Adjust			
Norm	Lo	Hi	
On/Off Delay			
0/90	30/90	0/0	ENH
Continuous Fan			
Lo	Med	Hi	

C01999