

SEWING MACHINE
MODEL 340 (1971-72)


TABLE OF CONTENTS




SECTION 1	KEYBOARD FUNCTIONS AND PROGRAMMING SEQUENCE	SECTION 3	TRUBLE SHOOTING
SECTION 2	MECHANICAL SERVICE	3A	CHECK POINTS
2A	CHECK POINTS	3B	TROUBLE SHOOTING
2B	TROUBLE SHOOTING	3B.1	Machine not in "totally off" (power-on led and sewing bulbs are dead)
2B.1	Needle breaks	3B.2	Machine is inoperative (keyboard does not respond, led's and display remain off)
2B.2	Skipped stitches	3B.3	Only certain stitch patterns being sewn
2B.3	Upper thread breaks and/or hook jams	3B.4	Seam and stitch pattern poorly sewn
2B.4	Bobbin thread breaks	3B.5	Speed problems of electrical motor
2B.5	Loose stitches or puckering	3B.6	Machine operates, but one or both bulbs remain dead
2B.6	Does not straight-stitch properly	3B.7	Noisy vibrations from needle bar or feed unit, when they are around their central positions
2B.7	Does not knot stitches properly	3B.8	Sudden changes in stitch length or width when zigzag sewing or sewing various pattern
2B.8	Does not zigzag-stitch properly	2B.9	Feed is only in one direction and with max. stitch length, even when selected pattern would require different feeding
2B.9	Bobbin thread does not wind properly	3B.10	Needle bar is positioned all on one side of its swing
2B.10	Feed dog engagement and disengagement	3B.11	Machine runs without foot control being pressed
2B.11	Poor feeding of fabric	3B.12	Foot control problems
2B.12	Machine does not run	3B.13	Imper buttonholes
2B.13	Machine does not baste	3B.14	Required adjustments whenever logic board or closed loop board is replaced.
2B.14	Machine does not make buttonholes properly		
2B.15	Machine runs without depressing foot control		
2B.16	The bulbs do not turn on		
2B.17	Motor speed selection does not work		
2B.18	Keyboard does not work properly		
2C	ADJUSTMENTS AND REPLACEMENTS	SECTION 4	BOARD LAYOUTS AND WIRING DIAGRAM
2C.1	Top thread tension control		
2C.2	Needle and shuttle area		
2C.2.1	Needle timing and clearance to hook		
2C.2.2	Needle bar height and orientation		
2C.2.3	Bobbin case holder to stop clearance		
2C.2.4	Needle position at straight stitching		
2C.2.5	Zigzag width and timing		
2C.2.6	Needle bar support		
2C.2.7	Shuttle hook and gear replacement		
2C.3	Fabric feed mechanism		
2C.3.1	Needle timing to feed		
2C.3.2	Feed dog height and centering		
2C.3.3	Zero feed and stitch length		
2C.3.4	Feed dog engagement and disengagement		
2C.4	Miscellaneous		
2C.4.1	Bobbin winder and clutch		
2C.4.2	Buttonhole mechanism		
2C.4.3	Presser foot height and position		
2C.4.4	Replacement of belts		
2C.4.5	Adjusting potentiometers		
2C.4.6	Motor repair or replacement		
2C.4.7	Cable connector positioning		







SECTION 1 340.1991180






KEYBOARD FUNCTIONS

FOLLOWING IS A BRIEF DESCRIPTION OF EACH KEY ON THE KEYBOARD SHOWING ITS LOCATION, IDENTIFICATION AND FUNCTION.



1.  Power ON Indicator: Glows when Power is "ON"
2.  Zig-Zag Stitch Key: Pre-programmed to 2 mm length, 5 mm width
3.  Stitch width modifier Key: touching permits stitch width change

4.  Double needle limit Key limits stitch width to maximum allowable for double needle (5 mm)
5.  Single pattern Key programs machine to stop after a single pattern is completed
6.  Pattern add Key permits addition of a second stitch pattern to one selected previously. Permits two patterns to be sewn alternately
7.  Pattern length modifier Key: touching permits change in pattern length (up to 99 mm) without affecting stitch length
8.  Reverse stitch, Balance Key. touching permits change of reverse stitch balance
9.  Backtacking Key. when touched machine will make three forward, three backward stitches and then begin straight stitching

10.  Reverse Stitch Key: machine will sew in reverse as long as key is touched.
11.  Stitch length modifier key: touching permits stitch length change.
12.  Straight Stitch key: programmed to 2.5 mm stitch length
13.  Confirm Program key: touched to show acceptance of program any time the digital read-out is changed.
14.  Digital Read-out change key: Stitch length or width change the two keys on the left (+), (-) change read-out rapidly The two keys on the right (+), (-) change read out slowly

NOTE. Stitch length and width read-outs always show a decimal point

PATTERN SELECTION The two left keys (+) & (-) control the left number in the read out
The two right keys (+) & (-) control the right number in the read out

NOTE. Pattern numbers do not show a decimal point

15. DIGITAL READ OUT displays numbers corresponding to the stitch pattern selected or to the length or width programmed for the selected stitch pattern

NOTE Out the Digital read out display, stitch sewings show a decimal point, pattern selection show no decimal point

PROGRAMMING SEQUENCE

THE FOLLOWING CHARTS PROVIDE A BRIEF EXPLANATION OF THE STEPS REQUIRED TO PROPERLY ENTER A PARTICULAR STITCH OR PATTERN. TO OBTAIN THE STITCH SHOWN IN THE LEFT HAND COLUMN TOUCH KEYS IN THE ORDER SHOWN UNDER STEPS 1 THROUGH 5 BEFORE PRESSING ON FOOT CONTROL.

MACHINE PROGRAMMING

UTILITY STRETCH SATIN STITCHES, MONOGRAMS	STITCH VARIATION	STEP 1	STEP 2	STEP 3	STEP 4	STEP 5
----- Straight	Stitch memorized length (2.5 mm)					
----- Straight	Longer stitches (up to 6 mm)					
----- Straight	Shorter stitches (down to 1 mm)					
~~~~~ Zig-Zag	As memorized					
~~~~~ Zig Zag	Wider than memorized					
~~~~~ Zig-Zag	Wider & longer					
~~~~~ Zig-Zag	Narrower					
~~~~~ Zig-Zag	Narrower & shorter					

UTILITY STRETCH, SATIN STITCHES, MONOGRAMS		STEP 1	STEP 2	STEP 3	STEP 4	STEP 5	STEP 6	STEP 7
Any numbered pattern shown in machine cover	Continuous pattern as memorized							
Same pattern	But wider							
Same pattern	But narrower							
Same pattern	But wider & longer							
Same pattern	But narrower & shorter							
Satin stitches	Elongated, same stitch density							
Any numbered pattern	Single pattern or monogram							
Two letters or patterns continuously alternating	To be selected in same pattern group as shown in machine cover							

UTILITY STRETCH, SATIN STITCHES, MONOGRAMS		Clear	STEP 1	STEP 2	STEP 3	STEP 4	STEP 5
Two monograms (or monogram and period)	Single pattern						
Buttonholes*	Memorized width						
Buttonholes*	Wider						

* NOTE: Machine will sew one complete buttonhole, then it stops automatically. No need to touch . If you want to sew same buttonhole again, simply touch key.

## SECTION 2 CHECK POINTS

Past service records indicate that customers sometimes do not follow or misinterpret instructions in the Owner's Manual. Threading the machine and balancing thread tension are commonly misunderstood.

Before proceeding with troubleshooting chart, refer to important information in Section 5--General Maintenance. Users and technicians should understand the basic points covered in this section.

The following chart will help you determine whether the machine needs further adjustment.

### COMPLAINTS RELATING TO STITCHING PERFORMANCE

Ask the customer to sew in order to duplicate the problem and check the following points as she/he sews.

**IS THE CORRECT NEEDLE PROPERLY USED AND INSERTED?**

**NO** - Replace with correct needle or reinsert needle properly.

**YES**



**IS THE TOP THREADING CORRECT?**

**NO** - Correct top threading.

**YES**



**IS THE BOBBIN CASE THREADED CORRECTLY?**

**NO** - Correct bobbin case threading.

**YES**



**IS THE PRESSER FOOT PRESSURE REGULATOR SET CORRECTLY?**

**NO** - Correct the setting.

**YES**



**DOES THE PRESSER FOOT SUIT THE TYPE OF STITCHING?**

**NO** - Replace the presser foot with suitable one (see instructions in Owner's Manual).

**YES**



**ARE ALL CONTROLS SET CORRECTLY?**

**NO** - Correct all the settings.

**YES**

- Make sure**
- Only Kenmore needle is used
  - Needle is correct size for thread and fabric (see Section 5B)
  - Bent or blunt needle is not used
  - Needle is securely clamped with screw
  - Basting using stitch program 37 requires special basting needle

- Refer to Section 5A**
- Make sure**
- Thread passes between the thread tension discs
  - Thread is not tangled
  - Thread tension control is functioning properly (see Section 2C 1)

- Refer to Section 5A**
- Make sure**
- Bobbin thread is under tension spring
  - Bobbin is installed to rotate counterclockwise as thread is pulled

- Refer to Section 5E**
- Make sure pressure knob is**
- Set for more pressure with lightweight fabric
  - Set for less pressure with heavy fabric

**Refer to Section 5E**

- Make sure**
- Bobbin winder lever is properly positioned
  - Feed dog control lever is properly positioned

### 2. CHECK POINTS

**IS THREAD TENSION BALANCED BETWEEN TOP AND BOBBIN?**

**NO** - Usually balance of thread tension is achieved by adjusting the top thread tension control. If bobbin thread tension adjustment is also needed, see Section 5C.

**YES**



**WAS STITCH PROGRAM ENTERED CORRECTLY?**

**NO** - Try to enter selected program following Owner's Manual instructions step by step.

**YES**



Check the following list for section which corresponds with customer's complaint.

COMPLAINT	SECTION
Needle breaks . . . . .	2B 1
Skipped stitches . . . . .	2B 2
Top thread breaking and/or jamming of hook . . . . .	2B 3
Bobbin thread breaking . . . . .	2B 4
Loose stitches or puckering . . . . .	2B 5
Does not straight stitch properly . . . . .	2B 6
Does not knot stitches properly . . . . .	2B 7
Does not zigzag properly . . . . .	2B 8
Does not wind bobbins properly . . . . .	2B 9
Disengagement and engagement of feeding . . . . .	2B 10
Poor feed of fabric . . . . .	2B 11
Machine does not run . . . . .	2B 12
Machine does not baste . . . . .	2B 13
Poor buttonholing . . . . .	2B 14
Machine sews without foot control being pressed . . . . .	2B 15
Lights remain off . . . . .	2B 16
Motor speed selection does not work . . . . .	2B 17
Faulty keyboard . . . . .	2B 18

340 1991100  
2B TROUBLESHOOTING  
2B1 NEEDLE BREAKS

### TROUBLESHOOTING IN MECHANICAL AREA

Pulling or pushing the fabric by hand against machine feeding action will make the needle bend. A bent needle will contact and can damage the needle plate or hook resulting in needle breakage.

IS NEEDLE STRIKING NEEDLE PLATE OR SCRAPING  
EDGE OF THE NEEDLE HOLE?

YES - Needle position is not correct. See Sections 2C 2 4 &  
2C 2 5 for adjustment.

Set machine for straight stitching. Use straight stitch  
needle plate.

NO



IS NEEDLE HITTING HOOK OR BOBBIN CASE?

YES - If needle clearance to hook is zero or too little see  
Section 2C 2 1 for adjustment.

Remove both needle plate and cover plate.

Check that bobbin case is properly fastened by holder,  
with enough play left between case and holder. See  
Section 2C 2 3.

NO



IS HOOK/BOBBIN CASE AREA CLEAR OF THREAD OR  
LINT?

NO - Refer to Section 2B 3 "Top Thread Breaking or  
Jamming in Hook." Also refer to Section 5D.

YES



IS THE TIMING BETWEEN NEEDLE VERTICAL MOTION  
AND ZIGZAG BIGHT CORRECT?

NO -- Set correct timing.

Refer to Section 2C 2 5.

YES



IS THE TIMING BETWEEN VERTICAL MOTION AND  
FEED CORRECT?

NO -- Set correct timing.

Refer to Section 2C 3 1.

340 1991100  
2B1 NEEDLE BREAKS

### USER HINTS

Advise user to follow instructions "Getting Ready to Sew" in Owner's Manual. Frequent needle breakings are often caused by the fact that user is still unfamiliar with sewing.

#### ADVISE CUSTOMER ABOUT FOLLOWING DON'TS

- 1 Don't pull or push fabric while sewing, simply guide it.
- 2 Don't leave needle plate and presser foot for straight stitching while programming any zigzag stitch pattern.
- 3 Don't try to use worn-out needles, replace them regularly.
- 4 Don't use high speed when sewing thick fabrics.

#### AND THE FOLLOWING DO'S

- 1 Use needles according to instructions in Owner's Manual. When using double needle, always press double needle key on keyboard to limit zigzag width.
- 2 Always use presser feet as indicated in Owner's Manual.
- 3 Select needle according to Owner's Manual.
- 4 Always draw approximately 4 inches of both top and bobbin thread to the rear of the machine before placing the fabric.
- 5 Check that surface of the parts along the thread path are smooth. Damaged, scratched or rough surfaces on parts along the thread path, will weaken thread resulting in thread breaking and/or shuttle hook jamming.

**IMPORTANT:** If machine is off with fabric under presser foot, check first needle position, before switching the machine on. If needle is down, piercing the fabric, rotate handwheel toward you to raise needle. When needle is out of fabric, it is all right to switch machine on. You could damage the needle or fabric by not following this instruction.

**340 1991100**  
**2B 2 SKIPPED STITCHES**

IS THE NEEDLE SIZE SUITABLE FOR THREAD AND FABRIC?

NO - Sewing sheer fabric with needle size larger than 12 may cause puckering. Select suitable size needle for the fabric. Refer to *Section 5B*.

YES

IS THE NEEDLE CLEARANCE TO SHUTTLE HOOK CORRECT?

NO - Check clearance with proper tools and gauges for clearance adjustment. Refer to *Section 2C 2 1*.

YES

IS NEEDLE HEIGHT CORRECT?

NO - Check with proper gauge. Refer to *Section 2C 2 2*. Refer to *Section 2C 2 2* for adjustment.

YES

IS NEEDLE TIMING TO SHUTTLE HOOK CORRECT?

NO - Check with timing gauges. Refer to *Section 2C 2 1* for adjustment.

YES

If customer is having problems with stretch fabric suggest use of O Needle™. With this special needle we recommend use of the completely flat sole presser foot located in the machine's accessories tray.

**340 1991100**  
**2B 2 SKIPPED STITCHES**

IS THE HOOK TIP SHARP AND SMOOTH?

NO - Replace hook. Refer to *Section 2C 2 7*.

YES

IS HOOK 3 PIVOT PROPERLY POSITIONED AT 45°?  
(Check with gauge and tool)

NO - Refer to *Section 2C 2* for adjustment.

YES

IS NEEDLE BAR CORRECTLY ORIENTED? (Check with gauge)

NO - Refer to *Section 2C 2 2* for adjustment.

YES

ARE YOU GETTING SKIPPED STITCHES WHEN SEWING WITH MAXIMUM WIDTH STITCHES (8 MILLIMETER)?

NO - Check that machine is not stitching at width larger than 8 mm. Refer to *Section 2C 2 5* for the adjustment.

YES

IS UPPER THREAD TAUT ENOUGH WHEN THE NEEDLE EYE IS DOWN TO NEEDLE PLATE LEVEL?

NO - Before lowering needle, place remnant of sheer fabric under presser foot, rotate handwheel to bring needle eye down to needle plate level. Verify that the check spring is functioning correctly. Refer to *Section 2C 1* for adjustments.

**340.1991180**  
**2B.3 TOP THREAD BREAKING OR JAMMING IN SHUTTLE HOOK**

IS UPPER TENSION CORRECTLY SET?

NO - Set correct tension. Refer to Section 5C.

YES

↓  
IS GOOD QUALITY THREAD USED?

NO - Some poor quality threads on the market are not suitable for machine sewing. Use good quality thread such as cotton wrapped polyester.

YES

↓  
IS TOP THREAD TANGLING ON PARTS ALONG THE THREAD PATH?

YES - Check needle, spool pins, thread guides, tension assembly, etc. Rethread machine.

NO

↓  
DO ANY PARTS ALONG THREAD PATH HAVE ROUGH SURFACES OR ARE ANY DAMAGED?

YES - Check thread guides, tension control, thread take up lever, needle eye, presser foot, needle hole, needle plate, rotary shuttle hook, etc. Replace parts if necessary.

NO

↓  
IS THE TIP OF THE SHUTTLE HOOK SHARP AND SMOOTH?

NO - Replace shuttle hook. Refer to Section 2C.2.7.

YES

↓  
IS LINT OR BROKEN THREAD ACCUMULATED IN SHUTTLE HOOK OR FEED DOG AREA?

YES - Clean shuttle hook and feed dog areas. Refer to Section 5D.

NO

↓

**340.1991180**  
**2B.3 TOP THREAD BREAKING OR JAMMING IN SHUTTLE HOOK**

IS THE BOBBIN CASE HINGE LATCH PROPERLY POSITIONED AND IS IT PROPERLY TIGHTENED BY BOTH SMALL LATCHES OF THE SPRING HOLDER?

NO - Properly reset latch.

YES

↓

ARE NEEDLE HEIGHT, NEEDLE TIMING TO SHUTTLE HOOK, CLEARANCE BETWEEN BOBBIN CASE AND LATCH CORRECT?

NO - Refer to Sections 2C.2.1, 2C.2.2 and 2C.2.3 for adjustments.

**USER HINTS**

Advise user to follow instructions *Getting Ready to Sew* in Owner's Manual. Always draw 4 inches of both top and bottom threads to the rear of the machine before placing the fabric.

Use proper needle according to kind of fabric and thread.

Lint or broken thread in these areas will delay timing of thread escape from shuttle hook, resulting in thread breaking.

340 1991100  
2B 4 BOBBIN THREAD BREAKING

DO ANY PARTS ALONG THREAD PATH HAVE ROUGH SURFACES OR ARE ANY DAMAGED?

YES - Replace damaged parts

Check smoothness of bobbin case tension spring and thread path along bobbin case and needle plate

NO

IS BOBBIN CASE PROPERLY THREADED?

NO - Reinsert bobbin case

Check that bobbin rotates counterclockwise while thread is pulled. Check that thread passes under bobbin case tension spring

YES

IS BOBBIN ENTIRELY FREE TO ROTATE INSIDE CASE?

YES - Replace damaged part

Damaged bobbin or bobbin case will interfere with smooth feeding of thread

NO

IS TENSION OF BOBBIN CASE SPRING CORRECT?

NO - Reset tension refer to Section 5C

YES

IS BOBBIN THREAD EVENLY WOUND ON BOBBIN?

NO - Rewind the bobbin thread

If thread is not evenly wound on bobbin it will not unwind smoothly

340 1991100  
2B 5 LOOSE STITCHES OR PUCKERING

IS TENSION OF TOP THREAD AND BOBBIN THREAD BALANCED?

NO - Adjust tension of top thread and of bobbin thread to obtain good balance. Refer to Section 5C

Loose stitches occur when top thread tension is too loose or bobbin thread is too tight

YES

IS NEEDLE TIP DAMAGED?

YES - Replace needle

NO

IS NEEDLE SIZE SUITABLE FOR THREAD AND FABRIC?

NO - Select suitable size needle for the fabric. Refer to Section 5B

Sewing sheer fabric with needle size larger than 10 may cause puckering

YES

IS UPPER THREAD PROPERLY THREADED BETWEEN TENSION DISCS?

NO - Do upper threading with presser foot lifted so that tension discs are open

YES

IS PRESSURE ON PRESSER FOOT CORRECT?

NO - Set pressure knob on position 3 for normal sewing. Increase pressure for light fabric, decrease it for thick fabric

YES

IS CHECK SPRING FUNCTIONING PROPERLY?

NO - Replace tension group. Refer to Section 2C 1

Check smooth movement of check spring several times with finger

YES

ARE TENSION DISCS WORKING PROPERLY?

NO - Replace tension group. Refer to Section 2C 1

Thread machine from spool to take up lever and check that thread flows freely between tension discs when presser foot is raised, while correct tension is made on thread when presser foot is lowered. Check to see that friction on thread increases when tension knob is rotated toward higher values

YES



**340.1991100**  
**2B6 LOOSE STITCHES OR PUCKERING**

IS UPPER TENSION KNOB PROPERLY POSITIONED?

NO - Decrease tension when sewing light fabric, increase it when sewing on heavy fabric

Correct tension for general sewing is 3 setting

YES  
↓

IS FEED DOG HEIGHT CORRECT?

NO - Refer to Section 2C32 for adjustment

Incorrect feed dog height will cause poor feeding or loose stitches. Check height of feed dog with gauge

YES  
↓

IS TIMING BETWEEN NEEDLE AND FEED CORRECT?

NO - To check it refer to Section 2C31  
 To adjust timing refer to Section 2C31

**SERVICE HINTS**

- 1 Sheer or elastic fabrics tend to cause puckering. To avoid this, recommend tissue paper under layer for sewing such fabrics
- 2 Every sewing machine is adjusted at the factory to produce best sewing in the most frequently used stitch widths and lengths. Apparent loose tension when sewing widest stitch width and longest stitch length should not be considered a mechanical problem

**340.1991100**  
**2B6 IRREGULAR STRAIGHT STITCHING**

ARE STITCHES IN STRAIGHT SEAM ALIGNED?

NO  
↓

YES

IS NEEDLE BAR PRODUCING NOISY VIBRATIONS?

YES - Refer to Section 3B7

NO  
↓

IS PRESSER FOOT PRESSURE PROPERLY SET?

YES  
↓

NO N 3 is the proper setting for general sewing. Insufficient pressure may allow irregular feeding of fabric  
 Adjust pressure

IS PROPER SIZE OF NEEDLE BEING USED?

YES  
↓

NO If using thin needles on fabrics woven with thick threads seam may show irregular stitches  
 Select and install needle of proper size  
 Refer to Section 5B

DO YOU FIND EXCESSIVE PLAY IN THE KINEMATIC CHAIN OF MECHANISMS CONNECTING THE ACTUATOR WITH NEEDLE BAR?

YES - Refer to Section 2C26

IS NEEDLE POSITIONED TOWARD LEFT OR RIGHT OF THE NEEDLE HOLE BORED IN NEEDLE PLATE?

YES - Check and if necessary replace fuses of close loop boards. See Section 2C47. Check that connector is well plugged into the potentiometer of needle bar actuator, refer to Section 2C47. If problem persists, refer to Section 3B10

NO  
↓

WITH MACHINE SWITCHED ON, BUT NOT OPERATING, CAN NEEDLE BAR BE MANUALLY PUSHED TO LEFT OR RIGHT, WITHOUT ANY RESISTANCE?

YES - Check that connector between needle bar actuator and close loop board is properly connected at both ends. Refer to Section 2C47. If negative, refer to Section 3B10

NO

**340 1901100**  
**20 6 IRREGULAR STRAIGHT STITCHING**

WITH NEEDLE PLATE POSITIONED FOR STRAIGHT STITCHING (SMALL ROUND WINDOW) IS NEEDLE POINT CORRECTLY CENTERED OVER PLATE HOLE?

YES - Install thick needle (Size 16) and switch machine on

Program machine for straight stitching. Rotate handwheel verify that needle tip is well centered in needle plate hole. Refer to Section 2C 2 1 for adjustments.

**HINTS FOR USER**

Among the accessories of your machine you find the special straight stitch presser foot (the one with a small hole drilled right above the presser foot fork) to be used when sewing sheer stretch fabrics.

Needle plate should be positioned with the small round hole for straight stitching.

**340 1901100**  
**20 7 POOR KNOTTING OF STITCHING**

ARE UPPER THREAD AND BOBBIN THREAD PATHS CORRECTLY FOLLOWED?

NO - Retread

Refer to Section 5A

YES



IS THREAD COMING OFF OF THREAD SPOOL SMOOTHLY?

NO - Check that proper size of spool disc is being used and that disc edge is smooth all around.

YES



ARE BOTH UPPER AND BOBBIN TENSIONS BALANCED?

NO - Recheck and balance tensions. Refer to Sections 4E and 5C.

YES



IS CLEARANCE BETWEEN LATCH AND BOBBIN CASE CORRECT?

NO - Refer to Section 2C 2 3 for adjustment.

If clearance is too close upper thread cannot be fed smoothly. Irregular knots may appear in lower side of fabric.

YES



ARE SURFACES OF UPPER PART OF BOBBIN CASE AND OF BOBBIN SMOOTH?

NO - Smooth surface of parts, or replace rough parts.

YES



IS THE CHECK SPRING OF THE TAKE-UP LEVER GROUP PROPERLY PULLING BACK UP THREAD?

NO - Refer to Section 2C 1 for adjustment.

YES



ARE THE SHUTTLE HOOK GROOVE, BOBBIN CASE SLOT, AND BOBBIN CASE HOLDER CLEAN OF DUST OR LINT?

NO - Carefully clean all shuttle hook components.

Lint and dust cause excessive attrition between bobbin case and hook so that thread is not smoothly fed.

**340.1991100**  
**2B.7 POOR KNOTTING OF STITCHING**

**SERVICE HINTS**

Variation in stitch knotting may be caused by machine being run at uneven speed

Upper tension, when sewing with stretch stitches should be set at higher value than when sewing the utility stitches, especially when machine is being run at top speed

**340.1991100**  
**2B.8 IRREGULAR ZIGZAG STITCHING**

This section deals with problems of machine zigzag stitches producing incorrect or deformed patterns or insufficient zigzag width

**WHEN MACHINE IS TURNED OFF, IS SIDE MOVEMENT OF NEEDLE BAR SMOOTH AND EASY?**

**NO** Check kinematic chain of mechanisms from needle bar actuator to needle bar, be sure no part is damaged. Check that magnetic field created by actuator has not attracted metallic particles

Refer to *Section 2C 26*

**YES**



**TURN MACHINE ON AND PROGRAM ZIGZAG STITCHING IF YOU ROTATE HANDWHEEL. IS MACHINE PERFORMING ZIGZAG STITCHING?**

**NO** - Check to see that connector is securely fastened to close loop control board. Refer to *Section 2C 4 7*. If problem still remains, refer to *Section 3B 7 and 3B 10*

**YES**



**IS ZIGZAG WIDTH DIFFERENT FROM THE ONE THAT HAS BEEN PROGRAMMED?**

**YES** - Set zigzag at maximum width. Bight should be from 7.5 to 7.8 millimeters, at least. Refer to *Section 2C 25*

**NO**



**IS THE RIGHT PRESSURE ON PRESSER FOOT PROPERLY SET?**

**NO** - Poor pressure causes irregular feeding

Set proper pressure

**YES**



**WITH ZIGZAG SET AT MAXIMUM WIDTH, TURN HANDWHEEL AND CHECK WHETHER NEEDLE EVER TOUCHES EDGES OF NEEDLE PLATE OPENING**

**YES** - Refer to *Section 2C 25* for adjustments

**NO**



340.1991100  
28.8 IRREGULAR ZIGZAG STITCHING

IS NEEDLE PATH CENTERED ALL ALONG NEEDLE PLATE OPENING, WHEN NEEDLE MOVES OVER OPENING DRIVEN BY ZIGZAG BIGHT?

NO - Refer to Section 2C 2 5 for adjustments

YES

↓  
DO YOU HEAR MECHANICAL BANGING WHEN NEEDLE SEWS AT MAXIMUM ZIGZAG WIDTH?

YES - Check correct positioning of actuator Refer to Section 2C 2 5 Check correct positioning of actuator coil limiting devices Check that maximum zigzag width does not exceed 7.8 mm Refer to Sections 2C 2 5 for adjustments

NO

↓  
DOES ZIGZAG WIDTH CHANGE WHEN SEWING SPEED IS BEING INCREASED?

YES - Check that machine is not running over 1,000 r p m

Refer to Section 2C 4 5 for adjustment With special gauge check zigzag timing phase, Section 2C 2 5

NO

↓  
DO YOU FIND SUDDEN VARIATION IN STITCH WIDTH AND/OR LENGTH WHEN ZIGZAG SEWING?

YES - Refer to Section 3B 8

### SERVICE HINTS

Machine should not be run at speed higher than 1,000 stitches/minute Higher speed would not allow enough time for electromechanical actuators to properly position needle bar or feed eccentric rod, resulting in irregular sewing of pattern

340.1991100  
28.9 BOBBIN THREAD DOES NOT WIND, OR WINDS IMPROPERLY

DOES CLUTCH RELEASE UPPER SHAFT FROM MOTOR?

NO - Check clutch mechanism, replace damaged parts Refer to Section 2C 4 1

YES

↓  
DOES BOBBIN WINDER SHAFT RUN PROPERLY?

NO - Check to see if thread is tangled around bobbin winder shaft Check shape of rubber ring in bobbin winder assembly rubber material may change shape with age Replace rubber ring Refer to Section 2C 4 1

YES

↓  
IS INITIAL THREADING OF BOBBIN CORRECT?

NO - Correct initial threading of bobbin Refer to Owner's Manual

YES

↓  
IS THREAD PROPERLY WOUND ON BOBBIN?

NO - A correctly wound bobbin should have a cylindrical shape If shape is rather irregular, bobbin winder tension disc may need adjustment Refer to Section 2C 4 1

YES

↓  
IS PROPER AMOUNT OF THREAD WOUND ON BOBBIN?

NO - Bobbin winder mechanism automatically stops before bobbin is full Too much thread on bobbin can be a cause of thread breaking or loose stitches

Adjust winder limiting device Refer to Section 2C 4 1 for adjustments

340.1991100  
2B.10 ENGAGEMENT & DISENGAGEMENT OF FEED DOGS

WHEN FEED DOGS ARE DISENGAGED, ARE THEY LOWERED BELOW THE NEEDLE PLATE?

NO - Check conditions of the lifting spring pulling the feed dog mount. Lifting spring could be unhooked or broken. Check to see that feed dog's teeth are not leaning against edges of feed dog's windows. Check to see that feed lifting lever has not jumped out of position. Refer to *Section 2C34* for repairs.

YES

IS THE FEED DOG GROUP SOMETIMES JUMPING OUT OF ENGAGEMENT?

YES - Spring controlling the position of the feed lifting lever may be out of position, or damaged. Replace spring, refer to *Section 2C34*.

NO

DO YOU FIND THE FEED DOG GROUP HARD TO ENGAGE?

YES - Check to see that surface between cylindrical portion of feed lifting lever and the eccentric shaft is not pitted or damaged. Check to see that feed dogs are correctly aligned with needle plate windows. Refer to *Sections 2C32 and 2C34* for repairs, or part replacement.

340.1991100  
2B.11 POOR FEEDING OF FABRIC

IS FEED DOG LOWERING LEVER (LOCATED IN BOBBIN AREA, TO THE RIGHT SIDE OF SHUTTLE HOOK) PROPERLY POSITIONED?

NO - Move lever in the proper position.

YES

IS PROPER PRESSURE APPLIED ON PRESSER FOOT?

NO - More pressure for light-weighted fabric, less pressure for heavy fabric. Refer to *Section 5E*.

YES

LINT OR PIECES OF BROKEN THREAD ACCUMULATED IN FEED DOGS AREA?

YES - Remove needle plate, clean feed dog area.

Lint or pieces of thread accumulated in feed dog area will decrease feeding i.e. stitch length.

NO

ARE FEED DOG TEETH ALIGNED WITH NEEDLE PLATE WINDOWS?

NO - Check that clearance between feed dogs and needle plate openings are as indicated in *Section 2C32*.

Correct alignment accordingly.

YES

IS HEIGHT OF FEED DOG TEETH CORRECT?


NO - Incorrect feed dog height may result in poor feeding or loose stitches. Use feed dog height gauge to check height. Refer to *Section 2C32* for adjustments. In straight stitching, check to see that maximum stitch length is between 5.5 and 8.0 millimeters. For necessary adjustments, refer to *Section 2C33*.

YES

ARE FEED DOGS BELOW NEEDLE PLATE WHENEVER NEEDLE IS IN ITS LOWER POSITION?

NO - Check feed timing to needle movement, as per *Section 2C31*. Reset timing accordingly.

YES



**340.1991100**  
**2B.11 POOR FEEDING OF FABRIC**

IS FABRIC BEING FED WITHOUT EXCESSIVE SIDE DRIFTING?

NO - Side drifting is caused by insufficient attrition between presser foot, sole and feed dogs

Replace presser foot if sole appears damaged or uneven

YES

IS LENGTH OF SEWED STITCHES DIFFERENT FROM KEYBOARD PROGRAMMED LENGTH?

YES - Check to see that no part is stuck in feed kinematic mechanism. Refer to Section 1B.6. Reset stitch length control referring to Section 2C.3.3

NO

STITCHING WITH REVERSE, ARE YOU MAKING BACKWARD STITCHES OF SAME LENGTH AS WHEN STITCHING FORWARD?

NO - Refer to Section 2C.3.3 for necessary adjustments. As a final check, enter program 26 through keyboard and sew

YES

IS MACHINE FED ONLY IN ONE DIRECTION AND WITH MAXIMUM STITCH LENGTH, EVEN WHEN DIFFERENT STITCH PATTERNS ARE PROGRAMMED?

YES - Verify that connector from feeding actuator is properly plugged to close loop board. Check fuses of close loop board and replace them if necessary. If problem persists, refer then to Section 3B.3

NO

DO SOME STITCH PATTERNS SEEM TO BE SEWING IN A STRETCHED ELONGATED SHAPE?

YES - Check to see that no loose tolerances are in the kinematic chain of mechanisms linking feed actuator with feed dog, refer to Section 1B.6 for adjustments, or for replacing defective parts. Also, see Section 1B.10. Check that metallic burrs are not trapped inside actuator magnetic field. If you still have problems, refer to Section 3B.4 and 3B.8

**USER HINTS**

With proper presser foot and feed dogs at the correct height, the sewing machine automatically feeds the fabric. User must not pull or push fabric against machine's feeding action

**340.1991100**  
**2B.12 MACHINE DOES NOT RUN**

Jamming or freezing of mechanical parts or electric components will be the main cause of this problem

**CAUTION:** When a machine will not run due to mechanical jamming, do not force it to run with extra power otherwise machine may lose its timing completely and fail to sew

IS BOBBIN WINDER LEVER DISENGAGED?

NO - Disengage lever

YES

IS CLUTCH WORKING PROPERLY?

NO - Check clutch components, replace damaged parts, referring to Section 2C.4.1

Clutch allows machine to be driven by electric motor when bobbin winder is not engaged. When bobbin winder is engaged, clutch cuts off upper & lower machine shafts so that motor drive is directed to bobbin winder group only (see Section 1B.1)

YES

DO YOU FEEL STRONG RESISTANCE IF YOU TRY TO MANUALLY ROTATE HANDWHEEL?

NO

YES

IS ANYTHING TANGLED IN THE GEARS OF ROTARY HOOK, OR DO GEARS SHOW DAMAGED TEETH?

NO

YES - Clean parts. Oil adequately only where you find dried up lubricant. Be careful that no oil drips on PC boards. Refer to Section 2C.4.1

WAS THE MACHINE DROPPED?

YES - Repair or replace damaged parts. If the main frame is bent or broken machine is not economically repairable

DO BULBS LIGHT UP?

NO - Replace main fuse. Replace electric cord. Refer to Section 3B.1 and 3B.2

Check to see that machine is properly plugged into wall socket and that foot control plug is well plugged into machine

YES

IS THE "ON-OFF" LED SIGNAL ON KEYBOARD OPERATIVE?

NO - Replace fuses of close loop board. If you still have problems, refer to Section 3B.1 and 3B.2

Connectors of controlling potentiometers of both needle bar and feeding actuators must be securely connected. A faulty erratic connection would cause fuse to cut feeder's circuit

YES

**340.1991180**  
**2B 12 MACHINE DOES NOT RUN**

ARE THE CORRECT LED'S LIT WHEN STRAIGHT OR ZIGZAG STITCHING IS PROGRAMMED?

NO - Problems are in the electronic circuitry, refer to *Section 3B 1 and 3B 2*

YES



ONCE THE STITCHING PROGRAM HAS BEEN ENTERED, CAN THE MACHINE SEW AS SOON AS CONTROL IS BEING PRESSED?

NO - Replace foot control, if machine still does not work, check to see that connectors joining motor and foot control to the motor control board are properly plugged in. Refer to *Section 2C 4 7*. Check to see whether electric motor brushes need replacement, check brush springs. Check condition of motor commutator.

For all these checking procedures, refer to *Section 2C 4 6*

**SERVICE HINT**

If motor commutator shows damage due to excessive sparking, replace motor to avoid second service call. To replace motor, refer to *Section 2C 4 6*.

If above checks show no result, refer to *Section 3B 5*.

**340.1991180**  
**2B 13 MACHINE DOES NOT BASTE**

IS BASTING NEEDLE INSTALLED ON MACHINE?

NO - Basting on this electronic sewing machine requires the special needle (the one with the golden stem)

Install correct needle

YES



WAS BASTING PROGRAM CORRECTLY ENTERED?

NO - Basting program code number is 37. Try to enter it again into keyboard. If inoperative, refer to *Section 3B 10*.

YES



ARE NEEDLE HEIGHT AND NEEDLE BAR ORIENTATION CORRECT?

NO - Check with proper gauge. Refer to *Section 2C 2 2* for adjustment.

YES



ARE TIMING BETWEEN NEEDLE AND SHUTTLE HOOK RIGHT?

NO - Check with proper gauge. Refer to *Section 2C 2 1* for adjustment.

YES



IS CLEARANCE BETWEEN NEEDLE AND SHUTTLE HOOK CORRECT?

NO - Check clearance, referring to *Section 2C 2 1*.

Adjust clearance accordingly

YES



IS ZIGZAG TIMING CORRECT?

NO - Check timing with timing gauge, refer to *Section 2C 2 5*.

Reset timing as per *Section 2C 2 5*

YES



IS THE SHUTTLE HOOK TIP SHARP AND SMOOTH?

NO - Replace hook, refer to *Section 2C 2 7*.

**USER HINTS**

Suggest that user select low speed for basting, it's the best way to achieve better control in guiding fabric, since basting program number 37 provides extremely fast feeding of machine.

**340.1991100**  
**2B.14 UNSATISFACTORY BUTTONHOLING**

DOES BUTTONHOLE LOOK PROPERLY CLOSED AND COMPLETE?

NO - Check to see that machine contact points properly respond to buttonhole foot motion. Refer to *Section 2C.4.2*

YES

↓  
ARE BAR TACKS OF THE SAME LENGTH?

NO - Check to see that sole glides freely along buttonholer's guide, and that sole is properly positioned before starting to sew. Check to see that the sole correctly positioned to start buttonholing, the distance between sensor levers and contact points is properly set. For possible adjustments, refer to *Section 2C.4.2*

**USER HINTS**

- 1 Set speed selector on low speed, we recommend low sewing speed for better buttonholing. Be sure buttonholer foot is properly mounted, refer to *Owner's Manual*
- 2 Selection of buttonhole length and shape should be checked on remnant of the same material over which buttonholes will be later sewn. In this way you ascertain that feeding stitch length and width are the most suited to your demand
- 3 Feed on some fabrics such as terry cloth, sheer fabrics and velvet are uneven. We suggest to increase pressure on presser foot and to lay tissue paper under fabric before lowering presser foot. Stitch length should also be increased
- 4 Before starting to sew a buttonhole, be sure that gliding sole is correctly positioned (all the way forward, toward operator)

**340.1991100**  
**2B.15 MACHINE SEWS WITHOUT FOOT CONTROL BEING PRESSED**

TURNING THE MAIN SWITCH ON, DOES MACHINE START SEWING, EVEN IF NO PROGRAM WAS ENTERED THROUGH THE KEYBOARD?

YES - Refer to *Section 3B.11*

NO

↓  
WHEN A STITCH PATTERN HAS BEEN ENTERED AND THE O.K. KEY PRESSED, DOES MACHINE SEW WITHOUT THE FOOT CONTROLLER BEING PUSHED DOWN, OR DOES MACHINE CONTINUE SEWING EVEN IF FOOT CONTROL IS RELEASED?

YES - Replace foot control. If problem remains, refer to *Section 3B.11*



**340.1991100**  
**2B.16 LIGHTS REMAIN OFF?**

IS JUST ONE BULB OFF?

YES - Replace bulbs

If problem remains refer to *Section 3B6*

NO



ARE BOTH BULBS OFF BUT MACHINE OPERATES  
REGULARLY?

YES - Check connectors to see that they are firmly  
connected

Replace bulbs  
Refer to *Section 3B6*

**340.1991100**  
**2B.17 MOTOR SPEED SELECTION DOES NOT WORK**

You may have a mechanical or an electrical problem

The low speed control will allow machine to sew up to 500 rpm's, maximum speed should be between 950 and 1 000 rpm's. Machine should not be allowed to run faster or poor stitch quality will result

**A WORD OF CAUTION:** If you notice machine to be very stiff, do not force it to operate. Find the reasons first

DO YOU FIND HANDWHEEL STIFF WHEN YOU  
ROTATE IT?

NO



YES

IS THERE ANY TANGLED THREAD OR DRIED  
LUBRICANT BETWEEN OPERATIVE PARTS?

NO



IS TOOTHED BELT BETWEEN UPPER AND LOWER  
SHAFT TOO TIGHT?

NO



IS TOOTHED BELT BETWEEN MOTOR AND UPPER  
SHAFT TOO TIGHT?

NO



WAS MACHINE DROPPED?

YES - Remove thread clean out dry lubricant oil  
CAREFULLY (oil can interfere with P.C. board  
contacts)

YES - Refer to *Sections 2C44* for adjustments

YES - Refer to *Section 2C44* for adjustments

YES - If main frame is bent or broken the machine is not  
economically repairable

Otherwise, repair or replace damaged parts

WITH MACHINE ALL SET TO SEW, IS JUST A LIGHT  
PRESSURE ON FOOT CONTROL ENOUGH TO CAUSE  
MACHINE TO RUN AT FULL SPEED?

YES - Replace foot control. Check to see that interruptor is  
securely fastened to motor control board. Refer to  
*Section 2C47* if problem remains, refer to *Section*  
*3B5*

NO



340.1991100

**2B 17 MOTOR SPEED SELECTION DOES NOT WORK**

KEEPING SAME PRESSURE ON FOOT CONTROL DO YOU NOTICE A DIFFERENCE IN SPEED, WHEN FLIPPING SPEED CONTROL LEVER FROM LOWER TO HIGH SPEED, AND VICE VERSA?

NO - Refer to *Section 3B 5*

YES



IS THE MAXIMUM SPEED WITHIN SUGGESTED RANGE?

NO - Refer to *Section 2C 4 5* for adjustment of potentiometer

YES



IS FOOT CONTROL MAINTAINING SAME SPEED, WHEN BEING PRESSED WITH EQUAL PRESSURE?

NO - Replace foot control

YES



AS SOON AS A STITCHING PROGRAM IS ENTERED, DOES MACHINE RUN WITHOUT FOOT CONTROL BEING PRESSED?

YES - Replace foot control If problem remains refer to *Section 3B 11*

340.1991100


**2B 18 FAULTY KEYBOARD**

Faulty keyboard performance is usually related to a problem in the electronic circuitry  
Refer to *Section 3B 2*

**SERVICE HINTS**

It is always advisable to check tensions of toothed belts. Too much tension is stressing pulley supports, excessive tension on motor belt reduces speed and it fatigues motor

340.1991100  
2C ADJUSTMENT AND REPLACEMENT



**SERVICE ACCESS**


For service access side A B D and base C covers can be removed by removing screws as shown. Before loosening screw (A1) remove first cover B, which is pressure mounted under machine head. Attach to the five studs protruding from underneath of main frame, the five support feet No. 68949.

340.1991100  
2C.1 TOP THREAD TENSION CONTROL

**1 CHECKING TENSION CONTROL DISC OPENING**


**SPECIFICATIONS** When presser foot is raised clearance between tension discs should be .012 inches (.3 mm). To verify the above specifications:

- Lower presser foot
- Set thread tension regulator at 6
- Insert upper tension disc gauge 68939 between discs (Figure 1). The gauge should not fall.



**FIGURE 1**

- Raise presser foot. The gauge should fall (Figure 2).



**FIGURE 2**

**2 ADJUSTING DISC OPENING WHILE PRESSER FOOT IS UP**

If adjustment is necessary, loosen screw (A) slightly (Figure 2) and adjust position or level (B) upward or downward as illustrated. Tighten screw (A) securely after adjustment.

340.1991100  
2C.1 TOP THREAD TENSION CONTROL

3 TOP THREAD TENSION CONTROL

- Use a cotton wrapped polyester thread
- Raise presser foot and insert thread between discs in tension assembly
- Lower presser foot
- Set tension control at 3
- Tie the 55 gram weight (No. 68940) to the end of the thread. Sitting in front of machine tilt machine toward you (Figure 3). The thread should be held between the tension discs and the 55 gram weight should not lower. Add the 15 gram weight to the 55 gram weight. The thread should move slowly through the tension discs allowing the weights to move downward.




FIGURE 3

- Remove weights and set tension control to 0. Pull on thread and verify that no tension is present.
- Set tension control to 1. A very light tension should be felt as the thread is pulled through the discs.
- If tension assembly does not operate as described above, adjust thread tension assembly.

340.1991100  
2C.1 TOP THREAD TENSION CONTROL

4 TOP THREAD TENSION ADJUSTMENT

- The thread tension assembly is adjusted by turning knurled nut (A) (Figure 4). It will be necessary to remove the tension assembly (Figure 4) from the machine to make this adjustment. Refer to "Upper Tension Assembly Replacement" paragraph 7.
- To adjust tension assembly, rotate the knurled ring nut (A) (Figure 4) repeating the thread tension tests described previously. If satisfactory adjustment cannot be obtained, replace tension assembly.




FIGURE 4

### 5 CHECKING THE THREAD CHECKSPRING

- Thread machine set tension regulator at 3. Place a lightweight piece of fabric under presser foot. Lower presser foot.
- Rotate handwheel and watch the checkspring (G) motion (Figure 5). When the checkspring is properly positioned it will contact the small limiting bracket (F) at the same time the needle tip starts piercing the fabric.

### 6 ADJUSTING CHECKSPRING

- To adjust checkspring position, loosen screw (E) and adjust limiting bracket (F), then tighten screw (E) while holding limiting bracket (F) in its newly adjusted position with a second screwdriver (Figure 5).
- Tension created by the checkspring has been factory adjusted. Adjustment was made by positioning checkspring tail into one of the notches curved in the back end of the checkspring bracket (F) to achieve a tension load on the thread of 13.17 grams.
- If this adjustment is incorrect, the checkspring can be readjusted. Changing the checkspring tail location will alter the checkspring tension.




FIGURE 5

### 7. TENSION ASSEMBLY REPLACEMENT

To remove the tension assembly from the machine, first remove adjuster ring (M) (Figure 6) from the pivot rod of the needle bar holder. To do this, remove "E" clip (I) and then lift connecting rod (L) in order to gain access and loosen screws (M) and (N). Remove adjuster ring (H).

#### 7.1 Removing Tension Assembly

- Lower presser foot.
- Rotate handwheel until take up lever is in its lowest position. Remove screw (A) (Figure 6) and remove lever (B).
- Remove screws (C) and (D). NOTE: It may be necessary to loosen screw E and rotate bracket (F) to remove screw (D) if checkspring (G) interferes with removal of screw (D).
- Push lower part of tension assembly in the direction indicated by arrow (1) in Figure 6 and then rotate it as shown by arrow (2). This dual motion will facilitate removal.

#### 7.2 Installing Tension Assembly

- To install, reverse procedure explained in preceding paragraph 7.1. It is suggested that you tighten screw (D) before screw (C).
- After installing tension assembly, place adjuster ring (H) back into position with the larger opening up. Tighten screw (N) and then tighten screw (M) from under connecting rod (L). Reinstall connecting rod (L) and check to see that needle bar holder moves freely but has no vertical play on shaft. Reinstall "E" clip (I).
- Reposition checkspring bracket (F) (see paragraph 5).
- Install lever (B) and tighten screw (A). Check tension disc specifications as described in paragraphs 1 and 3.




FIGURE 6

340.1991100  
2C.2 NEEDLE AND SHUTTLE HOOK AREA

1 CHECKING ROTARY SHUTTLE HOOK ANGLE AND AXIAL POSITIONING

NOTE The following instructions should be followed whenever adjustments or repairs of machine were made that could have caused misadjustments in shuttle hook angle and axial positioning.

- Rotate handwheel to bring needle to its highest position. Remove needle, presser foot, needle plate, bobbin, bobbin case and bobbin case holder. To remove bobbin case holder, slide tab "R" (Figure 9) downward. This will release the bobbin case holder retaining ring.
- Remove bobbin case stop (A) (Figure 8) by removing screws (B).




FIGURE 8

- Loosen screws (C) (Figure 9) and move crown gear (D) away from shuttle pinion gear (E).
- Loosen screws (F) and (G) (Figure 9) and pull shuttle hook assembly upward.
- Reinstall needle plate and drop feed dogs.




FIGURE 9

340.1991100  
2C.2 NEEDLE AND SHUTTLE HOOK AREA

- Rotate shuttle hook by hand until the shuttle hook tip reaches its 12 o'clock position. Insert gauge No. 68935 firmly into the shuttle assembly (Figure 10) and position it so that upper sides (A) of gauge are parallel with the feed dog openings in needle plate (B).
- Lower the shuttle hook assembly and gauge together until the feet of the gauge's upper portion are all touching the needle plate and the lower portion of the gauge is maintaining the proper angle of the shuttle assembly (gauge must be evenly seated in shuttle race assembly).
- Tighten screws (F) and (G) securely. Reinstall gauge and recheck shuttle position. Remove the gauge and verify that the shuttle assembly rotates freely and smoothly.
- Reposition crown gear (D) and tighten screws (C) securely (Figure 9). CAUTION Gears should be snug but not so tight as to create a binding. There should not be any up and down movement of the shuttle assembly.
- Reinstall gauge and recheck alignment to needle plate.





FIGURE 10

340.1001100  
**2C.2.1 NEEDLE TO SHUTTLE HOOK TIMING AND CLEARANCE**

NOTE Before starting adjustments described in this Section check and if necessary adjust needle to needle plate centering refer to Section 2C.2.4

**1 CHECKING NEEDLE-TO-SHUTTLE-HOOK TIMING**


- Needle to shuttle hook timing is correct when the shuttle hook tip is directly behind the needle when the needle is centered for straight stitching and the needle is 0.1 inch (2.5 mm) above its lowest position
- To check position and alignment rotate handwheel to bring needle bar to its highest position. Remove needle, presser foot, needle plate, bobbin and bobbin case. Remove bobbin case stop (A) (Figure 8) by removing screws (B).
- Insert gauge No. 68936 into needle bar actuator to center needle bar as illustrated in Figure 11. Attach gauge No. 68933 to needle bar. Turn handwheel to bring needle bar to its lowest position.



**FIGURE 11**


340.1001100  
**2C.2.1 NEEDLE TO SHUTTLE HOOK TIMING AND CLEARANCE**

- Position gauge No. 68932 on needle bar. Place gauge No. 68931 around needle bar and on top of gauge No. 68932 and raise both gauges until they are tight against needle bar holder (Figure 12). Tighten knob on gauge No. 68932 and remove forked gauge No. 68931. Be sure the pulse motor centering tool No. 68936 is securely in place.



**FIGURE 12**


- By hand turn handwheel toward you until gauge No. 68932 is raised and stops against the needle bar holder (Figure 13).



**FIGURE 13**

340.1991100  
**2C.2.1 NEEDLE TO SHUTTLE HOOK TIMING AND CLEARANCE**

- The timing between needle and shuttle hook is correct if, with gauge No 68936 in place and having performed the steps described in paragraphs C, D and E, the shuttle hook tip is hidden by the thin lower caliber rod of No 68933 and cannot be seen while sitting in front of the machine (Figures 13 and 14)




**FIGURE 14**

**2 ADJUSTING NEEDLE TO SHUTTLE HOOK TIMING**

If alignment described in paragraph above is not correct, make adjustment as follows

- Loosen screws (A) in crown gear (B) (Figure 15) Turn handwheel to raise gauge No 68932 until it stops against needle bar holder (Figure 13) Rotate shuttle hook manually, until shuttle hook tip is hidden behind thin caliber rod of gauge No 68933 Pulse motor centering tool No 68936 must be in place during this adjustment
- Reposition crown gear (B) and tighten screws (A) Recheck alignment as described in the last paragraph under number 1
- **CAUTION:** Crown gear (B) and pinion gear (D) should be snug but not so tight as to create binding There should be no up and down movement of the shuttle assembly This adjustment is critical for smoothness of operation and noise level
- Check clearance between needle and shuttle hook as explained in the following paragraph 3




**FIGURE 15**

340.1991100  
**2C.2.1 NEEDLE TO SHUTTLE HOOK TIMING AND CLEARANCE**

**3 CHECKING NEEDLE-TO-SHUTTLE-HOOK CLEARANCE**

With needle positioned for straight stitching, clearance of .004-.008 inch (0.1-0.2 mm) between shuttle hook tip and back side of needle is acceptable, when measured with needle tip raised .112 inch (2.8 mm) from its lowest position

- To check needle-to-shuttle-hook clearance position gauge No 68936 into needle bar actuator (Figure 11) Install a #14 needle
- Lower needle bar to its lowest position Position gauge No 68932 on needle bar Place gauge No 68931 around needle bar and on top of gauge No 68932 and raise both gauges until they are tight against needle bar holder (Figure 12) Tighten knob on gauge No 68932 and remove gauge No 68931 Turn handwheel manually until gauge No 68932 is tight against needle bar support
- Clearance between needle and hook is correct when with very light pressure on the needle (toward back of machine) the needle tip touches shuttle hook tip (Figure 16) Clearance should be .004-.008 inch (0.1-0.2 mm)




**FIGURE 16**



340.1991180  
**2C.2.1 NEEDLE TO SHUTTLE HOOK TIMING AND CLEARANCE**

**4 ADJUSTING NEEDLE-TO-HOOK CLEARANCE**

- If clearance is not correct, loosen screws (A) and rotate rest bushing (B) which supports the hook until the correct setting is obtained (Figure 17). Tighten screws (A) securely after adjustment.



**FIGURE 17**

- Remove gauge No. 68932 from needle bar. Rotate handwheel toward you, checking to see that shuttle hook tip does not hit needle. If it does, repeat adjustment as described in preceding paragraph.
- Recheck shuttle hook needle timing as covered in paragraph 1, Figures 13 and 14. Check and if necessary adjust needle bar height and needle bar orientation as described in following Section 2C.2.2.


340.1991180  
**2C.2.1 NEEDLE TO SHUTTLE HOOK TIMING AND CLEARANCE**

**1. CHECKING NEEDLE BAR HEIGHT**

**NOTE:** Before proceeding with the steps described in this paragraph, we suggest you verify and, if necessary, adjust centering, width and zigzag timing (see Section 2C.2.5).


Set zigzag at maximum width with needle positioned all the way to the left. Needle bar height is properly adjusted when needle, in its upward stroke from its lowest position, has top of needle eye located 0.20 inch (5 mm) below shuttle hook tip when the shuttle hook tip is directly behind the needle.

- Remove needle, presser foot, needle plate, bobbin case and bobbin case stop from the machine.
- Install gauge No. 68933 to needle bar (Figure 18).



**FIGURE 18**

- Turn machine on Program stitch pattern 1 (left zigzag) and set zigzag width at zero mm.
- Manually rotate handwheel toward you to assure that needle bar has moved to the left position. Continue to rotate the handwheel until the needle has gone all the way down and is beginning to rise.
- Needle bar height is correct when, having performed the procedure in 1 above, tip of shuttle hook is hidden by the thin rod of gauge No. 68933 and the very tip of the hook is at the same level as the groove on the gauge (Figure 19).



**FIGURE 19**

**2. ADJUSTING NEEDLE BAR HEIGHT**

- Loosen screw (A) (Figure 18) and adjust needle bar up or down to proper position. Tighten screw (A) securely while holding needle bar in the proper orientation.
- Check adjustment, rotating handwheel.

340.1991100

## 2C.2.2 NEEDLE BAR HEIGHT AND ORIENTATION

### 3 CHECKING NEEDLE BAR ORIENTATION

Needle bar orientation is within specification when right side bar of gauge No. 68933 is between zero and .060 inch (1.5 mm) of parallel line with front edge of needle plate. See Figures 20, 21 and 22.

- The .060 inches (1.5 mm) position will improve machine performance when using stretch threads (Figures 21 and 22). This .060 inch twist given to the needle bar will make it easier for the hook tip to pick up the thread loop.
- In no case should the left hand rod (rather than the right rod) be closer to the plate edge (Figure 22).

### 4 ADJUSTING NEEDLE BAR ORIENTATION

- To adjust, loosen screw (A) (Figure 20) and rotate the needle bar as required for proper adjustment. Be careful not to change needle bar height. Tighten screw (A) securely. Remove gauge and reinstall bobbin case, needle, needle plate, presser foot and bobbin case stop.
- Adjust the position of bobbin case stop. Refer to Section 2C.2.3.




FIGURE 20

FIGURE 21

FIGURE 22

## 340.1991100 2C.2.3 CLEARANCE BETWEEN BOBBIN CASE HOLDER AND BOBBIN CASE STOP

### 1. CHECKING THE CLEARANCE

- Clearance between the small stud protruding from upper portion of bobbin case holder and the bottom of slot in bobbin case stop must be .015-.022 inch.
- To check clearance, use wire feeler gauges (Figure 24). The .015 gauge should enter clearance and the .022 gauge should be too thick to enter.

### 2. ADJUSTING CLEARANCE

Loosen screws (A) and adjust the stop position. Tighten screws securely after adjustment.




FIGURE 24

340.1991180  
**2C.2.4 NEEDLE POSITION AT STRAIGHT STITCHING**


To obtain correct alignment both mechanical and electrical zero positions must be properly set

**1 CHECKING MECHANICAL ZERO POSITION**

- To verify set needle plate with straight stitch hole under needle
- Place gauge No 68936 into needle bar actuator (Figure 25)
- Remove needle and attach gauge No 68933 to needle bar as illustrated
- Rotate handwheel to slowly move needle bar down
- The mechanical zero position is correct if gauge rod penetrates the needle hole without touching hole edge

**2 ADJUSTING MECHANICAL ZERO POSITION**

- If needle is just slightly off center then simply loosen screw (B) (Figure 25) and turn eccentric screw (C) until needle is centered right and left. Tighten screw (B) securely after adjustment
- If needle centering cannot be obtained with eccentric screw (C) slightly loosen screws (A) and move needle bar actuator toward front or back of machine until gauge rod centers in needle hole. Tighten screws (A) securely after adjustment



**FIGURE 25**

340.1991180  
**2C.2.4 NEEDLE POSITION AT STRAIGHT STITCHING**


- If adjustment is needed because needle is not centered front to back in needle hole adjust eccentric in needle plate screw (A) (Figure 26)

**3 CHECKING ELECTRICAL ZERO POSITION**

- Remove gauge from needle bar actuator
- Rotate handwheel to raise needle bar to upper position
- Turn machine "on" and program it for straight stitching
- Rotate handwheel to lower the needle bar
- The rod of gauge No 68933 should penetrate the straight stitch needle hole in the center and should not contact the needle plate

**4. ADJUSTING THE ELECTRICAL ZERO POSITION**

- If electrical centering is not correct as described above it will be necessary to adjust the potentiometer. Refer to Section 2C.4.5




**FIGURE 26**


340.1991180  
**2C.2.5 CHECKING TIMING AND WIDTH OF ZIGZAG**

**1 CHECKING ZIGZAG TIMING**

- Zigzag timing is correct if needle starts its side motion when its tip is  $\frac{3}{40}$  inch (8.5 mm) above the needle plate. This measurement is taken when the needle is being raised toward its upper position. Check this measurement as follows:
- Position needle plate for zigzag stitching.
- Install a size 14 needle.
- Turn the machine "on" and program it for zigzag stitching at maximum width.
- Lower feed dogs.
- Manually rotate the handwheel toward you at least one complete turn, then stop with needle in upper position.
- Place gauge No. 68931 on needle plate. Make sure that gauge is directly centered over zigzag needle hole, as shown in Figure 27a.
- Manually rotate handwheel toward you and observe that needle passes over the second step of the gauge without touching it (Figure 27a). Then, slide the gauge toward the front of the machine, so that the third step is positioned under the needle. The side motion of the needle should cause the gauge to tip over when handwheel is being rotated (Figure 27b).



**FIGURE 27a**




**FIGURE 27b**

340.1991180  
**2C.2.5 CHECKING TIMING AND WIDTH OF ZIGZAG**

**2. ADJUSTING ZIGZAG TIMING**


- To adjust, slightly loosen screw (A) of lever (B) on machine lower shaft (F) (Figure 28). Rotate lever (B) on the shaft to obtain the correct setting. Recheck needle bite with gauge No. 68931. When setting is correct, tighten screw (A) securely.
- Remove gauge and turn off the machine.
- Rotate handwheel and check the clearance between board and magnet (C) (Figure 28). The clearance should be  $0.12 - 0.040$  inch between magnet (C) and each of the two magnitors (D) and (E). Check this clearance with feeler gauges.
- Recheck needle bite using gauge No. 68931.



**FIGURE 28**

**3. CHECKING ZIGZAG WIDTH**

- Maximum zigzag width (8.0 on readout) should allow the needle a bite between 7.5 and 7.8 millimeters when operated manually with the handwheel.
- To verify this position needle plate for zigzag stitching:
- Install a number 14 needle.
- Lower feed dogs.
- Turn machine "on" and program for widest zigzag stitch.
- Check needle bite clearance using gauge No. 68931 (Figure 27).
- Manually rotate handwheel toward you through one complete zigzag cycle and observe needle bar holder (A) and pivot (B) (Figure 29). The clearances between pivot (B) and each of the limiting devices (C) must be equal. Also limiter (C) must be  $0.020 - 0.032$  inches below holder (A) (Figure 29). Check clearances with feeler gauges.
- If adjustment is required, loosen screw (D) slightly and rotate limits. After adjustment, tighten screw (D) securely and recheck clearances.



**FIGURE 29**

340.1991180

### 2C.2.5 CHECKING TIMING AND WIDTH OF ZIGZAG

- Place a firm piece of paper over needle plate. Manually rotate handwheel toward you through one complete zigzag cycle. Remove the paper and measure the distance between the two holes. The correct distance will be 7.5-7.8 mm (Figure 30)

### 4 ADJUSTING ZIGZAG WIDTH

If needle hole spacing is not correct adjustment of potentiometer is needed. Refer to Section 2C.4.5




FIGURE 30

340.1991180

### 2C.2.6 NEEDLE BAR SUPPORT

#### 1. REMOVING THE SUPPORT

- Remove "E" clips (A) (Figure 31) and remove connecting rod (B) off of pivots of actuator and needle bar support
- Loosen screws holding ring (C). Remove ring
- Loosen screw (D) of limiting device (E)
- Loosen screw (F) lower pivot (G), remove "E" clip (H) and slip out pivot (G)
- Remove needle bar support (I) from machine




FIGURE 31

340.1991100  
2C.2.6 NEEDLE BAR SUPPORT

2 INSTALLING THE SUPPORT

- Manually turn handwheel until take up lever is at its highest position. Insert pivot rod from block (L) (Figure 32) into the articulated joint (floating bushing) (M) in rod (N).




FIGURE 32

- Insert pivot (G) through the bottom of the needle bar support. Before pivot reaches the highest portion of needle bar support, locate the limiting device (E). Be sure that pivot (O) is between the two stops of the limiting device (E). Place elastic washer (P) on pivot (G).
- Reinstall 'E' clip (H) (Figure 31) into slot in pivot (G). Be sure that elastic washer (P) is above 'E' clip (H). While maintaining an upward pressure on the bottom of pivot (G), install the retainer ring (C).
- The wider opening of the ring should be up. Tighten screws securely.
- Clearance between bottom of needle bar support and mainframe section should be .040 (1 mm) inch (Figure 31). Check clearance with feeler gauge, then tighten screw (F).
- Manually move needle bar support back and forth to be sure it operates smoothly and does not have any vertical play. If vertical play exists, loosen screws holding retainer ring (C), adjust ring level and tighten screws securely.
- Install connecting rod (B) as illustrated in Figure 33a. Figure 33b shows connecting rod incorrectly installed. Reinstall the 'E' clips (A) (Figure 31).




FIGURE 33a




FIGURE 33b

340.1991100  
2C.2.6 NEEDLE BAR SUPPORT

- Turn machine on and program it for maximum zigzag width. Manually rotate handwheel toward you through one complete zigzag cycle while observing pivot (O) and limiting devices (E). The clearance between the pivot and each stop should be equal (Figure 34). Check the clearance between tip of both stops and needle bar support using feeler gauge. The correct clearance will be .020-.032 inch. If adjustment is required, loosen screw (D) and reposition limiting device (E). NOTE: Be sure pivot does not hit or bind on limiting device (E).




FIGURE 34

340.1991180  
2C.2.7 REPLACING THE SHUTTLE HOOK AND RELATED GEARS

1 REMOVING THE SHUTTLE HOOK ASSEMBLY

- Remove needle presser foot needle plate and bobbin case holder
- Loosen screws (B) and remove bobbin case stop (A) (Figure 36)




FIGURE 36

- Loosen screws (C) (Figure 37) and slide crown gear (D) away from shuttle hook pinion gear (E)
- Turn handwheel manually to bring take up lever to its lowest position
- Loosen screws (F) (Figure 37) and remove shuttle hook pinion gear (E) Loosen screws (G) slightly




FIGURE 37

340.1991180  
2C.2.7 REPLACING THE SHUTTLE HOOK AND RELATED GEARS

- Lift and push back feed dog bracket (H) (Figure 38) then remove shuttle hook




FIGURE 38

2. REMOVING THE SHUTTLE HOOK DRIVE BUSHING

After removing the shuttle assembly, the bushing can be removed by loosening screw (I) slightly and sliding out the shuttle hook drive bushing (L) (Figure 39)

3. REMOVING THE CROWN DRIVE GEAR

- Turn handwheel by hand to bring take up lever to its lowest position
- Remove screws (G) (Figure 39) remove bracket (M) and slide bushing holder (N) off of lower shaft





FIGURE 39

340 1901100  
**2C 27 REPLACING THE SHUTTLE HOOK AND RELATED GEARS**

- Carefully pull lower shaft (O) downward. Watch for sector block (F) which may come out of guide (R). Remove crown gear (D) (Figure 40).

**4 INSTALLING CROWN GEAR**


- Holding lower shaft (O) slide on the crown gear (D) then bushing holder (N) (Figure 41).
- Verify that block (P) is properly located in guide (R) and reposition lower shaft into its mounting position (Figure 40).
- Position bracket (A) (Figure 39) and loosely install screws (G).



**FIGURE 40**

**5 INSTALLING HOOK BUSHING**

Install shuttle hook bushing (L) (Figure 41) into bushing holder (N). Bushing should be positioned so that its beveled end (S) enters the top of the bushing holder and protrudes from the bottom of the holder, and its flat side (T) is facing crown gear (D) (Figure 41). Only the beveled end (S) of the bushing should protrude below the holder. Tighten screw (I).




**FIGURE 41**

340 1901100  
**2C 27 REPLACING THE SHUTTLE HOOK AND RELATED GEARS**


**6 INSTALLING THE SHUTTLE HOOK**

- Verify that the take up lever is still in its lowest position. Lift and push backward on the feed dogs (H) (Figure 42). Slip shuttle hook into its bushing and apply pinion gear (E) to the end of shuttle hook shaft. Press pinion gear and shuttle hook firmly together as shown in Figure 43. Be sure that one of the two screws (F) is located over the flat side of the shuttle hook shaft. Keeping firm pressure with your fingers on the shuttle hook and pinion gear, tighten screws (F) securely.



**FIGURE 42**

- Turn shuttle hook by hand to be sure that it turns freely and does not have any vertical play. Tighten screws (G) (Figure 43).
- Turn machine 'on'. While machine is running lightly and repeatedly hit machine lower shaft with screwdriver handle to help self-aligning bushings adjust themselves.
- Switch machine off. Check that the shuttle hook angle is set correctly. Check shuttle hook axial positioning. Check needle timing to shuttle hook. Refer to Section 2C 2.
- Install bobbin case stop. Refer to Section 2C 2 3.
- Install needle plate and needle.



**FIGURE 43**



340.1991100  
2C.3 FEED MECHANISM

2C.3.1 NEEDLE TIMING TO FEED

1 CHECKING NEEDLE TIMING TO FEED

- Needle timing to feed is correct when, after having moved the needle bar to its lowest position, you can verify both of the following conditions:
- FIRST CONDITION—The tip (A) impressed on toothed wheel (B) (Figure 44) pegged to machine lower shaft (D) must be facing support (C) which protrudes from mainframe.
- SECOND CONDITION—The protruding eccentric portion of feed eccentric (E) must be oriented in the same direction as tip (A). (They must be oriented opposite of operator.) (Figure 44)

2 ADJUSTING NEEDLE TIMING TO FEED

- If the first of these two conditions cannot be verified, it means that the cinematic mechanism linking the needle bar to the lower shaft motions is out of timing. This may have happened if the cogged belt connecting upper and lower shafts and/or cogged belt connecting upper shaft and needle bar unit had been removed and improperly installed (for belt to pulley timing refer to Section 2C.4.4).
- If the second condition cannot be verified, it means that feed eccentric (E) (Figure 44) was removed from lower shaft (D) and later installed with the wrong orientation (that is, turned 180 degrees). To properly reposition feed eccentric, loosen screw (F) slightly, rotate feed eccentric 180 degrees and tighten screw (F) securely.

NOTE: Be sure to recheck both conditions expressed in paragraph 1.




FIGURE 44

340.1991100  
2C.3.2 FEED DOGS CENTERING AND HEIGHT

1 CHECKING FEED DOGS CENTERING

- Feed dogs are correctly positioned when the clearance between the edges of needle plate windows and the feed dogs is at least .002 inch (.05 mm).
- To check clearance, remove needle and presser foot.
- Turn handwheel by hand to bring feed dogs to their highest position above the needle plate.
- Check to see that the .002 inch (.05 mm) blade of the feeler gauge can be inserted between each side of feed dogs and the facing needle plate edge (Figure 45).

2 ADJUSTING FEED DOGS CENTERING

Loosen both screws (A) slightly and adjust position of feed shaft pins (B) together with feed holder (C). Be sure not to leave any play between feed holder and feed shaft pins. Tighten screws (A) securely after adjustment.

3 CHECKING FEED DOG HEIGHT

- With feed dogs raised to the highest position, the tips of feed dog teeth should be .036 inch (.9 mm) above needle plate level.
- Switch machine 'on' and program it for straight stitching at maximum stitch length.




FIGURE 45

340.1991100  
2C.32 FEED DOGS CENTERING AND HEIGHT

- Place gauge No. 68931 across feed dog opening as shown in Figure 46a with red mark right above feed dog teeth (Figure 46a). Manually rotate handwheel toward you. The feed dog teeth should lift the gauge.
- Slide gauge so that red mark is beyond feed dog teeth (Figure 46b). Turn handwheel again. The teeth should not lift the gauge.

4 ADJUSTING FEED DOG HEIGHT

- Loosen screw (A) slightly (Figure 46) and adjust eccentric pivot (B) located in the feed lifting lever. When test described in preceding paragraph 3 can be successfully performed, tighten screw (A) securely.
- Repeat test again. Turn machine off and install presser foot and needle.




FIGURE 46a

FIGURE 46b




FIGURE 46

340.1991100  
2C.33 ZERO FEED POSITIONING: STITCH LENGTH

Zero feed positioning is properly set when the feeding mechanism causes a lifting motion only without any feeding at all. For the correct zero feed positioning both mechanical and electrical zero positions must be properly set.

1. CHECKING MECHANICAL ZERO POSITION

- Place one thickness of fabric (with a series of parallel lines drawn) under the presser foot (Figure 47).





FIGURE 47

340 1891100  
**2C.3.3 ZERO FEED POSITIONING, STITCH LENGTH**

- Attach gauge No. 68936 to feed actuator (Figure 48)
- Manually rotate handwheel several turns and watch the lines drawn on the fabric. They should not move.

**2 ADJUSTING MECHANICAL ZERO POSITION**


- Attach gauge No. 68936 to feed actuator
- Loosen screw (A) slightly and rotate block sector guide (B) until zero feed is obtained (Figure 48). Tighten screw (A). Remove gauge from feed actuator.



**FIGURE 48**

340 1891100  
**2C.3.3 ZERO FEED POSITIONING, STITCH LENGTH**

- Loosen screws (C) and (F) slightly from retaining rings (D) and (G) (Figure 49)
- Move the actuator lever (X) toward top of machine. Insert a cardboard shim .020-.032 inch (.5-8 mm) into opening in actuator (Figure 49)
- Move actuator lever (X) toward bottom of machine until actuator coil rests against shim. Place .004 inch feeler gauge blade between block sector (M) and lever (N). Move shaft (I) right or left until the correct clearance exists between block sector (M) and lever (N)
- With actuator coil held snugly against cardboard shim, rotate retaining ring (D) until its stop stud (E) touches rib on machine frame
- Push retaining ring (D) against bushing (O) and tighten screw (C) securely. Recheck .004 inch clearance block sector (M) and lever (N)
- Move cardboard shim to opposite end of opening and move actuator lever (X) until coil rests against shim
- Position retaining ring (G) so that stop stud (H) touches rib on machine frame and is tight against bushing (P). Tighten screw (F) securely. Recheck .004 inch clearance between lever (N) and block sector (M)
- Recheck actuator coil clearance. Place cardboard shim in the actuator openings and move actuator lever (X). The limit studs (E) and (H) should limit the actuator coil movement. Coil must not hit actuator housing. Check the movement of actuator lever (X) and verify that it can smoothly operate the feed mechanism.



**FIGURE 49**

340 1991100  
2C 33 ZERO FEED POSITIONING, STITCH LENGTH

3 CHECKING ELECTRICAL ZERO POSITION

- Place one thickness of fabric (with a series of parallel lines drawn) under the presser foot (Figure 47)
- Turn machine on Program machine for straight stitching with zero stitch length
- Set speed selector to low speed
- Run the machine watching the parallel lines drawn on the fabric. They should not move

4 ADJUSTING ELECTRICAL ZERO POSITION

- If electrical zero feed is incorrect (fabric moving) adjustment of potentiometer is required. Refer to Section 2C 4 5

5 CHECKING STITCH LENGTH

- Stitch must be of the same length as indicated on the keyboard display
- Check feed dog height. Refer to Section 2C 3 2
- Install size 14 needle
- Set presser foot control knob to position 3
- Thread machine with cotton wrapped polyester thread
- Check and if necessary adjust upper and lower tensions
- Place two layers of fabric under the presser foot
- Turn machine on Enter straight stitching program
- Set stitch length at 4.0 mm
- Set speed selector lever for low speed. Run machine
- Measure ten stitches in the middle of the seam: eleven holes (Figure 50). The measurement should be 1.44 - 1.60 inches (36.40 mm)

6 ADJUSTING STITCH LENGTH

If stitch length is not correct adjustment of potentiometer is required. Refer to Section 2C 4 5




FIGURE 50

340 1991100  
2C 34 REPAIRING FEED LIFTING LEVER (FEED DOG DROP)

- Check to see that feed lifting lever (A) holds firmly in position whenever it is engaged or disengaged (Figure 51)
- Check to see that spring (B) is being correctly installed into notch (C) and snaps into recess (D) whenever feed unit is disengaged
- Replace spring (B) if damaged or weak




FIGURE 51

340.1991100  
 2C.4 MISCELLANEOUS  
 2C.4.1 BOBBIN WINDER

1 CHECKING CORRECT THREAD WINDING

- Bobbin is properly wound when the thread fills the bobbin evenly
- A properly filled bobbin will have a cylindrical shape (even) and stop winding when the thread is approximately .080 inch (2 mm) inside the outer diameter of the bobbin disc

2 ADJUSTING BOBBIN WINDING AND FILL

- If bobbin does not wind evenly, loosen screw (B) slightly and adjust tension unit (A) upward or downward as necessary (Figure 52). Tighten screw (B) securely
- If bobbin fill is incorrect, loosen screw (D) slightly and adjust position of eccentric (C) with slight partial rotation. Tighten screw (D) securely




FIGURE 52

340.1991100  
 2C.4 MISCELLANEOUS  
 2C.4.1 BOBBIN WINDER

3 CHECKING BOBBIN WINDER AND WINDER CLUTCH

- When winder is engaged, motor will drive only the winder. The rest of machine will remain inoperative
- When bobbin winder lever is in the disengaged position, motor motion is transmitted only to machine sewing parts. Bobbin winder will not operate
- Be sure the winder shank rotates smoothly and does not jump or bounce
- If winder does not operate smoothly, check the condition of rubber friction ring (F) (Figure 52). Remove screw (D) and stopping knob (C) (Figure 52). Lift off bobbin winder cover plate (L). Bobbin winder ring is now accessible. Refer to paragraph 4 below if bobbin winder assembly requires repair
- If winder does not engage or disengage properly as described above, check condition of connecting spring (E) located in the clutch unit (Figure 56). To check the spring, it is necessary to remove machine upper shaft and clutch unit

4. REMOVING MACHINE UPPER SHAFT WITH BOBBIN WINDER ASSEMBLY

- Loosen motor mounting screws (A) slightly (Figure 53). Raise motor (B) and remove drive belt (C)
- Loosen screws (D) slightly to reduce tension on timing belt (F)




FIGURE 53

340.1991100  
2C.4 MISCELLANEOUS

2C.4.1 BOBBIN WINDER AND CLUTCH

- Working on left side of machine (Figure 54) remove screws (A) and remove upper shaft support (B). Slip timing belt (C) off its upper shaft toothed pulley.




FIGURE 54

- Working on the right side of machine (Figure 55) remove screws (A) to remove support (C) from mainframe. Slip timing belt off lower shaft toothed pulley and pull out upper shaft (B) complete with bobbin winder clutch and coiled belt.

5 REMOVING MACHINE CLUTCH UNIT

- Loosen screws (E) slightly (Figure 55) and slide retaining ring (D) and support (C) away from clutch unit.




FIGURE 55

340.1991100  
2C.4 MISCELLANEOUS

2C.4.1 BOBBIN WINDER AND CLUTCH

- Remove the four screws (A) (Figure 56). Slide the flange (B), the toothed ring (C) and spring (E) along the main shaft away from pulley (G).




FIGURE 56

- Check the condition of spring (E) and its hooked end (F). Replace if needed. To replace spring, remove E clip (L) (Figure 57). Slip off toothed pulley (H) and remove spring (E) by slipping it around pulley (G).

6 RE-ASSEMBLING MACHINE CLUTCH UNIT

- Ensure hook (F) and spring (E) are installed as shown in Figure 56.
- Reinstall toothed pulley (H) and E clip (L) (Figure 57).




FIGURE 57

340.1991100  
2C.4 MISCELLANEOUS

2C.4.1 BOBBIN WINDER AND CLUTCH

- To reinstall spring (E) (Figure 58) wrap some of its coils around pulley (G) so that a screwdriver blade will guide all spring coils around toothed wheel (H) inner sleeve




FIGURE 58

- Install toothed ring (C) (Figure 56) and rotate it until spring hook end (F) enters slot (D). Install flange (B) and tighten the four screws (A) securely.
- Slide support (C) (Figure 55) against toothed pulley and position retaining ring (D) against bushing in support (C). Tighten screws (E) securely. Be sure that support (C) has no side to side movement.

7 INSTALLING MACHINE UPPER SHAFT

- To reinstall upper shaft reverse the disassembly procedure. Be sure that timing belt (F) is located above stud (G) (Figure 53).
- Before tightening screws (A) securely (Figure 55) make sure that the right side support (C) of upper shaft is positioned so that the bobbin winder shaft (G) is correctly located in the corresponding slot of the bobbin winder cover plate.
- After installing timing belt needle timing to feed must be checked. For needle timing to feed and proper tension of belts (F) and (C) (Figure 53) refer to Section 2C.4.4.
- Switch machine on and let it run for a while to allow the self-adjusting bushing to set into proper position. Operation may be accelerated by repeatedly knocking (lightly) the upper mainshaft with an aluminum or brass bar. To do so remove accessory tray (E) by loosening screws (F) (Figure 52). Upper shaft may then be reached through a shroud hole.

340.1991100  
2C.4.2 BUTTONHOLE FOOT

1 CHECKING THE BUTTONHOLE FOOT

- Check foot before installing it on the machine. Be sure that sole (A) slides smoothly along its guide and lever (B) swings without any jump (Figure 59).
- Be sure that springs have the right tension to reposition both sole (A) and lever (B) properly.
- If buttonhole foot does not function as described above it should be replaced.




FIGURE 59

- Install buttonhole foot and make sure that sole slant allows lever (B) to be properly positioned in front of lever (E) (Figure 60).




FIGURE 60

340.1991180  
2C.4.2 BUTTONHOLE FOOT

- When the sole (A) is moved so that lever (B) is between slants (C) and (D) (Figure 59) lever (B) should not be putting any pressure on lever (E) which allows the commutator bar (G) to move away from commutator bar (H) (Figure 61).
- There must be a .020 inch (5 mm) clearance between lever (B) and lever (E). Use feeler gauge to check clearance.

2 ADJUSTING BUTTONHOLE FOOT

- If buttonhole foot does not function as described above it should be replaced.
- If the clearances described above are not met, loosen screw (F) and adjust lever (E) (Figure 61). Tighten screw (F) and recheck.




FIGURE 61

340.1991180  
2C.4.3 HEIGHT AND ANGULAR POSITION OF  
PRESSER FOOT

1 CHECKING PRESSER FOOT HEIGHT

- When presser foot is raised, clearance between its sole and needle plate should be 0.3 inch (7.5 mm).
- To check above requirement, disengage feed dog.
- Manually rotate handwheel toward you to raise needle bar to its highest position.
- Raise presser foot using lever (A) (Figure 63) and remove needle and presser foot.
- Attach gauge No. 68934 to needle bar (Figure 62).
- If clearance is correct, it should be possible to insert only the lowest of the four steps of gauge No. 68931 between the sole of gauge No. 68934 and the needle plate.

2. ADJUSTING PRESSER FOOT HEIGHT

- If clearance is too low, raise presser foot further by pushing down more on presser foot lever (A). Place gauges as illustrated in Figure 62.
- Loosen screw (D) slightly and slide the presser bar guide (C) up or down until it touches cam (B) (Figure 62). Be careful not to allow the presser bar to rotate. Tighten screw (D) securely.
- Recheck presser foot height, then remove gauges.




FIGURE 62



340.1991180  
2C.4.3 HEIGHT AND ANGULAR POSITION OF  
PRESSER FOOT

3 PRESSER FOOT ANGULAR POSITION

- Presser foot angular position is correct when the sole of presser foot is perfectly aligned with feed dog openings in the needle plate
- To check disengage (drop) the feed dogs Attach gauge No. 68934 to presser foot bar. Lower bar and visually check alignment of gauge sides with feed dog openings

4 ADJUSTING ANGULAR POSITION

- Loosen screw (D) slightly (Figure 63) and adjust orientation of presser foot bar until proper alignment is achieved. Be careful not to allow presser foot bar (C) to move vertically. Tighten screw (D) securely
- Remove gauge, install presser foot and needle. Engage feed dogs




FIGURE 63

340.1991180  
2C.4.4 REPLACING THE BELTS

1 COGGED DRIVE BELT

- Removing the cogged drive belt  
Loosen screws (A) and move motor and bracket (B) upward (Figure 64)  
Remove belt (C) first slipping it off the toothed motor wheel and then off the mainshaft toothed wheel
- Installing cogged drive belt  
Place belt (C) over mainshaft toothed wheel (Figure 64). Move motor and bracket (B) upward and place belt around motor toothed wheel. Lower motor bracket and tighten screws (A) securely




FIGURE 64

340.1991180  
2C.4.4 REPLACING THE BELTS

Check belt tension. Proper adjustment will allow the belt to be pushed inward for about .240 inch (6 mm) with light finger pressure (Figure 65). If tension is incorrect, loosen screws (A) and move motor unit (B) upward or downward.

**NOTE** When belts are too tight the machine gets stiff and bearings overheat. When belts are too loose machine gets noisy.




FIGURE 65

340.1991180  
2C.4.4 REPLACING THE BELTS

2 UPPER TO LOWER SHAFT TIMING BELT

● Removing upper to lower shaft timing belt

Remove drive belt (C) as explained in preceding paragraph. Loosen screws (D) and move tension pulley (E) upward (Figure 64).

Remove belt (F) from lower shaft toothed wheel.

Slip belt (F) (Figure 66) between upper shaft toothed wheel (G) and bobbin winder and remove it.

● Installing upper to lower shaft timing belt

Place belt (F) over upper shaft (G) toothed wheel. Slip belt between wheel and bobbin winder and make sure belt is positioned around toothed wheel (H) of upper shaft (Figure 66).




FIGURE 66

340.1991100  
2C.4.4 REPLACING THE BELTS

In order to keep the correct needle timing to feed upper to lower shaft timing belt must be properly positioned

Rotate handwheel manually to bring needle bar to its lowest position. Attach gauge No. 68932 to needle bar tight against needle bar support. Manually rotate toothed wheel (A) until its tip (B) is facing that part of mainframe indicated by (C) in Figure 67. Hold toothed wheel stationary while placing belt (F) around it. Make sure that belt (F) is placed above stud (G) and then put tension on belt through tension pulley (E) and tighten screws (D).




FIGURE 67

340.1991100  
2C.4.4 REPLACING THE BELTS

Check belt tension. A light finger pressure (Figure 68) should push belt 1/60 inch (4 mm) upward. If necessary, adjust position of tension pulley (E). Tighten screws (D) securely.

Check once more to see that tip (B) is still facing (C) (Figure 67). If it is not, repeat operation. Loosen screws (D), release belt tension, remove belt (F) from wheel (A), and carefully follow instructions in the two preceding paragraphs. When completed, remove gauge from needle bar.

**NOTE:** When belts are too tight, machine gets stiff and bearings overheat. When belts are too loose, machine gets noisy.




FIGURE 68

340.1991180  
2C.4.4 REPLACING THE BELTS

3 UPPER-SHAFT-TO-COUNTERWEIGHT TIMING BELT

● Removing belt

Remove needle bar support Refer to Section 2C.2.6

Remove screw (B) and remove lampholder unit (A) (Figure 69)

Disconnect wiring connectors (D) and (E)

Remove screws (C) and remove needle bar actuator




FIGURE 69

Remove screw (B) (Figure 70) and remove buttonholer contact unit (A)

Raise presser foot Rotate pressure control knob to zero position Loosen screw (C) and remove support (D) by pushing its lower portion to the left and then up Remove rod (E)




FIGURE 70

340.1991180  
2C.4.4 REPLACING THE BELTS

Insert screwdriver blade into slot in connecting rod (A) (Figure 71) Slightly rotate screwdriver to open up the connecting rod bushing Slip rod (A) and takeup lever off of the shafts




FIGURE 71

Loosen screws (L) (Figure 72) and remove upper shaft support (M) Slip cogged belt (N) off of the upper shaft toothed wheel

Rotate counterweight (R) so that the belt can slip off between the counterweight and the tension discs lever (S)




FIGURE 72

340.1991100  
2C.4.4 REPLACING THE BELTS

● Installing belt

Install belt and replace support (M) and screws (L). Adjust and check the belt tension. Correctly set, the belt may be pushed down about .120 inch (3 mm) with slight finger pressure (Figure 73). If belt tension is not correct, loosen screws (L) slightly and adjust support (M). Then tighten screws (L) securely.




FIGURE 73

340.1991100  
2C.4.4 REPLACING THE BELTS

Reassemble by following disassembly procedure in reverse. Be sure that connecting rod (A) (Figure 71) is properly positioned on its pivot (C). Connecting rod (A) should snap into place. When installing the lampholder (A) (Figure 69) be sure that the small fork (F) clips over the mainframe.

Loosen screws (D) (Figure 67) slightly. Lift tension pulley (E) and remove belt (F) from toothed wheel (A). Reset needle timing to feed as explained below.

Rotate handwheel manually to bring needle bar to its lowest position. Attach gauge No. 68932 to needle bar tight against needle bar support. Manually rotate toothed wheel (A) until its tip (B) is facing that part of mainframe indicated by (C) in Figure 67. Hold toothed wheel stationary while placing belt (F) around it. Make sure that belt (F) is placed above stud (G) and then adjust tension on belt through tension pulley (E) and tighten screws (D).

Check belt tension. A light finger pressure (Figure 68) should push belt .160 inch (4 mm) upward. If necessary, adjust position of tension pulley (E). Tighten screws (D) securely.

Check needle position at straight stitching. Refer to Section 2C.2.4.

Turn machine "on" and let it run to allow self-adjusting bushings to assume proper position. With light, aluminum or brass bar, knock against upper shaft to speed up bushings' self-adjustment. To do so, loosen screws (F) and remove accessory tray (E) (Figure 74). Insert bar in small mainframe opening.

**NOTE** When belts are too tight, machine gets stiff and bearings overheat. When belts are too loose, machine gets noisy.





FIGURE 74

340.1901100  
**2C.4.6 ADJUSTING THE POTENTIOMETERS (POTS)**

**1 ADJUSTING MOTOR TOP SPEED**

- **WARNING** Whenever making adjustments on pots, use insulated screwdrivers only, to avoid short-circuiting machine
- Machine top speed should reach 950/1000 r.p.m.s with speed selector set at maximum speed position and foot control pressed all the way down
- Apply a speed indicator (tachometer) to handwheel and check top speed. Make necessary adjustments on pot (B) (Figure 75) which is located on motor control board (A)



**FIGURE 75**

340.1901100  
**2C.4.6 ADJUSTING THE POTENTIOMETERS (POTS)**

**2 ADJUSTING NEEDLE POSITION IN STRAIGHT STITCHING**

- To set mechanical zero position refer to Section 2C.2.4
- To set electrical zero position adjust pot (B) (Figure 76) located on closed loop control board (A)

**3 ADJUSTING ZIGZAG WIDTH**

- After performing mechanical adjustments as described in Section 2C.2.5 adjust pot (C) (Figure 76) located on closed loop control board (A)
- After adjusting pot controlling zigzag width, check needle position in straight stitching which could have been accidentally upset while adjusting zigzag width. If this is the case adjust both pots (B) and (C) (Figure 76) alternately until you succeed by trial and error


**4. ADJUSTING ELECTRIC ZERO FEED POSITION**

- After performing checks and adjustments of the mechanical zero feed (Section 2C.3.3) proceed with adjustment of the electrical zero position
- Adjust pot (D) (Figure 76) located on closed loop control board (A)

**5. ADJUSTING STITCH LENGTH**

- Perform checks and mechanical adjustments as indicated in Section 2C.3.3
- Adjust pot (E) (Figure 76) located on closed loop control board (A)
- After adjustments of stitch length pot, check electrical zero feed positioning which could have been accidentally upset. If necessary, readjust pot (D) (Figure 76)
- In order to check results of adjustments on stitch length enter program 26 into machine (little star pattern). Stitch at medium speed. Take a close look at some of the star patterns particularly the alignment of stitches coming out from the center. They should be at a 45° angle
- A line of ten star patterns should be 3.644 inches long. If you do not obtain the correct total length adjust stitch length pot (E) (Figure 76)
- Another visual check for correct stitch length may be obtained by programming and stitching patterns 21, 22, 71, 72

**WARNING:** Pots (M) and (N) settings are factory adjusted. Their adjustments should never be modified



**FIGURE 76**

340.1901100  
2C 4.6 MOTOR UNIT

**WARNING:** Unplug machine from wall socket any time you work on motor unit and motor control board

**1 REMOVING MOTOR FROM MACHINE**

- Disconnect motor (D) (Figure 77) and interruptor (C) connectors from motor control board (A)
- Unplug ground connector (E) from motor
- Remove screws (F) and (G) Remove drive belt and then remove motor from motor bracket (H)




FIGURE 77

340.1901100  
2C 4.6 MOTOR UNIT

**2 REPLACING MOTOR BRUSHES AND SPRINGS**

- Loosen caps (A) (Figure 78) Remove brushes (C) and replace them
- Install caps (A) making sure that terminals (F) and (G) are positioned between brush spring (B) and cap
- **NOTE** Motor should be replaced whenever one or more commutator bars (D) show corrosion because of excessive arcing from brushes

**3 INSTALLING MOTOR ON MACHINE**

To install reverse procedure in paragraph 1. Verify that belt has proper tension. Refer to Section 2C 4.4




FIGURE 78

340.1991100  
2C47 POSITIONING OF CONNECTORS

1 CLOSE LOOP CONTROL BOARD (Figure 79)

- A from secondary winding of transformer
- B from logic board
- C to motor control board
- D to feed actuator
- E to needle bar actuator
- F protective fuses




FIGURE 79

2 SYNCHRONISM BOARD (Figure 80)

- A from buttonhole sensors
- B to logic board




FIGURE 80

340.1991100  
2C47 POSITIONING OF CONNECTORS

3 LOGIC BOARD (Figure 81)

- A from synchronism board
- B to close loop board




FIGURE 81

4 MOTOR CONTROL BOARD (Figure 82)

- B from foot pedal
- C from closed loop board
- D to the motor
- E to transformer primary winding
- F from mains through main switch




FIGURE 82



340 1991100  
2C 4 7 POSITIONING OF CONNECTORS

5 OUT-OF-BOARD CONNECTORS

- A (Figure 83) to needle bar actuator coil (L)
- B (Figure 83) from needle bar actuator pot (L)




FIGURE 83

- C (Figure 84) from feed actuator pot (M)
- G (Figure 82) to the machine bulbs




FIGURE 84

THIS PAGE  
INTENTIONALLY LEFT  
BLANK

SECTION 3.

ELECTRONIC CIRCUIT SERVICE

EXACT DIAGNOSIS OF ANY SOURCE OF TROUBLES MUST REPRESENT THE FIRST TARGET FOR THE SERVICE TECHNICIAN; FOR THIS REASON WE HAVE WRITTEN A SPECIAL SECTION OF "CHECK POINTS" (SEE FOLLOWING PARAGRAPH 3A).

WE WOULD SUGGEST YOU USE THE "CHECK POINTS" SECTION NOT ONLY FOR DIAGNOSIS PURPOSES, BUT ALSO TO CHECK CONDITIONS OF MACHINE, BEFORE DELIVERING IT BACK TO CUSTOMER.

RECOMMENDED EQUIPMENT FOR ELECTRONIC CIRCUIT REPAIRS:

VOLT- OHM-METER - DIGITAL

- SOLDERING IRON (PERCU)
- CIRCUIT BOARD FOIL CUTTER.

SPECIAL NOTE:

ELECTRONIC BOARD REPAIR IS NOT RECOMMENDED AT THE LOCAL SERVICE DEPARTMENT LEVEL.

THE FOLLOWING ELECTRIC SERVICE INFORMATION SHOULD ONLY BE USED FOR ISOLATING A DEFECTIVE BOARD OR DIAGNOSING AND REPAIRING NON BOARD MALFUNCTIONS.

MAINFUNCTIONING BOARDS SHOULD BE REPLACED AND RETURNED TO SPECIALTY REPAIR CENTER IN MUPPOSE PARK IL. SEE CODE "10" ON ULTRAFICHE.

NOTE: ELECTRONIC BOARD REPAIRS NOT RECOMMENDED IN THE FIELD. SEE SPECIAL NOTE CONTAINED ON 1ST PAGE OF SECTION 3.

3.A CHECK POINTS.

VERIFY THAT AS SOON AS MAIN SWITCH IS TURNED ON, BOTH SEWING LIGHT BULBS UNDERNATH MACHINE ARM AS WELL AS THE LED ABOVE POWER-ON CONTROL KEY LIGHT UP; ACTUATORS COILS SHOULD ACTIVATE TO THEIR CENTRAL POSITION; FOOT CONTROL, EVEN IF PRESSED, MUST REMAIN INOPERATIVE UNTIL A STITCHING PROGRAM IS ENTERED.

DO POWER-ON LED AND SEWING LIGHT BULBS REMAIN OFF?  
NO YES  
REFER TO SECT. 3 B.1

ARE ONE OR BOTH SWING BULBS OFF?  
NO YES  
REFER TO SECT. 3 B.6

DO YOU HEAR NOISY VIBRATION FROM THE ACTUATORS COILS?  
NO YES  
REFER TO SECT. 3 B.7

IS NEEDLE BAR POSITIONED AT ONE EXTREME OF ITS SWING?  
NO YES  
REFER TO SECT. 3 B.10

IS FEED ACTUATOR COIL POSITIONED EITHER ALL THE WAY TO THE RIGHT OR LEFT OF ITS OSCILLATION FIELD?  
NO YES  
REFER TO SECT. 3 B.9

IS MACHINE RUNNING EVEN WHEN FOOT CONTROL IS NOT BEING PRESSED?  
OR DOES MACHINE RUN EVEN WHEN NO STITCHING PROGRAM WAS ENTERED?  
NO YES  
REFER TO SECT. 3 B.11

ENTER ANY STITCH PATTERN: DO CORRESPONDING LED'S AND DISPLAY LIGHT UP?  
YES NO  
REFER TO SECT. 3 B.2

ENTER STRAIGHT STITCHING, THEN ZIGZAG STITCHING. DO BOTH LED'S LIGHT UP CORRECTLY?  
YES NO  
REFER TO SECT. 3 B.3

ENTER ANY STITCH PATTERN: DOES MACHINE START SINGING, WITHOUT FOOT CONTROL BEING PRESSED?  
NO YES  
REFER TO SECT. 3 B.11

WHEN PRESSING FOOT CONTROL DOES MOTOR RUN?  
YES NO  
REFER TO SECT. 3 B.5

NOTE: ELECTRONIC BOARD REPAIRS NOT RECOMMENDED IN THE FIELD. SEE SPECIAL NOTE CONTAINED ON 1ST PAGE OF SECTION 3.

DOES MOTOR RUN AT IRREGULAR SPEED?

NO YES  
REFER TO SECT. 3 B.5

SWITCH SPEED SELECTOR, DOES MOTOR PROMPTLY REACT?

YES NO  
REFER TO SECT. 3 B.5

ENTER ZIGZAG STITCHING; SEW SOME STITCHES ON FABRIC. DO YOU SPOT SUDDEN CHANGES IN STITCH LENGTH OR WIDTH?

NO YES  
REFER TO SECT. 3 B.8

ENTER PROGRAM 26 (LITTLE STARS) AND STITCH A FEW PATTERNS ON FABRIC: ARE THEY PROPERLY STITCHED?

YES NO

IF YOU SUSPECT FAULTY ADJUSTMENTS CONCERNING CENTRAL POSITIONING OF ACTUATORS COILS OF THE GAIN IN THE ACTUATORS, ADJUST THEIR POTENTIOMETERS: P201 FOR THE ZERO POSITIONING OF NEEDLE BAR ACTUATOR; P202 FOR ZERO POSITIONING OF FEED ACTUATOR; P203 FOR THE GAIN ADJUSTMENT IN NEEDLE BAR ACTUATOR; P204 FOR THE GAIN ADJUSTMENT OF FEED ACTUATOR. IF PROBLEMS CONCERNING COIL POSITIONING OF ACTUATORS REMAINS, REFER TO SECT. 3 B.4.

KEEP PROGRAM 26 OPERATIVE, PUT SET BOTH STITCH LENGTH AND WIDTH AT MAX. VALUES (6 MM. AND 8 MM.).

DO YOU HEAR EITHER OR BOTH ACTUATORS BANGING?

NO YES  
REFER TO SECT. 3 B.4

ENTER BUTTONHOLING PROGRAM NUMBER 4; INSTALL BUTTON-HOLER FOOT AND SEW. IS BUTTONHOLE PROPERLY SEWN?

YES NO  
REFER TO SECT. 3 B.13

ENTER PROGRAM 71 AND 72 FOR ALTERNATING STITCHING (71+72); SEW, AND CHECK WHETHER BALANCE CONTROL KEY "B" OF KEYBOARD WORKS PROPERLY. IS EVERYTHING ALL RIGHT?

YES NO  
REFER TO SECT. 3 B.4

ENTER PROGRAM NUMBER 40, AND CHANGE PATTERN LENGTH.

IS PATTERN ELONGATION BEING ACCEPTED BY KEYBOARD, AND CORRECTLY SEWN BY MACHINE?

YES NO  
THE MACHINE IS OK.  
REFER TO SECT. 3B.4

FOR PROBLEMS AFFECTING FOOT CONTROL, REFER TO SECT. 3B.12.

NOTE: ELECTRONIC BOARD REPAIRS NOT RECOMMENDED IN THE FIELD. SEE SPECIAL NOTE CONTAINED ON 1ST PAGE OF SECTION 3.

TABLE OF CONTENTS

SEE SECTION

- MACHINE REMAINS TOTALLY "OFF" (POWER-ON LED AND SEWING MOTOR ARE DEAD) 3 B.1
- MACHINE IS INOPERATIVE (FEED DOES NOT RESPOND, LED'S AND DISPLAY REMAIN OFF) 3 B.2
- ONLY CERTAIN STITCH PATTERNS BEING SEWN 3 B.3
- STITCHES AND STITCH PATTERNS POORLY SEWN 3 B.4
- SPEED PROBLEMS OF ELECTRICAL MOTOR 3 B.5
- MACHINE OPERATES, BUT ONE OR BOTH LURBS REMAIN DEAD 3 B.6
- NOISY VIBRATIONS FROM NEEDLE BAR OF FEED UNIT, WHEN THEY ARE AROUND THEIR CENTRAL POSITIONS 3 B.7
- SUDDEN CHANGES IN STITCH LENGTH OR WIDTH WHEN ZIGZAG SEWING OR SEWING VARIOUS PATTERNS 3 B.8
- FEED UNIT GOES IN ONE DIRECTION AND WITH MAX. STITCH LENGTH, EVEN WHEN SELECTED PATTERN WOULD REQUIRE DIFFERENT FEEDING 3 B.9
- NEEDLE BAR IS POSITIONED ALL ON ONE SIDE OF THE SEWING 3 B.10
- MACHINE RUNS WITHOUT FOOT CONTROL BEING PRESSED 3 B.11
- FOOT CONTROL PROBLEMS 3 B.12
- IMPROPER BUTTONHOLES 3 B.13
- REQUIRED ADJUSTMENTS WHENEVER LOGIC BOARD OR CLOSED LOOP BOARD IS REPLACED 3 B.14


NOTE: ELECTRONIC BOARD REPAIRS NOT RECOMMENDED IN THE FIELD. SEE SPECIAL NOTE CONTAINED ON 1ST PAGE OF SECTION 3.

3 B.1 - MACHINE REMAINS TOTALLY "OFF" ("POWER ON" LED AND SEWING LIGHTS ARE DEAD).

PLUG-IN MACHINE AND TURN MAIN SWITCH "ON".

TOUCH STRAIGHT STITCH CONTROL KEY.

DOES LED OVER STRAIGHT STITCH KEY LIGHT?




NOTE: ELECTRONIC BOARD REPAIRS NOT RECOMMENDED IN THE FIELD. SEE SPECIAL NOTE CONTAINED ON 1ST PAGE OF SECTION 3.

3 B.2 - MACHINE IS INOPERATIVE: KEYBOARD DOES NOT RESPOND, LED'S NOT DISPLAY "MACHINE OFF".

BY SAYING KEYBOARD DOESN'T RESPOND, WE MEAN THAT EITHER THE KEYBOARD REMAINS DEAD OR LED'S LIGHT UP EVEN IF THEY DO NOT CORRESPOND TO THE CONTROL KEYS WHICH WERE PRESSED. IN THE LATTER CASE THE TROUBLE IS PROBABLY IN THE LOGIC BOARD; REFER TO SECT. 3 B.14 WHEN KEYBOARD REMAINS DEAD, CHECK FUSES ON CLOSED LOOP CONTROL BOARD. SEE WIRING DIAGRAM - SECTION 4

ARE THE FUSES OPEN?



NOTE: ELECTRONIC BOARD REPAIRS NOT RECOMMENDED IN THE FIELD. SEE SPECIAL NOTE CONTAINED ON 1ST PAGE OF SECTION 3.

3 B.3 - MACHINE IS ONLY STITCHING CERTAIN PATTERNS.

MACHINE CAN CORRECTLY STITCH ZIGZAG AND ALL PATTERNS HAVING A CODE NUMBER UP TO 65; STRAIGHT STITCHING AND CODE NUMBERED PATTERNS ABOVE 65 CAUSE MACHINE TO BECOME INOPERATIVE. THIS MALFUNCTION INDICATES FAULTY DATA COMMUNICATIONS BETWEEN THE TWO MICROPROCESSORS: REPLACE IN THE LOGIC BOARD - REFER TO SECT. 3 B.14

NOTE: ELECTRONIC BOARD REPAIRS NOT RECOMMENDED IN THE FIELD. SEE SPECIAL NOTE CONTAINED ON 1ST PAGE OF SECTION 3.


3 B.4 - SEAMS AND STITCH PATTERNS POORLY SEWN.

ANY STITCH PATTERN CAN BE ENTERED, AND SELECTION IS PROPERLY CONFIRMED ON THE DISPLAY - BUT THE STITCHED PATTERNS ARE IRREGULARLY SEWN, OR DIFFERENT FROM WHAT THEY SHOULD BE.

TURN MACHINE ON, AND MANUALLY MOVE NEEDLE BAR ALL THE WAY TO THE LEFT: CHECK TO SEE THAT OUTPUT FROM PIN 16 OF SP101 LOCATED ON THE LOGIC BOARD (SEE DIAGRAM SECT. 4) - IS ABOUT +2.5V.D.C. (USING A SCOPE OR DIGITAL VOLT METER)

MANUALLY MOVE NEEDLE BAR ALL THE WAY TO THE LEFT AND CHECK TO SEE THAT OUTPUT FROM PIN 16 OF SP101 IS NOW "0" VOLTS.

IS VOLTAGE ON SP101 PIN 16 CHANGING WITHIN ABOVE INDICATED VALUES?



NOTE: ELECTRONIC BOARD REPAIRS NOT RECOMMENDED IN THE FIELD. SEE SPECIAL NOTE CONTAINED ON 1ST PAGE OF SECTION 3.

SWITCH MACHINE ON AND MANUALLY MOVE FEED ACTUATOR COIL FROM END TO END: VOLTAGE READING AT PIN 16 OF SP101 SHOULD VARY BETWEEN +2.5 AND 0 V. USING A SCOPE OR DIGITAL VOLT METER.

IS VOLTAGE READING WITHIN ABOVE VALUES?

YES

NO  
SWITCH MACHINE OFF AND DISCONNECT SP205A FROM CLOSED LOOP CONTROL BOARD. TAKE READINGS WITH OHM-METER (R x 10) BETWEEN PIN 1 AND PIN 2 OF SP205A, WHILE MOVING FEED ACTUATOR COIL FROM END TO END. DO READINGS VARY BETWEEN 330  $\Omega$   $\pm$  20% AND 800  $\Omega$   $\pm$  20% ?

NO  
REPLACE CLOSED LOOP BOARD REFER TO SECT. 3 B.14

YES  
REPLACE LOGIC BOARD REFER TO SECT. 3 B.14.

CHECK ELECTRICAL CONTINUITY OF CONNECTIONS OF FEED ACTUATOR CONTROLLING POTENTIOMETER. IF YOU FIND BREAK IN THE CONNECTIONS, REPLACE ACTUATOR: REFER TO WIRING DIAGRAM - SECTION 4.

SWITCH MACHINE OFF AND DISCONNECT SP205A FROM CLOSED LOOP BOARD. TAKE READINGS OF RESISTANCE BETWEEN PIN 6 AND PIN 5 OF SP205A, WITH OHM-METER (R x 1).

IS RESISTANCE READING EQUAL TO 4?

YES  
REPLACE CLOSED LOOP BOARD.  
REFER TO SECT. 3 B.14.

NO  
CHECK CONNECTIONS OF FEED ACTUATOR COIL: IF NECESSARY, REPLACE ACTUATOR.

3 B.5 - SPEED PROBLEMS OF ELECTRICAL MOTOR.

3 B.5.A - MOTOR DOES NOT RUN. DISCONNECT SP315A AND CHECK MOTOR FOR OPEN CIRCUIT.

IS MOTOR OPEN?

YES  
REPLACE MOTOR

NO  
IS +5VDC AVAILABLE ON PIN 2 OF SP317A?

YES  
REPLACE MOTOR CONTROL BOARD

NO  
IS +5VDC PRESENT ON PIN #2 OF SP317A?

YES  
LOCAL AND REPAIR BROKEN OR LOOSE CONNECTION

NO  
REPLACE CLOSED LOOP BOARD (REFER TO 3 B.14)

3 B.5.B - MOTOR RUNS AT TOP SPEED REGARDLESS OF ANY PRESSURE APPLIED TO FOOT CONTROL.

REPLACE MOTOR CONTROL BOARD.

3 B.5.C - MOTOR DOES NOT REACH TOP SPEED. WHILE OPERATING MACHINE, MOVE SPEED SWITCH FROM HIGH TO LOW POSITION.

DOES MOTOR SPEED CHANGE?

YES  
IS 11 VOLTS A.C. PRESENT ACROSS PINS 4 AND 5 OF SP314?

NO  
CHECK CONNECTIONS BETWEEN SWITCH AND MOTOR CONTROL BOARD.

YES  
REPLACE MOTOR CONTROL BOARD

NO  
REPLACE TRANSFORMER

3 B.5.D - MOTOR SPEED IS IRREGULAR.

CHECK FOOT CONTROL FOR INTERMITTANT CIRCUIT.

IS FOOT CONTROL O.K.?

YES  
REPLACE MOTOR CONTROL BOARD

NO  
REPLACE FOOT CONTROL

3 P.5.1 - MOTOR PULSES WHENEVER FOOT CONTROL IS DEPRESSSED (CUT THROUGH BY PROCEED) WAS ENTERED IN THE MACHINE.

IS A RICH LOGIC LEVEL OF +5 VOLTS (MEASURED WITH A SCOPE) PRESENT AT PIN #1 OF SP317?

<u>NO</u>	<u>YES</u>
REPLACE LOGIC BOARD (REFER TO SECTION 3 B.14)	REPLACE MOTOR CONTROL BOARD

3 P.6 - MACHINE WORKS PROPERLY - BUT ONE OF BOTH PULSES ARE NOT ON.

IF CASE ONE OF THE TWO PULSES (EVEN THOUGH REPLACED) DOES NOT LIGHT, CHECK THE ELECTRICAL CONNECTIONS AND THE LAMPHOOLDERS.

IN CASE BOTH PULSES (EVEN THOUGH REPLACED) ARE NOT LIGHTING, CHECK THE LAMP FUSE WHICH IS LOCATED ON THE TRANSFORMER.

IS THE FUSE OPEN?

<u>NO</u>	<u>YES</u>
DO YOU FIND ANY BREAK IN THE CONNECTOR BETWEEN TRANSFORMER AND BULBS?	REPLACE IT AND MAKE SURE LAMPHOLDER IS NOT SHORT-CIRCUITING.

<u>NO</u>	<u>YES</u>
REPLACE TRANSFORMER	REPAIR CONNECTOR.

3 B.7 - NEEDLE BAR AND FEED UNIT ARE NOISILY VIBRATING AROUND THEIR CENTRAL POSITION.  
REPLACE CLOSE LOOP BOARD REFER TO 3B.14

3 B.8 - SUDDEN VARIATION IN STITCH LENGTH OR WIDTH WHILE SEWING ZIGZAG OR SELECTED PATTERNS.

CLOSE LOOP CONTROL BOARD

FAULTY PERFORMANCE OF CLOSE LOOP BOARD CAUSES BOTH ACTUATORS TO REMAIN INOPERATIVE.  
TO LOCATE THE POSSIBLE TROUBLE FOLLOW THIS PROCEDURE:  
DO YOU READ A +5 VOLTS D.C. ON PINS OF SP410A?

<u>YES</u>	<u>NO</u>
TURN HANDWHEEL MANUALLY TO POSITION MAGNET (PLACED ON TIP OF ARM ON MACHINE LOWER SHAFT) MIDWAY BETWEEN THE TWO MAGNISTORS.	CHECK CONNECTIONS WITH LOGIC BOARD (REFER TO WIRING DIAGRAM SECTION 4)

CAN YOU READ +5 VOLTS D.C. ON PINS 6 AND 8 OF SP410A?

<u>YES</u>	<u>NO</u>
TURN HAND WHEEL, TO POSITION MAGNET TO FACE MAG401. DOES PIN8 OF SP410A SHOW ZERO VOLTS?	CHECK TO SEE THAT ELECTRONS TO R401 AND R402 CONNECTING PINS 3 OF MAG401 AND MAG402 TO +5 VOLTS ARE PROPERLY CONNECTED, AND NOT OPEN. IF NECESSARY, REPLACE FAULTY RESISTOR. THEN CHECK TO SEE THAT THE MAGNISTOR WHICH DOES NOT SHOW A +5 VOLTS IS NOT SHORTED BETWEEN PIN2 AND PIN3. REPLACE MAGNISTOR IF NECESSARY.

<u>YES</u>	<u>NO</u>
FURTHER ROTATE HANDWHEEL TO POSITION MAGNET TO FACE MAG402. DOES PIN6 OF SP410A SHOW ZERO VOLTS?	REPLACE MAG401

<u>YES</u>	<u>NO</u>
REPLACE LOGIC BOARD	REPLACE MAG402

3 B.9 - MACHINE IS FEEDING IN ONLY ONE DIRECTION AT MAXIMUM STITCH LENGTH, AND NOT PERFORMING DIFFERENT REQUIREMENTS OF THE SELECTED STITCH PATTERN.  
CHECK ACTUATOR - IF O.K. REPLACE CLOSED LOOP BOARD.  
(REFER TO SEC. 3 B.14)

3 B.10 - NEEDLE BAR REMAINS POSITIONED AT ONE END OF ITS TRIP.  
CHECK ACTUATOR - IF O.K. REPLACE CLOSED LOOP BOARD.  
(REFER TO SEC. 3 B.14)

3 B.11 - AS SOON AS A STITCH PATTERN IS ENTERED, MACHINE WILL RUN WITHOUT FOOT CONTROL BEING PRESSED.  
REPLACE MOTOR CONTROL BOARD.

3 B.12 - PROBLEMS RELATED TO FOOT CONTROL.  
CHECK FOOT CONTROL. IF FOOT CONTROL O.K.,  
REPLACE MOTOR CONTROL BOARD  
(REFER TO WIRING DIAGRAM SET 4)

3 B.13 - IMPROPER BUTTONHOLES.

THE MACHINE WILL SEW BUTTONHOLES IN THE FOLLOWING SEQUENCE:  
(1) LEFT SIDE; (2) ACROSS TO RIGHT SIDE AND THEN REVERSE IN STRAIGHT STITCHING; (3) UPPER BAR TACK; (4) RIGHT SIDE; (5) LOWER BAR TACK.

SIGNALS TO START THE ELECTRONIC SYSTEM TO DIRECT THE BUTTONHOLES SEQUENCE ORIGINATE FROM TWO CONTACT POINTS LOCATED CLOSE TO THE NEEDLE BAR ACTUATOR. THESE CONTACT POINTS ARE ACTIVATED BY THE MOVEMENT OF BUTTОННОLEER FOOT.

CHECK TO SEE THAT THERE IS ELECTRICAL CONTINUITY IN THE WIRES FROM THE CONTACT POINTS TO CONNECTOR SP411 OF SYNCHRONISM BOARD. RESTORE CONNECTIONS IF NECESSARY. CLEAN CONTACT POINTS: IF YOU MUST REPLACE THEM, REFER TO SECT. 2 C.4.2.

CHECK CONNECTIONS BETWEEN SP411A AND SP411 RESTORE CONNECTIONS, IF NECESSARY. IF CONNECTIONS ARE O.K., REPLACE LOGIC BOARD.  
(REFER TO SECTION 3B.14.)

3 B.14 - REQUIRED ADJUSTMENTS WHENEVER LOGIC BOARD OR CLOSED LOOP BOARD IS REPLACED.


NOTE: POTENTIOMETERS P205 AND P206 ("M" AND "N" ON FIGURE 76 IN SECTION 2C.4.5) ARE FACTORY ADJUSTED AND SHOULD NOT REQUIRE ADJUSTMENT UNLESS A LOGIC OR ANALOGIC (CLOSED LOOP BOARD) IS REPLACED.

- . ADJUSTMENT OF THESE TWO POTENTIOMETERS WHEN REQUIRED WILL PERMIT CORRECTLY MATCHING (INTERFACING) THE LOGIC AND ANALOGIC BOARD.
- . REMOVE FEED ACTUATOR FROM MACHINE IF ANOTHER ACTUATOR IS NOT AVAILABLE.
- . LAY ACTUATOR ON IT'S SIDE SO THAT THE INTERNAL COIL (ARMATURE) MOVES IN A HORIZONTAL PLANE. BE SURE LEAD WIRES DO NOT RESTRICT FREE MOVEMENT OF COIL.
- . PLUG ACTUATOR CONNECTOR INTO SOCKET SP205 (P) TO ADJUST POTENTIOMETER P206 (N) OR CONNECT TO SOCKET SP209 TO ADJUST POTENTIOMETER P205.
- . TURN MACHINE "ON".
- . TOUCH STRAIGHT STITCH KEY ON CONTROL BOARD.
- . WATCH ACTUATOR COIL. IT WILL MOVE TO A CENTRAL POSITION AND STOP.
- . CONTINUE TO WATCH COIL FOR 5 SECONDS.
- . IF COIL CHANGES POSITION WITHIN 5 SECONDS POTENTIOMETER IS NOT CORRECTLY ADJUSTED. CONTINUE TO MAKE SLIGHT ADJUSTMENTS UNTIL COIL NO LONGER MOVES AFTER STRAIGHT STITCH KEY IS TOUCHED.



SECTION 4 - WIRING DIAGRAMS  
 MODEL 340.1991180

MOTOR CONTROL BOARD



NOTE: CAUTION: SCOPE MUST NOT  
 BE GROUNDED TO A.C. LINE.  
 USE ISOLATION TRANSFORMER

SECTION 4 - WIRING DIAGRAMS  
MODEL 340.1991180

**CIRCUIT BOARDS AND RELATED CIRCUITS**  
**Motor Control Board**

**FUNCTIONS:**

- Filters 120 VAC line voltage to prevent spikes, etc., which could damage electronic components
- Controls motor speed by sensing pressure applied to foot control, and motor rpm's as sensed via pulses from the speed reader

**VOLTAGE AND COMPONENT CHECKS**

● **TRANSFORMER**

Primary—Plug SP314A pins 2 to 4—120VAC

Secondary outputs

Lamp circuit—12VAC

SP208A


Pins 1 to 2—22VAC

Pins 4 to 1—11VAC

Pins 4 to 2—11VAC

● **MOTOR**

SP315A—60 to 120VAC—varies with pressure on foot control and torque of machine



Sp316A

● **SPEED READER**

Component Check

SP316A—Pin 2 to 4 is an LED

Pin 4 output is a sine wave whose frequency varies with motor speed

● **SP317A INPUTS FROM ANALOGIC BOARD**

Pin 1—+5 VDC logic level (must measure with scope)

Pin 2—+5VDC


Pin 3—DC Gnd

Pin 4—from motor speed switch

**Keyboard**

**FUNCTIONS:**

- Instructions to the microcomputer are through the keyboard's switches
- LED's indicate that selection has been accepted by the microcomputer



SIDE

FRONT

**Keyboard Continuity Chart**

Example of use When is depressed, continuity should exist between pins 10 and 6 on the keyboard

	2	3	4	5	6	7	8	9
1								
10								

SECTION 4 - WIRING DIAGRAMS  
MODEL 340.1991180

LOGICAL BOARD

Logical Board

FUNCTIONS:


- Microcomputer
- Synchronizes feed and needle movement by sensing pulses from synchronism board

VOLTAGE INPUTS: All DC voltages to gnd.  
(Located On Closed Loop Board)


- SP101A
- Pin 2— -5VDC
  - Pin 4— +2.6VDC
  - Pin 5— +5VDC
  - Pin 7— +5VDC
  - Pin 9— +5VDC

- Synchronism Board SP410A
- Pin 5— +5VDC
  - Pin 6*— 0 or +5VDC
  - Pin 7— Gnd
  - Pin 8*— 0 or +5VDC

*When magnet is facing Mag 402, Pin 6 will be 0  
When magnet is facing Mag 401 Pin 8 will be 0



SECTION 4 - WIRING DIAGRAMS  
MODEL 340.1991180



**Analogic Board (closed loop control board)**

**FUNCTIONS:**

- DC power supply
- Amplifies output from logic board
- Controls movement of feed and needle bar actuators
- Monitors position of actuator levers via potentiometers built into actuators

**VOLTAGE INPUTS:**

SP208A  
Pins 1 to 2—22VAC  
Pins 4 to 1—11VAC  
Pins 4 to 2—11VAC

**VOLTAGE OUTPUTS: AN DC voltages to D.C. and (Located On Closed Loop Board)**

SP206  
Pin 2—-5VDC  
Pin 4—+2.6VDC  
Pin 5—+5VDC  
Pin 7—+5VDC  
Pin 9—+5VDC  
SP207—Pin 2—+5VDC  
SP205—Pin 3—+2.5 to 3VDC (measured with scope)  
SP209—Pin 3—+2.5 to 3VDC (measured with scope)

**ACTUATOR RESISTANCE CHECKS:**

Pins 5 to 6—4Ω  
Pins 1 to 2—330 to 860Ω ± 20%  
Pins 1 to 3—330 to 860Ω ± 20%

**THIS PAGE  
INTENTIONALLY LEFT  
BLANK**

**THIS PAGE  
INTENTIONALLY LEFT  
BLANK**

**THIS PAGE  
INTENTIONALLY LEFT  
BLANK**

**THIS PAGE  
INTENTIONALLY LEFT  
BLANK**