

## C

DE68-03843A

A diagram showing four horizontal arrows of decreasing length from left to right. Each arrow is labeled with its length: 1", 3/4", 1/2", and 3/8".


## Rear wall

**NOTE:**  
Install power supply cord  
bushing around hole  
drilled in metal cabinet.

**Cut out this area of upper cabinet bottom if venting through the roof.**

F

D

**9<sup>3</sup>/<sub>8</sub>"**  
**(238.2mm)**  
**to rear wall**  
**must be**  
**maintained**

# E

**9 3/8"**  
**(238.2mm)**  
**to rear wall**  
**must be**  
**maintained**

— 7<sup>1</sup>/<sub>16</sub>" —  
(179.5mm)  
— 6<sup>3</sup>/<sub>16</sub>" —  
(164.5mm)

— **6<sup>31/64"</sup>** —  
(164.5mm)

**12"**  
(304.5mm)

— 11<sup>13</sup>/<sub>32</sub>"  
(289.5mm)

**9<sup>3</sup>/<sub>8</sub>"**  
to rear wall  
must be  
maintained

6 1/4"

13"


**- 6 1/2**

**5 3/4"**

# B

3/8" 1/2" 3/4" 1"

5"



--	--