

**OPERATING INSTRUCTIONS
AND PARTS LIST FOR**

CRAFTSMAN BENCH SAW

8 INCH

MODEL NUMBER 103.21041

The model number of your Bench Saw will be found on a plate on the rear of the Base. Always mention this model number when communicating with us regarding your Bench Saw or when ordering parts.

HOW TO ORDER REPAIR PARTS

All parts listed herein may be ordered through SEARS, ROEBUCK AND CO. or SIMPSONS-SEARS LIMITED. When ordering parts by mail from the mail order house which serves the territory in which you live, selling prices will be furnished on request or parts will be shipped at prevailing prices and you will be billed accordingly.

WHEN ORDERING REPAIR PARTS, ALWAYS GIVE THE FOLLOWING INFORMATION AS SHOWN IN THIS LIST

1. THE PART NUMBER 3. THE MODEL NUMBER 103.21041
2. THE PART NAME 4. THE NAME OF ITEM BENCH SAW

**COAST TO COAST NATION-WIDE
SERVICE FROM SEARS
FOR YOUR CRAFTSMAN POWER TOOLS**



SEARS, ROEBUCK AND CO. and SIMPSONS-SEARS LIMITED in Canada back up your investment with quick, expert mechanical service and genuine CRAFTSMAN replacement parts.

If and when you need repairs or service, call on us to protect your investment in this fine piece of equipment.

**SEARS, ROEBUCK AND CO. — U.S.A.
IN CANADA, SIMPSONS-SEARS LIMITED**

**OPERATING INSTRUCTIONS AND PARTS LIST FOR
8 INCH BENCH SAW
MODEL 103.21041**




FIGURE 1

Careful planning, precision machining, and rigid inspection have all contributed toward maintaining the high standard of quality found in this tool. We are confident that you will find it satisfactory in every respect.

To increase the versatility of this saw beyond the normal range of bench saw operations, various attachments are readily available.

To prevent damage in shipment some of the parts were disassembled from the tool. These parts are listed below. Be sure they are all accounted for before discarding any of the packing material.

1. Fence; item 110.
2. Miter gauge assembly; item 118.
3. Motor rail bar; item 21.
4. Motor Mount; item 32.
5. Insert with clips; items 13, 14, 15 and 16.
6. Motor pulley; item 65.
7. V-belt; item 61.
8. Bag contains items 8, 9, 10, 11, 18, 19, 22, 23, 25, 26, 27, 28 and 34.
9. Fence Slide Bar; item 7.

ASSEMBLY:

Front Fence Bar

The front fence bar must be fastened to the front edge of the saw table with three (3) slotted head screws, No. 8, spacers, No. 9, lock washers, No. 10, and hex nuts, No. 11. See Fig. 2.

Before tightening the screws securely, the fence bar must be accurately adjusted to the 21/32 dimension over the entire length.

Motor Mount

Install as shown in Fig. 3 and outlined under "Installation of Saw".

Insert with clips,

Install in opening provided in table top. See Fig. 4.

INSTALLATION OF SAW

There are four 5/16 diameter holes, provided in the base of the saw through which the tool should be fastened securely with screws or bolts to a well built work bench. A large hole in the bench below the blade will allow sawdust to escape.

The Motor Mount Bracket should be installed as shown in Fig. 3.

1. Set the saw at 0 inches elevation and 0 degrees tilt. (See paragraph headed "Controls".)




FIGURE 2

- Fasten the motor rail bracket, No. 20, to the rear of the saw so it is flush with the bottom of the base. Use the two (2) slotted head machine screws, No. 26, lock washers, Nos. 19 and 27 and hex nuts, Nos. 18 and 28 provided.
- Turn the guide pin, No. 34, into the hole at rear of saw body as shown in Fig. 3.
- Assemble motor support bracket to the motor rail bracket, as shown. The grooved end of the motor rail, No. 21 MUST be placed in end of bracket with elongated hole.
- Bolt your motor loosely to the motor support bracket.
- Slide the motor rail guide, No. 32, over the guide pin.
- Align the motor and saw pulleys by adjusting the motor on the motor support bracket. Tighten the motor mounting bolts securely.



FIGURE 3

Check before Operation!

- The motor alignment rod must project at least $\frac{1}{4}$ inch through the mount slot with the blade retracted and tilted 45 degrees. This setting should be checked often during operation. As the belt wears or stretches, loosen the set screw and pull the alignment rod out of the bracket the amount needed.
- The motor mount must not strike the miter mount bracket at either end of the motor rail at 0 or 45 degrees tilt.
- Be sure that the teeth of the blade point toward the front of the saw and the top of the blade turns toward the front.

Spring must be retained by projection on motor support bracket at all times.

MOTOR MOUNT




FIGURE 4

MOTORS:

For general home workshop use, a 1/2 horsepower 3450 R.P.M. motor will provide adequate speed and power. However, to enable you to take full advantage of the rugged performance features and full cutting efficiency of this saw, especially for heavy duty work, a 3/4 horsepower 3450 R.P.M. motor should be used. Note: When a 3/4 H.P. motor is used, a 35 inch V-belt and a motor pulley with 5/8 bore is necessary.

SPEED:

The motor pulley, No. 63, installed on a 3450 R.P.M. motor with a 5/8 inch diameter shaft will drive the saw at the recommended speed—4500 R.P.M.

BELT:

The saw is driven by a V-belt, No. 61. A replacement may be purchased by ordering under part number given in parts list.

LUBRICATION:

The precision ball bearing assembly used on the saw arbor has been packed with lubricant and sealed at the factory. It should require no further attention for the life of the bearing assembly.

To maintain the smooth, easy operation of the controls, oil the following points occasionally:

- The guide, No. 52, at the front of the arbor support.
- The guide ways of the front and rear trunnions, Nos. 80 and 92.
- The elevation screw, No. 76.
- The motor rail, No. 21.

CONTROLS:

The Control Knob raises the saw from 0 to 2 1/2 inches above the table level when pushed in and turned. It tilts the saw 0 to 45 degrees when pulled out and turned.

The Angle of Tilt is shown by a pointer on the scale just below the control knob.

The Miter Protractor face is a guide surface for cross cutting or diagonal cutting to a definite angle. The protractor may be used on either side of the blade at any angle or depth of cut desired. The angle is shown by the pointer on the calibrated scales on the protractor head. The lock knob clamps the head in the selected position.

CAUTION:

This saw has an extra long spindle for greater dado capacity. If the blade is extended more than 2 3/8 inches the spindle will strike the table insert when the saw blade is tilted.

The Fence Lock Handle when down clamps the fence at both ends of the table. Raise the handle to unlock and by grasping the front fence end move the fence to any point across the table. To make sure that the fence is perpendicular to the table, push down on fence as you lock it.

ADJUSTMENTS:

The following items may require adjustment due to rough handling during shipment:

The Blade Tilt Stop Screw, No. 98, located just behind the front trunnion on the left side of the body causes stops the tilt mechanism when the blade is at right angles to the table.

The Pointer for the Tilt Scale should indicate 0 degrees when the blade is at right angles to the table.




FIGURE 5

The Blade Must Be Parallel with the Miter Slots in the Table to Get a Straight Cut. (See Fig. 5).

Adjustment, if necessary, may be made as follows:

1. Raise the blade to 2 1/2 inches depth of cut and set at right angle (0 degrees) to table.
2. Measure accurately from a raker tooth on the blade to an edge of either miter slot, as explained and shown in Fig. 5.
3. Loosen the bolts, Nos. 79 and 93, holding each trunnion, Nos. 80 and 92, to the lower table surface. (4 bolts total.)
4. Shift the complete under-table mechanism until the blade is parallel with the miter slot.
5. Re-tighten the four trunnion screws, front pair first.
6. Check this adjustment as previously explained to be certain it is correct after re-assembly is complete.

The Fence Must Lock Parallel with the Miter Slots. Using one hand on the front end of the fence, slide the fence to the edge of the miter slot. Push the lock handle down slowly. If fence does not lock parallel to miter slot adjust as follows:

1. Loosen the two screws, No. 108, on top of the fence end.
2. Release the fence lock handle, No. 103.
3. Adjust the two set screws on the front of the fence until the fence is parallel with miter slot. Turn the two screws on the top, up snug. Then tighten each one securely.
4. Check the adjustment by sliding the fence away from the slot and returning several times to see if it looks parallel each time. The fence lock arm may require occasional adjustment to maintain proper tension.

With the fence lock handle, No. 103, in the unlocked position turn the fence lock rod, No. 112, slightly in a clockwise direction until proper tension is attained when fence lock handle is placed in the lock position.

The Arbor Tilt Tension Spring, No. 99, provides tension to keep the mechanism tilted at any angle, thus eliminating the need for a manual control lock. After the tool is "broken in," you may find it necessary to increase this tension. Loosen the lock nut, No. 85, and turn the bolt, No. 98, until enough tension has been applied. Re-tighten the lock nut.

Note: After a few hours of operation, tighten all pulley set screws.

OPERATION:

The blade provided with this saw may be used for both cross-cutting and ripping.

For proper chip clearance and best general results, the blade should project through the work-piece approximately 1/4 in.

Do not force material into the blade too fast. Use a straight, direct, steady feed which does not overtax the cutting capacity of the blade.

To eliminate creep of your work when making a miter cut, clamp the work piece to the miter gage.

Support long work as it leaves the rear of the table.

When using dado saws, the hex set, No. 83, will hold saws securely without the use of the saw clamp washer, No. 84, if that is desired.

SAFETY:

While the bench saw is one of the most widely used woodshop power tools, it is by nature of its general design, one of the most dangerous in the hands of inexperienced or careless operators. The bench saw is not, however, an unsafe tool when used with common sense and good judgment.

Use a push block rather than letting the hands get closer than 3 inches to the blade on narrow cuts.

Never hold the hands over the blade when making blind groove type cuts. Stand to one side when completing a cut. A loose piece caught by the blade can fly back with surprising force.

Always stop the saw when removing waste stock from near the blade, when making adjustments, or when changing settings.

Do not wear dangling neck ties, loose baggy sleeves etc., while operating power tools.




FIGURE 6

ACCESSORIES:




SAW GUARD—CATALOG No. 9-21046

TABLE EXTENSION—CATALOG No. 99-21047

TOOL STAND—CATALOG No. 99-21048

POWR PANEL—CATALOG No. 9-21205

TABLE EXTENSION—CATALOG No. 99-2178.



PARTS LIST

Do not use Key Numbers when ordering Repair Parts, always use Part Numbers.

Key No.	Order by Part No.	PART NAME	Key No.	Order by Part No.	PART NAME
1	374440	Base	62	X-178	Socket head set screw $\frac{5}{16}$ -18 x $\frac{3}{8}$ cap point
2	177177	Front Panel	63	**18036-B	Polyester with Set Screw
3	XK-1804	Sheet Metal Screw No. 7-16 x $\frac{3}{8}$	64	38826	Pivot bearing retaining screw
4	XK-178	Machine Head Set Screw $\frac{5}{16}$ -18 x $\frac{3}{8}$	65	38786	Retainer washer
5	374413	Handwheel	66	38786	Clip
6	XK-1806	Sheet Metal Screw 7-16 x $\frac{3}{8}$	67	38643	Pivot socket bearing
7	17831	Fence Sliding Bar	68	38644	Pivot Pin
8	*X-194	Front Head Machine Screw No. 10-24 x $\frac{1}{4}$	69	X-179	Socket head set screw No. 10-18 x $\frac{3}{8}$ cap point
9	38626	Spacer	71	38647	Rubber plug
10	*X-608	Washer No. 10 Amer. Std.	72	38447	Nylon plug
11	X-624	Hex Nut No. 10-24	73	X-632	Plain washer $\frac{1}{2}$ ID. x 1 inch O.D.
12	37324	Table	74	38728	Spring washer
13	*X-175	Bushing Head Machine Screw No. 6-32 x $\frac{3}{8}$	75	38340	Swivel castor
14	18036	Table Insert Clip	76	38623	Central nut
15	X-2455	Internal Tooth Lock Washer No. 6	77	38176	Arcbar and bearing unit with lock
16	37324	Table Insert	78	X-681	Socket head set screw No. 10-24 x $\frac{3}{8}$ cap point
17	X-748	Machin Screw No. 10-18 x $\frac{3}{8}$ Hex Washer Head with External Lock Washer	79	X-383	Hex head machine screw No. 10-18 x $\frac{3}{8}$
18	*X-418	Square Nut No. 18	80	38639	Rear trunnion
19	*X-611	Lock Washer $\frac{3}{16}$ Am. Std.	81	X-179	Socket head set screw No. 10-18 x $\frac{3}{8}$ cap point
20	37328	Motor Rail Bracket	82	**38729	8 inch diameter chisel tooth blade
21	37328	Motor Rail Bar	83	X-409	Hex Jam nut $\frac{1}{2}$ -20
22	*X-418	Square Nut No. 18	84	38448	Saw clamp washer
23	*X-601	Plain Washer $\frac{1}{2}$ ID. x $\frac{1}{8}$ O.D.	85	38175	Hex jam nut $\frac{5}{16}$
24	37213	Bottom Support Bracket	86	38753	Shoulder shield
25	X-3322	Square Head Machine Screw No. 10-18 x $\frac{3}{8}$	87	38649	Spacer
26	*X-525	Slotted Round Head Machine Screw No. 10-18 x $\frac{3}{8}$	88	37439	Push pin
27	*X-611	Lock Washer $\frac{3}{16}$ Am. Std.	89	X-636	Plain washer $\frac{1}{2}$ ID. x $\frac{3}{8}$ O.D.
28	*X-418	Square Nut No. 18	90	37771	Clay plate
29	38674	Roll Pin	91	38986	Hex Head cap screw No. 10-18 x $\frac{3}{8}$
30	*X-418	Square Nut No. 18	92	38438	Front trunnion
31	38782	Flat Spring	93	X-383	Hex head cap screw No. 10-18 x $\frac{3}{8}$
32	38764	Motor Rail Guide	94	38755	Fiber washer
33	*X-425	Slotted Round Head Machine Screw No. 10-18 x $\frac{3}{8}$	95	38734	Flat washer
34	38691	Guide Pin	96	38684	Trunnion lock spring
35	37208	Motor Mount Complete	97	38667	Trunnion lock bolt
36	X-340	Sliding Head Machine Screws 8-32 x $\frac{3}{8}$, Phillips Head	98	38833	Spring
37	37286	Tilt Pointer	99	37291	Replace with Elliptical Head machine screw $\frac{1}{4}$ -20 x $\frac{3}{8}$
38	X-334	Round Head Machine Screw No. 10-24 x $\frac{3}{8}$	100	33437	Fence lock bar
39	X-734	Round Head Machine Screw No. 10-24 x $\frac{3}{8}$ with External Lock Washer	101	X-467	Square nut No. 10-24
40	38732	Fence Plate	102	X-9601	Slotted head set screw No. 10-24 x $\frac{3}{8}$
41	38749	Retaining Ring	103	38644	Fence lock handle
42	38749	Plain Washer	104	38668	Fence swivel
43	38637	Door Catch	105	X-620	Hex nut $\frac{1}{2}$ -20
44	37430	Mounting Shaft with Pin	106	38621	Washer plate
45	37432	Pin	107	37416	Fence base pad
46	X-1307	Small Bell No. 8	108	37204	Slotted oval head machine screw No. 10-24 x $\frac{3}{8}$
47	18190	Control Shaft Tension Spring	109	37012	Spacer body
48	X-734	Round Head Machine Screw No. 10-24 x $\frac{3}{8}$ with External Lock Washer	110	37011	Spacer body
49	18251	Tension Plate	111	37661	Fence tie rod
50	18051	Tension Plate Spring	112	37624	Fence lock rod
51	X-201	Hex Head Cap Screw No. 10-20 x $\frac{3}{8}$	113	37429	Fence lock pin
52	18432	Guide Shoe	114	37429	Fence fence end
53	X-607	Plain Washer $\frac{1}{2}$ ID. x $\frac{1}{8}$ O.D.	115	37758	Fence shoe
54	X-718	Round Head Machine Screw No. 10-18 x $\frac{3}{8}$ with External Lock Washer	116	37776	Lock arm spring
55	37388	Spindle Support with Bearing Key	117	37425	Fence lock arm
56	38454	Spindle Support	118	37204	Complete outer gauge arm's
57	18031	Square Key	119	36936	Elliptical head machine screw No. 10-24 x $\frac{3}{8}$
58	38169	Tool pulley with set screw	120	37776	Miter protractor pointer
59	X-179	Slotted head set screw No. 10-18 x $\frac{3}{8}$ cap point	121	37290	Miter bar
60	X-1409	Allan wrench $\frac{3}{16}$	122	37240	Miter protractor
61	*X-1477	V-belt $1\frac{1}{2}$ x 35 inches long	123	38647	Washer
			124	38429	Knob
			125	37988	Instruction sheet and parts list

*Parts marked in this manner may be purchased locally.

This sheet is intended for restoration and repair parts only and is not a packing slip.
The parts shown and listed may include accessories not necessarily part of this tool.

**Items are regular stock in Sales Hardware Department and Mail Order House.

May also be ordered as repair parts by part number provided.