

KEK1522



KitchenAid®

WELCOME TO THE WORLD OF KITCHENAID.

We're committed to helping you create a lifetime of delicious meals for family and friends. To help ensure the longevity and performance of your appliance, keep this guide handy. It will empower you with the best way to use and care for your product. Your satisfaction is our #1 goal. Remember to register your product online at www.kitchenaid.com, or by mail using the enclosed Product Registration Card.



Join us in the kitchen at www.proline.kitchenaid.com.

USA: 1.800.832.7173
Canada: 1.800.807.6777

KitchenAid.com
KitchenAid.ca

TABLE OF CONTENTS

WATER KETTLE SAFETY	
Important safeguards	4
Electrical requirements	5
PARTS AND FEATURES	
Parts and accessories	6
USING THE WATER KETTLE	
Filling the Water Kettle	7
Setting the water temperature	8
Water temperature guide for best results	8
CARE AND CLEANING	
Cleaning the Water Kettle and base	9
Descaling the Water Kettle	9
Inserting and removing the filter	10
Cleaning the filter	10
WARRANTY AND SERVICE	11

WATER KETTLE SAFETY

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word "DANGER" or "WARNING." These words mean:

DANGER

You can be killed or seriously injured if you don't immediately follow instructions.

WARNING

You can be killed or seriously injured if you don't follow instructions.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

State of California Proposition 65 Warnings:

WARNING: This product contains one or more chemicals known to the State of California to cause cancer.

WARNING: This product contains one or more chemicals known to the State of California to cause birth defects or other reproductive harm.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against fire, electric shock and injury to persons do not immerse cord, plugs, or water kettle in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug water kettle from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not use near or on a hot gas or electric burner stove, or in a heated oven.
11. Do not use the appliance for other than intended use.
12. Do not use Water Kettle without lid properly closed.
13. Do not use Water Kettle with loose or weakened handle.

WATER KETTLE SAFETY

14. Do not clean Water Kettle with abrasive cleaners, steel wool, or other abrasive materials.
15. This product is designed for indoor household use only. Not designed for commercial use.
16. Do not overfill Water Kettle.
17. To disconnect, turn any control to "off," then remove plug from wall outlet.
18. Scalding may occur if the lid is removed or opened during the brewing cycles.

SAVE THESE INSTRUCTIONS

Electrical requirements

⚠ WARNING



Electrical Shock Hazard


Plug into a grounded 3 prong outlet.

Do not remove ground prong.

Do not use an adapter.

Do not use an extension cord.

Failure to follow these instructions can result in death, fire, or electrical shock.



Volts: 120 V.A.C.

Hertz: 60 Hz

NOTE: The Water Kettle has a 3 prong grounded plug. To reduce the risk of electrical shock, this plug will fit in an outlet only one way. If the plug does not fit in the outlet, contact a qualified electrician. Do not modify the plug in any way.

Do not use an extension cord. If the power supply cord is too short, have a qualified electrician or serviceman install an outlet near the appliance.

A short power supply cord (or detachable power supply cord) should be used to reduce the risk resulting from becoming entangled in or tripping over a longer cord.


Longer detachable power supply cord or extension cords are available and may be used.

If a longer detachable power supply cord or extension cord is used:

- The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.
- If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord.
- The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

PARTS AND FEATURES

Parts and accessories




USING THE WATER KETTLE

Filling the Water Kettle


Before First Use

Before using your Water Kettle, fill with water to the maximum level, boil; then discard water.

IMPORTANT: The Water Kettle is designed to heat water only. Do not put any other liquids or substances into the Water Kettle.




- 1 Press lid release button to open lid. Fill Water Kettle with cold, filtered water.



- 2 Push lid down until it locks into place.


NOTE: There must be a minimum of 0.25 L to operate.




- 3 Place Water Kettle on the base.

USING THE WATER KETTLE


Setting the water temperature



- 1 Slide the temperature selector knob on the base to the desired setting (50-100° C).



- 2 Press the POWER button on the side of the base. The controls will light up and the Water Kettle will begin to heat.



- 3 The temperature gauge will rise as the water heats.

NOTE: The water kettle will stop automatically once the set temperature is reached. The heating cycle can also be turned off manually by pressing POWER.

Water temperature guide for best results

Preparing hot beverages and tea is easy with the KitchenAid ProLine Water Kettle. For best results when making tea, follow the directions on your tea's packaging for suggested water temperature. If the tea does not have directions, follow the chart below as a guideline.


60°C/140°F	70°C/158°F	80°C/176°F	90°C/194°F	100°C/212°F
Delicate tea	Delicate tea	Green tea	Oolong tea	Boil water
		White tea	Black tea	Black tea
		Yerba mate	Chai	Herbal tea
		Matcha	Blooming tea	Rooibos tea
			Instant coffee	Oatmeal
			Hot chocolate	Instant soup
			French press coffee*	

*Recommendations vary anywhere from 195-205°F

CARE AND CLEANING

Cleaning the Water Kettle and base


IMPORTANT: Before cleaning, always disconnect the Water Kettle from the electrical outlet and make sure that the Water Kettle has cooled completely.



Wash Water Kettle and base by hand with a damp cloth. Dry and polish with a soft cloth. Abrasives and scouring agents of any kind are not recommended.

English

Descaling the Water Kettle




Calcium deposits may form on the interior metal parts of the Water Kettle. To get the best performance from your Water Kettle, clean periodically. The cleaning interval will depend on the hardness of the water you put into the Water Kettle. The use of a commercial descaler is recommended.

If a commercial descaler is not available:


1. Fill the Water Kettle with white vinegar to the MIN (0.25 L) mark.
2. Add water to the 0.75 L mark.
3. Boil and allow to stand overnight.
4. Empty the solution from the Water Kettle.
5. Fill the Water Kettle with water, bring to a boil and drain out the water. Repeat this step twice. The Water Kettle is now ready to use.

CARE AND CLEANING

Inserting and removing the filter




Inserting the filter: The filter is located behind the spout inside the Water Kettle. Open the lid. Slide the filter down into the slot behind the spout, making sure that the curve facing outward on the filter matches to the curve of the kettle.



Removing the filter: Open the lid. Grasp the top of the filter, behind the spout, and pull out to remove.

Cleaning the filter




Remove filter from Water Kettle (see “Inserting and removing the filter”); then rinse under running water.

NOTE: If calcium deposits remain on the filter, let it stand overnight in a solution of water and white vinegar. Rinse the filter thoroughly and replace in the Water Kettle.

KitchenAid® Pro Line® Total Replacement Limited Warranty for the 50 United States, the District of Columbia, Puerto Rico, and Canada

This warranty extends to the purchaser and any succeeding owner for KitchenAid Pro Line® products operated in the 50 United States, the District of Columbia, Puerto Rico, and Canada.

<p>Length of Limited Total Replacement Warranty:</p>	<p>Five Years from the date of purchase.</p>
<p>KitchenAid Will Pay for Your Choice of:</p> 	<p>Hassle-Free Replacement of your Pro Line® product. See the next page for details on how to arrange for replacement, or call the Customer eXperience Center toll-free at 1-800-832-7173.</p> <p>OR</p> <p>The replacement parts and repair labor costs to correct defects in materials and workmanship. Service must be provided by an Authorized KitchenAid Service Center.</p>
<p>KitchenAid Will than Not Pay for:</p>	<ul style="list-style-type: none"> A. Repairs when your Pro Line® product is used in other normal single family home use. B. Damage resulting from accident, alteration, misuse or abuse. C. Any shipping or handling costs to deliver your Pro Line® product to an Authorized Service Center. D. Replacement parts or repair labor costs for Pro Line® products operated outside the 50 United States, District of Columbia, Puerto Rico, and Canada.
<p>DISCLAIMER OF IMPLIED WARRANTIES IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO FIVE YEARS OR THE SHORTEST PERIOD ALLOWED BY LAW. Some states and provinces do not allow limitations on the duration of implied warranties or merchantability or fitness, so this limitation may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state and province to province.</p> <p>DISCLAIMER OF REPRESENTATIONS OUTSIDE OF WARRANTY KitchenAid makes no representations about the quality, durability or need for service or repair of this appliance other than the representations contained in this Warranty. If you want longer or more comprehensive coverage than the limited warranty that comes with this appliance, you should ask KitchenAid or your retailer about buying a service contract.</p> <p>LIMITATION OF REMEDIES; EXCLUSION OF INCIDENTAL AND CONSEQUENTIAL DAMAGES YOUR SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPLACEMENT OR REPAIR AS PROVIDED HEREIN. KITCHENAID SHALL NOT BE RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages, so these limitations and exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state and province to province.</p>	

Hassle-Free Replacement Warranty – 50 United States, District of Columbia, and Puerto Rico

We're so confident the quality of our products meets the exacting standards of KitchenAid that, if your Pro Line® product should fail within the first five years of ownership, KitchenAid will arrange to deliver an identical or comparable replacement to your door free of charge and arrange to have your original Pro Line® product returned to us. Your replacement unit will also be covered by our five-year limited warranty. Please follow these instructions to receive this quality service.

If your Pro Line® product should fail within the first five years of ownership, simply call our toll-free Customer eXperience Center at **1-800-832-7173** Monday through Friday. Please have your original sales receipt available when you call. Proof of purchase will be required to initiate the claim. Give the consultant your complete shipping address. (No P.O. Box numbers, please.)

When you receive your replacement Pro Line® product, use the carton and packing materials to pack up your original Pro Line® product.

Hassle-Free Replacement Warranty – Canada

We're so confident the quality of our products meets the exacting standards of the KitchenAid brand that, if your Pro Line® product should fail within the first five years of ownership, KitchenAid Canada will replace your Pro Line® product with an identical or comparable replacement. Your replacement unit will also be covered by our five-year limited warranty. Please follow these instructions to receive this quality service.

If your Pro Line® product should fail within the first five years of ownership, take the Pro Line® product or ship collect to an Authorized KitchenAid Service Centre.

In the carton include your name and complete shipping address along with a copy of the proof of purchase (register receipt, credit card slip, etc.). Your replacement Pro Line® product will be returned prepaid and insured. If you are unable to obtain satisfactory service in this manner call our toll-free Customer eXperience Centre at **1-800-807-6777**.

Or write to us at:
Customer eXperience Centre
KitchenAid Canada
200 - 6750 Century Ave.
Mississauga, ON L5N 0B7

Arranging for Service after the Warranty Expires, or Ordering Accessories and Replacement Parts

In the United States and Puerto Rico:

For service information, or to order accessories or replacement parts, call toll-free at **1-800-832-7173** or write to: Customer eXperience Center, KitchenAid Small Appliances, P.O. Box 218, St. Joseph, MI 49085-0218

Outside the United States and Puerto Rico:

Consult your local KitchenAid dealer or the store where you purchased your Pro Line® product for information on how to obtain service.

For service information in Canada:

Call toll-free **1-800-807-6777**.

Or write to:
Customer eXperience Centre
KitchenAid Canada
200 - 6750 Century Ave.
Mississauga, ON L5N 0B7

KitchenAid®

®/™ © 2016 KitchenAid. All rights reserved. Used under license in Canada.

®/™ © 2016 KitchenAid. Tous droits réservés. Utilisé sous licence au Canada.

®/™ © 2016 KitchenAid. Todos los derechos reservados. Usada en Canadá bajo licencia.