



SAVE THIS USE AND CARE BOOK

Coffeematic® Drip Coffeemakers



1-800-231-9786

QUESTIONS? Please call us TOLL FREE

MODELS DCM12WH, DCM12WL, DCM94WH

IMPORTANT:
PLEASE WASH
CARAFE BEFORE
FIRST USE!

IMPORTANT SAFEGUARDS

When using electrical appliances, in order to reduce the risk of fire, electric shock and/or injury, basic safety precautions should always be followed, including the following:

PLEASE READ ALL INSTRUCTIONS.

- Use only for its intended use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, or injury, do not place cord, plug or Coffeemaker base in water or other liquid.
- Do not remove the bottom cover from the Coffeemaker. There are no user-serviceable parts inside. Any repairs should be done by authorized personnel only.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug when Coffeemaker is not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning the Coffeemaker.
- Be sure there is water in the reservoir before brewing.
- Do not operate if this appliance or the electrical cord or plug is damaged or after the appliance malfunctions or has been damaged in any manner. Return the Coffeemaker to the nearest authorized service facility for examination, repair, or adjustment.
- To avoid an electrical overload, do not operate another high-wattage appliance on the same circuit with this Coffeemaker.
- The use of an accessory not recommended or approved for operation with this Coffeemaker may result in fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over the edge of table or counter, or come in contact with hot surfaces.
- Do not place Coffeemaker or Carafe on or near a hot gas or electric burner or in a heated oven.
- Do not store anything directly on top of the Coffeemaker.
- Keep the lid on the serving carafe when in use.
- Use the "Keeps Hot" plate only. Do not heat the Carafe on a range top or in a microwave oven.
- Do not set a hot carafe down on a wet or cold surface.

- Do not use the Carafe if the glass is cracked or has a loose or weakened handle.
- Do not remove Carafe from “Keeps Hot” plate while liquid is dripping from basket. Allow basket to cool before removing it from the Coffeemaker.
- Do not clean the Carafe with cleansers, steel wool, or other abrasives.
- Do not pour liquid other than water or the cleaning solution specified in this manual into the water reservoir.
- Remember to place the empty Carafe on the “Keeps Hot” plate before brewing.
- Do not operate any electric appliance in the presence of explosive and/or flammable fumes or liquids.
- This product is intended FOR HOUSEHOLD USE ONLY and not for commercial or industrial use.


SAVE THESE INSTRUCTIONS

POLARIZED PLUG

The Coffeematic® Drip Coffeemaker has a polarized plug — one blade is wider than the other. As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse it and try again. If it still does not fit, contact an electrician. Do not attempt to defeat this safety feature.

TAMPER-RESISTANT SCREW

This appliance is equipped with a tamper-resistant screw to prevent removal of the outer cover. To reduce the risk of fire or electric shock, **do not attempt to remove the outer cover**. There are no consumer serviceable parts inside. Repair should be done only by authorized service personnel (see pages 10-11 for a list of Black & Decker Company-Owned Service Centers).



How To Use

PREPARATION FOR USE

Before the first use, remove all stickers, packing material, and literature.

Clean the Carafe, Filter Basket, Water Spreader, and Carafe Lid by washing in hot, sudsy water — rinse thoroughly.

Brew 10 (model DCM94WH) or 12 (model DCM12WH or model DCM12WL) cups of fresh water through the system as instructed in the BREWING COFFEE instructions, but do not add coffee grounds.

BREWING COFFEE




Figure A



Figure B

1. Remove the Water Spreader and place a paper coffee filter into the Filter Basket. Add drip grind coffee to the filter corresponding to the amount of coffee to be brewed (usually one heaping tablespoon for every two cups. Adjust to suit your taste). When brewing 2-4 cups, use slightly more grounds per cup. Replace the Water Spreader over the Filter Basket.
2. Use the Carafe to fill the Water Reservoir with cold water to the desired cup level. Close the Flip-Up Reservoir Cover.
3. Place the Filter Basket (with Water Spreader) over the empty Carafe, (Figure A) then sit the Carafe on the "Keeps Hot" plate.
4. Slide the Control to "On." You will see a red square in the display. The "Keeps Hot" plate comes on automatically when brewing begins.
5. Let all the brewed coffee drip from the Basket. Remove the Basket and Spreader and set it aside. Place the Serving Lid on the Carafe. (Figure B)
6. Place the Carafe on the "Keeps Hot" plate when not serving to keep coffee hot. The "Keeps Hot" plate will remain warm until the unit is turned off by sliding the Control to "Off".
7. DO NOT pour brewed coffee back into the Water Reservoir to reheat it. Reheat coffee in a saucepan on a range or in a microwave-safe container in a microwave oven. Do not put the Carafe in a microwave oven.

CLEANING YOUR COFFEEMAKER

To clean your Coffeemaker after brewing coffee, be sure the unit is OFF and has cooled. Discard the paper filter and grounds, and clean as follows:

Filter Basket, Water Spreader, Carafe, and Carafe Serving Lid are all top rack dishwasher-safe; or, they may be hand washed in hot, sudsy water.

NOTE: Since the white Filter Basket and Water Spreader are prone to staining, you may want to wash them well with soap and water after each use.

The Coffeemaker's exterior and "Keeps Hot" plate may be cleaned with a damp cloth. Do not use abrasive cleansers or scouring pads. Never immerse the Coffeemaker in water.

CARING FOR YOUR CARAFE

The Carafe capacity for the DCM12WH and DCM12WL is 12 cups; for the DCM94WH, it is 10 cups (Figure C). A damaged Carafe may result in possible burns from hot liquid. To avoid breaking the Carafe:




Figure C

- Do not let all liquid evaporate from the Carafe while on the "Keeps Hot" plate, or heat the Carafe when empty.
- Discard the Carafe if damaged in any manner. A chip or crack could result in breakage.
- Never use abrasive scouring pads or cleansers, they will scratch the glass.
- Do not place the Carafe on or near a hot gas or electric burner, in a heated oven, or in a microwave oven.
- Avoid rough handling and sharp blows.

MINERAL DEPOSITS AND CLOGGING

Mineral deposits left by hard water can clog your Coffeemaker. It is necessary to regularly clean your Coffeemaker to flush out these deposits. Excessive steaming or a prolonged brewing cycle are signs that a cleaning is needed.

Clean your Coffeemaker approximately every 1-3 months. The frequency of cleaning required is affected by your specific usage and water hardness. You may have to clean the Coffeemaker more or less often.

During cleaning, more steaming occurs than when brewing coffee.

1. Fill the Water Reservoir half way with white vinegar and add cold water up to the 10-cup line (model DCM94WH) or 12-cup line (model DCM12WH or DCM12WL).
2. Put an empty paper filter in the Filter Basket, place the Water Spreader over the basket, and place the Basket over the empty Carafe. Set the empty Carafe securely onto the "Keeps Hot" plate.
3. Turn the Coffeemaker on.
4. Let half the cleaning solution brew into the Carafe, then turn the Coffeemaker off to soak.
5. Allow the Coffeemaker to remain off for at least 15 minutes to soften the deposits.
6. Turn the Coffeemaker on again to brew the remaining cleaning solution into the Carafe.
7. Turn the Coffeemaker off; discard the cleaning solution and the soiled Filter.

8. Fill the Reservoir with cold water to the 10-cup line (model DCM94WH) or the 12-cup line (model DCM12WH or DCM12WL); replace the empty Basket, Water Spreader, and Carafe.

9. Turn on the Coffeemaker for a complete brew cycle to flush out the remaining cleaning solution.

10. Wash the Filter Basket, Water Spreader, and Carafe as instructed in "Cleaning Your Coffeemaker" (see page 6).

ELECTRICAL CORD

The cord length of this Drip Coffeemaker was selected to reduce safety hazards that may occur with a longer cord. If more cord length is needed, an extension cord with a polarized plug may be used. It should be rated not less than 10 amperes, 120 Volts, and have Underwriters Laboratories listing. A properly rated extension cord may be purchased from a Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Center. When using a longer cord, be sure it does not drape over a working area or dangle where it could be pulled on or tripped over. Handle cord carefully for longer life; avoid jerking or straining it at outlet and appliance connections.

SERVICE OR REPAIR

Service, if necessary, must be performed by a Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Center. The Service Center nearest you can be found in the yellow pages of your phone book under "Appliances-Small-Repairing." For your convenience, a complete listing of our Company-Owned Service Centers is listed on pages 10-11.

If mailing or shipping your Coffeemaker, pack it carefully in a sturdy carton with enough packing material to prevent damage. Be sure to empty water from the reservoir and Carafe before packing. You may use original packaging as long as you've include packing material suitable for shipping. Include a note describing the problem to our Service Center and be sure to give your return address. We also suggest that you insure the package for your protection.

Consumer-replaceable parts and accessories are available at Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Centers. To order a replacement Carafe by phone (or any other replacement part such as the brew basket, water spreader, or serving lid), call toll free, 1-800-258-6003.

BLACK AND DECKER COMPANY-OWNED SERVICE CENTERS

ALABAMA

BIRMINGHAM — 2412 Green Springs, Hwy., 35209
205-942-0538
MOBILE — 3831 Airport Blvd., 36608 205-343-6624

ALASKA

ANCHORAGE — 910 West International Airport Rd., 99518
907-563-4664

ARIZONA

MESA — 535 South Dobson Rd., Suite 7, 85202
602-461-1074
PHOENIX — 4501 N. 7th Ave., 85013 602-279-6414
TUCSON — 4845 E. Speedway Blvd., 85712 602-323-3388

ARKANSAS

LITTLE ROCK — 519 W. Seventh St., 72201 501-372-3040

CALIFORNIA

ANAHEIM — 540 South State College Blvd., 92806
714-772-4050
CHULA VISTA — 309 Broadway, 91911 619-420-6350
CONCORD — 1500 Monument Blvd., #C2, 94520
510-682-4880
FRESNO — 5412 North Blackstone Ave., 93710 209-435-0810
LONG BEACH — 2011 South St., 90805 310-422-5825
LOS ANGELES — 4820 South Eastern Ave., Suite "L" 90040
213-720-1834
RIVERSIDE — 6215 Magnolia Ave., Suite B, 92506
714-787-9700
SACRAMENTO — 2033 Fulton Ave., 95825 916-972-9090
SAN DIEGO — 9270 Clairmont Mesa Blvd., 92123
619-279-2011
SAN JOSE — 1185 South Bascom Ave., 95128 408-293-7350
SAN LEANDRO — 15206 East 14th St., 94578 510-276-1610
VAN NUYS — 14920 Victory Blvd., 91411 818-787-5531

COLORADO

DENVER — 1171 South Federal Blvd., Box 19220, 80219
303-922-8325

CONNECTICUT

HARTFORD — 662 Silas Deane Hwy., 06109 203-563-5800
ORANGE — 481 Boston Post Rd., 06477 203-795-3583

DISTRICT OF COLUMBIA

COLMAR MANOR, MD — 4153 Bladensburg Rd., 20710
301-779-3808
FALLS CHURCH, VA — 344 W. Broad St., 22046
703-533-7313

FLORIDA

FT. LAUDERDALE — 799 East Oakland Pk. Blvd., 33334
305-566-5102
FT. MYERS — 5224 Bank St., 33907 813-278-1188
JACKSONVILLE — 920 Cassat Ave., 32205 904-781-2253
MIAMI — 13345 North West Seventh Ave., 33168
305-681-6658
MIAMI — 12233 South Dixie Hwy., 33156 305-232-9497
ORLANDO — 3807 East Colonial Dr., 32803 407-894-7011
ST. PETERSBURG — 5635 49th St. North, 33709
813-525-0273
TAMPA — 3432 West Kennedy Blvd., 33609 813-872-8317
WEST PALM BEACH — 310 South Military Trail, 33415
407-689-3247

GEORGIA

ATLANTA (South) — 5330 Old National Hwy., 30349 404-762-8844
SMYRNA — 2550 Cobb Parkway South, 30080 404-956-0869
STONE MOUNTAIN — 5723 Memorial Dr., 30083 404-292-4714

HAWAII

HONOLULU — Unit No. 106, Sand Island Access Rd., 96819
808-847-7447

ILLINOIS

CHICAGO (Lincolnwood) — 6710 North Crawford Ave., 60646
708-673-0923
DES PLAINES — 1277 South Elmhurst Rd., 60018 708-364-5220
LISLE — 2950 Ogden Ave., Unit H, 60532 708-717-1075
MOLINE — 4433 23rd Ave., 61265 309-762-3000
OAK LAWN — 6343 W. 95th St., 60453 708-423-7212
WAUKEGAN — 39 S. Greenbay Rd., 60085 703-249-4390

INDIANA

EVANSVILLE — 307 First Ave., Crescent Ctr., 47710 812-425-4269
HAMMOND — 7103 Kennedy Ave., 46323 219-845-5100
INDIANAPOLIS (Speedway) — 5999 Crawfordsville Rd., 46224
317-243-8308

IOWA

DES MOINES — 3427 Merle Hay Rd., 50310 515-270-1340

KANSAS

WICHITA — 155 South West St., 67213 316-943-1271

KENTUCKY

LOUISVILLE — 5211 Preston Hwy., 40213 502-968-7100

LOUISIANA

BATON ROUGE — 11859 Florida Blvd., 70815 504-272-8111
HARVEY — 2500 Lapalco Blvd., 70058 504-366-8676
METAIRIE (New Orleans) — 3504 North Causeway Blvd., 70002
504-837-2550
SHREVEPORT — 7710-7714 Jewella Rd., 71108 318-688-1553

MARYLAND

BALTIMORE — 4712 Erdman Ave., 21205 410-485-5550
BALTIMORE — 29-31 Cranbrook Rd., Cockeysville, 21030
410-666-5966
COLMAR MANOR (Wash. D.C.) — 4153 Bladensburg Rd., 20722
301-779-3808
PASADENA — 8220 Ritchie Hwy., 21122 410-647-8456

MASSACHUSETTS

BRIGHTON (Boston) — 12 Market St., 02135 617-782-6264
SEEKONK — 120 Highland Ave., 02771 508-336-6510

MICHIGAN

GRAND RAPIDS — 3040 28th St., SE, 49512 616-949-8331
LANSING — 3203 W. Saginaw Hwy., 48917 517-323-4181
WARREN — 27035 Van Dyke Blvd., 48093 313-756-6711
WESTLAND — 8067 N. Wayne Rd., 48185 313-427-1520

MINNESOTA

BLOOMINGTON — 9517 Lyndale Ave., South, 55420 612-884-9191

MISSOURI

KANSAS CITY — 4324 Main St., 64111 **816-531-0629**
ST. ANN — 3637 North Lindbergh Blvd., 63074
314-739-4661
ST. LOUIS — 12852 Manchester Rd., 63131 **314-821-8740**

NEBRASKA

OMAHA — 4225 South 84th St., 68127 **402-592-5666**

NEVADA

LAS VEGAS — 3411 East Charleston Blvd., 89104
702-641-6555

NEW JERSEY

CHERRY HILL — 1444 East Marlton Pike (Rt. 70), 08034
609-429-2822
LITTLE FALLS — 1189 U.S. Hwy. 46, 07424 **201-256-9373**
SCOTCH PLAINS — 2520 Route #22 East, 07076 **908-233-5665**

NEW MEXICO

ALBUQUERQUE — 5617 Menaul Blvd., N.E., 87110
505-884-1002

NEW YORK

ALBANY (Latham) — 836 Troy-Schenectady Rd., 12110
518-785-1867
BUFFALO — 881 West Delavan Ave., 14209 **716-884-6220**
CENTEREACH L.I. — 2061-63 Middle Country Rd., 11720
516-737-4706
NEW YORK (Elmhurst) — 77-20 Queens Blvd., 11373
718-335-1042
NEW YORK (Manhattan) — 50 West 23rd St., 10010
212-929-6450
NEW YORK (Westbury, L.I.) — 1061 Old Country Rd., 11590
516-997-6140
ROCHESTER — 2969 W. Henrietta Rd., 14623 **716-424-1310**
SYRACUSE — 3485 Erie Blvd., East, 13214 **315-446-3086**

NORTH CAROLINA

CHARLOTTE — 3007 East Independence Blvd., 28205
704-374-1779
GREENSBORO — 3716 High Point Rd., 27407 **919-852-1300**
RALEIGH — 2930 Capital Blvd., 27604 **919-878-0357**

OHIO

CINCINNATI — 2310 East Sharon Rd., 45241 **513-772-3111**
COLUMBUS — 3975 East Livingston Ave., 43227
614-237-0461
DAYTON — 2898 South Dixie Drive, 45409 **513-298-1951**
MAYFIELD HEIGHTS — 5881 Mayfield Rd., 44124
216-449-2770
PARMA HEIGHTS (Cleveland) — 6483 Pearl Rd., 44130
216-842-9100
TOLEDO — 3231 Dorr St., 43607 **419-531-8921**

OKLAHOMA

OKLAHOMA CITY — 1318 Linwood Blvd., 73106
405-232-7515
TULSA — 3120 S. Sheridan Rd, 74145 **918-622-5666**

OREGON

PORTLAND — 1640 NW Johnson St., 97209
503-228-8631

PENNSYLVANIA

ALLENTOWN (Whitehall) — 2242 MacArthur Rd., 18052
215-435-9544
EVANS CITY — Cranberry Town Center Plaza, 20808 Rt. 19 N., 16033
412-779-9600
HARRISBURG — 6080 Allentown Blvd., 17112 **717-545-0651**
LANCASTER — 118 Keller Ave., 17601 **717-393-5251**
PHILADELPHIA — 9977-81 Bustleton Ave., 19115
215-464-7771
PHILADELPHIA — 333 North 20th St., 19103 **215-564-5520**
PITTSBURGH — 5437 Baum Blvd., 15232 **412-362-2700**
WILKES-BARRE — 759 Kidder St., 18702 **717-824-5704**

PUERTO RICO

GUAYNABO — “C” Street # 14, Rexco Industrial Park, 00922-1924
809-783-3535

RHODE ISLAND

SEEKONK, MA — 120 Highland Ave., 02771 **508-336-6510**

SOUTH CAROLINA

GREENVILLE — 1557 Laurens Rd., 29607 **803-232-3038**

TENNESSEE

CHATTANOOGA — Perimeter Place Shopping Ctr., Sp. E,
6231 Perimeter Dr., 37421 **615-894-5957**
KNOXVILLE — 4118 North Broadway, 37917 **615-688-0921**
MEMPHIS — 1085 East Brooks Rd., 38116 **901-332-3444**
NASHVILLE — 4811 Nolensville Rd., 37211 **615-833-8277**

TEXAS

AMARILLO — 3008 West 6th Ave., 79106 **806-373-1531**
AUSTIN — 6549 Burnet Rd., 78757 **512-459-1133**
DALLAS — 2257 Royal Lane, 75229 **214-620-8655**
EL PASO — 6822 Gateway East, 79915 **915-778-9769**
FORT WORTH — 721 North Beach St., 76111 **817-831-3828**
GARLAND — 78 West Centerville Rd., 75043 **214-686-9302**
HOUSTON — 536 East Tidwell Rd., 77022 **713-692-7111**
SAN ANTONIO — 500 Culebra Ave., 78201 **210-732-1221**
WEBSTER — 100 East Nasa Road One, Ste. 75, 77598 **713-338-4556**

UTAH

SALT LAKE CITY — 1541 S. Third West St., 84115 **801-486-5828**

VIRGINIA

FALLS CHURCH — 344 W. Broad St., 22046 **703-533-7313**
HAMPTON — 3416 W. Mercury Blvd., 23666 **804-826-9382**
NORFOLK — 7631 Sewells Point Rd., 23513 **804-480-3333**
RICHMOND — 1424 Chamberlayne Ave., 23222 **804-649-9245**

WASHINGTON

SEATTLE — 421 S. Michigan, 98108 **206-763-2010**
SPOKANE — N. 7011 Division St., 99208 **509-467-8190**
TACOMA — 2602 S. 38th St., 98409 **206-473-6040**

WEST VIRGINIA

CHARLESTON — 1638 Sixth Ave., 25312 **304-343-0289**

WISCONSIN

MILWAUKEE (Wauwatosa) — 10424 W. Bluemound Rd., 53226
414-453-4240

REV: 8/94

FULL TWO-YEAR WARRANTY

Black & Decker (U.S.) Inc. warrants this product against any defects that are due to faulty material or workmanship for a two-year period after the original date of consumer purchase or receipt as a gift. This warranty does not include damage to the product resulting from accident or misuse.

If the product should become defective within the warranty period, we will repair it or elect to replace it free of charge, including free return transportation, provided it is delivered prepaid to any Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Center. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Answers to any questions regarding warranty or service locations may be obtained by calling toll free 1-800-231-9786 or by writing:

Consumer Assistance and Information
Black & Decker (U.S.) Inc.
626 Hanover Pike
Hampstead, MD 21074-0618



 **BLACK & DECKER®**

Listed by Underwriters Laboratories Inc.
Copyright © 1990, 1991, 1994 Black & Decker
Printed in U.S.A.
Pub. No. 168638-01-RV03